



2.6 BRC7E63W / BRC7E66 (for FXH(Q))

2.6.1 Operation



1

COOL/HEAT CHANGEOVER REMOTE CONTROL SWITCH

















1-3

2

3PA63363-21T-0






NAMES AND FUNCTIONS OF THE OPERATING SECTION (Fig. 1, 2)

1	DISPLAY “▲” (SIGNAL TRANSMISSION)
	This lights up when a signal is being transmitted.
2	DISPLAY “” “” “” “” “” (OPERATION MODE)
	This display shows the current OPERATION MODE. For straight cooling type, “  ” (Auto) and “  ” (Heating) are not installed.
3	DISPLAY “” (SET TEMPERATURE)
	This display shows the set temperature.
4	DISPLAY “ hr. 0.3” “ hr. 0.4” (PROGRAMMED TIME)
	This display shows PROGRAMMED TIME of the system start or stop.
5	DISPLAY “” (AIR FLOW FLAP) Refer to Note 1.
6	DISPLAY “” “” (FAN SPEED)
	The display shows the set fan speed.
7	DISPLAY “ TEST” (INSPECTION/ TEST OPERATION)
	When the INSPECTION/TEST OPERATION BUTTON is pressed, the display shows the system mode is in.
8	ON/OFF BUTTON
	Press the button and the system will start. Press the button again and the system will stop.
9	FAN SPEED CONTROL BUTTON
	Press this button to select the fan speed, HIGH or LOW, of your choice.

10	TEMPERATURE SETTING BUTTON
	Use this button for SETTING TEMPERATURE (Operates with the front cover of the remote controller closed.)
11	PROGRAMMING TIMER BUTTON
	Use this button for programming “START and/or STOP” time. (Operates with the front cover of the remote controller opened.)
12	TIMER MODE START/STOP BUTTON Refer to Note 2.
13	TIMER RESERVE/CANCEL BUTTON Refer to Note 3.
14	AIR FLOW DIRECTION ADJUST BUTTON
	Refer to Note 4.
15	OPERATION MODE SELECTOR BUTTON
	Press this button to select OPERATION MODE.
16	FILTER SIGN RESET BUTTON
	Refer to the section of MAINTENANCE in the operation manual attached to the indoor unit.
17	INSPECTION/TEST OPERATION BUTTON
	This button is used only by qualified service persons for maintenance purposes.
18	EMERGENCY OPERATION SWITCH This switch is readily used if the remote controller does not work.
19	RECEIVER
	This receives the signals from the remote controller.
20	OPERATING INDICATOR LAMP (Red)
	This lamp stays lit while the air conditioner runs. It flashes when the unit is in trouble.
21	TIMER INDICATOR LAMP (Green) This lamp stays lit while the timer is set.

C: 3PA63363-21T-2

Note 1 : page 111, Note 2 : page 112, Note 3 : page 113, Note 4 : page 111


22	AIR FILTER CLEANING TIME INDICATOR LAMP (Red) Lights up when it is time to clean the air filter.
23	DEFROST LAMP (Orange) Lights up when the defrosting operation has started. (For straight cooling type this lamp does not turn on.)
24	FAN/AIR CONDITIONING SELECTOR SWITCH Set the switch to “  ” (FAN) for FAN and “  ” (A/C) for HEAT or COOL.
25	COOL/HEAT CHANGEOVER SWITCH Set the switch to “  ” (COOL) for COOL and “  ” (HEAT) for HEAT.
NOTES 	
<ul style="list-style-type: none"> • For the sake of explanation, all indications are shown on the display in Figure 1 contrary to actual running situations. • Fig. 1-2 shows the remote controller with the front cover opened. • Fig. 1-3 shows this remote controller can be used in conjunction with the one provided with the VRV system. • If the air filter cleaning time indicator lamp lights up, clean the air filter as explained in the operation manual provided with the indoor unit. After cleaning and reinstalling the air filter, press the filter sign reset button on the remote controller. The air filter cleaning time indicator lamp on the receiver will go out. 	

HANDLING FOR WIRELESS REMOTE CONTROLLER

Precautions in handling remote controller

Direct the transmitting part of the remote controller to the receiving part of the air conditioner.

If something blocks the transmitting and receiving path of the indoor unit and the remote controller as curtains, it will not operate.



Transmitting distance is approximately 7 m.

Do not drop or get it wet.

It may be damaged.

Never press the button of the remote controller with a hard, pointed object.

The remote controller may be damaged.


Installation site

- It is possible that signals will not be received in rooms that have electronic fluorescent lighting. Please consult with the salesman before buying new fluorescent lights.
- If the remote controller operated some other electrical apparatus, move that machine away or consult your dealer.

C: 3PA63363-21T-3

Placing the remote controller in the remote controller holder

Install the remote controller holder to a wall or a pillar with the attached screw. (Make sure it transmits)




How to put the dry batteries

(1) Remove the back cover of the remote controller to the direction pointed by the arrow mark.

(2) Put the batteries
Use two LR03<IEC> dry cell batteries. Put dry batteries correctly to fit their (+) and (-).

(3) Close the cover



— When to change batteries —

Under normal use, batteries last about a year. However, change them whenever the indoor unit doesn't respond or responds slowly to commands, or if the display becomes dark.

[CAUTIONS]

- Replace all batteries at the same time, do not use new and old batteries intermixed.
- In case the remote controller is not used for a long time take out all batteries in order to prevent liquid leak of the battery.

IN THE CASE OF CENTRALIZED CONTROL SYSTEM

If the indoor unit is under centralized control, it is necessary to switch the remote controller's setting.

In this case, contact your DAIKIN dealer.

OPERATION PROCEDURE

Refer to figure 1 (Note)

- Operating procedure varies with heat pump type and cooling only type. Contact your Daikin dealer to confirm your system type.
- To protect the unit, turn on the main power switch 6 hours before operation.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

COOLING, HEATING, AUTOMATIC, FAN, AND PROGRAM DRY OPERATION

Operate in the following order.

- AUTOMATIC OPERATION can be selected only by Heat recovery system.
- For cooling only type, "COOLING", and "FAN" and "DRY" operation are able to select.

C: 3PA63363-21T-4

Note : page 106

《《FOR SYSTEMS WITHOUT COOL/HEAT CHANGEOVER REMOTE CONTROL SWITCH》》

Refer to figure 1-1, 2 (Note)

1  **OPERATION MODE SELECTOR**

Press **OPERATION MODE SELECTOR** button several times and select the **OPERATION MODE** of your choice as follows.

- COOLING OPERATION “ ❄ ”
- HEATING OPERATION..... “ ☀ ”
- AUTOMATIC OPERATION..... “ ⏸ ”
 - In this operation mode, COOL/HEAT changeover is automatically conducted.
- FAN OPERATION “ 🌀 ”
- DRY OPERATION..... “ 🏠 ”
 - The function of this program is to decrease the humidity in your room with the minimum temperature decrease.
 - Micro computer automatically determines TEMPERATURE and FAN SPEED.
 - This system does not go into operation if the room temperature is below 16°C.

2  **ON/OFF**

Press **ON/OFF** button
OPERATION lamp lights up or goes off and the system starts or stops OPERATION.





- NOTE** 📌
- Do not turn OFF power immediately after the unit stops. Then, wait no less than 5 minutes.
Water is leaking or there is something else wrong with the unit.

《《FOR SYSTEMS WITH COOL/HEAT CHANGEOVER REMOTE CONTROL SWITCH》》

Refer to figure 1-1, 3 (Note)

1  **OPERATION MODE SELECTOR**

(1) Select **OPERATION MODE** with the **COOL/HEAT CHANGEOVER REMOTE CONTROL SWITCH** as follows.

- COOLING OPERATION “ ❄ ” 
- HEATING OPERATION..... “ ☀ ” 
- FAN OPERATION “ 🌀 ” 
- DRY OPERATION..... “ 🏠 ” 

- See “FOR SYSTEM WITHOUT COOL/HEAT CHANGEOVER REMOTE CONTROL SWITCH” for details on dry operation.

(2) Press **OPERATION MODE SELECTOR** button several times and select “ 🏠 ” (This operation is only available during dry operation.)

2  **ON/OFF**

Press **ON/OFF** button
OPERATION lamp lights up or goes off and the system starts or stops OPERATION.

- NOTE** 📌
- Do not turn OFF power immediately after the unit stops. Then, wait no less than 5 minutes.
Water is leaking or there is something else wrong with the unit.

[EXPLANATION OF HEATING OPERATION] DEFROST OPERATION

- As the frost on the coil of an outdoor unit increase, heating effect decreases and the system goes into DEFROST OPERATION.
- The fan operation stops and the DEFROST lamp of the indoor unit goes on. After 6 to 8 minutes (maximum 10 minutes) of DEFROST OPERATION, the system returns to HEATING OPERATION.

Heating capacity & Outdoor air temperature

- Heating capacity drops as outdoor air temperature lowers. If feeling cold, use another heater at the same time as this air conditioner.
- Hot air is circulated to warm the room. It will take some time from when the air conditioner is first started until the entire room becomes warm. The internal fan automatically turns at low speed until the air conditioner reaches a certain temperature on the inside. In this situation, all you can do is wait.
- If hot air accumulates on the ceiling and feet are left feeling cold, it is recommended to use a circulator. For details, contact the place of purchase.


ADJUSTMENT

For programming TEMPERATURE, FAN SPEED and AIR FLOW DIRECTION, follow the procedure shown below.



TEMPERATURE SETTING


Press TEMPERATURE SETTING button and program the setting temperature.



Each time this button is pressed, setting temperature rises 1°C.

Each time this button is pressed, setting temperature lowers 1°C.

In case of automatic operation



Each time this button is pressed, setting temperature shifts to "H" side.

Each time this button is pressed, setting temperature shifts to "L" side.

[°C]

	H	■	M	■	L
Setting temperature	25	23	22	21	19

- The setting is impossible for fan operation.

NOTE

- The setting temperature range of the remote controller is 16°C to 32°C.



FAN SPEED CONTROL

Press FAN SPEED CONTROL button.


High or Low fan speed can be selected. The microchip may sometimes control the fan speed in order to protect the unit.



AIR FLOW DIRECTION ADJUST

- There are 2 ways of adjusting the air discharge angle.
 1. A. Up and down adjustment
 2. B. Left and right direction

Fig. 1




C: 3PA63363-21T-6

A. UP AND DOWN DIRECTION

- The movable limit of the flap is changeable. Contact your Daikin dealer for details.

Press the AIR FLOW DIRECTION ADJUST button to select the air direction as shown below.



DISPLAY appears and the air flow direction continuously varies. (Automatic swing setting)



Press AIR FLOW DIRECTION ADJUST button to select the air direction of your choice.



DISPLAY vanishes the air flow direction is fixed (Fixed air flow direction setting).

MOVEMENT OF THE AIR FLOW FLAP

For the following conditions, micro computer controls the air flow directions so it may be different from the display.

Operation mode	Cooling	Heating
Operation condition	<ul style="list-style-type: none"> • When room temperature is lower than the set temperature 	<ul style="list-style-type: none"> • When room temperature is higher than the set temperature • At defrost operation
	<ul style="list-style-type: none"> • When operating continuously at horizontal air flow direction 	

NOTE

- If you try cooling or programmed drying, while the flaps are facing downward, air flow direction may change unexpectedly. There is nothing wrong with the equipment. This serves to prevent dew formed

on parts in the air discharge outlet from dripping.

- Operation mode includes automatic operation.

B. LEFT AND RIGHT DIRECTION

- Adjusting air flow direction in the left and right direction. (Refer to Fig. 1)

NOTE

- Only make adjustments after you have stopped the air flow direction swing in a position.
- Stop flaps from swinging before trying to angle them. Working while the flaps are moving may get your fingers pinched.

PROGRAM TIMER OPERATION

Operate in the following order.

- The timer is operated in the following two ways.
 - Programming the stop time (⊕ - ○)
 - The system stops operating after the set time has elapsed.
 - Programming the start time (⊕ - |)
 - The system starts operating after the set time has elapsed.
- The timer can be programmed a maximum of 72 hours.
- The start and the stop time can be simultaneously programmed.



TIMER MODE START/STOP

Press the TIMER MODE START/STOP button several times and select the mode on the display.

The display flashes.


For setting the timer stop “⊕ - ○”

For setting the timer start “⊕ - |”



PROGRAMMING TIME

Press the **PROGRAMMING TIME** button and set the time for stopping or starting the system.



When this button is pressed, the time advances by 1 hour.

When this button is pressed, the time goes backward by 1 hour.



TIMER RESERVE


Press the **TIMER RESERVE** button. The timer setting procedure ends. The display or changes from flashing light to a constant light.



TIMER CANCEL

Press the **TIMER OFF** button to cancel programming. The display vanishes.

For example.



When the timer is programmed to stop the system after 3 hours and start the system after 4 hours, the system will stop after 3 hours and then 1 hour later the system will start.

NOTE


- When the timer is programmed to stop the system after 3 hours and start the system after 4 hours, the system will stop after 3 hours and then 1 hour later the system will start.
- After the timer is programmed, the display shows the remaining time.

HOW TO SET MASTER REMOTE CONTROLLER (For VRV system)

- When the system is installed as shown below, it is necessary to designate the master remote controller.


■For Heat pump system

When one outdoor unit is connected with several indoor units.



■For Heat recovery system

When one BS unit is connected with several indoor units.



- Only the master remote controller can select HEATING, COOLING or AUTOMATIC (only Heat recovery system) OPERATION.

C: 3PA63363-21T-8

When the indoor unit with master remote controller is set to "COOL", you can switch over operation mode between "FAN", "DRY" and "COOL".

When the indoor unit with master remote controller is set to "HEAT", you can switch over operation mode between "FAN" and "HEAT".

When the indoor unit with master remote controller is set to "FAN", you cannot switch operation mode.

When attempting settings than that consented above, a "peep" is emitted as a warning.

Only with Heat recovery system, you can set the indoor unit to AUTOMATIC. Attempting to do so, a "peep" will be emitted as a warning.

How to designate the master remote controller

Operate in the following order.



Continuously press the OPERATION MODE SELECTOR button for 4 seconds.

The displays showing "⊕" of all slave indoor unit connected to the same outdoor unit or BS unit flash.



Press the OPERATION MODE SELECTOR button to the indoor unit that you wish to designate as the master remote controller. Then designation is completed. This indoor unit is designated as the master remote controller and the display showing "⊕" vanishes.

- To change settings, repeat steps ① and ②.


EMERGENCY OPERATION

When the remote controller does not work due to battery failure or the absence thereof, use this switch which is located beside the discharge grille on the main unit. When the remote controller does not work, but the battery low indicator on it is not lit, contact your dealer.

[START]

1 To press the emergency operation switch.

The machine runs in the previous mode. The system operates with the previously set air flow direction.



[STOP]

2 Press the EMERGENCY OPERATION switch again.

PRECAUTIONS FOR GROUP CONTROL SYSTEM OR TWO REMOTE CONTROLLER CONTROL SYSTEM

This system provides two other control systems beside individual control (one remote controller controls one indoor unit) system. Confirm the following if your unit is of the following control system type.

■Group control system

One remote controller controls up to 16 indoor units.
All indoor units are equally set.

C: 3PA63363-21T-9

■ Two remote controller control system

Two remote controllers control one indoor unit. (In case of group control system, one group of indoor units)
The unit follows individual operation.

NOTES

- Cannot have two remote controller control system with only wireless remote controllers. (It will be a two remote controller control system having one wired and one wireless remote controllers.)
- Under two remote controller control system, wireless remote controller cannot control timer operation.
- Only the operating indicator lamp out of 3 other lamps on the indoor unit display functions.

NOTE

- Contact your Daikin dealer in case of changing the combination or setting of group control and two remote controller control systems.

NOT MALFUNCTION OF THE AIR CONDITIONER

The following symptoms do not indicate air conditioner malfunction

I. THE SYSTEM DOES NOT OPERATE

- **The system does not restart immediately after the ON/OFF button is pressed.**
If the OPERATION lamp lights, the system is in normal condition. It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.
- **The system does not restart immediately when TEMPERATURE SETTING**

button is returned to the former position after pushing the button.

It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.

- **If the reception beep is rapidly repeated 3 times (It sounds only twice when operating normally.)**
Control is set to the optional controller for centralized control.
- **If the defrost lamp on the indoor unit's display is lit when heating is started.**
This indication is to warn against cold air being blown from the unit. There is nothing wrong with the equipment.

HOW TO DIAGNOSE TROUBLE SPOTS

I. EMERGENCY STOP

When the air conditioner stops in emergency, the run lamp on the indoor unit starts blinking. Take the following steps yourself to read the malfunction code that appears on the display. Contact your dealer with this code. It will help pinpoint the cause of the trouble, speeding up the repair.



Press the INSPECTION/TEST button to select the inspection mode “”.

“” appears on display and blinks. “UNIT” lights up.

C: 3PA63363-21F-10



Press PROGRAMMING TIMER BUTTON and change the unit number.

Press to change the unit number until the indoor unit beeps and perform the following operation according to the number of beeps.

Number of beeps

3 short beeps Perform all steps from **3** to **6**.

1 short beep Perform **3** and **6** steps
1 long beep Normal state



Press OPERATION MODE SELECTOR BUTTON

“ ” on the left-hand of the malfunction code blinks.



Press PROGRAMMING TIMER BUTTON and change the malfunction code.

Press until the indoor unit beeps twice.



Press OPERATION MODE SELECTOR BUTTON

“ ” on the right-hand of the malfunction code blinks.



Press PROGRAMMING TIMER BUTTON and change the malfunction code.


Press until the indoor unit makes a long beep.

The malfunction code is fixed when the indoor unit makes a long beep.



Reset of the display

Press OPERATION MODE SELECTOR BUTTON to get the display back to the normal state.





II. IN CASE BESIDES EMERGENCY STOP

1. The unit does not operate at all.

- Check if the receiver is exposed of sunlight or strong light. Keep receiver away from light.
- Check if there are batteries in the remote controller. Place the batteries.
- Check if the indoor unit number and wireless remote controller number are equal.

C: 3PA63363-21T-11



Operate the indoor unit with the remote controller of the same number.

Signal transmitted from a remote controller of a different number cannot be accepted. (If the number is not mentioned, it is considered as "1")

2. The system operates but it does not sufficiently cool or heat.

- If the set temperature is not proper.
- If the FAN SPEED is set to LOW SPEED.
- If the air flow angle is not proper.


Contact the place of purchase in the following case.

⚠ WARNING

When you detect a burning odor, shut OFF power immediately and contact the place of purchase. Using the equipment in anything but proper working condition can result in equipment damage, electric shock and/or fire.

[Trouble]

The RUN lamp of the indoor unit is flashing and the unit does not work at all.



[Remedial action]

Check the malfunction code (A1 - UF) on the remote control and contact the place of purchase. (Note)

2.6.2 Installation

To the installer of the unit:
Instruct the user how to operate the unit following the operation manual.

Caution

- Carefully read the installation manual attached to the indoor unit.
- Confirm that the place where the unit will be installed satisfies the following conditions:
 - Where the wireless remote controller is operable.
 - (No strong light source or inverter fluorescent lamp must be near the signal receiver. (The signal receiver must not be directly exposed to the sun light.)
 - Where the operation display lamp is easily visible.

ACCESSORIES

Check if the following accessories are included with your unit.

Name	Shape	Quantity	Name	Shape	Quantity	Name	Shape	Quantity	Name	Shape	Quantity
Receiver assembly		1 set	Remote controller holder		1 pc.	Dry cell battery LR 03 (AM4)		2 pcs.	Wire harness		1 pc.
Transmission PC board assembly		1 set	Wireless remote controller		1 pc.	Unit No. label		1 pc.	Screw for installing remote controller holder		2 pcs.
									Operation manual		1 pc.
									Clamp		2 pcs.

1 INSTALLATION OF WIRELESS REMOTE CONTROLLER

<Installation of wireless remote controller >

- Do not throw the wireless remote controller or give strong shock.
- Do not store it where it may get wet or directly exposed to the sun light.
- Direct the wireless remote controller transmitting part toward the receiving part of the unit.
- The distance operable by the wireless remote controller from the unit is approximately 7 meters.
- If an obstacle such as curtains blocks the signal between the receiver and the wireless remote controller, the system does not operate.
- Installing to a wall or a pillar
Slide the wireless remote controller into the remote controller holder from the top.

Fix the remote controller holder with the screws.

- How to set the batteries

- ① Slide and open the back cover in the direction shown by the arrow.
- ② Set the attached dry cell batteries to the place. Make sure to match the polarity (+) (-) of the batteries to the marks indicated where the batteries are to be placed when setting the batteries.

2 INSTALLATION OF RECEIVER ASSEMBLY

(1) Preparation before installation
Remove the suction grille and the piping side decorative panel according to the installation manual attached to the indoor unit.

(2) Installation of receiver assembly

- Remove the decorative name plate mount of the indoor unit.

- ① Insert the tip of the flat blade (-) screwdriver into the place shown by black circle (●) (both A and B) of the name plate.
- ② Tilt the screwdriver in the direction shown by the arrow, (both A and B)
- ③ Pull the entire name plate mount toward yourself and remove one side.
- ④ Do the same to the remaining two places, (C and D)
- ⑤ Remove the entire name plate. (The name plate mount is no longer required.)

- Installation of receiver assembly
After passing the wire harness of the receiver through the electric wire penetrating hole, set the receiving part in the direction shown by the arrow. (Fix the receiver after matching the projection of the receiving part and the notch of the bottom frame.)

1P067740-1B

3 INSTALLATION OF TRANSMISSION PC BOARD ASSEMBLY

- ① Remove the switch box and its cover mounted at the rear of the unit.
- ② Mount the transmission PC board assembly on the right side of the indoor unit.
- ③ Connect the wire harness attached to the receiver assembly to the connector (X1A) on the transmission PC board.
- ④ Bind the wire harness and the lead wires of the swing motor with the clamp (accessory).
- ⑤ Connect the attached wire harness to the connector (X2A) on the transmission PC board.
- ⑥ Wire between the transmission PC board of the indoor unit and the switch box. (Make sure to clamp the wires with the clamp.)
- ⑦ Connect the wires to the connector (for Skyair X24A and for VRV X23A) on the PC board assembly mounted inside the switch box. (Make sure to clamp the wires with the clamp material.)
- ⑧ Put the switch box and its cover back to their place.

4 SETTING OF ADDRESS

<Setting the address and the MAIN/SUB stations>
 When multiple units are installed in a room and controlled by one wireless remote controller, (including individual remote control in group control) make sure to set the address to both the receiving part and the wireless remote controller, see the installation manual attached to the air conditioners.

SETTING PROCEDURE (For setting the remote controllers for other units, see the installation manual attached to the air conditioners.)

- (1) Setting the receiver
 - ① Set the wireless address switch (SS2) on the transmission PC board according to the table 1.
 - ② When using both wired and wireless remote controllers together, change the MAIN/SUB setting switch on the receiving part (SS1) to the SUB side since the wired remote controller will be used as MAIN. (refer to table 2)
- (2) Setting the address of wireless remote controller
 - ① Press the **ON/OFF** and **MODE** buttons at the same time for 4 seconds or more to go into the FIELD SETTING mode. (The liquid crystal display on the remote controller is shown in the above drawing.)
 - ② Press the **MODE** button and select the multiple setting. (A/b setting)
 (Each time the button is pressed, the display changes from "A" to "b".)
 - ③ Press the **UP** and **DOWN** buttons for set the address. The address can be set from 1 to 6, but set it from 1 to 3 to correspond with the receiving part. (It does not work when it is set to 4 to 6.)
 - ④ Press the **RESERVE** button and "define" the settings.
 - ⑤ Press the **MODE** button for 1 second or more and the setting is completed. (It returns to normal display.)

Unit No.	NO. 1	NO. 2	NO. 3
Wireless address switch (SS2)	1	2	3

	MAIN	SUB
MAIN/SUB switch (SS1)	MAIN	SUB

When the indoor unit operated by this remote controller is controlled from the outside such as centralized control, sometimes the command of operation changeover and temperature setting is not accepted. After confirming the customer's request, set the remote controller according to the following table.

Remote controller	Indoor unit
Multifield Remote controller display A: Standard All items displayed, Receiving sound is: 1 LONG BEEP or 3 SHORT BEEP b: Multi System Only the items operated remain displayed for a short time	When the operation of the indoor unit is controlled by other air conditioners and equipment Commands other than operation changeover and temperature setting are accepted. Receiving sound is: 1 LONG BEEP or 3 SHORT BEEP All commands are accepted. Receiving sound is: 2 SHORT BEEPS

PRECAUTIONS
 Set the unit No. of the receiving part and the wireless remote controller the same. If the numbers are not set the same, the signal from the remote controller cannot be received.

- (3) Stick the Unit No. label at the indoor unit as well as on the back of the wireless remote controller.

5 MOUNTING SUCTION GRILLE AND DECORATIVE PANEL

Put the piping side decorative panel and the suction grille back to the place in the reverse order according to the installation manual attached to the indoor unit.

6 TEST RUN

Perform test run according to the installation manual attached to the indoor unit.