


Service Manual

SUPER MULTI *NX*

F-Series



[Applied Models]

- Inverter pair Cooling mode
- Inverter pair Heating mode

SUPER MULTI NX F-Series

●Cooling Only

Indoor Unit

FTKS20D3VMW
FTKS20D3VML
FTKS25D3VMW
FTKS25D3VML
FTKS35D3VMW
FTKS35D3VML
FTKS50D2V1W
FTKS50D2V1L

FTKS20CAVMB
FTKS25CAVMB
FTKS35CAVMB
FTKS50FV1B
FTKS60FV1B
FTKS71FV1B

FDKS25CAVMB
FDKS35CAVMB
FDKS50CVMB
FDKS60CVMB
FDKS25EAVMB
FDKS35EAVMB

FLKS25BAVMB
FLKS35BAVMB
FLKS50BAVMB
FLKS60BAVMB
FVXS25FV1B
FVXS35FV1B
FVXS50FV1B
FHQ35BVV1B
FHQ50BVV1B
FHQ60BVV1B

Outdoor Unit

4MKS75F2V1B

●Heat Pump

Indoor Unit

FTXG25EV1BW
FTXG25EV1BS
FTXG35EV1BW
FTXG35EV1BS
CTXG50EV1BW
CTXG50EV1BS
FTXS20D3VMW
FTXS20D3VML
FTXS25D3VMW
FTXS25D3VML

FTXS35D3VMW
FTXS35D3VML
FTXS50D2V1W
FTXS50D2V1L
FTXS20CAVMB
FTXS25CAVMB
FTXS35CAVMB
FTXS50FV1B
FTXS60FV1B
FTXS71FV1B

FDXS25CAVMB
FDXS35CAVMB
FDXS50CVMB
FDXS60CVMB
FDXS25EAVMB
FDXS35EAVMB

FLXS25BAVMB
FLXS35BAVMB
FLXS50BAVMB
FLXS60BAVMB
FVXS25FV1B
FVXS35FV1B
FVXS50FV1B
FHQ35BVV1B
FHQ50BVV1B
FHQ60BVV1B

Outdoor Unit

4MXS68F2V1B

1. Introduction	V
1.1 Safety Cautions	v
1.2 Used Icons	ix
Part 1 List of Functions	1
1. List of Functions	2
1.1 Cooling Only Models	2
1.2 Heat Pump Models	7
Part 2 Specifications	13
1. Specifications	14
1.1 Indoor Units - Cooling Only	14
1.2 Outdoor Units - Cooling Only	23
1.3 Indoor Units - Heat Pump	24
1.4 Outdoor Units - Heat Pump	35
Part 3 Printed Circuit Board Connector Wiring Diagram	37
1. Printed Circuit Board Connector Wiring Diagram	38
1.1 Wall Mounted Type	38
1.2 Duct Connected Type	47
1.3 Floor / Ceiling Suspended Dual Type	49
1.4 Floor Standing Type	52
1.5 Ceiling Suspended Type	54
1.6 Outdoor Units	56
Part 4 Function and Control	59
1. Main Functions	60
1.1 Frequency Principle	60
1.2 Power-Airflow Dual Flaps, Wide Angle Louvers and Auto-Swing	62
1.3 Operation Starting Control	64
1.4 Fan Speed Control for Indoor Units	65
1.5 Programme Dry Function	66
1.6 Automatic Operation	67
1.7 Thermostat Control	68
1.8 Night Set Mode	69
1.9 ECONO Mode	70
1.10 INTELLIGENT EYE (Wall Mounted Type only)	71
1.11 HOME LEAVE Operation	73
1.12 Inverter POWERFUL Operation	74
1.13 Other Functions	75
2. Function of Main Structural Parts	77
2.1 Main Structural Parts	77
2.2 Function of Thermistor	78
3. Control Specification	82
3.1 Mode Hierarchy	82
3.2 Frequency Control	83
3.3 Controls at Mode Changing / Start-up	86
3.4 Discharge Pipe Control	88
3.5 Input Current Control	88

3.6	Freeze-up Protection Control	89
3.7	Heating Peak-cut Control	89
3.8	Fan Control.....	90
3.9	Liquid Compression Protection Function 2.....	90
3.10	Defrost Control	91
3.11	Electronic Expansion Valve Control	92
3.12	Malfunctions	96
3.13	Forced Operation Mode	97
3.14	Wiring-Error Check.....	98
3.15	Additional Function.....	100

Part 5 Operation Manual..... 103

1.	System Configuration.....	104
1.1	Operation Instructions	104
2.	Instruction.....	105
2.1	FTK(X)S, FTXG, CTXG, FDK(X)S, FLK(X)S Series	105
2.2	FVXS Series.....	181
2.3	FHQ Series.....	212

Part 6 Service Diagnosis..... 225





1.	Caution for Diagnosis.....	226
1.1	Troubleshooting with Operation Lamp	226
2.	Problem Symptoms and Measures	228
3.	Service Check Function	229
3.1	Check Method 1	229
3.2	Check Method 2	231
4.	Code Indication on the Remote Control	233
4.1	Error Codes and Description of Fault.....	233
5.	Troubleshooting	234
5.1	Indoor Units	234
5.2	Outdoor Units	235
5.3	Indoor Unit PCB Abnormality	236
5.4	Freeze-up Protection Control or High Pressure Control.....	237
5.5	Fan Motor or Related Abnormality	239
5.6	Thermistor or Related Abnormality (Indoor Unit).....	242
5.7	Front Panel Open / Close Fault.....	243
5.8	Signal Transmission Error (between Indoor and Outdoor Unit)	244
5.9	Unspecified Voltage (between Indoor and Outdoor Units).....	246
5.10	Freeze-up Protection Control	247
5.11	Outdoor Unit PCB Abnormality.....	249
5.12	OL Activation (Compressor Overload)	250
5.13	Compressor Lock	251
5.14	DC Fan Lock	252
5.15	Input Over Current Detection	253
5.16	Discharge Pipe Temperature Control.....	255
5.17	High Pressure Control in Cooling	256
5.18	Compressor Sensor System Abnormality	258
5.19	Position Sensor Abnormality	260
5.20	CT or Related Abnormality	261
5.21	Thermistor or Related Abnormality (Outdoor Unit).....	263

5.22 Electrical Box Temperature Rise.....	265
5.23 Radiation Fin Temperature Rise	267
5.24 Output Over Current Detection.....	269
5.25 Insufficient Gas.....	271
5.26 Low-voltage Detection or Over-voltage Detection.....	273
5.27 Signal Transmission Error (on Outdoor Unit PCB).....	274
5.28 Anti-icing Function in Other Rooms / Unspecified Voltage (between Indoor and Outdoor Units).....	275
6. Check.....	276
6.1 How to Check.....	276
Part 7 Removal Procedure	287
1. Outdoor Unit.....	288
1.1 Removal of the Panels and Plates	288
1.2 Removal of the Electrical Box	292
1.3 Removal of the PCB.....	300
1.4 Removal of the Propeller Fan / Fan Motor	306
1.5 Removal of the Sound Blanket.....	308
1.6 Removal of Electronic Expansion Valve Coil, Four Way Valve Coil and Thermistor	312
1.7 Removal of the Distributor.....	315
1.8 Removal of the Four Way Valve.....	316
1.9 Removal of the Compressor.....	317
Part 8 Others	319
1. Others	320
1.1 Test Run from the Remote Control	320
1.2 Jumper Settings	321
Part 9 Appendix.....	323
1. Piping Diagrams.....	324
1.1 Indoor Units.....	324
1.2 Outdoor Units	330
2. Wiring Diagrams.....	331
2.1 Indoor Units.....	331
2.2 Outdoor Units	336
Index	i
Drawings & Flow Charts	v








1. Introduction




1.1 Safety Cautions









Cautions and Warnings

- Be sure to read the following safety cautions before conducting repair work.
- The caution items are classified into “ **Warning**” and “ **Caution**”. The “ **Warning**” items are especially important since they can lead to death or serious injury if they are not followed closely. The “ **Caution**” items can also lead to serious accidents under some conditions if they are not followed. Therefore, be sure to observe all the safety caution items described below.
- About the pictograms
 - △ This symbol indicates the item for which caution must be exercised.
The pictogram shows the item to which attention must be paid.
 - This symbol indicates the prohibited action.
The prohibited item or action is shown in the illustration or near the symbol.
 - This symbol indicates the action that must be taken, or the instruction.
The instruction is shown in the illustration or near the symbol.
- After the repair work is complete, be sure to conduct a test operation to ensure that the equipment operates normally, and explain the cautions for operating the product to the customer.












1.1.1 Cautions Regarding Safety of Workers






 Warning	
<p>Be sure to disconnect the power cable plug from the plug socket before disassembling the equipment for repair. Working on the equipment that is connected to the power supply may cause an electrical shock. If it is necessary to supply power to the equipment to conduct the repair or inspecting the circuits, do not touch any electrically charged sections of the equipment.</p>	
<p>If the refrigerant gas is discharged during the repair work, do not touch the discharged refrigerant gas. The refrigerant gas may cause frostbite.</p>	
<p>When disconnecting the suction or discharge pipe of the compressor at the welded section, evacuate the refrigerant gas completely at a well-ventilated place first. If there is a gas remaining inside the compressor, the refrigerant gas or refrigerating machine oil discharges when the pipe is disconnected, and it may cause injury.</p>	
<p>If the refrigerant gas leaks during the repair work, ventilate the area. The refrigerant gas may generate toxic gases when it contacts flames.</p>	
<p>The step-up capacitor supplies high-voltage electricity to the electrical components of the outdoor unit. Be sure to discharge the capacitor completely before conducting repair work. A charged capacitor may cause an electrical shock.</p>	
<p>Do not start or stop the air conditioner operation by plugging or unplugging the power cable plug. Plugging or unplugging the power cable plug to operate the equipment may cause an electrical shock or fire.</p>	







 Warning	
Be sure to wear a safety helmet, gloves, and a safety belt when working at a high place (more than 2m). Insufficient safety measures may cause a fall accident.	
In case of R410A refrigerant models, be sure to use pipes, flare nuts and tools for the exclusive use of the R410A refrigerant. The use of materials for R22 refrigerant models may cause a serious accident such as a damage of refrigerant cycle as well as an equipment failure.	






 Caution	
Do not repair the electrical components with wet hands. Working on the equipment with wet hands may cause an electrical shock.	
Do not clean the air conditioner by splashing water. Washing the unit with water may cause an electrical shock.	
Be sure to provide the grounding when repairing the equipment in a humid or wet place, to avoid electrical shocks.	
Be sure to turn off the power switch and unplug the power cable when cleaning the equipment. The internal fan rotates at a high speed, and cause injury.	
Be sure to conduct repair work with appropriate tools. The use of inappropriate tools may cause injury.	
Be sure to check that the refrigerating cycle section has cooled down enough before conducting repair work. Working on the unit when the refrigerating cycle section is hot may cause burns.	
Use the welder in a well-ventilated place. Using the welder in an enclosed room may cause oxygen deficiency.	

1.1.2 Cautions Regarding Safety of Users

 Warning	
<p>Be sure to use parts listed in the service parts list of the applicable model and appropriate tools to conduct repair work. Never attempt to modify the equipment. The use of inappropriate parts or tools may cause an electrical shock, excessive heat generation or fire.</p>	
<p>If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Do not use a joined power cable or extension cable, or share the same power outlet with other electrical appliances, since it may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Be sure to use an exclusive power circuit for the equipment, and follow the local technical standards related to the electrical equipment, the internal wiring regulations, and the instruction manual for installation when conducting electrical work. Insufficient power circuit capacity and improper electrical work may cause an electrical shock or fire.</p>	
<p>Be sure to use the specified cable for wiring between the indoor and outdoor units. Make the connections securely and route the cable properly so that there is no force pulling the cable at the connection terminals. Improper connections may cause excessive heat generation or fire.</p>	
<p>When wiring between the indoor and outdoor units, make sure that the terminal cover does not lift off or dismount because of the cable. If the cover is not mounted properly, the terminal connection section may cause an electrical shock, excessive heat generation or fire.</p>	
<p>Do not damage or modify the power cable. Damaged or modified power cable may cause an electrical shock or fire. Placing heavy items on the power cable, and heating or pulling the power cable may damage the cable.</p>	
<p>Do not mix air or gas other than the specified refrigerant (R410A / R22) in the refrigerant system. If air enters the refrigerating system, an excessively high pressure results, causing equipment damage and injury.</p>	
<p>If the refrigerant gas leaks, be sure to locate the leaking point and repair it before charging the refrigerant. After charging refrigerant, make sure that there is no refrigerant leak. If the leaking point cannot be located and the repair work must be stopped, be sure to perform pump-down and close the service valve, to prevent the refrigerant gas from leaking into the room. The refrigerant gas itself is harmless, but it may generate toxic gases when it contacts flames, such as fan and other heaters, stoves and ranges.</p>	
<p>When relocating the equipment, make sure that the new installation site has sufficient strength to withstand the weight of the equipment. If the installation site does not have sufficient strength and if the installation work is not conducted securely, the equipment may fall and cause injury.</p>	





 Warning	
Check to make sure that the power cable plug is not dirty or loose, then insert the plug into a power outlet securely. If the plug has dust or loose connection, it may cause an electrical shock or fire.	
Be sure to install the product correctly by using the provided standard installation frame. Incorrect use of the installation frame and improper installation may cause the equipment to fall, resulting in injury.	For unitary type only 
Be sure to install the product securely in the installation frame mounted on the window frame. If the unit is not securely mounted, it may fall and cause injury.	For unitary type only 
When replacing the coin battery in the remote control, be sure to disposed of the old battery to prevent children from swallowing it. If a child swallows the coin battery, see a doctor immediately.	

 Caution	
Installation of a leakage breaker is necessary in some cases depending on the conditions of the installation site, to prevent electrical shocks.	
Do not install the equipment in a place where there is a possibility of combustible gas leaks. If the combustible gas leaks and remains around the unit, it may cause a fire.	
Check to see if the parts and wires are mounted and connected properly, and if the connections at the soldered or crimped terminals are secure. Improper installation and connections may cause excessive heat generation, fire or an electrical shock.	
If the installation platform or frame has corroded, replace it. Corroded installation platform or frame may cause the unit to fall, resulting in injury.	
Check the grounding, and repair it if the equipment is not properly grounded. Improper grounding may cause an electrical shock.	

 Caution	
Be sure to measure the insulation resistance after the repair, and make sure that the resistance is 1 MΩ or higher. Faulty insulation may cause an electrical shock.	
Be sure to check the drainage of the indoor unit after the repair. Faulty drainage may cause the water to enter the room and wet the furniture and floor.	
Do not tilt the unit when removing it. The water inside the unit may spill and wet the furniture and floor.	
Be sure to install the packing and seal on the installation frame properly. If the packing and seal are not installed properly, water may enter the room and wet the furniture and floor.	For unitary type only 

1.2 Used Icons

Icons are used to attract the attention of the reader to specific information. The meaning of each icon is described in the table below:

Icon	Type of Information	Description
 Note:	Note	A “note” provides information that is not indispensable, but may nevertheless be valuable to the reader, such as tips and tricks.
 Caution	Caution	A “caution” is used when there is danger that the reader, through incorrect manipulation, may damage equipment, lose data, get an unexpected result or has to restart (part of) a procedure.
 Warning	Warning	A “warning” is used when there is danger of personal injury.
	Reference	A “reference” guides the reader to other places in this binder or in this manual, where he/she will find additional information on a specific topic.

Part 1

List of Functions

1. List of Functions	2
1.1 Cooling Only Models	2
1.2 Heat Pump Models.....	7

1. List of Functions

1.1 Cooling Only Models

Category	Functions	FTKS20-35D3VMW(L)	FTKS50D2V1W(L)	Category	Functions	FTKS20-35D3VMW(L)	FTKS50D2V1W(L)	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter	—	—	
	Operation Limit for Cooling (°CDB)	—	—		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CWB)	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	
Compressor	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	○	○	
	Oval Scroll Compressor	—	—		Longlife Filter (Option)	—	—	
	Swing Compressor	—	—		Mold Proof Air Filter	○	○	
	Rotary Compressor	—	—		Wipe-clean Flat Panel	○	○	
Comfortable Airflow	Reluctance DC Motor	—	—		Washable Grille	—	—	
	Power-Airflow Flap	—	—		Filter Cleaning Indicator	—	—	
	Power-Airflow Dual Flaps	○	○		Mold Proof Operation	—	—	
	Power-Airflow Diffuser	—	—	Heating Dry Operation	—	—		
	Wide-Angle Louvers	○	○	Good-Sleep Cooling Operation	—	—		
	Vertical Auto-Swing (Up and Down)	○	○	Timer	Weekly Timer	—	—	
	Horizontal Auto-Swing (Right and Left)	—	—		24-Hour On/Off Timer	○	○	
	3-D Airflow	—	—		72-Hour On/Off Timer	—	—	
	Comfort Control	Comfort Airflow Mode	○	○	Night Set Mode	○	○	
3-Step Airflow (H/P Only)		—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
Auto Fan Speed		○	○		Self-Diagnosis (Digital, LED) Display	○	○	
Indoor Unit Quiet Operation		○	○		Wiring Error Check	—	—	
Night Quiet Mode (Automatic)		—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	
Outdoor Unit Quiet Operation (Manual)		—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
Intelligent Eye		○	○		Flexible Voltage Correspondence	○	—	
Quick Warming Function		—	—		High Ceiling Application	—	—	
Hot-Start Function	—	—	Chargeless		—	—		
Operation	Automatic Defrosting	—	—	Either Side Drain (Right or Left)	○	○		
	Automatic Operation	—	—	Power Selection	—	—		
	Programme Dry Function	○	○	Remote Control	5-Rooms Centralized Controller (Option)	○	○	
Fan Only	○	○	Remote Control Adapter (Normal Open-Pulse Contact) (Option)		○	○		
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—		Remote Control Adapter (Normal Open Contact) (Option)	○	○	
	Inverter Powerful Operation	○	○		DIII-NET Compatible (Adapter) (Option)	○	○	
	Priority-Room Setting	—	—		Remote Control	Infrared	○	○
	Cooling / Heating Mode Lock	—	—			Wired	—	—
	Home Leave Operation	—	—					
	ECONO Mode	○	○					
	Indoor Unit On/Off Switch	○	○					
	Signal Reception Indicator	○	○					
Temperature Display	—	—						
Another Room Operation	—	—						

Note: ○ : Holding Functions

— : No Functions

Category	Functions	FTKS20-35CAVMB	FTKS50-71FV1B	Category	Functions	FTKS20-35CAVMB	FTKS50-71FV1B	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter	—	—	
	Operation Limit for Cooling (°CDB)	—	—		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CWB)	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	○	—	
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	○	
Compressor	Oval Scroll Compressor	—	—		Longlife Filter (Option)	—	—	
	Swing Compressor	—	—		Mold Proof Air Filter	○	○	
	Rotary Compressor	—	—		Wipe-clean Flat Panel	○	○	
	Reluctance DC Motor	—	—		Washable Grille	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—		Filter Cleaning Indicator	—	—	
	Power-Airflow Dual Flaps	○	○		Mold Proof Operation	—	—	
	Power-Airflow Diffuser	—	—	Heating Dry Operation	—	—		
	Wide-Angle Louvers	○	○	Good-Sleep Cooling Operation	—	—		
	Vertical Auto-Swing (Up and Down)	○	○	Timer	Weekly Timer	—	—	
	Horizontal Auto-Swing (Right and Left)	—	○		24-Hour On/Off Timer	○	○	
	3-D Airflow	—	○		72-Hour On/Off Timer	—	—	
	Comfort Airflow Mode	—	—		Night Set Mode	○	○	
Comfort Control	3-Step Airflow (H/P Only)	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	Auto Fan Speed	○	○		Self-Diagnosis (Digital, LED) Display	○	○	
	Indoor Unit Quiet Operation	○	○		Wiring Error Check	—	—	
	Night Quiet Mode (Automatic)	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	
	Outdoor Unit Quiet Operation (Manual)	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	
	Intelligent Eye	○	○		Flexible Voltage Correspondence	○	—	
	Quick Warming Function	—	—		High Ceiling Application	—	—	
	Hot-Start Function	—	—		Chargeless	—	—	
Operation	Automatic Defrosting	—	—	Either side Drain (Right or Left)	○	○		
	Automatic Operation	—	—	Power Selection	—	—		
	Programme Dry Function	○	○	Remote Control	5-Rooms Centralized Controller (Option)	○	○	
Fan Only	○	○	Remote Control Adapter (Normal Open-Pulse Contact) (Option)		○	○		
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—		Remote Control Adapter (Normal Open Contact) (Option)	○	○	
	Inverter Powerful Operation	○	○		DIIII-NET Compatible (Adapter) (Option)	○	○	
	Priority-Room Setting	—	—		Remote Control	Infrared	○	○
	Cooling / Heating Mode Lock	—	—			Wired	—	—
	Home Leave Operation	○	○		Another Room Operation	—	—	
	ECONO Mode	—	—					
	Indoor Unit On/Off Switch	○	○					
	Signal Reception Indicator	○	○					
Temperature Display	—	—						

Note: ○ : Holding Functions
— : No Functions

Category	Functions				Category	Functions			
		FDKS25/35CAVMB	FDKS50/60CYMB	FDKS25/35EAVMB			FDKS25/35CAVMB	FDKS50/60CYMB	FDKS25/35EAVMB
Basic Function	Inverter (with Inverter Power Control)	○	○	○	Health & Clean	Air Purifying Filter	—	—	—
	Operation Limit for Cooling (°CDB)	—	—	—		Photocatalytic Deodorizing Filter	—	—	—
	Operation Limit for Heating (°CWB)	—	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	—
	PAM Control	—	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—	—
Compressor	Oval Scroll Compressor	—	—	—	Longlife Filter (Option)	—	—	—	
	Swing Compressor	—	—	—	Mold Proof Air Filter	○	○	○	
	Rotary Compressor	—	—	—	Wipe-clean Flat Panel	—	—	—	
	Reluctance DC Motor	—	—	—	Washable Grille	—	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—	—	Filter Cleaning Indicator	—	—	—	
	Power-Airflow Dual Flaps	—	—	—	Mold Proof Operation	—	—	—	
	Power-Airflow Diffuser	—	—	—	Heating Dry Operation	—	—	—	
	Wide-Angle Louvers	—	—	—	Good-Sleep Cooling Operation	—	—	—	
	Vertical Auto-Swing (Up and Down)	—	—	—	Timer	Weekly Timer	—	—	—
	Horizontal Auto-Swing (Right and Left)	—	—	—		24-Hour On/Off Timer	○	○	○
	3-D Airflow	—	—	—		72-Hour On/Off Timer	—	—	—
	Comfort Airflow Mode	—	—	—		Night Set Mode	○	○	○
Comfort Control	3-Step Airflow (H/P Only)	—	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	○
	Auto Fan Speed	○	○	○		Self-Diagnosis (Digital, LED) Display	○	○	○
	Indoor Unit Quiet Operation	○	○	○		Wiring-Error Check	—	—	—
	Night Quiet Mode (Automatic)	—	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	—
	Outdoor Unit Quiet Operation (Manual)	—	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	○
	Intelligent Eye	—	—	—		Flexible Voltage Correspondence	○	○	○
	Quick Warming Function	—	—	—		High Ceiling Application	—	—	—
	Hot-Start Function	—	—	—		Chargeless	—	—	—
Operation	Automatic Defrosting	—	—	—	Either Side Drain (Right or Left)	—	—	—	
	Automatic Operation	—	—	—	Power-Selection	—	—	—	
	Programme Dry Function	○	○	○	Remote Control	5-Rooms Centralized Controller (Option)	○	○	○
	Fan Only	○	○	○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○	○
				Remote Control Adapter (Normal Open Contact) (Option)		○	○	○	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—	—	Remote Control	DIII-NET Compatible (Adapter) (Option)	○	○	○
	Inverter Powerful Operation	○	○	○		Infrared	○	○	○
	Priority-Room Setting	—	—	—		Wired	—	—	—
	Cooling / Heating Mode Lock	—	—	—					
	Home Leave Operation	○	○	○					
	ECONO Mode	—	—	—					
	Indoor Unit On/Off Switch	○	○	○					
	Signal Reception Indicator	○	○	○					
Temperature Display	—	—	—						
Another Room Operation	—	—	—						

Note: ○ : Holding Functions
 — : No Functions

Category	Functions	FLKS25-60BAVMB	FYXS25-50FV1B	FHQ35-60BVV1B	Category	Functions	FLKS25-60BAVMB	FYXS25-50FV1B	FHQ35-60BVV1B	
Basic Function	Inverter (with Inverter Power Control)	○	○	○	Health & Clean	Air Purifying Filter	○	—	—	
	Operation Limit for Cooling (°CDB)	—	—	—		Photocatalytic Deodorizing Filter	○	—	—	
	Operation Limit for Heating (°CWB)	—	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	—	
	PAM Control	—	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	○	—	
Compressor	Oval Scroll Compressor	—	—	—		Longlife Filter (Option)	—	—	○	
	Swing Compressor	—	—	—		Mold Proof Air Filter	○	○	○	
	Rotary Compressor	—	—	—		Wipe-clean Flat Panel	—	○	—	
	Reluctance DC Motor	—	—	—		Washable Grille	—	—	○	
Comfortable Airflow	Power-Airflow Flap	—	—	—		Timer	Filter Cleaning Indicator	—	—	○
	Power-Airflow Dual Flaps	—	—	—			Mold Proof Operation	—	—	—
	Power-Airflow Diffuser	—	—	—	Heating Dry Operation		—	—	—	
	Wide-Angle Louvers	—	○	—	Good-Sleep Cooling Operation		—	—	—	
	Vertical Auto-Swing (Up and Down)	○	○	○	Weekly Timer		—	○	—	
	Horizontal Auto-Swing (Right and Left)	—	—	—	24-Hour On/Off Timer		○	○	—	
	3-D Airflow	—	—	—	72-Hour On/Off Timer		—	—	○	
	Comfort Airflow Mode	—	—	—	Night Set Mode		○	○	—	
Comfort Control	3-Step Airflow (H/P Only)	—	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	○	
	Auto Fan Speed	○	○	—		Self-Diagnosis (Digital, LED) Display	○	○	○	
	Indoor Unit Quiet Operation	○	○	—		Wiring-Error Check	—	—	—	
	Night Quiet Mode (Automatic)	—	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	—	
	Operation	Outdoor Unit Quiet Operation (Manual)	—	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	○
		Intelligent Eye	—	—	—		Flexible Voltage Correspondence	○	—	—
		Quick Warming Function	—	—	—		High Ceiling Application	—	—	○
		Hot-Start Function	—	—	—		Chargeless	—	—	—
Operation	Automatic Defrosting	—	—	—	Remote Control	Either Side Drain (Right or Left)	—	—	—	
	Automatic Operation	—	—	—		Power-Selection	—	—	—	
Lifestyle Convenience	Programme Dry Function	○	○	○		5-Rooms Centralized Controller (Option)	○	○	—	
	Fan Only	○	○	○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○	—	
	New Powerful Operation (Non-Inverter)	—	—	—	Remote Control Adapter (Normal Open Contact) (Option)	○	○	—		
	Inverter Powerful Operation	○	○	—	DIII-NET Compatible (Adapter) (Option)	○	○	○		
	Priority-Room Setting	—	—	—	Remote Control	Infrared	○	○	○	
	Cooling / Heating Mode Lock	—	—	—		Wired	—	—	○	
	Home Leave Operation	○	—	—						
	ECONO Mode	—	○	—						
	Indoor Unit On/Off Switch	○	○	—						
	Signal Reception Indicator	○	○	—						
Temperature Display	—	—	—							
Another Room Operation	—	—	—							

Note: ○ : Holding Functions

— : No Functions

Category	Functions	4MKS75F2V1B	Category	Functions	4MKS75F2V1B	
Basic Function	Inverter (with Inverter Power Control)	○	Health & Clean	Air Purifying Filter	—	
	Operation Limit for Cooling (°CDB)	-10 46		Photocatalytic Deodorizing Filter	—	
	Operation Limit for Heating (°CWB)	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	
	PAM Control	○		Titanium Apatite Photocatalytic Air-Purifying Filter	—	
Compressor	Oval Scroll Compressor	—		Longlife Filter (Option)	—	
	Swing Compressor	○		Mold Proof Air Filter	—	
	Rotary Compressor	—		Wipe-clean Flat Panel	—	
	Reluctance DC Motor	○		Washable Grille	—	
Comfortable Airflow	Power-Airflow Flap	—		Filter Cleaning Indicator	—	
	Power-Airflow Dual Flaps	—		Mold Proof Operation	—	
	Power-Airflow Diffuser	—		Heating Dry Operation	—	
	Wide-Angle Louvers	—		Good-Sleep Cooling Operation	—	
	Vertical Auto-Swing (Up and Down)	—	Timer	Weekly Timer	—	
	Horizontal Auto-Swing (Right and Left)	—		24-Hour On/Off Timer	—	
	3-D Airflow	—		72-Hour On/Off Timer	—	
	Comfort Airflow Mode	—		Night Set Mode	—	
Comfort Control	3-Step Airflow (H/P Only)	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	—	
	Auto Fan Speed	—		Self-Diagnosis (Digital, LED) Display	○	
	Indoor Unit Quiet Operation	—		Wiring-Error Check	○	
	Night Quiet Mode (Automatic)	○		Anticorrosion Treatment of Outdoor Heat Exchanger	○	
	Operation	Outdoor Unit Quiet Operation (Manual)	○	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	—
		Intelligent Eye	—		Flexible Voltage Correspondence	—
		Quick Warming Function	—		High Ceiling Application	—
		Hot-Start Function	—		Chargeless	○
Automatic Defrosting		—	Either Side Drain (Right or Left)		—	
Power-Selection		—				
Operation	Automatic Operation	—	Remote Control	5-Rooms Centralized Controller (Option)	—	
	Programme Dry Function	—		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	—	
	Fan Only	—		Remote Control Adapter (Normal Open Contact) (Option)	—	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	Remote Control	DIII-NET Compatible (Adapter) (Option)	—	
	Inverter Powerful Operation	—		Infrared	—	
	Priority-Room Setting	○		Wired	—	
	Cooling / Heating Mode Lock	○				
	Home Leave Operation	—				
	ECONO Mode	—				
	Indoor Unit On/Off Switch	—				
	Signal Reception Indicator	—				
	Temperature Display	—				
Another Room Operation	—					

Note: ○ : Holding Functions
— : No Functions

1.2 Heat Pump Models

Category	Functions			Category	Functions			
		FTXG25/35EV1BW(S)	CTXG50EV1BW(S)			FTXG25/35EV1BW(S)	CTXG50EV1BW(S)	
Basic Function	Inverter (with Inverter Power Control)	○	○	Health & Clean	Air Purifying Filter	—	—	
	Operation Limit for Cooling (°CDB)	—	—		Photocatalytic Deodorizing Filter	—	—	
	Operation Limit for Heating (°CWB)	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	
	PAM Control	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	○	○	
Compressor	Oval Scroll Compressor	—	—		Longlife Filter (Option)	—	—	
	Swing Compressor	—	—		Mold Proof Air Filter	○	○	
	Rotary Compressor	—	—		Wipe-clean Flat Panel	○	○	
	Reluctance DC Motor	—	—		Washable Grille	—	—	
Comfortable Airflow	Power-Airflow Flap	○	○		Filter Cleaning Indicator	—	—	
	Power-Airflow Dual Flaps	—	—		Mold Proof Operation	—	—	
	Power-Airflow Diffuser	—	—		Heating Dry Operation	—	—	
	Wide-Angle Louvers	○	○		Good-Sleep Cooling Operation	—	—	
	Vertical Auto-Swing (Up and Down)	○	○	Timer	Weekly Timer	—	—	
	Horizontal Auto-Swing (Right and Left)	○	○		24-Hour On/Off Timer	○	○	
	3-D Airflow	○	○		72-Hour On/Off Timer	—	—	
	Comfort Airflow Mode	○	○		Night Set Mode	○	○	
Comfort Control	3-Step Airflow (H/P Only)	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	
	Auto Fan Speed	○	○		Self-Diagnosis (Digital, LED) Display	○	○	
	Indoor Unit Quiet Operation	○	○		Wiring Error Check	—	—	
	Night Quiet Mode (Automatic)	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	
	Outdoor Unit Quiet Operation (Manual)	—	—		Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	—
	Intelligent Eye	○	○			Flexible Voltage Correspondence	—	—
	Quick Warming Function	—	—	High Ceiling Application	—	—		
	Hot-Start Function	○	○	Chargeless	—	—		
Automatic Defrosting	—	—	Either Side Drain (Right or Left)	○	○			
Operation	Automatic Operation	○	○	Power Selection	—	—		
	Programme Dry Function	○	○	Remote Control	5-Rooms Centralized Controller (Option)	○	○	
	Fan Only	○	○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—		Remote Control Adapter (Normal Open Contact) (Option)	○	○	
	Inverter Powerful Operation	○	○		DIII-NET Compatible (Adapter) (Option)	○	○	
	Priority-Room Setting	—	—		Remote Control	Infrared	○	○
	Cooling / Heating Mode Lock	—	—			Wired	—	—
	Home Leave Operation	—	—			Another Room Operation	—	—
	ECONO Mode	—	—					
	Indoor Unit On/Off Switch	○	○					
	Signal Reception Indicator	○	○					
Temperature Display	—	—						
Another Room Operation	—	—						

Note: ○ : Holding Functions
— : No Functions

Category	Functions				Category	Functions				
		FTXS20-35D3VMW(L)	FTXS50D2V1W(L)	FTXS20-35CAVMB			FTXS20-35D3VMW(L)	FTXS50D2V1W(L)	FTXS20-35CAVMB	
Basic Function	Inverter (with Inverter Power Control)	○	○	○	Health & Clean	Air Purifying Filter	—	—	—	
	Operation Limit for Cooling (°CDB)	—	—	—		Photocatalytic Deodorizing Filter	—	—	—	
	Operation Limit for Heating (°CWB)	—	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	○	
PAM Control	—	—	—	Titanium Apatite Photocatalytic Air-Purifying Filter		○	○	—		
Compressor	Oval Scroll Compressor	—	—	—		Longlife Filter (Option)	—	—	—	
	Swing Compressor	—	—	—		Mold Proof Air Filter	○	○	○	
	Rotary Compressor	—	—	—		Wipe-clean Flat Panel	○	○	○	
	Reluctance DC Motor	—	—	—		Washable Grille	—	—	—	
Comfortable Airflow	Power-Airflow Flap	—	—	—		Filter Cleaning Indicator	—	—	—	
	Power-Airflow Dual Flaps	○	○	○		Mold Proof Operation	—	—	—	
	Power-Airflow Diffuser	—	—	—		Heating Dry Operation	—	—	—	
	Wide-Angle Louvers	○	○	○		Good-Sleep Cooling Operation	—	—	—	
	Vertical Auto-Swing (Up and Down)	○	○	○		Timer	Weekly Timer	—	—	—
	Horizontal Auto-Swing (Right and Left)	—	—	—	24-Hour On/Off Timer		○	○	○	
	3-D Airflow	—	—	—	72-Hour On/Off Timer		—	—	—	
	Comfort Airflow Mode	○	○	—	Night Set Mode		○	○	○	
3-Step Airflow (H/P Only)	—	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	○		
Comfort Control	Auto Fan Speed	○	○		○	Self-Diagnosis (Digital, LED) Display	○	○	○	
	Indoor Unit Quiet Operation	○	○		○	Wiring Error Check	—	—	—	
	Night Quiet Mode (Automatic)	—	—		—	Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	—	
	Outdoor Unit Quiet Operation (Manual)	—	—		—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	○
	Intelligent Eye	○	○		○		Flexible Voltage Correspondence	○	—	○
	Quick Warming Function	—	—		—		High Ceiling Application	—	—	—
	Hot-Start Function	○	○		○		Chargeless	—	—	—
	Automatic Defrosting	—	—	—	Power Selection	—	—	—		
Operation	Automatic Operation	○	○	○	Remote Control	5-Rooms Centralized Controller (Option)	○	○	○	
	Programme Dry Function	○	○	○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○	○	
	Fan Only	○	○	○		Remote Control Adapter (Normal Open Contact) (Option)	○	○	○	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—	—		Remote Control	DIII-NET Compatible (Adapter) (Option)	○	○	○
	Inverter Powerful Operation	○	○	○			Infrared	○	○	○
	Priority-Room Setting	—	—	—			Wired	—	—	—
	Cooling / Heating Mode Lock	—	—	—			Another Room Operation	—	—	—
	Home Leave Operation	—	—	○						
	ECONO Mode	○	○	—						
	Indoor Unit On/Off Switch	○	○	○						
	Signal Reception Indicator	○	○	○						
Temperature Display	—	—	—							

Note: ○ : Holding Functions

— : No Functions

Category	Functions	FTXS50-71FV1B	Category	Functions	FTXS50-71FV1B	
Basic Function	Inverter (with Inverter Power Control)	○	Health & Clean	Air Purifying Filter	—	
	Operation Limit for Cooling (°CDB)	—		Photocatalytic Deodorizing Filter	—	
	Operation Limit for Heating (°CWB)	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	
	PAM Control	—		Titanium Apatite Photocatalytic Air-Purifying Filter	○	
Compressor	Oval Scroll Compressor	—		Longlife Filter (Option)	—	
	Swing Compressor	—		Mold Proof Air Filter	○	
	Rotary Compressor	—		Wipe-clean Flat Panel	○	
	Reluctance DC Motor	—		Washable Grille	—	
Comfortable Airflow	Power-Airflow Flap	—		Filter Cleaning Indicator	—	
	Power-Airflow Dual Flaps	○		Mold Proof Operation	—	
	Power-Airflow Diffuser	—		Heating Dry Operation	—	
	Wide-Angle Louvers	○		Good-Sleep Cooling Operation	—	
	Vertical Auto-Swing (Up and Down)	○		Timer	Weekly Timer	—
	Horizontal Auto-Swing (Right and Left)	○			24-Hour On/Off Timer	○
	3-D Airflow	○			72-Hour On/Off Timer	—
	Comfort Airflow Mode	—			Night Set Mode	○
Comfort Control	3-Step Airflow (H/P Only)	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	
	Auto Fan Speed	○		Self-Diagnosis (Digital, LED) Display	○	
	Indoor Unit Quiet Operation	○		Wiring-Error Check	—	
	Night Quiet Mode (Automatic)	—	Flexibility	Anticorrosion Treatment of Outdoor Heat Exchanger	—	
	Outdoor Unit Quiet Operation (Manual)	—		Multi-Split / Split Type Compatible Indoor Unit	○	
	Intelligent Eye	○		Flexible Voltage Correspondence	—	
	Quick Warming Function	—		High Ceiling Application	—	
	Hot-Start Function	○		Chargeless	—	
Automatic Defrosting	—	Either Side Drain (Right or Left)	○			
Operation	Automatic Operation	○	Power-Selection	—		
	Programme Dry Function	○	Remote Control	5-Rooms Centralized Controller (Option)	○	
	Fan Only	○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—		Remote Control Adapter (Normal Open Contact) (Option)	○	
	Inverter Powerful Operation	○	DIIII-NET Compatible (Adapter) (Option)	○		
	Priority-Room Setting	—	Remote Control	Infrared	○	
	Cooling / Heating Mode Lock	—		Wired	—	
	Home Leave Operation	○				
	ECONO Mode	—				
	Indoor Unit On/Off Switch	○				
	Signal Reception Indicator	○				
	Temperature Display	—				
Another Room Operation	—					

Note: ○ : Holding Functions
 — : No Functions

Category	Functions	FDXS25/35CAVMB	FDXS50/60CVMB	FDXS25/35EAVMB	Category	Functions	FDXS25/35CAVMB	FDXS50/60CVMB	FDXS25/35EAVMB
Basic Function	Inverter (with Inverter Power Control)	○	○	○	Health & Clean	Air Purifying Filter	—	—	—
	Operation Limit for Cooling (°CDB)	—	—	—		Photocatalytic Deodorizing Filter	—	—	—
	Operation Limit for Heating (°CWB)	—	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	—
	PAM Control	—	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	—	—
Compressor	Oval Scroll Compressor	—	—	—		Longlife Filter (Option)	—	—	—
	Swing Compressor	—	—	—		Mold Proof Air Filter	○	○	○
	Rotary Compressor	—	—	—		Wipe-clean Flat Panel	—	—	—
	Reluctance DC Motor	—	—	—		Washable Grille	—	—	—
Comfortable Airflow	Power-Airflow Flap	—	—	—		Filter Cleaning Indicator	—	—	—
	Power-Airflow Dual Flaps	—	—	—		Mold Proof Operation	—	—	—
	Power-Airflow Diffuser	—	—	—		Heating Dry Operation	—	—	—
	Wide-Angle Louvers	—	—	—		Good-Sleep Cooling Operation	—	—	—
	Vertical Auto-Swing (Up and Down)	—	—	—	Timer	Weekly Timer	—	—	—
	Horizontal Auto-Swing (Right and Left)	—	—	—		24-Hour On/Off Timer	○	○	○
	3-D Airflow	—	—	—		72-Hour On/Off Timer	—	—	—
	3-Step Airflow (H/P Only)	—	—	—		Night Set Mode	○	○	○
Comfort Control	Auto Fan Speed	○	○	○	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	○
	Indoor Unit Quiet Operation	○	○	○		Self-Diagnosis (Digital, LED) Display	○	○	○
	Night Quiet Mode (Automatic)	—	—	—		Wiring-Error Check	—	—	—
	Outdoor Unit Quiet Operation (Manual)	—	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	—
	Intelligent Eye	—	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	○
	Quick Warming Function	—	—	—		Flexible Voltage Correspondence	○	○	○
	Hot-Start Function	○	○	○		High Ceiling Application	—	—	—
	Automatic Defrosting	—	—	—		Chargeless	—	—	—
Operation	Automatic Operation	○	○	○	Remote Control	Either Side Drain (Right or Left)	—	—	—
	Programme Dry Function	○	○	○		Power-Selection	—	—	—
	Fan Only	○	○	○		5-Rooms Centralized Controller (Option)	○	○	○
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—	—	Remote Control	Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○	○
	Inverter Powerful Operation	○	○	○		Remote Control Adapter (Normal Open Contact) (Option)	○	○	○
	Priority-Room Setting	—	—	—		DIII-NET Compatible (Adapter) (Option)	○	○	○
	Cooling / Heating Mode Lock	—	—	—	Remote Control	Infrared	○	○	○
	Home Leave Operation	○	○	○		Wired	—	—	—
	ECONO Mode	—	—	—					
	Indoor Unit On/Off Switch	○	○	○					
	Signal Reception Indicator	○	○	○					
	Temperature Display	—	—	—					
Another Room Operation	—	—	—						

Note: ○ : Holding Functions
 — : No Functions

Category	Functions				Category	Functions			
		FLXS25-60BAVMB	FYXS25-50FV1B	FHQ35-60BVV1B			FLXS25-60BAVMB	FYXS25-50FV1B	FHQ35-60BVV1B
Basic Function	Inverter (with Inverter Power Control)	○	○	○	Health & Clean	Air Purifying Filter	○	—	—
	Operation Limit for Cooling (°CDB)	—	—	—		Photocatalytic Deodorizing Filter	○	—	—
	Operation Limit for Heating (°CWB)	—	—	—		Air Purifying Filter with Photocatalytic Deodorizing Function	—	—	—
	PAM Control	—	—	—		Titanium Apatite Photocatalytic Air-Purifying Filter	—	○	—
Compressor	Oval Scroll Compressor	—	—	—	Longlife Filter (Option)	—	—	○	
	Swing Compressor	—	—	—	Mold Proof Air Filter	○	○	○	
	Rotary Compressor	—	—	—	Wipe-clean Flat Panel	—	○	—	
	Reluctance DC Motor	—	—	—	Washable Grille	—	—	○	
Comfortable Airflow	Power-Airflow Flap	—	—	—	Filter Cleaning Indicator	—	—	○	
	Power-Airflow Dual Flaps	—	—	—	Mold Proof Operation	—	—	—	
	Power-Airflow Diffuser	—	—	—	Heating Dry Operation	—	—	—	
	Wide-Angle Louvers	—	○	—	Good-Sleep Cooling Operation	—	—	—	
	Vertical Auto-Swing (Up and Down)	○	○	○	Timer	Weekly Timer	—	○	—
	Horizontal Auto-Swing (Right and Left)	—	—	—		24-Hour On/Off Timer	○	○	—
	3-D Airflow	—	—	—		72-Hour On/Off Timer	—	—	○
	Comfort Airflow Mode	—	—	—		Night Set Mode	○	○	—
Comfort Control	3-Step Airflow (H/P Only)	—	—	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	○	○	○
	Auto Fan Speed	○	○	—		Self-Diagnosis (Digital, LED) Display	○	○	○
	Indoor Unit Quiet Operation	○	○	—		Wiring-Error Check	—	—	—
	Night Quiet Mode (Automatic)	—	—	—		Anticorrosion Treatment of Outdoor Heat Exchanger	—	—	—
	Outdoor Unit Quiet Operation (Manual)	—	—	—	Flexibility	Multi-Split / Split Type Compatible Indoor Unit	○	○	○
	Intelligent Eye	—	—	—		Flexible Voltage Correspondence	○	—	—
	Quick Warming Function	—	—	—		High Ceiling Application	—	—	○
	Hot-Start Function	○	○	○		Chargeless	—	—	—
Operation	Automatic Defrosting	—	—	—	Either Side Drain (Right or Left)	—	—	—	
	Automatic Operation	○	○	○	Power-Selection	—	—	—	
	Programme Dry Function	○	○	○	Remote Control	5-Rooms Centralized Controller (Option)	○	○	—
	Fan Only	○	○	○		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	○	○	—
				Remote Control Adapter (Normal Open Contact) (Option)		○	○	—	
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	—	—	Remote Control	DIII-NET Compatible (Adapter) (Option)	○	○	○
	Inverter Powerful Operation	○	○	—		Infrared	○	○	○
	Priority-Room Setting	—	—	—		Wired	—	—	○
	Cooling / Heating Mode Lock	—	—	—					
	Home Leave Operation	○	—	—					
	ECONO Mode	—	○	—					
	Indoor Unit On/Off Switch	○	○	—					
	Signal Reception Indicator	○	○	—					
	Temperature Display	—	—	—					
Another Room Operation	—	—	—						

Note: ○ : Holding Functions

— : No Functions

Category	Functions	4MXS68F2V1B	Category	Functions	4MXS68F2V1B
Basic Function	Inverter (with Inverter Power Control)	○	Health & Clean	Air Purifying Filter	—
	Operation Limit for Cooling (°CDB)	-10 ~ 46		Photocatalytic Deodorizing Filter	—
	Operation Limit for Heating (°CWB)	-15 ~ 15.5		Air Purifying Filter with Photocatalytic Deodorizing Function	—
	PAM Control	○		Titanium Apatite Photocatalytic Air-Purifying Filter	—
Compressor	Oval Scroll Compressor	—		Longlife Filter (Option)	—
	Swing Compressor	○		Mold Proof Air Filter	—
	Rotary Compressor	—		Wipe-clean Flat Panel	—
	Reluctance DC Motor	○		Washable Grille	—
Comfortable Airflow	Power-Airflow Flap	—		Filter Cleaning Indicator	—
	Power-Airflow Dual Flaps	—		Mold Proof Operation	—
	Power-Airflow Diffuser	—	Heating Dry Operation	—	
	Wide-Angle Louvers	—	Good-Sleep Cooling Operation	—	
	Vertical Auto-Swing (Up and Down)	—	Timer	Weekly Timer	—
	Horizontal Auto-Swing (Right and Left)	—		24-Hour On/Off Timer	—
	3-D Airflow	—		72-Hour On/Off Timer	—
	Comfort Airflow Mode	—		Night Set Mode	—
Comfort Control	3-Step Airflow (H/P Only)	—	Worry Free "Reliability & Durability"	Auto-Restart (after Power Failure)	—
	Auto Fan Speed	—		Self-Diagnosis (Digital, LED) Display	○
	Indoor Unit Quiet Operation	—		Wiring-Error Check	○
	Night Quiet Mode (Automatic)	○	Flexibility	Anticorrosion Treatment of Outdoor Heat Exchanger	○
	Outdoor Unit Quiet Operation (Manual)	○		Multi-Split / Split Type Compatible Indoor Unit	—
	Intelligent Eye	—		Flexible Voltage Correspondence	—
	Quick Warming Function	○		High Ceiling Application	—
	Hot-Start Function	—		Chargeless	30m
Automatic Defrosting	○	Either Side Drain (Right or Left)	—		
Operation	Automatic Operation	—	Power-Selection	—	
	Programme Dry Function	—	Remote Control	5-Rooms Centralized Controller (Option)	—
	Fan Only	—		Remote Control Adapter (Normal Open-Pulse Contact) (Option)	—
Lifestyle Convenience	New Powerful Operation (Non-Inverter)	—	Remote Control	Remote Control Adapter (Normal Open Contact) (Option)	—
	Inverter Powerful Operation	—		DIII-NET Compatible (Adapter) (Option)	—
	Priority-Room Setting	○	Remote Control	Infrared	—
	Cooling / Heating Mode Lock	○		Wired	—
	Home Leave Operation	—			
	ECONO Mode	—			
	Indoor Unit On/Off Switch	—			
	Signal Reception Indicator	—			
	Temperature Display	—			
Another Room Operation	—				

Note: ○ : Holding Functions
— : No Functions

Part 2

Specifications

1. Specifications	14
1.1 Indoor Units - Cooling Only	14
1.2 Outdoor Units - Cooling Only	23
1.3 Indoor Units - Heat Pump.....	24
1.4 Outdoor Units - Heat Pump.....	35

1. Specifications

1.1 Indoor Units - Cooling Only

Wall Mounted Type

50Hz 230V

Model			FTKS20D3VMW	FTKS20D3VML
Rated Capacity			2.0kW Class	2.0kW Class
Front Panel Color			White	Silver Line
Air Flow Rates	m ³ /min (cfm)	H	8.7 (307)	8.7 (307)
		M	6.7 (237)	6.7 (237)
		L	4.7 (166)	4.7 (166)
		SL	3.9 (138)	3.9 (138)
Fan	Type	Cross Flow Fan		Cross Flow Fan
	Motor Output	W	40	40
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.16	0.16
Power Consumption (Rated)		W	35	35
Power Factor		%	95.1	95.1
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	283x800x195	283x800x195
Packaged Dimensions (HxWxD)		mm	265x855x340	265x855x340
Weight		kg	9	9
Gross Weight		kg	12	12
Operation Sound	H/L/SL	dBA	38/25/22	38/25/22
Sound Power	H	dBA	56	56
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D051079	3D051080

Model			FTKS25D3VMW	FTKS25D3VML
Rated Capacity			2.5kW Class	2.5kW Class
Front Panel Color			White	Silver Line
Air Flow Rates	m ³ /min (cfm)	H	8.7 (307)	8.7 (307)
		M	6.7 (237)	6.7 (237)
		L	4.7 (166)	4.7 (166)
		SL	3.9 (138)	3.9 (138)
Fan	Type	Cross Flow Fan		Cross Flow Fan
	Motor Output	W	40	40
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.16	0.16
Power Consumption (Rated)		W	35	35
Power Factor		%	95.1	95.1
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	283x800x195	283x800x195
Packaged Dimensions (HxWxD)		mm	265x855x340	265x855x340
Weight		kg	9	9
Gross Weight		kg	12	12
Operation Sound	H/L/SL	dBA	38/25/22	38/25/22
Sound Power	H	dBA	56	56
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D051081	3D051082

Conversion Formulae

kcal/h=kW×860
 Btu/h=kW×3414
 cfm=m³/min×35.3

50Hz 230V

Model			FTKS35D3VMW	FTKS35D3VML
Rated Capacity			3.5kW Class	3.5kW Class
Front Panel Color			White	Silver Line
Air Flow Rates	m ³ /min (cfm)	H	8.9 (314)	8.9 (314)
		M	6.9 (244)	6.9 (244)
		L	4.8 (169)	4.8 (169)
		SL	4.0 (141)	4.0 (141)
Fan	Type	Cross Flow Fan		Cross Flow Fan
	Motor Output	W	40	40
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.18	0.18
Power Consumption (Rated)		W	40	40
Power Factor		%	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	283x800x195	283x800x195
Packaged Dimensions (HxWxD)		mm	265x855x340	265x855x340
Weight		kg	9	9
Gross Weight		kg	12	12
Operation Sound	H/L/SL	dBA	39/26/23	39/26/23
Sound Power	H	dBA	57	57
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D051083	3D051084

Model			FTKS50D2V1W	FTKS50D2V1L
Rated Capacity			5.0kW Class	5.0kW Class
Front Panel Color			White	Silver Line
Air Flow Rates	m ³ /min (cfm)	H	11.4 (402)	11.4 (402)
		M	9.3 (328)	9.3 (328)
		L	7.1 (251)	7.1 (251)
		SL	6.2 (219)	6.2 (219)
Fan	Type	Cross Flow Fan		Cross Flow Fan
	Motor Output	W	40	40
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.21	0.21
Power Consumption (Rated)		W	48	48
Power Factor		%	99.4	99.4
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	283x800x195	283x800x195
Packaged Dimensions (HxWxD)		mm	265x855x340	265x855x340
Weight		kg	9	9
Gross Weight		kg	12	12
Operation Sound	H/M/L/SL	dBA	46/41/35/32	46/41/35/32
Sound Power	H	dBA	62	62
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ12.7	φ12.7
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D051812	3D051813

Conversion Formulae

kcal/h=kWx860
 Btu/h=kWx3414
 cfm=m³/minx35.3

50Hz 230V

Model			FTKS20CAVMB	FTKS25CAVMB
Rated Capacity			2.0kW Class	2.5kW Class
Front Panel Color			White	White
Air Flow Rates	m ³ /min (cfm)	H	7.7 (272)	7.7 (272)
		M	5.9 (208)	5.9 (208)
		L	4.2 (148)	4.2 (148)
		SL	3.6 (127)	3.6 (127)
Fan	Type	Cross Flow Fan		Cross Flow Fan
	Motor Output	W	18	18
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.18	0.18
Power Consumption (Rated)		W	40	40
Power Factor		%	96.6	96.6
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	273x784x195	273x784x195
Packaged Dimensions (HxWxD)		mm	258x834x325	258x834x325
Weight		kg	7.5	7.5
Gross Weight		kg	11	11
Operation Sound	H/M/L/SL	dBA	38/32/25/22	38/32/25/22
Sound Power	H	dBA	56	56
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D050947	3D050949

Model			FTKS35CAVMB	FTKS50FV1B
Rated Capacity			3.5kW Class	5.0kW Class
Front Panel Color			White	White
Air Flow Rates	m ³ /min (cfm)	H	7.7 (272)	14.7 (519)
		M	6.0 (212)	12.4 (438)
		L	4.4 (155)	10.3 (364)
		SL	3.8 (134)	9.5 (335)
Fan	Type	Cross Flow Fan		Cross Flow Fan
	Motor Output	W	18	43
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.18	0.15
Power Consumption (Rated)		W	40	34
Power Factor		%	96.6	98.6
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	273x784x195	290x1,050x238
Packaged Dimensions (HxWxD)		mm	258x834x325	337x1,147x366
Weight		kg	7.5	12
Gross Weight		kg	11	17
Operation Sound	H/M/L/SL	dBA	39/33/26/23	43/39/34/31
Sound Power	H	dBA	57	59
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ12.7
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D050951	3D056016

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

50Hz 230V

Model			FTKS60FV1B	FTKS71FV1B
Rated Capacity			6.0kW Class	7.1kW Class
Front Panel Color			White	White
Air Flow Rates	m ³ /min (cfm)	H	16.2 (572)	17.4 (614)
		M	13.6 (480)	14.6 (516)
		L	11.4 (403)	11.6 (410)
		SL	10.2 (360)	10.6 (374)
Fan	Type		Cross Flow Fan	Cross Flow Fan
	Motor Output	W	43	43
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.18	0.20
Power Consumption (Rated)		W	40	45
Power Factor		%	96.6	97.8
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	290x1,050x238	290x1,050x238
Packaged Dimensions (HxWxD)		mm	337x1,147x366	337x1,147x366
Weight		kg	12	12
Gross Weight		kg	17	17
Operation Sound	H/M/L/SL	dBA	45/41/36/33	46/42/37/34
Sound Power	H	dBA	61	62
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 12.7	φ 15.9
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D056017	3D056018

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

Duct Connected Type

50Hz 230V

Model			FDKS25CAVMB	FDKS35CAVMB
Rated Capacity			2.5kW Class	3.5kW Class
Front Panel Color			—	—
Air Flow Rates	m ³ /min (cfm)	H	9.5 (335)	10.0 (353)
		M	8.8 (311)	9.3 (328)
		L	8.0 (282)	8.5 (300)
		SL	6.7 (237)	7.0 (247)
Fan	Type	Sirocco Fan		Sirocco Fan
	Motor Output	W	62	62
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.47	0.47
Power Consumption (Rated)		W	100	100
Power Factor		%	92.5	92.5
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	200x900x620	200x900x620
Packaged Dimensions (HxWxD)		mm	266x1,106x751	266x1,106x751
Weight		kg	25	25
Gross Weight		kg	31	31
Operation Sound	H/M/L/SL	dBA	35/33/31/29	35/33/31/29
External Static Pressure		Pa	40	40
Moisture Removal		L/h	1.2	1.9
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	VP20 (O.D. φ26 / I.D. φ20)	VP20 (O.D. φ26 / I.D. φ20)
Drawing No.			3D048947C	3D048948C

Model			FDKS50CVMB	FDKS60CVMB
Rated Capacity			5.0kW Class	6.0kW Class
Front Panel Color			—	—
Air Flow Rates	m ³ /min (cfm)	H	12.0 (424)	16.0 (565)
		M	11.0 (388)	14.8 (523)
		L	10.0 (353)	13.5 (477)
		SL	8.4 (297)	11.2 (395)
Fan	Type	Sirocco Fan		Sirocco Fan
	Motor Output	W	130	130
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.64	0.74
Power Consumption (Rated)		W	140	160
Power Factor		%	95.1	94.0
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	200x900x620	200x1,100x620
Packaged Dimensions (HxWxD)		mm	266x1,106x751	266x1,306x751
Weight		kg	27	30
Gross Weight		kg	34	37
Operation Sound	H/M/L/SL	dBA	37/35/33/31	38/36/34/32
External Static Pressure		Pa	40	40
Moisture Removal		L/h	2.9	3.9
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ12.7	φ12.7
	Drain	mm	VP20 (O.D. φ26 / I.D. φ20)	VP20 (O.D. φ26 / I.D. φ20)
Drawing No.			3D052134A	3D052135

Note: 1. The operating sound is based on the rear side suction inlet and the external static pressure 40 Pa. Operating sound for under side suction inlet: [operating sound for rear side suction inlet]+5 dB. However, when installation to which the external static pressure becomes low is carried out, 5 dB or more may go up.

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

50Hz 230V

Model			FDKS25EAVMB	FDKS35EAVMB
Rated Capacity			2.5kW Class	3.5kW Class
Front Panel Color			—	—
Air Flow Rates	m ³ /min (cfm)	H	8.7 (307)	8.7 (307)
		M	8.0 (282)	8.0 (282)
		L	7.3 (258)	7.3 (258)
		SL	6.2 (219)	6.2 (219)
Fan	Type		Sirocco Fan	Sirocco Fan
	Motor Output	W	62	62
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.48	0.48
Power Consumption (Rated)		W	71	71
Power Factor		%	64.3	64.3
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	200x700x620	200x700x620
Packaged Dimensions (HxWxD)		mm	274x906x751	274x906x751
Weight		kg	21	21
Gross Weight		kg	29	29
Operation Sound	H/M/L/SL	dBA	35/33/31/29	35/33/31/29
External Static Pressure		Pa	30	30
Moisture Removal		L/h	1.2	1.9
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	VP20 (O.D.φ 26 / I.D.φ 20)	VP20 (O.D.φ 26 / I.D.φ 20)
Drawing No.			3D051882A	3D051884A

- Note:** 1. The operating sound is based on the rear side suction inlet and the external static pressure 30 Pa. Operating sound for under side suction inlet: [operating sound for rear side suction inlet]+6 dB. However, when installation to which the external static pressure becomes low is carried out, 6 dB or more may go up.

Conversion Formulae

kcal/h=kWx860
 Btu/h=kWx3414
 cfm=m³/minx35.3

Floor / Ceiling Suspended Dual Type

50Hz 230V

Model			FLKS25BAVMB	FLKS35BAVMB
Rated Capacity			2.5kW Class	3.5kW Class
Front Panel Color			Almond White	Almond White
Air Flow Rates	m ³ /min (cfm)	H	7.6 (268)	8.6 (304)
		M	6.8 (240)	7.6 (268)
		L	6.0 (212)	6.6 (233)
		SL	5.2 (184)	5.6 (198)
Fan	Type	Sirocco Fan		Sirocco Fan
	Motor Output	W	34	34
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.34	0.36
Power Consumption (Rated)		W	74	78
Power Factor		%	94.6	94.2
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	490x1,050x200	490x1,050x200
Packaged Dimensions (HxWxD)		mm	566x1,100x280	566x1,100x280
Weight		kg	16	16
Gross Weight		kg	22	22
Operation Sound	H/M/L/SL	dBA	37/34/31/28	38/35/32/29
Sound Power	H	dBA	53	54
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D050862	3D050864

Model			FLKS50BAVMB	FLKS60BAVMB
Rated Capacity			5.0W Class	6.0kW Class
Front Panel Color			Almond White	Almond White
Air Flow Rates	m ³ /min (cfm)	H	11.4 (402)	12.0 (424)
		M	10.0 (353)	10.7 (378)
		L	8.5 (300)	9.3 (328)
		SL	7.5 (265)	8.3 (293)
Fan	Type	Sirocco Fan		Sirocco Fan
	Motor Output	W	34	34
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.45	0.45
Power Consumption (Rated)		W	96	98
Power Factor		%	92.8	94.7
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	490x1,050x200	490x1,050x200
Packaged Dimensions (HxWxD)		mm	280x1,100x566	280x1,100x566
Weight		kg	17	17
Gross Weight		kg	24	24
Operation Sound	H/M/L/SL	dBA	47/43/39/36	48/45/41/39
Sound Power	H	dBA	63	64
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ12.7	φ12.7
	Drain	mm	φ18.0	φ18.0
Drawing No.			3D050896	3D050881

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

Floor Standing Type

50Hz 230V

Model			FVXS25FV1B	FVXS35FV1B
Rated Capacity			2.5kW Class	3.5kW Class
Front Panel Color			White	White
Air Flow Rates	m ³ /min (cfm)	H	8.2 (290)	8.5 (300)
		M	6.5 (229)	6.7 (237)
		L	4.8 (169)	4.9 (174)
		SL	4.1 (146)	4.5 (158)
Fan	Type	Turbo Fan		Turbo Fan
	Motor Output	W	48	48
	Speed	Steps	5 Steps, Quiet, Auto	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.13	0.13
Power Consumption (Rated)		W	15	15
Power Factor		%	50.2	50.2
Temperature Control			Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	600x700x210	600x700x210
Packaged Dimensions (HxWxD)		mm	696x786x286	696x786x286
Weight		kg	14	14
Gross Weight		kg	18	18
Operation Sound	H/M/L/SL	dBA	38/32/26/23	39/33/27/24
Sound Power	H	dBA	54	55
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4	φ 6.4
	Gas	mm	φ 9.5	φ 9.5
	Drain	mm	φ 20	φ 20
Drawing No.			3D056295	3D056296

Model			FVXS50FV1B
Rated Capacity			5.0kW Class
Front Panel Color			White
Air Flow Rates	m ³ /min (cfm)	H	10.7 (378)
		M	9.2 (326)
		L	7.8 (274)
		SL	6.6 (233)
Fan	Type	Turbo Fan	
	Motor Output	W	48
	Speed	Steps	5 Steps, Quiet, Auto
Air Direction Control			Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof
Running Current (Rated)		A	0.17
Power Consumption (Rated)		W	27
Power Factor		%	69.1
Temperature Control			Microcomputer Control
Dimensions (HxWxD)		mm	600x700x210
Packaged Dimensions (HxWxD)		mm	696x786x286
Weight		kg	14
Gross Weight		kg	18
Operation Sound	H/M/L/SL	dBA	44/40/36/32
Sound Power	H	dBA	56
Heat Insulation			Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4
	Gas	mm	φ 12.7
	Drain	mm	φ 20.0
Drawing No.			3D056297

Conversion Formulae

kcal/h=kWx860
 Btu/h=kWx3414
 cfm=m³/minx35.3

Ceiling-suspended Type

50Hz 230V

Model			FHQ35BVV1B	FHQ50BVV1B	FHQ60BVV1B
Rated Capacity			3.5kW Class	5.0kW Class	6.0kW Class
Decoration Panel	Color		White	White	White
	Dimensions (HxWxD)		—	—	—
Air Flow Rates	m ³ /min (cfm)	H	13.0 (458)	13.0 (458)	17.0 (600)
		M	—	—	—
		L	10.0 (353)	10.0 (353)	13.0 (459)
		SL	—	—	—
Fan	Type		Sirocco Fan	Sirocco Fan	Sirocco Fan
	Motor Output	W	62	62	62
	Speed	Steps	2 Steps	2 Steps	2 Steps
Air Direction Control			Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward	Right, Left, Horizontal, Downward
Air Filter			Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof	Removable-Washable-Mildew Proof
Temperature Control			Microcomputer Control	Microcomputer Control	Microcomputer Control
Dimensions (HxWxD)		mm	195x960x680	195x960x680	195x1,160x680
Packaged Dimensions (HxWxD)		mm	279x1,046x818	279x1,046x818	279x1,246x818
Weight		kg	24	25	27
Gross Weight		kg	31	32	35
Operation Sound	H/L	dBA	37/32	38/33	39/33
	Sound Power	H/L	dBA	53/48	54/49
Heat Insulation			Both Liquid and Gas Pipes	Both Liquid and Gas Pipes	Both Liquid and Gas Pipes
Piping Connection	Liquid	mm	φ 6.4 (Flare)	φ 6.4 (Flare)	φ 6.4 (Flare)
	Gas	mm	φ 9.5 (Flare)	φ12.7 (Flare)	φ12.7 (Flare)
	Drain	mm	VP20 (O.D.φ 26 / I.D.φ 20)	VP20 (O.D.φ 26 / I.D.φ 20)	VP20 (O.D.φ 26 / I.D.φ 20)
Drawing No.			3D037992E	3D037992E	3D037992E

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

1.2 Outdoor Units - Cooling Only

50Hz 230V

Model		4MKS75F2V1B	
Cooling Capacity	kW	—	
Power Consumption	W	—	
Running Current	A	—	
Casing Color	Ivory White		
Compressor	Type	Hermetically Sealed Swing Type	
	Model	2YC45DXD	
	Motor Output	W	1,380
Refrigerant Oil	Model	FVC50K	
	Charge	L	0.65
Refrigerant	Type	R-410A	
	Charge	kg	2.3
Air Flow Rates	m ³ /min	H	52.7
		M	49.4
		L	43.5
	cfm	H	1,861
		M	1,744
		L	1,536
Fan	Type	Propeller	
	Motor Output	W	53
	Running Current	A	H: 0.20 / M: 0.16 / L: 0.10
	Power Consumption	W	H: 70 / M: 58 / L: 36
Starting Current	A	6.2	
Dimensions (HxWxD)	mm	735x936x300	
Packaged Dimensions (HxWxD)	mm	797x992x390	
Weight	kg	57	
Gross Weight	kg	61	
Operation Sound	dBA	48	
Sound Power	dBA	61	
Piping Connection	Liquid	mm	φ 6.4×4
	Gas	mm	φ 9.5×2, φ 12.7×1, φ 15.9×1
	Drain	mm	φ 18.0
Heat Insulation	Both Liquid and Gas Pipes		
No. of Wiring Connection	3 for Power Supply, 4 for Interunit Wiring		
Max. Interunit Piping Length	m	60 (for Total of Each Room)	
	m	25 (for One Room)	
Amount of Additional Charge	g/m	Chargeless	
Max. Installation Height Difference	m	15 (between Indoor Unit and Outdoor Unit)	
	m	15 (between Indoor Units)	
Drawing No.	3D056453		

Note: 1. The data are based on the conditions shown in the table below.

Cooling	Piping Length
Indoor : 27°CDB/19°CWB Outdoor : 35°CDB	5m

Conversion Formulae

kcal/h=kW×860
Btu/h=kW×3414
cfm=m³/min×35.3

1.3 Indoor Units - Heat Pump

Wall Mounted Type

50Hz 230V

Model			FTXG25EV1BW		FTXG25EV1BS	
			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5kW Class		2.5kW Class	
Front Panel Color			Mat Crystal White		Mat Crystal Silver	
Air Flow Rates	m ³ /min (cfm)	H	7.7 (271)	9.0 (317)	7.7 (271)	9.0 (317)
		M	6.1 (215)	7.9 (278)	6.1 (215)	7.9 (278)
		L	4.7 (165)	6.7 (236)	4.7 (165)	6.7 (236)
		SL	3.8 (134)	5.4 (190)	3.8 (134)	5.4 (190)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.15-0.14-0.13	0.15-0.14-0.13	0.15-0.14-0.13	0.15-0.14-0.13
Power Consumption (Rated)		W	30-30-30	30-30-30	30-30-30	30-30-30
Power Factor		%	90.9-93.2-96.2	90.9-93.2-96.2	90.9-93.2-96.2	90.9-93.2-96.2
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	275x840x150		275x840x150	
Packaged Dimensions (HxWxD)		mm	222x894x345		222x894x345	
Weight		kg	9		9	
Gross Weight		kg	13		13	
Operation Sound	H/M/L/SL	dBA	38/32/25/22	38/33/28/25	38/32/25/22	38/33/28/25
Sound Power	H	dBA	56	56	56	56
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D051101		3D051102	

Model			FTXG35EV1BW		FTXG35EV1BS	
			Cooling	Heating	Cooling	Heating
Rated Capacity			3.5kW Class		5.0kW Class	
Front Panel Color			Mat Crystal White		Mat Crystal Silver	
Air Flow Rates	m ³ /min (cfm)	H	8.1 (285)	9.6 (338)	8.1 (285)	9.6 (338)
		M	6.5 (229)	8.2 (289)	6.5 (229)	8.2 (289)
		L	4.9 (173)	6.7 (236)	4.9 (173)	6.7 (236)
		SL	4.1 (144)	5.9 (208)	4.1 (144)	5.9 (208)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.15-0.14-0.13	0.15-0.14-0.13	0.15-0.14-0.13	0.15-0.14-0.13
Power Consumption (Rated)		W	30-30-30	30-30-30	30-30-30	30-30-30
Power Factor		%	90.9-93.2-96.2	90.9-93.2-96.2	90.9-93.2-96.2	90.9-93.2-96.2
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	275x840x150		275x840x150	
Packaged Dimensions (HxWxD)		mm	222x894x345		222x894x345	
Weight		kg	9		9	
Gross Weight		kg	13		13	
Operation Sound	H/M/L/SL	dBA	39/33/26/23	39/34/29/26	39/33/26/23	39/34/29/26
Sound Power	H	dBA	57	57	57	57
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ12.7	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D051103		3D051104	

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

50Hz 230V

Model			CTXG50EV1BW		CTXG50EV1BS	
			Cooling	Heating	Cooling	Heating
Rated Capacity			5.0kW Class		5.0kW Class	
Front Panel Color			Mat Crystal White		Mat Crystal Silver	
Air Flow Rates	m ³ /min (cfm)	H	11.3 (398)	12.6 (444)	11.3 (398)	12.6 (444)
		M	9.1 (320)	10.6 (373)	9.1 (320)	10.6 (373)
		L	7.1 (250)	8.7 (306)	7.1 (250)	8.7 (306)
		SL	6.7 (236)	7.7 (271)	6.7 (236)	7.7 (271)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.15-0.14-0.13	0.15-0.14-0.13	0.15-0.14-0.13	0.15-0.14-0.13
Power Consumption (Rated)		W	30	30	30	30
Power Factor		%	90.9-93.2-96.2	90.9-93.2-96.2	90.9-93.2-96.2	90.9-93.2-96.2
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	275x840x150		275x840x150	
Packaged Dimensions (HxWxD)		mm	222x894x345		222x894x345	
Weight		kg	9		9	
Gross Weight		kg	13		13	
Operation Sound	H/M/L/SL	dBA	47/41/35/32	47/41/35/32	47/41/35/32	47/41/35/32
Sound Power	H	dBA	64	64	64	64
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 12.7		φ 12.7	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D051105		3D051106	

Model			FTXS20D3VMW		FTXS20D3VML	
			Cooling	Heating	Cooling	Heating
Rated Capacity			2.0kW Class		2.0kW Class	
Front Panel Color			White		Silver Line	
Air Flow Rates	m ³ /min (cfm)	H	8.7 (307)	9.4 (332)	8.7 (307)	9.4 (332)
		M	6.7 (237)	7.6 (268)	6.7 (237)	7.6 (268)
		L	4.7 (166)	5.8 (205)	4.7 (166)	5.8 (205)
		SL	3.9 (138)	5.0 (177)	3.9 (138)	5.0 (177)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.16	0.16	0.16	0.16
Power Consumption (Rated)		W	35	35	35	35
Power Factor		%	95.1	95.1	95.1	95.1
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	283x800x195		283x800x195	
Packaged Dimensions (HxWxD)		mm	265x855x340		265x855x340	
Weight		kg	9		9	
Gross Weight		kg	12		12	
Operation Sound	H/L/SL	dBA	38/25/22	38/28/25	38/25/22	38/28/25
Sound Power	H	dBA	56	56	56	56
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D051085		3D051086	

Conversion Formulae
kcal/h=kW×860
Btu/h=kW×3414
cfm=m ³ /min×35.3

50Hz 230V

Model			FTXS25D3VMW		FTXS25D3VML	
			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5kW Class		2.5kW Class	
Front Panel Color			White		Silver Line	
Air Flow Rates	m ³ /min (cfm)	H	8.7 (307)	9.4 (332)	8.7 (307)	9.4 (332)
		M	6.7 (237)	7.6 (268)	6.7 (237)	7.6 (268)
		L	4.7 (166)	5.8 (205)	4.7 (166)	5.8 (205)
		SL	3.9 (138)	5.0 (177)	3.9 (138)	5.0 (177)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.16	0.16	0.16	0.16
Power Consumption (Rated)		W	35	35	35	35
Power Factor		%	95.1	95.1	95.1	95.1
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	283x800x195		283x800x195	
Packaged Dimensions (HxWxD)		mm	265x855x340		265x855x340	
Weight		kg	9		9	
Gross Weight		kg	12		12	
Operation Sound	H/L/SL	dBA	38/25/22	38/28/25	38/25/22	38/28/25
Sound Power	H	dBA	56	56	56	56
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D051087		3D051088	

Model			FTXS35D3VMW		FTXS35D3VML	
			Cooling	Heating	Cooling	Heating
Rated Capacity			3.5kW Class		3.5kW Class	
Front Panel Color			White		Silver Line	
Air Flow Rates	m ³ /min (cfm)	H	8.9 (314)	9.7 (342)	8.9 (314)	9.7 (342)
		M	6.9 (244)	7.9 (279)	6.9 (244)	7.9 (279)
		L	4.8 (169)	6.0 (212)	4.8 (169)	6.0 (212)
		SL	4.0 (141)	5.2 (184)	4.0 (141)	5.2 (184)
Fan	Type	Cross Flow Fan		Cross Flow Fan		
	Motor Output	W	40		40	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.18	0.18	0.18	0.18
Power Consumption (Rated)		W	40	40	40	40
Power Factor		%	96.6	96.6	96.6	96.6
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	283x800x195		283x800x195	
Packaged Dimensions (HxWxD)		mm	265x855x340		265x855x340	
Weight		kg	9		9	
Gross Weight		kg	12		12	
Operation Sound	H/L/SL	dBA	39/26/23	39/29/26	39/26/23	39/29/26
Sound Power	H	dBA	57	57	57	57
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D051089		3D051090	

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

50Hz 230V

Model			FTXS50D2V1W				FTXS50D2V1L				
			Cooling		Heating		Cooling		Heating		
Rated Capacity			5.0kW Class				5.0kW Class				
Front Panel Color			White				White				
Air Flow Rates	m ³ /min (cfm)	H	11.4 (402)		11.4 (402)		11.4 (402)		11.4 (402)		
		M	9.3 (328)		9.4 (332)		9.3 (328)		9.4 (332)		
		L	7.1 (251)		7.4 (261)		7.1 (251)		7.4 (261)		
		SL	6.2 (219)		6.3 (222)		6.2 (219)		6.3 (222)		
Fan	Type	Cross Flow Fan				Cross Flow Fan					
	Motor Output	W	40				40				
	Speed	Steps	5 Steps, Quiet, Auto				5 Steps, Quiet, Auto				
Air Direction Control			Right, Left, Horizontal, Downward				Right, Left, Horizontal, Downward				
Air Filter			Removable-Washable-Mildew Proof				Removable-Washable-Mildew Proof				
Running Current (Rated)			A	0.21		0.21		0.21		0.21	
Power Consumption (Rated)			W	48		48		48		48	
Power Factor			%	99.4		99.4		99.4		99.4	
Temperature Control			Microcomputer Control				Microcomputer Control				
Dimensions (HxWxD)			mm	283x800x195				283x800x195			
Packaged Dimensions (HxWxD)			mm	265x855x340				265x855x340			
Weight			kg	9				9			
Gross Weight			kg	12				12			
Operation Sound	H/M/L/SL	dBA	46/41/35/32		46/40/34/31		46/41/35/32		46/40/34/31		
Sound Power	H	dBA	62		62		62		62		
Heat Insulation			Both Liquid and Gas Pipes				Both Liquid and Gas Pipes				
Piping Connection	Liquid	mm	φ 6.4				φ 6.4				
	Gas	mm	φ12.7				φ15.9				
	Drain	mm	φ18.0				φ18.0				
Drawing No.			3D051814				3D051815				

Model			FTXS20CAVMB				FTXS25CAVMB				
			Cooling		Heating		Cooling		Heating		
Rated Capacity			2.5kW Class				2.5kW Class				
Front Panel Color			White				White				
Air Flow Rates	m ³ /min (cfm)	H	7.7 (272)		7.8 (275)		7.7 (272)		7.8 (275)		
		M	5.9 (208)		6.5 (230)		5.9 (208)		6.5 (230)		
		L	4.2 (148)		5.3 (187)		4.2 (148)		5.3 (187)		
		SL	3.6 (127)		4.6 (162)		3.6 (127)		4.6 (162)		
Fan	Type	Cross Flow Fan				Cross Flow Fan					
	Motor Output	W	18				18				
	Speed	Steps	5 Steps, Quiet, Auto				5 Steps, Quiet, Auto				
Air Direction Control			Right, Left, Horizontal, Downward				Right, Left, Horizontal, Downward				
Air Filter			Removable-Washable-Mildew Proof				Removable-Washable-Mildew Proof				
Running Current (Rated)			A	0.18		0.18		0.18		0.18	
Power Consumption (Rated)			W	40		40		40		40	
Power Factor			%	96.6		96.6		96.6		96.6	
Temperature Control			Microcomputer Control				Microcomputer Control				
Dimensions (HxWxD)			mm	273x784x195				273x784x195			
Packaged Dimensions (HxWxD)			mm	258x834x325				258x834x325			
Weight			kg	7.5				7.5			
Gross Weight			kg	11				11			
Operation Sound	H/M/L/SL	dBA	38/32/25/22		38/33/28/25		38/32/25/22		38/33/28/25		
Sound Power	H	dBA	56		56		56		56		
Heat Insulation			Both Liquid and Gas Pipes				Both Liquid and Gas Pipes				
Piping Connection	Liquid	mm	φ 6.4				φ 6.4				
	Gas	mm	φ 9.5				φ 9.5				
	Drain	mm	φ18.0				φ18.0				
Drawing No.			3D050941				3D050943				

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

50Hz 230V

Model			FTXS35CAVMB			
			Cooling		Heating	
Rated Capacity			3.5kW Class			
Front Panel Color			White			
Air Flow Rates	m³/min (cfm)	H	7.7 (272)		8.1 (286)	
		M	6.0 (212)		6.7 (237)	
		L	4.4 (155)		5.3 (187)	
		SL	3.8 (134)		4.6 (162)	
Fan	Type	Cross Flow Fan				
	Motor Output	W	18			
	Speed	Steps	5 Steps, Quiet, Auto			
Air Direction Control			Right, Left, Horizontal, Downward			
Air Filter			Removable-Washable-Mildew Proof			
Running Current (Rated)		A	0.18		0.18	
Power Consumption (Rated)		W	40		40	
Power Factor		%	96.6		96.6	
Temperature Control			Microcomputer Control			
Dimensions (HxWxD)		mm	273x784x195			
Packaged Dimensions (HxWxD)		mm	258x834x325			
Weight		kg	7.5			
Gross Weight		kg	11			
Operation Sound	H/M/L/SL	dBA	39/33/26/23		39/34/29/26	
Sound Power	H	dBA	57		57	
Heat Insulation			Both Liquid and Gas Pipes			
Piping Connection	Liquid	mm	φ 6.4			
	Gas	mm	φ 9.5			
	Drain	mm	φ18.0			
Drawing No.			3D050945			

Model			FTXS50FV1B				FTXS60FV1B			
			Cooling		Heating		Cooling		Heating	
Rated Capacity			5.0kW Class				6.0kW Class			
Front Panel Color			White				White			
Air Flow Rates	m³/min (cfm)	H	14.7 (519)		16.1 (569)		16.2 (572)		17.4 (614)	
		M	12.4 (438)		13.9 (491)		13.6 (480)		15.1 (533)	
		L	10.3 (364)		11.5 (406)		11.4 (403)		12.7 (448)	
		SL	9.5 (335)		10.2 (360)		10.2 (360)		11.4 (403)	
Fan	Type	Cross Flow Fan				Cross Flow Fan				
	Motor Output	W	43			43				
	Speed	Steps	5 Steps, Quiet, Auto			5 Steps, Quiet, Auto				
Air Direction Control			Right, Left, Horizontal, Downward				Right, Left, Horizontal, Downward			
Air Filter			Removable-Washable-Mildew Proof				Removable-Washable-Mildew Proof			
Running Current (Rated)		A	0.15		0.16		0.18		0.20	
Power Consumption (Rated)		W	34		36		40		45	
Power Factor		%	98.6		97.8		96.6		97.8	
Temperature Control			Microcomputer Control				Microcomputer Control			
Dimensions (HxWxD)		mm	290x1,050x238				290x1,050x238			
Packaged Dimensions (HxWxD)		mm	337x1,147x366				337x1,147x366			
Weight		kg	12				12			
Gross Weight		kg	17				17			
Operation Sound	H/M/L/SL	dBA	43/39/34/31		42/38/33/30		45/41/36/33		44/40/35/32	
Sound Power	H	dBA	59		58		61		60	
Heat Insulation			Both Liquid and Gas Pipes				Both Liquid and Gas Pipes			
Piping Connection	Liquid	mm	φ 6.4				φ 6.4			
	Gas	mm	φ12.7				φ12.7			
	Drain	mm	φ18.0				φ18.0			
Drawing No.			3D056019				3D056020			

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m³/minx35.3

50Hz 230V

Model			FTXS71FV1B	
			Cooling	Heating
Rated Capacity			7.1kW Class	
Front Panel Color			White	
Air Flow Rates	m ³ /min (cfm)	H	17.4 (614)	19.7 (696)
		M	14.6 (516)	16.9 (597)
		L	11.6 (410)	14.3 (505)
		SL	10.6 (374)	12.7 (448)
Fan	Type	Cross Flow Fan		
	Motor Output	43		
	Speed	5 Steps, Quiet, Auto		
Air Direction Control			Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.20	0.27
Power Consumption (Rated)		W	45	60
Power Factor		%	97.8	96.6
Temperature Control			Microcomputer Control	
Dimensions (HxWxD)		mm	290x1,050x238	
Packaged Dimensions (HxWxD)		mm	337x1,147x366	
Weight		kg	12	
Gross Weight		kg	17	
Operation Sound	H/M/L/SL	dBA	46/42/37/34	46/42/37/34
Sound Power	H	dBA	62	62
Heat Insulation			Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4	
	Gas	mm	φ15.9	
	Drain	mm	φ18.0	
Drawing No.			3D056021	

Conversion Formulae

kcal/h=kWx860
 Btu/h=kWx3414
 cfm=m³/minx35.3

Duct Connected Type

50Hz 230V

Model			FDXS25CAVMB		FDXS35CAVMB	
			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5kW Class		3.5kW Class	
Front Panel Color			—		—	
Air Flow Rates	m ³ /min (cfm)	H	9.5 (335)	9.5 (335)	10.0 (353)	10.0 (353)
		M	8.8 (311)	8.8 (311)	9.3 (328)	9.3 (328)
		L	8.0 (282)	8.0 (282)	8.5 (300)	8.5 (300)
		SL	6.7 (237)	6.7 (237)	7.0 (247)	7.0 (247)
Fan	Type	Sirocco Fan		Sirocco Fan		
	Motor Output	W	62		62	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.47	0.47	0.47	0.47
Power Consumption (Rated)		W	100	100	100	100
Power Factor		%	92.5	92.5	92.5	92.5
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	200x900x620		200x900x620	
Packaged Dimensions (HxWxD)		mm	266x1,106x751		266x1,106x751	
Weight		kg	25		25	
Gross Weight		kg	31		31	
Operation Sound	H/M/L/SL	dBA	35/33/31/29	35/33/31/29	35/33/31/29	35/33/31/29
External Static Pressure		Pa	40		40	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)		VP20 (O.D. φ 26 / I.D. φ 20)	
Drawing No.			3D048945C		3D048946C	

Model			FDXS50CVMB		FDXS60CVMB	
			Cooling	Heating	Cooling	Heating
Rated Capacity			5.0kW Class		6.0kW Class	
Front Panel Color			—		—	
Air Flow Rates	m ³ /min (cfm)	H	12.0 (424)	12.0 (424)	16.0 (565)	16.0 (565)
		M	11.0 (388)	11.0 (388)	14.8 (523)	14.8 (523)
		L	10.0 (353)	10.0 (353)	13.5 (477)	13.5 (477)
		SL	8.4 (297)	8.4 (297)	11.2 (395)	11.2 (395)
Fan	Type	Sirocco Fan		Sirocco Fan		
	Motor Output	W	130		130	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.64	0.64	0.74	0.74
Power Consumption (Rated)		W	140	140	160	160
Power Factor		%	95.1	95.1	94.0	94.0
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	200x900x620		200x1,100x620	
Packaged Dimensions (HxWxD)		mm	266x1,106x751		266x1,306x751	
Weight		kg	27		30	
Gross Weight		kg	34		37	
Operation Sound	H/M/L/SL	dBA	37/35/33/31	37/35/33/31	38/36/34/32	38/36/34/32
External Static Pressure		Pa	40		40	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 12.7		φ 12.7	
	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)		VP20 (O.D. φ 26 / I.D. φ 20)	
Drawing No.			3D052132		3D052133	

Note: 1. The operating sound is based on the rear side suction inlet and the external static pressure 40 Pa. Operating sound for under side suction inlet : [operating sound for rear side suction inlet] +5 dB. However, when installation to which the external static pressure becomes low is carried out, 5 dB or more may go up.

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

50Hz 230V

Model			FDXS25EAVMB		FDXS35EAVMB	
			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5kW Class		3.5kW Class	
Front Panel Color			—		—	
Air Flow Rates	m ³ /min (cfm)	H	8.7 (307)	8.7 (307)	8.7 (307)	8.7 (307)
		M	8.0 (282)	8.0 (282)	8.0 (282)	8.0 (282)
		L	7.3 (258)	7.3 (258)	7.3 (258)	7.3 (258)
		SL	6.2 (219)	6.2 (219)	6.2 (219)	6.2 (219)
Fan	Type	Sirocco Fan		Sirocco Fan		
	Motor Output	W	62		62	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.48	0.48	0.48	0.48
Power Consumption (Rated)		W	71	71	71	71
Power Factor		%	64.3	64.3	64.3	64.3
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	200x700x620		200x700x620	
Packaged Dimensions (HxWxD)		mm	274x906x751		274x906x751	
Weight		kg	21		21	
Gross Weight		kg	29		29	
Operation Sound	H/M/L/SL	dBA	35/33/31/29	35/33/31/29	35/33/31/29	35/33/31/29
External Static Pressure		Pa	30		30	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	VP20 (O.D. φ 26 / I.D. φ 20)		VP20 (O.D. φ 26 / I.D. φ 20)	
Drawing No.			3D051881A		3D051883A	

- Note:**
- The operating sound is based on the rear side suction inlet and the external static pressure 30 Pa. Operating sound for under side suction inlet : [operating sound for rear side suction inlet] +6 dB. However, when installation to which the external static pressure becomes low is carried out, 6 dB or more may go up.

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

Floor / Ceiling Suspended Dual Type

50Hz 230V

Model			FLXS25BAVMB		FLXS35BAVMB	
			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5kW Class		3.5kW Class	
Front Panel Color			Almond White		Almond White	
Air Flow Rates	m ³ /min (cfm)	H	7.6 (268)	9.2 (325)	8.6 (304)	9.8 (346)
		M	6.8 (240)	8.3 (293)	7.6 (268)	8.9 (314)
		L	6.0 (212)	7.4 (261)	6.6 (233)	8.0 (282)
		SL	5.2 (184)	6.6 (233)	5.6 (198)	7.2 (254)
Fan	Type	Sirocco Fan		Sirocco Fan		
	Motor Output	W	34		34	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.32	0.34	0.36	0.36
Power Consumption (Rated)		W	70	74	78	78
Power Factor		%	95.1	94.6	94.2	94.2
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	490x1,050x200		490x1,050x200	
Packaged Dimensions (HxWxD)		mm	566x1,100x280		566x1,100x280	
Weight		kg	16		16	
Gross Weight		kg	22		22	
Operation Sound	H/M/L/SL	dBA	37/34/31/28	37/34/31/29	38/35/32/29	39/36/33/30
Sound Power	H	dBA	53	—	54	—
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D050866		3D050868	

Model			FLXS50BAVMB		FLXS60BAVMB	
			Cooling	Heating	Cooling	Heating
Rated Capacity			5.0kW Class		6.0kW Class	
Front Panel Color			Almond White		Almond White	
Air Flow Rates	m ³ /min (cfm)	H	11.4 (402)	12.1 (427)	12.0 (424)	12.8 (452)
		M	10.0 (353)	9.8 (346)	10.7 (378)	10.6 (374)
		L	8.5 (300)	7.5 (265)	9.3 (328)	8.4 (297)
		SL	7.5 (265)	6.8 (240)	8.3 (293)	7.5 (265)
Fan	Type	Sirocco Fan		Sirocco Fan		
	Motor Output	W	34		34	
	Speed	Steps	5 Steps, Quiet, Auto		5 Steps, Quiet, Auto	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Running Current (Rated)		A	0.45	0.45	0.47	0.45
Power Consumption (Rated)		W	96	96	98	96
Power Factor		%	92.8	92.8	90.7	92.8
Temperature Control			Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	490x1,050x200		490x1,050x200	
Packaged Dimensions (HxWxD)		mm	280x1,100x566		280x1,100x566	
Weight		kg	17		17	
Gross Weight		kg	24		24	
Operation Sound	H/M/L/SL	dBA	47/43/39/36	46/41/35/33	48/45/41/39	47/42/37/34
Sound Power	H	dBA	63	32	64	63
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ12.7		φ12.7	
	Drain	mm	φ18.0		φ18.0	
Drawing No.			3D050897		3D050882	

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

Floor Standing Type

50Hz 230V

Model			FVXS25FV1B		FVXS35FV1B	
			Cooling	Heating	Cooling	Heating
Rated Capacity			2.5kW Class		3.5kW Class	
Front Panel Color			White			
Air Flow Rates	m ³ /min (cfm)	H	8.2 (290)	8.8 (311)	8.5 (300)	9.4 (332)
		M	6.5 (229)	6.9 (244)	6.7 (237)	7.3 (258)
		L	4.8 (169)	5.0 (178)	4.9 (174)	5.2 (184)
		SL	4.1 (146)	4.4 (155)	4.5 (158)	4.7 (168)
Fan	Type	Turbo Fan				
	Motor Output	W	48			
	Speed	Steps	5 Steps, Quiet, Auto			
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof			
Running Current (Rated)		A	0.13	0.14	0.13	0.14
Power Consumption (Rated)		W	15	17	15	17
Power Factor		%	50.2	52.8	50.2	52.8
Temperature Control			Microcomputer Control			
Dimensions (HxWxD)		mm	600x700x210		600x700x210	
Packaged Dimensions (HxWxD)		mm	696x786x286			
Weight		kg	14			
Gross Weight		kg	18			
Operation Sound	H/M/L/SL	dBA	38/32/26/23	38/32/26/23	39/33/27/24	39/33/27/24
Sound Power	H	dBA	54	54	55	55
Heat Insulation			Both Liquid and Gas Pipes			
Piping Connection	Liquid	mm	φ 6.4		φ 6.4	
	Gas	mm	φ 9.5		φ 9.5	
	Drain	mm	φ 20.0		φ 20.0	
Drawing No.			3D056274		3D056275	

Model			FVXS50FV1B		
			Cooling	Heating	
Rated Capacity			5.0kW Class		
Front Panel Color			White		
Air Flow Rates	m ³ /min (cfm)	H	10.7 (378)	11.8 (417)	
		M	9.2 (326)	10.1 (358)	
		L	7.8 (274)	8.5 (300)	
		SL	6.6 (233)	7.1 (250)	
Fan	Type	Turbo Fan			
	Motor Output	W	48		
	Speed	Steps	5 Steps, Quiet, Auto		
Air Direction Control			Right, Left, Horizontal, Downward		
Air Filter			Removable-Washable-Mildew Proof		
Running Current (Rated)		A	0.17	0.19	
Power Consumption (Rated)		W	27	34	
Power Factor		%	69.1	77.8	
Temperature Control			Microcomputer Control		
Dimensions (HxWxD)		mm	600x700x210		
Packaged Dimensions (HxWxD)		mm	696x786x286		
Weight		kg	14		
Gross Weight		kg	18		
Operation Sound	H/M/L/SL	dBA	44/40/36/32	45/40/36/32	
Sound Power	H	dBA	56	57	
Heat Insulation			Both Liquid and Gas Pipes		
Piping Connection	Liquid	mm	φ 6.4		
	Gas	mm	φ 12.7		
	Drain	mm	φ 20.0		
Drawing No.			3D056276		

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

Ceiling-suspended Type

50Hz 230V

Model			FHQ35BVV1B		FHQ50BVV1B		FHQ60BVV1B	
			Cooling	Heating	Cooling	Heating	Cooling	Heating
Rated Capacity			3.5kW Class		5.0kW Class		6.0kW Class	
Decoration Panel	Color	White						
	Dimensions (HxWxD)	—						
Air Flow Rates	m ³ /min (cfm)	H	13.0 (458)	13.0 (458)	13.0 (458)	13.0 (458)	17.0 (600)	16.0 (565)
		M	—		—		—	
		L	10.0 (353)	10.0 (353)	10.0 (353)	10.0 (353)	13.0 (459)	13.0 (459)
		SL	—		—		—	
Fan	Type	Sirocco Fan						
	Motor Output	W	62		62		62	
	Speed	Steps	2 Steps		2 Steps		2 Steps	
Air Direction Control			Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward		Right, Left, Horizontal, Downward	
Air Filter			Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof		Removable-Washable-Mildew Proof	
Temperature Control			Microcomputer Control		Microcomputer Control		Microcomputer Control	
Dimensions (HxWxD)		mm	195x960x680		195x960x680		195x1,160x680	
Packaged Dimensions (HxWxD)		mm	279x1,046x818		279x1,046x818		279x1,246x818	
Weight		kg	24		25		27	
Gross Weight		kg	31		32		35	
Operation Sound	H/L	dBA	37/32		38/33		39/33	
Sound Power	H/L	dBA	53/48		54/49		55/49	
Heat Insulation			Both Liquid and Gas Pipes		Both Liquid and Gas Pipes		Both Liquid and Gas Pipes	
Piping Connection	Liquid	mm	φ 6.4 (Flare)		φ 6.4 (Flare)		φ 6.4 (Flare)	
	Gas	mm	φ 9.5 (Flare)		φ12.7 (Flare)		φ12.7 (Flare)	
	Drain	mm	VP20 (O.D.φ 26 / I.D.φ 20)		VP20 (O.D.φ 26 / I.D.φ 20)		VP20 (O.D.φ 26 / I.D.φ 20)	
Drawing No.			3D037992E		3D037992E		3D037992E	

Conversion Formulae
kcal/h=kWx860
Btu/h=kWx3414
cfm=m ³ /minx35.3

1.4 Outdoor Units - Heat Pump

50Hz 230V

Model		4MXS68F2V1B		
		Cooling	Heating	
Cooling Capacity	kW	—		
Power Consumption	W	—		
Running Current	A	—		
Casing Color		Ivory White		
Compressor	Type	Hermetically Sealed Swing Type		
	Model	2YC45DXD		
Refrigerant Oil	Motor Output	W	1,380	
	Model		FVC50K	
Refrigerant	Charge	L	0.65	
	Type		R-410A	
Air Flow Rates	m ³ /min	H	52.7	46.4
		M	49.4	44.5
		L	43.5	16.3
	cfm	H	1,861	1,638
		M	1,744	1,571
		L	1,536	576
Fan	Type	Propeller		
	Motor Output	W	53	
	Running Current	A	H: 0.20 / M: 0.16 / L: 0.10	H: 0.16 / M: 0.14 / L: 0.03
	Power Consumption	W	H: 70 / M: 58 / L: 36	H: 55 / M: 48 / L: 10
Starting Current	A	6.2		
Dimensions (HxWxD)	mm	735x936x300		
Packaged Dimensions (HxWxD)	mm	797x992x390		
Weight	kg	58		
Gross Weight	kg	63		
Operation Sound	dBA	48	49	
Sound Power	dBA	61	—	
Piping Connection	Liquid	mm	φ 6.4×4	
	Gas	mm	φ9.5×2, φ12.7×2	
	Drain	mm	φ18.0	
Heat Insulation		Both Liquid and Gas Pipes		
No. of Wiring Connection		3 for Power Supply, 4 for Interunit Wiring		
Max. Interunit Piping Length	m	60 (for Total of Each Room)		
	m	25 (for One Room)		
Amount of Additional Charge	g/m	20 (30m or more)		
Max. Installation Height Difference	m	15 (between Indoor Unit and Outdoor Unit)		
	m	7.5 (between Indoor Units)		
Drawing No.		3D056404		

Note: 1. The data are based on the conditions shown in the table below.

Cooling	Heating	Piping Length
Indoor ; 27°CDB/19°CWB Outdoor ; 35°CDB	Indoor ; 20°CDB Outdoor ; 7°CDB/6°CWB	5m

Conversion Formulae
kcal/h=kW×860 Btu/h=kW×3414 cfm=m ³ /min×35.3

Part 3

Printed Circuit Board

Connector Wiring Diagram

1. Printed Circuit Board Connector Wiring Diagram.....	38
1.1 Wall Mounted Type	38
1.2 Duct Connected Type.....	47
1.3 Floor / Ceiling Suspended Dual Type.....	49
1.4 Floor Standing Type	52
1.5 Ceiling Suspended Type	54
1.6 Outdoor Units	56

1. Printed Circuit Board Connector Wiring Diagram

1.1 Wall Mounted Type

1.1.1 FTK(X)S20~50D

Connectors

PCB(1) (Control PCB)

- | | |
|--------|---|
| 1) S1 | Connector for DC fan motor |
| 2) S6 | Connector for swing motor (horizontal blades) |
| 3) S21 | Connector for centralized control (HA) |
| 4) S26 | Connector for display PCB |
| 5) S28 | Connector for signal receiver PCB |
| 6) S32 | Connector for heat exchanger thermistor |
| 7) S35 | Connector for INTELLIGENT EYE sensor PCB |

PCB(2) (Signal Receiver PCB)

- | | |
|--------|---------------------------|
| 1) S29 | Connector for control PCB |
|--------|---------------------------|

PCB(3) (Display PCB)

- | | |
|--------|---------------------------|
| 1) S27 | Connector for control PCB |
|--------|---------------------------|

PCB(4) (INTELLIGENT EYE sensor PCB)

- | | |
|--------|---------------------------|
| 1) S36 | Connector for control PCB |
|--------|---------------------------|



Note:

Other designations

PCB(1) (Control PCB)


- | | |
|----------|--|
| 1) V1 | Varistor |
| 2) JA | Address setting jumper |
| JB | Fan speed setting when compressor is OFF on thermostat |
| JC | Power failure recovery function (auto-restart) |
| | * Refer to page 321 for detail. |
| 3) LED A | LED for service monitor (green) |
| 4) FU1 | Fuse (3.15A) |

PCB(3) (Display PCB)

- | | |
|---------------|----------------------------------|
| 1) SW1 (S1W) | Forced operation ON / OFF switch |
| 2) LED1 | LED for operation (green) |
| 3) LED2 | LED for timer (yellow) |
| 4) LED3 | LED for INTELLIGENT EYE (green) |
| 5) RTH1 (R1T) | Room temperature thermistor |


PCB Detail

PCB(1): Control PCB




(R4288)

PCB(2): Signal Receiver PCB




(R5183)

PCB(3): Display PCB



(R4290)

PCB(4): INTELLIGENT EYE sensor PCB



(R4291)

1.1.2 FTK(X)S20~35C

Connectors

PCB(1) (Control PCB)

PCB(2) (Signal Receiver PCB)

- | | |
|--------|--|
| 1) S1 | Connector for fan motor |
| 2) S6 | Connector for swing motor (Horizontal Flap) |
| 3) S7 | Connector for fan motor |
| 4) S21 | Connector for centralized control to 5 rooms |
| 5) S26 | Connector for signal receiver PCB |
| 6) S27 | Connector for control PCB |
| 7) S32 | Connector for heat exchanger thermistor |
| 8) S35 | Connector for INTELLIGENT EYE Sensor PCB |

PCB(3) (INTELLIGENT EYE sensor PCB)

- | | |
|--------|---------------------------|
| 1) S36 | Connector for control PCB |
|--------|---------------------------|



Note:


Other designations

PCB(1) (Control PCB)

PCB(2) (Signal Receiver PCB)

- | | |
|----------|--|
| 1) V1 | Varistor |
| 2) JA | Address setting jumper |
| JB | Fan speed setting when compressor is OFF on thermostat |
| JC | Power failure recovery function |
| | * Refer to page 321 for more detail. |
| 3) SW7 | Forced operation ON/OFF switch |
| 4) LED1 | LED for operation (green) |
| 5) LED2 | LED for timer (yellow) |
| 6) LED3 | LED for HOME LEAVE operation (red) |
| 7) LED A | LED for service monitor (green) |
| 8) FU1 | Fuse (3.15A) |
| 9) RTH1 | Room temperature thermistor |

PCB




(R2413

PCB Detail


PCB(1): Control PCB

PCB(2): Signal Receiver PCB



(R4987)

PCB(3): INTELLIGENT EYE sensor PCB



(R4988)

1.1.3 FTK(X)S50~71F

Connectors

PCB(1) (Control PCB)

- | | |
|--------|---|
| 1) S1 | Connector for DC fan motor |
| 2) S6 | Connector for swing motor (horizontal blades) |
| 3) S8 | Connector for swing motor (vertical blades) |
| 4) S21 | Connector for centralized control (HA) |
| 5) S26 | Connector for buzzer PCB |
| 6) S28 | Connector for signal receiver PCB |
| 7) S32 | Connector for heat exchanger thermistor |
| 8) S35 | Connector for Intelligent Eye sensor PCB |

PCB(2) (Signal Receiver PCB)

- | | |
|--------|---------------------------|
| 1) S29 | Connector for control PCB |
|--------|---------------------------|

PCB(3) (Buzzer PCB)

- | | |
|--------|---------------------------|
| 1) S27 | Connector for control PCB |
| 2) S38 | Connector for display PCB |

PCB(4) (Display PCB)

- | | |
|--------|--------------------------|
| 1) S37 | Connector for buzzer PCB |
|--------|--------------------------|

PCB(5) (INTELLIGENT EYE sensor PCB)

- | | |
|--------|---------------------------|
| 1) S36 | Connector for control PCB |
|--------|---------------------------|



Note: Other designations

PCB(1) (Control PCB)

- | | |
|----------|--|
| 1) V1 | Varistor |
| 2) JA | Address setting jumper |
| JB | Fan speed setting when compressor is OFF on thermostat |
| JC | Power failure recovery function |
| | * Refer to page 321 for detail. |
| 3) LED A | LED A for service monitor (green) |
| 4) FU1 | Fuse (3.15A) |

PCB(2) (Signal Receiver PCB)

- | | |
|--------------|--------------------------------|
| 1) SW1 (S1W) | Forced operation ON/OFF switch |
|--------------|--------------------------------|

PCB(3) (Buzzer PCB)


- | | |
|---------------|-----------------------------|
| 1) RTH1 (R1T) | Room temperature thermistor |
|---------------|-----------------------------|

PCB(4) (Display PCB)


- | | |
|---------|------------------------------------|
| 4) LED1 | LED for operation (green) |
| 5) LED2 | LED for timer (yellow) |
| 6) LED3 | LED for HOME LEAVE operation (red) |

PCB Detail


PCB(1): Control PCB (indoor unit)




PCB(2): Signal Receiver PCB




PCB(3): Buzzer PCB



PCB(4): Display PCB



PCB(5): Intelligent Eye sensor PCB



1.1.4 FTXG25~35E, CTXG50E

Connectors

PCB(1) (Control PCB)

- | | |
|--------|--|
| 1) S1 | Connector for fan motor |
| 2) S21 | Connector for centralized control (HA) |
| 3) S32 | Connector for heat exchanger thermistor |
| 4) S36 | Connector for INTELLIGENT EYE sensor PCB and control PCB |
| 5) S41 | Connector for swing motor |
| 6) S46 | Connector for signal receiver PCB |
| 7) S49 | Connector for reduction motor (front panel mechanism) |
| 8) S51 | Connector for front panel limit switch |

PCB(2) (Signal Receiver PCB)

- | | |
|--------|---------------------------|
| 1) S47 | Connector for control PCB |
|--------|---------------------------|

PCB(3) (INTELLIGENT EYE sensor PCB)

- | | |
|--------|---------------------------|
| 1) S36 | Connector for control PCB |
|--------|---------------------------|



Note: Other designations

PCB(1) (Control PCB)


- | | |
|----------|--|
| 1) V1 | Varistor |
| 2) JA | Address setting jumper |
| JB | Fan speed setting when compressor is OFF on thermostat |
| JC | Power failure recovery function (auto-restart) |
| | * Refer to page 321 for detail. |
| 3) FU1 | Fuse (3.15A) |
| 4) LED A | LED for service monitor (green) |

PCB(2) (Signal Receiver PCB)

- | | |
|---------|----------------------------------|
| 1) SW1 | Forced operation ON / OFF switch |
| 2) LED2 | LED for INTELLIGENT EYE (green) |
| 3) LED3 | LED for timer (yellow) |
| 4) LED4 | LED for operation (green) |
| 5) RTH1 | Room temperature thermistor |


PCB Detail

PCB(1): Control PCB (indoor unit)




(R4991)

PCB(2): Signal Receiver PCB



(R4992)

PCB(3): INTELLIGENT EYE sensor PCB



(R4988)

1.2 Duct Connected Type

Connectors

PCB(1) (Control PCB)

- 1) S1 Connector for AC fan motor
- 2) S7 Connector for AC fan motor
- 3) S21 Connector for centralized control to 5 rooms
- 4) S26 Connector for display PCB
- 5) S32 Connector for heat exchanger thermistor

PCB(2) (Display PCB)

- 1) S1 Connector for control PCB



Note: Other designations

PCB(1) (Control PCB)


- 1) V1 Varistor
 - 2) JA Address setting jumper
 - JB Fan speed setting when compressor is OFF on thermostat
 - JC Power failure recovery function
- * Refer to page 321 for more detail.
- 3) LED A LED for service monitor (green)
 - 4) FU1 Fuse (3.15A)

PCB(2) (Display PCB)

- 1) SW1 (S1W) Forced operation ON/OFF switch
- 2) LED1 LED for operation (green)
- 3) LED2 LED for timer (yellow)
- 4) LED3 LED for HOME LEAVE operation (red)
- 5) RTH1 (R1T) Room temperature thermistor


PCB Detail

PCB (1): Control PCB



PCB Detail

PCB (2): Display PCB



2P084375

1.3 Floor / Ceiling Suspended Dual Type

Connectors

PCB(1) (Control PCB)

- | | |
|--------|--|
| 1) S6 | Connector for swing motor (horizontal swing) |
| 2) S7 | Connector for AC fan motor |
| 3) S21 | Connector for centralized control |
| 4) S24 | Connector for display PCB |
| 5) S26 | Connector for signal receiver PCB |
| 6) S32 | Connector for heat exchanger thermistor |
| 7) S37 | Connector for power supply PCB |

PCB(2) (Power Supply PCB)

- | | |
|--------|---------------------------|
| 1) S36 | Connector for control PCB |
|--------|---------------------------|

PCB(3) (Display PCB)

- | | |
|--------|---------------------------|
| 1) S25 | Connector for control PCB |
|--------|---------------------------|

PCB(4) (Signal Receiver PCB)

- | | |
|--------|---|
| 1) S27 | Connector for control PCB |
| 2) S31 | Connector for room temperature thermistor |



Note:

Other designations

PCB(1) (Control PCB)

- | | |
|----------|--|
| 1) JA | Address setting jumper |
| JB | Fan speed setting when compressor is OFF on thermostat |
| JC | Power failure recovery function
* Refer to page 321 for detail. |
| 2) SW2 | Select switch ceiling or floor |
| 3) LED A | LED for service monitor (green) |

PCB(2) (Power Supply PCB)

- | | |
|--------|--------------|
| 1) V1 | Varistor |
| 1) FU1 | Fuse (3.15A) |

PCB(3) (Display PCB)


- | | |
|---------|------------------------------------|
| 1) LED1 | LED for operation (green) |
| 2) LED2 | LED for timer (yellow) |
| 3) LED3 | LED for HOME LEAVE operation (red) |

PCB(4) (Signal Receiver PCB)

- | | |
|--------------|--------------------------------|
| 1) SW1 (S1W) | Forced operation ON/OFF switch |
|--------------|--------------------------------|

PCB Detail


PCB (1): Control PCB



2P084352


PCB Detail

PCB (2): Power Supply PCB




2P084361

PCB (3): Display PCB



2P084377

PCB (4): Signal Receiver PCB



1.4 Floor Standing Type

Connectors

PCB(1) (Sensor PCB)

- | | |
|--------|---------------------------|
| 1) S49 | Connector for control PCB |
|--------|---------------------------|

PCB(2) (Control PCB)

- | | |
|--------|--------------------------------------|
| 1) S1 | Connector for fan motor |
| 2) S21 | Connector for centralized control |
| 3) S26 | Connector for service PCB |
| 4) S41 | Connector for lower air outlet motor |
| 5) S42 | Connector for swing motor |
| 6) S46 | Connector for display PCB |
| 7) S48 | Connector for sensor PCB |

PCB(3) (Service PCB)

- | | |
|--------|---------------------------|
| 1) S27 | Connector for control PCB |
|--------|---------------------------|

PCB(4) (Display PCB)

- | | |
|--------|---------------------------|
| 1) S47 | Connector for control PCB |
|--------|---------------------------|



Note:

Other Designations

PCB(2) (Control PCB)

- | | |
|----------|--|
| 1) V1 | Varistor |
| 2) JA | Address setting jumper |
| JB | Fan speed setting when compressor is OFF on thermostat |
| JC | Power failure recovery function
* Refer to page 321 for detail. |
| 3) FU1 | Fuse (3.15A) |
| 4) LED A | LED for service monitor (green) |

PCB(3) (Service PCB)


- | | |
|--------|---------------------------------------|
| 1) SW2 | Changing upward air flow limit switch |
| 2) SW4 | Discharge changeover switch |

PCB(4) (Display PCB)


- | | |
|--------------|--------------------------------|
| 1) SW1 (S1W) | Forced operation ON/OFF switch |
| 2) LED1 | LED for operation (green) |
| 3) LED2 | LED for timer (yellow) |

PCB Detail


PCB(1): Sensor PCB




PCB(2): Control PCB



PCB(3): Service PCB



PCB(3): Display PCB



1.5 Ceiling Suspended Type

Connectors


1) X5A	Connector for Terminal Strip (for Wired Remote Control)
2) X14A	Connector for Limit Switch (for Swing Flap)
3) X15A	Connector for Drain Pump (Optional Accessory)
4) X17A	Connector for Heat Exchanger Thermistor (2)
5) X18A	Connector for Heat Exchanger Thermistor (1)
6) X19A	Connector for Room Temperature Thermistor
7) X20A, X26A	Connector for Fan Motor
8) X24A	Connector for Infrared Remote Control Receiver Unit
9) X25A	Connector for Drain Pump Motor (Optional Accessory)
10) X27A	Connector for Terminal Strip (for Inter Unit Wiring)
11) X29A	Connector for Swing Motor
12) X33A	Connector for Wiring Adapter PCB (Optional Accessory)
13) X35A	Connector for Group Control Adapter (Optional Accessory)
14) X40A	Connector for ON/OFF Input from Outside (for Optional Accessory)
15) X60A, X61A	Connector for Interface Adapter (Optional Accessory)



Note: Other Designation

1) HAP	Service Monitor LED
--------	---------------------

PCB Detail



2P095007

1.6 Outdoor Units

Connectors

PCB(1)(Main PCB)

1) S10	Connector for terminal strip (indoor-outdoor transmission)
2) S15	Connector for COOL / HEAT mode lock
3) S20	Connector for electronic expansion valve coil A port (white)
4) S21	Connector for electronic expansion valve coil B port (red)
5) S22	Connector for electronic expansion valve coil C port (blue)
6) S23	Connector for electronic expansion valve coil D port (yellow)
7) S40	Connector for overload protector
8) S51, S101	Connector for service monitor PCB
9) S70	Connector for fan motor
10) S80	Connector for four way valve coil
11) S90	Connector for thermistors (outdoor air, heat exchanger, and discharge pipe)
12) S92	Connector for gas pipe thermistor
13) S93	Connector for liquid pipe thermistor
14) AC1, AC2	Connector for terminal strip (power supply)
15) HR1, HR2	Connector for reactor

PCB(2)(Service Monitor PCB)

1) S52, S102	Connector for control PCB
--------------	---------------------------



Note:

Other Designations

PCB(1)(Main PCB)


1) FU1	Fuse (30A)
2) FU2, FU3	Fuse (3.15A)
3) V2, V3, V5 V9, V100	Varistor

PCB(2)(Service Monitor PCB)

1) LED A	Service monitor LED (green)
2) LED1 - LED4	Service monitor LED (red)
3) SW1	Forced operation ON/OFF switch
4) SW2	Operation mode switch
5) SW3	Wiring error check switch
6) SW4	Priorily room setting switch
7) SW5	Night quiet mode setting switch


PCB Detail

PCB(1): Main PCB



2P194316

PCB(2): Service Monitor PCB



3P165332

Part 4

Function and Control

1. Main Functions	60
1.1 Frequency Principle.....	60
1.2 Power-Airflow Dual Flaps, Wide Angle Louvers and Auto-Swing	62
1.3 Operation Starting Control.....	64
1.4 Fan Speed Control for Indoor Units.....	65
1.5 Programme Dry Function	66
1.6 Automatic Operation.....	67
1.7 Thermostat Control.....	68
1.8 Night Set Mode.....	69
1.9 ECONO Mode	70
1.10 INTELLIGENT EYE (Wall Mounted Type only)	71
1.11 HOME LEAVE Operation	73
1.12 Inverter POWERFUL Operation	74
1.13 Other Functions.....	75
2. Function of Main Structural Parts	77
2.1 Main Structural Parts.....	77
2.2 Function of Thermistor	78
3. Control Specification	82
3.1 Mode Hierarchy.....	82
3.2 Frequency Control.....	83
3.3 Controls at Mode Changing / Start-up.....	86
3.4 Discharge Pipe Control	88
3.5 Input Current Control.....	88
3.6 Freeze-up Protection Control	89
3.7 Heating Peak-cut Control	89
3.8 Fan Control.....	90
3.9 Liquid Compression Protection Function 2.....	90
3.10 Defrost Control	91
3.11 Electronic Expansion Valve Control	92
3.12 Malfunctions	96
3.13 Forced Operation Mode	97
3.14 Wiring-Error Check.....	98
3.15 Additional Function.....	100

1. Main Functions

i Note: See the list of functions for the functions applicable to different models.

1.1 Frequency Principle

Main Control Parameters

The compressor is frequency-controlled during normal operation. The target frequency is set by the following 2 parameters coming from the operating indoor unit:

- The load condition of the operating indoor unit
- The difference between the room temperature and the set temperature

Additional Control Parameters

The target frequency is adapted by additional parameters in the following cases:

- Frequency restrictions
- Initial settings
- Forced cooling / heating operation


Inverter Principle

To regulate the capacity, a frequency control is needed. The inverter makes it possible to vary the rotation speed of the compressor. The following table explains the conversion principle:

Phase	Description
1	The supplied AC power source is converted into the DC power source for the present.
2	The DC power source is reconverted into the three phase AC power source with variable frequency. <ul style="list-style-type: none"> ■ When the frequency increases, the rotation speed of the compressor increases resulting in an increased refrigerant circulation. This leads to a higher amount of the heat exchange per unit. ■ When the frequency decreases, the rotation speed of the compressor decreases resulting in a decreased refrigerant circulation. This leads to a lower amount of the heat exchange per unit.

Drawing of Inverter


The following drawing shows a schematic view of the inverter principle:



Inverter Features

The inverter provides the following features:

- The regulating capacity can be changed according to the changes in the outdoor air temperature and cooling / heating load.
- Quick heating and quick cooling
The compressor rotational speed is increased when starting the heating (or cooling). This enables a quick set temperature.



- Even during extreme cold weather, the high capacity is achieved. It is maintained even when the outdoor air temperature is 2°C.
- Comfortable air conditioning
A detailed adjustment is integrated to ensure a fixed room temperature. It is possible to air condition with a small room temperature variation.
- Energy saving heating and cooling
Once the set temperature is reached, the energy saving operation enables to maintain the room temperature at low power.

Frequency Limits

The following table shows the functions that define the minimum and maximum frequency:

Frequency limits	Limited during the activation of following functions
Low	<ul style="list-style-type: none"> ■ Four way valve operation compensation. Refer to page 86.
High	<ul style="list-style-type: none"> ■ Input current control. Refer to page 88. ■ Compressor protection function. Refer to page 86. ■ Heating Peak-cut control. Refer to page 89. ■ Freeze-up protection. Refer to page 89. ■ Defrost control. Refer to page 91.

Forced Cooling / Heating Operation

For more information, refer to "Forced operation mode" on page 97.

1.2 Power-Airflow Dual Flaps, Wide Angle Louvers and Auto-Swing

Power-airflow Dual Flaps

The large flaps send a large volume of air downwards to the floor. The flap provides an optimum control area in cooling, heating and dry mode.

Heating Mode

During heating mode, the large flap enables direct warm air straight downwards. The flap presses the warm air above the floor to reach the entire room.

Cooling Mode

During cooling mode, the flap retracts into the indoor unit. Then, cool air can be blown far and pervaded all over the room.





Wide-Angle Louvers

The louvers, made of elastic synthetic resin, provide a wide range of airflow that guarantees a comfortable air distribution.

Auto-Swing

In case of FTK(X)S20-50D


The following table explains the auto swing process for heating, cooling, dry and fan :

Vertical Swing (up and down)			Horizontal Swing (right and left: manual)
Cooling / Dry	Heating	Fan	
 <p>(R4281)</p>	 <p>(R4282)</p>	 <p>(R4283)</p>	 <p>(R4284)</p>

3-D Airflow

FTXG25-35E, CTXG50E, FTK(X)S50-71F

- Alternative repetition of vertical and horizontal swing motions enables uniform air-conditioning of the entire room. This function is effective for starting the air conditioner.
- When the horizontal swing and vertical swing are both set to auto mode, the airflow become 3-D airflow and the horizontal swing and vertical swing motions are alternated. The order of swing motion is such that it turns counterclockwise, starting from the right upper point as viewed to the front side of the indoor unit.





COMFORT AIRFLOW Mode

FTXG25-35E, CTXG50E

The vertical swing flap is controlled not to blow the air directly on the person in the room.

- The airflow rate is set to AUTOMATIC.
- The airflow rate has the upper limit (M tap) in heating mode.
- The latest command has the priority between POWERFUL and COMFORT AIRFLOW.

Heating	Cooling, Dry
 <p>80° (R3297)</p>	 <p>5° (R3298)</p>

FTK(X)S20-50D



The vertical swing flap is controlled not to blow the air directly on the person in the room.

- The airflow rate is controlled automatically within the following steps.

Cooling: L tap – MH tap (same as AUTOMATIC)

Heating: ML tap – M tap

- The latest command has the priority between POWERFUL and COMFORT AIRFLOW.

Heating	Cooling
 <p>70° (R4303)</p>	 <p>5° (R4302)</p>


1.3 Operation Starting Control

FTXG25-35E, CTXG50E


The system carries out the following control at the beginning to conduct every functional parts properly.

1. Opening the front panel fully
2. Output of the ΔD signal after the front panel starts moving
3. Opening the flap fully after the front panel opens fully
4. Making the fan rotate when the flap passes over the fan-banned area

Control Flow



Timing Chart



1.4 Fan Speed Control for Indoor Units

Control Mode

The airflow rate can be automatically controlled depending on the difference between the set temperature and the room temperature. This is done through phase control and Hall IC control.



For more information about Hall IC, refer to the troubleshooting for fan motor on page 239.

Phase Steps

Phase control and fan speed control contains 9 steps: LLL, LL, SL, L, ML, M, MH, H and HH. In automatic operation, the step "SL" is not available.

Step	Cooling		Heating		Cooling		Heating	
	Cooling		Heating		Cooling	Heating	Cooling	Heating
LLL								
LL								
L								
ML								
M								
MH								
H								
HH (Powerful)	H+70 (FTXG25/35E) H+50 (CTXG50E) H+40 (FVXS25-50F)	H+50 (FTXG25/35E, CTXG50E) H+40 (FVXS25-50F)	H+90	H+90	H+50	H+50		

= Within this range the airflow rate is automatically controlled when the FAN setting button is set to automatic.



Note:


1. Fan stops during defrost operation.
2. In time of thermostat OFF, the fan rotates at the following speed.
Cooling : The fan keeps rotating at the set tap.
Heating : The fan stops.

Automatic Air Flow Control for Heating

On heating mode, the indoor fan speed will be regulated according to the indoor heat exchanger temperature and the difference between the room temperature and the required set point.

Automatic Air Flow Control for Cooling

The following drawing explains the principle of fan speed control for cooling:



1.5 Programme Dry Function


Programme dry function removes humidity while preventing the room temperature from lowering.

Since the microcomputer controls both the temperature and air flow volume, the temperature adjustment and fan adjustment buttons are inoperable in this mode.

In Case of Inverter Units

The microcomputer automatically sets the temperature and fan settings. The difference between the room temperature at startup and the temperature set by the microcomputer is divided into two zones. Then, the unit operates in the dry mode with an appropriate capacity for each zone to maintain the temperature and humidity at a comfortable level.

Room temperature at startup	Set temperature X	Thermostat OFF point Y	Thermostat ON point Z
24°C or more	Room temperature at startup	$X - 2.5^{\circ}\text{C}$	$X - 0.5^{\circ}\text{C}$ or $Y + 0.5^{\circ}\text{C}$ (zone B) continues for 10 min.
23.5°C ⋮ 18°C		$X - 2.0^{\circ}\text{C}$	$X - 0.5^{\circ}\text{C}$ or $Y + 0.5^{\circ}\text{C}$ (zone B) continues for 10 min.
17.5°C ⋮	18°C	$X - 2.0^{\circ}\text{C}$	$X - 0.5^{\circ}\text{C} = 17.5^{\circ}\text{C}$ or $Y + 0.5^{\circ}\text{C}$ (zone B) continues for 10 min.



(R6841)

1.6 Automatic Operation


Automatic Cooling / Heating Function (Heat Pump Only)

When the AUTO mode is selected with the remote control, the microcomputer automatically determines the operation mode from cooling and heating according to the room temperature and setting temperature at the time of the operation startup, and automatically operates in that mode.

The unit automatically switches the operation mode to cooling or heating to maintain the room temperature at the main unit setting temperature.

Detailed Explanation of the Function

1. Remote control setting temperature is set as automatic cooling / heating setting temperature (18 to 30°C).
2. Main unit setting temperature equals remote control setting temperature.
3. Operation ON / OFF point and mode switching point are as follows.
 - ① Heating → Cooling switching point:
Room temperature \geq Main unit setting temperature +2.5 deg.
 - ② Cooling → Heating switching point:
Room temperature $<$ Main unit setting temperature -2.5 deg.
 - ③ Thermostat ON / OFF point is the same as the ON / OFF point of cooling or heating operation.
4. During initial operation
 Room temperature \geq Remote control setting temperature: Cooling operation
 Room temperature $<$ Remote control setting temperature: Heating operation



(R6842)

Ex: When the set point is 25°C

Cooling Operation → 23°C: Thermostat OFF → 22°C: Switch to Heating Operation

5. Heating Operation → 26.5°C: Thermostat OFF → 27.5°C: Switch to Cooling Operation

1.7 Thermostat Control

Thermostat control is based on the difference between the room temperature and the setpoint.

Thermostat OFF Condition


- ◆ The temperature difference is in the zone A.

Thermostat ON Condition

- ◆ The temperature difference is above the zone C after being in the zone A.
- ◆ The system resumes from defrost control in any zones except A.
- ◆ The operation turns on in any zones except A.
- ◆ The monitoring time has passed while the temperature difference is in the zone B.
(Cooling / Dry : 10 minutes, Heating : 10 seconds)


Cooling / Dry

- ◆ Wall Mounted Type
- ◆ Floor standing Type



(R4668)


- ◆ Floor/Ceiling suspended Type
- ◆ Duct Connected Type



(R6032)


Heating

- ◆ Wall Mounted Type
- ◆ Floor standing Type



(R4669)

- ◆ Floor/Ceiling suspended Type
- ◆ Duct Connected Type



(R6033)


1.8 Night Set Mode

When the OFF timer is set, the Night Set circuit automatically activates. The Night Set circuit maintains the airflow setting made by users.

The Night Set Circuit


The Night Set circuit continues heating or cooling the room at the set temperature for the first one hour, then automatically raises the temperature setting slightly in the case of cooling, or lowers it slightly in the case of heating, for economical operations. This prevents excessive heating in winter and excessive cooling in summer to ensure comfortable sleeping conditions, and also conserves electricity.

Cooling Operation




(R1361)

In case of FTXG25-35E, CTXG50E, FTK(X)S20-50D, FVXS25-50F the temperature rises once.



(R4421)

Heating Operation



(R1362)

1.9 ECONO Mode

Outline


FTK(X)S20-50D, FVXS25-50F

The "ECONO mode" reduces the maximum operating current and power consumption by approx. 30% during start up etc..

This mode is particularly convenient for energy-saving-oriented users. It is also a major bonus for those whose breaker capacities do not allow the use of multiple electrical devices and air conditioners.

It is easily activated from the Infrared remote control by pushing the ECONO button.

- When this function is ON, the maximum capacity is also down. (Approx. 20%)
- This function can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled.
- This function and POWERFUL operation cannot be used at the same time. The latest command has the priority.



Details


- ECONO mode can be activated while the unit is running. The remote control can send the ECONO command when the unit is in COOL, HEAT, DRY, or AUTO operation.
- When the ECONO command is valid, the upper limit of frequency is restricted.

1.10 INTELLIGENT EYE (Wall Mounted Type Only)

This is the function that detects existence of humans in the room by a human motion sensor (INTELLIGENT EYE) and reduces the capacity when there is no human in the room in order to save electricity.


Processing

1. Detection method by Intelligent Eye



- This sensor detects human motion by receiving infrared rays and displays the pulse wave output.
- A microcomputer in an indoor unit carries out a sampling every 20 msec. and if it detects 10 cycles of the wave in one second in total (corresponding to $20\text{msec.} \times 10 = 100\text{msec.}$), it judges human is in the room as the motion signal is ON.

2. The motions (for example: in cooling)



- When a microcomputer doesn't have a signal from the sensor in 20 minutes, it judges that nobody is in the room and operates the unit in temperature shifted 2°C from the set temperature. (Cooling : 2°C higher, Dry : 1°C higher and Auto : according to the operation mode at that time.)
- ★1 In case of Fan mode, the fan speed reduces by 50 rpm.

- Since the set temperature is shifted by 2°C higher for 40 minutes, compressor speed becomes low and can realize energy saving operation. But as thermostat is prone to be off by the fact that the set temperature has been shifted, the thermostat-off action is prohibited in 40 minutes so as to prevent this phenomena.
After this 40 minutes, the prohibition of the thermostat-off is cancelled and it can realize the conditions to conduct thermostat-off depending on the room temperature. In or after this 40 minutes, if the sensor detects human motion detection signal, it let the set temperature and the fan speed return to the original set point, keeping a normal operation.

Others

- The dry operation can't command the setting temperature with a remote control, but internally the set temperature is shifted by 1°C.

1.11 HOME LEAVE Operation

Outline

In order to respond to the customer's need for immediate heating and cooling of the room after returning home or for house care, a measure to switch the temperature and air volume from that for normal time over to outing time by one touch is provided. (This function responds also to the need for keeping up with weak cooling or heating.)

This time, we seek for simplicity of operation by providing the special temperature and air volume control for outing to be set by the exclusive button.

The SkyAir indoor models also have the function.

Detail of the Control

1. Start of Function

The function starts when the [HOME LEAVE] button is pressed in cooling mode or heating mode (including stopping and powerful operation). If this button is pressed while the operation is stopped, the function becomes effective when the operation is started. If this button is pressed in powerful operation, the powerful operation is reset and this function becomes effective.

- The [HOME LEAVE] button is ineffective in dry mode and fan mode.

2. Details of Function


A mark representing [HOME LEAVE] is indicated on the liquid crystal display of the remote control. The indoor unit is operated according to the set temperature and air volume for HOME LEAVE which were pre-set in the memory of the remote control.

The LED (Red) of indoor unit representing [HOME LEAVE] lights up. (It goes out when the operation is stopped.)


3. End of Function

The function ends when the [HOME LEAVE] button is pressed again during [HOME LEAVE] operation or when the powerful operation button is pressed.

Scene <Cooling>



Scene <Heating>



Others

The set temperature and set air volume are memorized in the remote control. When the remote control is reset due to replacement of battery, it is necessary to set the temperature and air volume again for [HOME LEAVE].

1.12 Inverter POWERFUL Operation

Outline

In order to exploit the cooling and heating capacity to full extent, operate the air conditioner by increasing the indoor fan rotating speed and the compressor frequency.


Details of the Control

When POWERFUL button is pushed in each operation mode, the fan speed / setting temperature will be converted to the following states in a period of twenty minutes.

In case of FTK(X)S20-50D

Operation mode	Fan speed	Target set temperature
COOL	H tap + 50 rpm	18°C
DRY	Dry rotating speed + 50 rpm	Normally targeted temperature in dry operation; Approx. -2°C
HEAT	H tap + 50 rpm	30°C
FAN	H tap + 50 rpm	—
AUTO	Same as cooling / heating in Powerful operation	The target is kept unchanged

Ex.) : Powerful operation in cooling mode.



(R4560)



Refer to "Fan Speed control" on page 65 for detail.


1.13 Other Functions

1.13.1 Hot Start Function

Heat Pump Only

In order to prevent the cold air blast that normally comes when heating is started, the temperature of the heat exchanger of the indoor unit is detected, and either the air flow is stopped or is made very weak thereby carrying out comfortable heating of the room.

*The cold air blast is also prevented using a similar control when the defrosting operation is started or when the thermostat gets turned ON.



1.13.2 Signal Receiving Sign


When the indoor unit receives a signal from the remote control, the unit emits a signal receiving sound.

1.13.3 ON/OFF Button on Indoor Unit

An ON/OFF button is provided on the front panel of the unit. Use this button when the remote control is missing or if its battery has run out.

Every press of the button switches from ON to OFF or from OFF to ON.

In case of FTK(X)S20-50D



- Push this button once to start operation. Push once again to stop it.
- This button is useful when the remote control is missing.
- The operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
Cooling Only	COOL	22°C	AUTO
Heat Pump	AUTO	25°C	AUTO

- In the case of multi system operation, there are times when the unit does not activate with this button.

<Forced operation mode>

Forced operation mode will be set by pressing the ON/OFF button for between 5 to 9 sec. while the unit is not operating.



Note: When the ON/OFF button is pressed for 10 sec. or more, the operation will be stopped. See page 97 for the detail of "Forced Operation Mode".

1.13.4 Titanium Apatite Photocatalytic Air-Purifying Filter

For FTK(X)S20-50D, FTK(X)S50-71F, FVXS25-50F, FTXG25/35E, CTXG50E

This filter combines the Air Purifying Filter and Titanium Apatite Photocatalytic Deodorizing Filter in a single highly effective unit. The filter traps microscopic particles, decompose odours and even deactivates bacteria and viruses. It lasts for three years without replacement if washed about once every six months.

1.13.5 Photocatalytic Deodorizing Filter

For FLK(X)S25-60B

Photocatalytic Deodorizing Filter demonstrates powerful oxidation characteristics when subjected to harmless ultraviolet light. Photocatalytic deodorizing power is recovered simply by exposing the filter to the sun for 6 hours once every 6 months.

1.13.6 Air-Purifying Filter

For FLK(X)S25-60B

A double structure made up of a bacteriostatic filter and an Air-Purifying Filter traps dust, mildew, mites, tobacco smoke, and allergy-causing pollen. Replace the Air-Purifying Filter once every 3 months.

1.13.7 Air Purifying Filter with Photocatalytic Deodorizing Function

For FTK(X)S20-35C

This filter incorporates the benefits the Air Purifying Filter and Photocatalytic Deodorizing Filter in a single unit. Combining the two filters in this way increases the active surface area of the new filter. This larger surface area allows the filter to effectively trap microscopic particles, decompose odours and deactivate bacteria and viruses even for the high volume of air required to air-condition large living rooms. The filter can be used for approximately 3 years if periodic maintenance is performed.

1.13.8 Mold Proof Air Filter (Prefilter)

For all indoor units

The filter net is treated with mold resisting agent TBZ (harmless, colorless, and odorless). Due to this treatment, the amount of mold growth is much smaller than that of normal filters.

1.13.9 Self-Diagnosis Digital Display

The microcomputer continuously monitors main operating conditions of the indoor unit, outdoor unit and the entire system. When an abnormality occur, the LCD remote control displays error code. These indications allow prompt maintenance operations.

1.13.10 Auto-restart Function

Even if a power failure (including one for just a moment) occurs during the operation, the operation restarts in the condition before power failure automatically when power is restored. (Note) It takes 3 minutes to restart the operation because the 3 minute stand-by function is activated.

1.13.11 WEEKLY TIMER Operation

Up to 4 timer settings can be saved for each day of the week (up to 28 settings in total). Those 3 items of "ON / OFF", "temperature" and "time" can be set.




Refer to "WEEKLY TIMER Operation" on page 198 for detail.


2. Function of Main Structural Parts

2.1 Main Structural Parts

Heat Pump Model




Cooling Only Model



Note: Expansion Valve : In Case of 2 port model.....EVA-B, 3 port model.....EVA-C, 4 port model.....EVA-D

2.2 Function of Thermistor

2.2.1 Heat Pump Model



A Outdoor Heat Exchanger Thermistor

1. The outdoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The outdoor heat exchanger thermistor is used for detecting disconnection of the discharge thermistor when cooling.
When the discharge pipe temperature becomes lower than the outdoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.

B Discharge Pipe Thermistor

1. The discharge pipe thermistor is used for controlling temperature of the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation halts.
2. The discharge pipe thermistor is used for detecting disconnection of the discharge thermistor.

C Gas Pipe Thermistor

1. In cooling, the gas pipe thermistors are used for gas pipe isothermal control. The system controls electronic expansion valve opening so that gas pipe temperature in each room becomes equal.


D Indoor Heat Exchanger Thermistor

1. The indoor heat exchanger thermistors are used for controlling target discharge temperature.
The system sets a target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The indoor heat exchanger thermistors are used for preventing freezing.
During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation halts.
3. The indoor heat exchanger thermistors are used for anti-icing control.
During the cooling operation, if the heat exchanger temperature in the room where operation is halted becomes -1°C , or if the room temperature - heat exchanger temperature in the room where operation is halted becomes $\geq 10^{\circ}\text{C}$, it is assumed as icing.
4. During heating: the indoor heat exchanger thermistors are used for detecting disconnection of the discharge pipe thermistor.
When the discharge pipe temperature becomes lower than the indoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.
The indoor heat exchanger thermistors are also used for preventing abnormal high pressure.
5. The indoor heat exchanger thermistors are used for detecting incorrect wiring.
During checking incorrect wiring, refrigerant is passed in order from the port A to detect a heat exchanger temperature, and then wiring and piping will be checked.
6. The indoor heat exchanger thermistors are used for sub-cooling control.
The actual sub-cooling is calculated from the liquid pipe temperature and the heat exchanger temperature. The system controls the electronic expansion valve opening to reach the target sub-cooling.
7. The indoor heat exchanger thermistors are used for heating isothermal control of heat exchanger.
When heating: if the difference in temperature of each room is greater than 8°C , the electronic expansion valve of the room in which the temperature is higher is opened.

E Liquid Pipe Thermistor

1. In heating, the liquid pipe thermistors are used for sub-cooling control.
The system calculates the actual sub-cooling with the liquid pipe temperature and the maximum heat exchanger temperature among all rooms, and controls the opening of the electronic expansion valve to reach the target sub-cooling.

2.2.2 Cooling Only Model



A Outdoor Heat Exchanger Thermistor

1. The outdoor heat exchanger thermistor is used for controlling target discharge temperature. The system sets a target discharge temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The outdoor heat exchanger thermistor is used for detecting disconnection of the discharge thermistor when cooling. When the discharge pipe temperature becomes lower than the outdoor heat exchanger temperature, the discharge pipe thermistor is judged as disconnected.

B Discharge Pipe Thermistor

1. The discharge pipe thermistor is used for controlling temperature of the discharge pipe. If the temperature of discharge pipe (used in place of the inner temperature of the compressor) rises abnormally, the operating frequency drops or the operation halts.
2. The discharge pipe thermistor is used for detecting disconnection of the discharge thermistor.

C Gas Pipe Thermistor

1. In cooling, the gas pipe thermistors are used for gas pipe isothermal control. The system controls electronic expansion valve opening so that gas pipe temperature in each room becomes equal.

D Indoor Heat Exchanger Thermistor

1. The indoor heat exchanger thermistors are used for controlling target discharge temperature.
The system sets a target discharge pipe temperature according to the outdoor and indoor heat exchanger temperature, and controls the electronic expansion valve opening so that the target discharge temperature can be obtained.
2. The indoor heat exchanger thermistors are used for preventing freezing.
During the cooling operation, if the temperature drops abnormally, the operating frequency becomes lower, then the operation halts.
3. The indoor heat exchanger thermistors are used for anti-icing control.
During the cooling operation, if the heat exchanger temperature in the room where operation is halted becomes -1°C , or if the room temperature - heat exchanger temperature in the room where operation is halted becomes $\geq 10^{\circ}\text{C}$, it is assumed as icing.
4. The indoor heat exchanger thermistors are used for detecting incorrect wiring.
During checking incorrect wiring, refrigerant is passed in order from the port A to detect a heat exchanger temperature, and then wiring and piping will be checked.

3. Control Specification

3.1 Mode Hierarchy


Outline

There are two modes; the mode selected in user's place (normal air conditioning mode) and forced operation mode for installation and providing service.

Detail

1. For heat pump model


There are following modes; stop, cooling (includes drying), heating (include defrosting)



(R1373)

2. For cooling only model

There are following models; stop and cooling (including drying).



(R1374)



Note:

Unless specified otherwise, an indoor dry operation command must be regarded as cooling operation. An indoor fan operation command cannot be made in a multiple indoor unit. (A forced fan command to the indoor unit from the outdoor unit must be made during forced operation.)

Determine Operating Mode

Judge the operating mode command set by each room in accordance with the instructing procedure, and determine the operating mode of the system.

The following procedure will be taken as the modes conflict with each other.

*1. The system will follow the mode determined first. (First-push, first-set)

*2. For the rooms set with different mode, select stand-by mode. (Operation lamp flashes)


3.2 Frequency Control

Outline

Frequency that corresponds to each room's capacity will be determined according to the difference in the temperature of each room and the temperature that is set by the remote control.

The function is explained as follows.

1. How to determine frequency.
2. Frequency command from an indoor unit. (The difference between a room temperature and the temperature set by the remote control.)
3. Frequency command from an indoor unit. (The ranked capacity of the operating room).
4. Frequency initial setting.
5. PI control.



(R1375)

Detail

How to Determine Frequency

The compressor's frequency will finally be determined by taking the following steps.

For Heat Pump Model

1. Determine command frequency

- ◆ Command frequency will be determined in the following order of priority.
 - 1.1 Limiting frequency by drooping function
 - ◆ Input current, discharge pipes, low Hz high pressure limit, peak cutting, freeze-up protection, dew prevention, fin thermistor temperature.
 - 1.2 Limiting defrost control time
 - 1.3 Forced cooling / heating
 - 1.4 Indoor frequency command

2. Determine upper limit frequency

- ◆ Set a minimum value as an upper limit frequency among the frequency upper limits of the following functions:
Compressor protection, input current, discharge pipes, Low Hz high pressure, peak cutting, freeze-up protection, defrost.

3. Determine lower limit frequency

- ◆ Set a maximum value as an lower limit frequency among the frequency lower limits of the following functions:
Four way valve operating compensation, draft prevention, pressure difference upkeep.

4. Determine prohibited frequency

- ◆ There is a certain prohibited frequency such as a power supply frequency.

For Cooling Only Model

1. Determine command frequency

- ◆ Command frequency will be determined in the following order of priority.
 - 1.1 Limiting frequency by drooping function
Input current, discharge pipes, freeze-up protection, dew prevention, fin thermistor temperature.
 - 1.2 Indoor frequency command

2. Determine upper limit frequency

- ◆ Set a minimum value as an upper limit frequency among the frequency upper limits of the following functions:
Compressor protection, input current, discharge pipes, freeze-up protection, dew prevention, fin thermistor temperature.

3. Determine lower limit frequency

- ◆ Set a maximum value as an lower limit frequency among the frequency lower limits of the following functions:
Pressure difference upkeep.

4. Determine prohibited frequency

- ◆ There is a certain prohibited frequency such as a power supply frequency.

Indoor Frequency Command (ΔD signal)

The difference between a room temperature and the temperature set by the remote control will be taken as the " ΔD signal" and is used for frequency command.

Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal	Temperature difference	ΔD signal
0	*Th OFF	2.0	4	4.0	8	6.0	C
0.5	1	2.5	5	4.5	9	6.5	D
1.0	2	3.0	6	5.0	A	7.0	E
1.5	3	3.5	7	5.5	B	7.5	F

*Th OFF = Thermostat OFF

Indoor Unit Capacity (S value)

The capacity of the indoor unit is a "S" value and is used for frequency command.

Capacity	S value	Capacity	S value
2.5 kW	25	6.0 kW	60
3.5 kW	35	7.1 kW	71
5.0 kW	50		

Frequency Initial Setting**<Outline>**

When starting the compressor, or when conditions are varied due to the change of the operating room, the frequency must be initialized according to the total of a maximum ΔD value of each room and a total value of Q (ΣQ) of the operating room (the room in which the thermostat is set to ON).
Q value: Indoor unit output determined from indoor unit volume, air flow rate and other factors.

PI Control (Determine Frequency Up / Down by ΔD Signal)**1. P control**

Calculate a total of the ΔD value in each sampling time (20 seconds), and adjust the frequency according to its difference from the frequency previously calculated.

2. I control

If the operating frequency is not change more than a certain fixed time, adjust the frequency up and down according to the $\Sigma \Delta D$ value, obtaining the fixed $\Sigma \Delta D$ value.

When the $\Sigma \Delta D$ value is small...lower the frequency.

When the $\Sigma \Delta D$ value is large...increase the frequency.

3. Limit of frequency variation width

When the difference between input current and input current drooping value is less than 1.5 A, the frequency increase width must be limited.

4. Frequency management when other controls are functioning

- ◆ When each frequency is drooping;
Frequency management is carried out only when the frequency droops.
- ◆ For limiting lower limit
Frequency management is carried out only when the frequency rises.

5. Upper and lower limit of frequency by PI control

The frequency upper and lower limits are set depending on the total of S values of a room. When low noise commands come from the indoor unit more than one room or when outdoor unit low noise or quiet commands come from all the rooms, the upper limit frequency must be lowered than the usual setting.

3.3 Controls at Mode Changing / Start-up

3.3.1 Preheating Operation

Outline Operate the inverter in the open phase operation with the conditions including the preheating command from the indoor, the outdoor air temperature and discharge pipe temperature. The power consumption of preheating operation is 35W. (The total power consumption depends on the number of the indoor units.)

Detail

Preheating ON Condition

- ◆ When outdoor air temperature is below 10.5°C or discharge pipe temperature is below 10.5°C, inverter in open phase operation starts.

OFF Condition

- ◆ When outdoor air temperature is higher than 12°C or discharge pipe temperature is higher than 12°C, inverter in open phase operation stops.

3.3.2 Four Way Valve Switching

Outline of heating operation

Heat Pump Only

During the heating operation current must be conducted and during cooling and defrosting current must not be conducted. In order to eliminate the switching sound (as the four way valve coil switches from ON to OFF) when the heating is stopped, the delay switch of the four way valve must be carried out after the operation stopped.

Detail

The OFF delay of four way valve
Energize the coil for 150 sec after unit operation is stopped.

3.3.3 Four Way Valve Operation Compensation

Outline

Heat Pump Only

At the beginning of the operation as the four way valve is switched, acquire the differential pressure required for activating the four way valve by having output the operating frequency, which is more than a certain fixed frequency, for a certain fixed time. The lower limit frequency is restricted to 40Hz for 70 seconds on both cooling and heating, except under the condition of heating overload (outdoor temperature ≥ 15 degree).

Detail

Starting Conditions

1. When starting compressor for heating.
2. When the operating mode changes from the previous time.
3. When starting compressor for rushing defrosting or resetting.
4. When starting compressor for the first time after the reset with the power is ON.

Set the lower limit frequency to 40 (model by model) Hz for 70 seconds with any conditions 1 through 4 above.


3.3.4 3 Minutes Stand-by

Prohibit to turn ON the compressor for 3 minutes after turning it off. (Except when defrosting. (Only for Heat Pump Model).)

3.3.5 Compressor Protection Function

When turning the compressor from OFF to ON, the upper limit of frequency must be set as follows. (The function must not be used when defrosting (only for heat pump model).)

	2YC45
FCG 3	80
FCG 2	65
FCG 1	55



Note: When the compressor doesn't run for long time in the condition that the discharge pipe temperature is 10°C or less, the time between FCG2 and FCG3 will be longer than 470 sec.


3.4 Discharge Pipe Control

Outline

The discharge pipe temperature is used as the compressor's internal temperature. If the discharge pipe temperature rises above a certain level, the operating frequency upper limit is set to keep this temperature from going up further.

Detail

Zones (typical value)



Management within the Zone

Zone	Control contents
Stop zone	When the temperature reaches the stop zone, stop the compressor and correct abnormality.
Drooping zone	Start the timer, and the frequency will be drooping.
Keep zone	Keep the frequency upper limit.
Return / Reset zone	Cancel the frequency upper limit.


3.5 Input Current Control

Outline

Detect an input current by the CT during the compressor is running, and set the frequency upper limit from such input current. In case of heat pump model, this control is the upper limit control function of the frequency which takes priority of the lower limit of four way valve activating compensation.

Detail

The frequency control will be made within the following zones.



When a "stop current" continues for 2.5 seconds after rushing on the stop zone, the compressor operation stops.
 If a "drooping current" is continues for 1.0 second after rushing on the drooping zone, the frequency will be 2 Hz drooping.
 Repeating the above drooping continues until the current rushes on the drooping zone without change. In the unchanged zone, the frequency limit will remain.
 In the return / reset zone, the frequency limit will be cancelled.

Limitation of current drooping and stop value according to the outdoor air temperature


1. In case the operation mode is cooling
 - ◆ The current droops when outdoor air temperature becomes higher than a certain level (model by model).
2. In case the operation mode is heating (only for heat pump model)
 - ◆ The current droops when outdoor air temperature becomes higher than a certain level (model by model).

3.6 Freeze-up Protection Control

Outline During cooling operation, the signals being sent from the indoor unit allow the operating frequency limitation and then prevent freezing of the indoor heat exchanger.

Detail **Conditions for Start Controlling**
 Judge the controlling start with the indoor heat exchanger temperature after 2 sec from operation start and after 30 sec from changing number of operation room.

Control in Each Zone
 The zone is determined by the commands from indoor units.
 In drooping zone, the frequency decreases 2Hz/20 seconds.




3.7 Heating Peak-cut Control

Outline **Heat Pump Only**
 During heating operation, the signals being sent from the indoor unit allow the operating frequency limitation and prevent abnormal high pressure. (The signal from the indoor unit must be divided as follows.)

Detail **Conditions for Start Controlling**
 Judge the controlling start with the indoor heat exchanger temperature after 2 min from operation start and after A sec from changing number of operation room.

	A
When increase	30
When decrease	2

Control in Each Zone
 The maximum value of heat exchange intermediate temperature of each indoor unit controls the following (excluding stopped rooms).
 In drooping zone, the frequency decreases 6Hz/40 seconds.
 In up zone, the frequency increases 2Hz/60 seconds.



3.8 Fan Control

Outline

- Fan control is carried out with following functions.
1. Fan ON control for electric component cooling fan
 2. Fan control when defrosting
 3. Fan OFF delay when stopped
 4. ON/OFF control when cooling operation
 5. Fan control when the number of heating rooms decreases
 6. Fan control when forced operation
 7. Fan control in indoor / outdoor silent operation
 8. Fan control for pressure difference upkeep
-

Detail

Fan OFF Control when Stopped

- ◆ Fan OFF delay for 60 seconds must be made when the compressor is stopped.

Fan control when the number of heating room decreases (Only for Heat Pump Model)

When the outdoor air temperature is more than 10°C, the fan must be turned OFF for 30 seconds.

Tap Control

On cooling, the fan tap changes L ↔ M when the outdoor air temperature is 8°C, and M ↔ H at 37°C.

On heating, the fan tap changes L ↔ M when the outdoor air temperature is 15°C with min. Hz, and

M ↔ H at 4°C.

Tap Control in Indoor Unit Silent Operation

1. When Cooling Operation
When the outdoor air temperature is less than 37°C, the fan tap must be lower.
2. When Heating Operation
When the outdoor air temperature is more than 4°C, the fan tap must be lower. (only for heat pump model).

3.9 Liquid Compression Protection Function 2

Outline

In order to obtain the dependability of the compressor, the compressor must be stopped according to the conditions of the temperature of the outdoor air and outdoor heat exchanger.

Detail

Heat Pump Model

- ◆ Operation stops depending on the outdoor air temperature.

Compressor operation turns OFF under the conditions that the system is in cooling operation and outdoor air temperature is below -10°C. (Except in forced cooling mode)

Cooling Only Model

- ◆ Operation stops depending on the outdoor air temperature.

Compressor operation turns OFF under the condition that outdoor air temperature is below -10°C. (Except in forced cooling mode)

3.10 Defrost Control

Outline

Heat Pump Only

Defrosting is carried out by the cooling cycle (reverse cycle). The defrosting time or outdoor heat exchanger temperature must be more than its fixed value when finishing.

Detail

Conditions for Starting Defrost

Under the conditions that the system is in heating operation, 6 minutes after the compressor is started and more than 38 minutes of accumulated time pass since the start of the operation or ending the defrosting.

When the outdoor air temperature and the outdoor heat exchanger temperature meet the following condition for 60 seconds, the defrost control starts.

$$A < -(19/256) \times B + (45/64) \times C$$

A: outdoor heat exchanger temperature

B: output frequency

C: outdoor air temperature

Conditions for Canceling Defrost


The target heat exchanger temperature as the canceling condition is selected in the range of 4°C ≤ Te ≤ 12°C according to the air temperature as the following formula.

$$\text{The target heat exchanger room temperature} = -(45/64) \times (\text{ambient temperature}) + 14$$

The defrost operation surely operates in 120 seconds after the start. (A→B)

After then the defrost operation stops at the following conditions.

1. When the heat exchanger temperature reaches the target heat exchanger temperature. (B→C)
2. When 650 seconds have passed after the start even if the heat exchanger temperature does not reaches the target heat exchanger temperature. (C)



(R6959)

3.11 Electronic Expansion Valve Control

Outline

The following items are included in the electronic expansion valve control.

Electronic expansion valve is fully closed

1. Electronic expansion valve is fully closed when turning on the power.
2. Pressure equalizing control

Room Distribution Control

1. Gas pipe isothermal control (distribution control in cooling)
2. SC control (only for heat pump model, distribution control in heating)

Open Control

1. Electronic expansion valve control when starting operation
2. Control when frequency changed
3. Control for defrosting (only for heat pump model)
4. Oil recover control
5. Control when a discharge pipe temperature is abnormally high
6. Control when the discharge pipe thermistor is disconnected
7. Control for indoor unit freeze-up protection

Feedback Control

1. Discharge pipe temperature control

Distribution control for each room

1. Liquid pipe temperature control (with all ports connected and all rooms being air-conditioned)
2. Liquid pipe temperature control for stopped rooms
3. Dew prevention function for indoor rotor

Detail

The followings are the examples of control which function in each mode by the electronic expansion valve control.

Operation pattern		Gas pipe isothermal control	SC control (only for heat pump model)	Control when frequency changed	Control for abnormally high discharge pipe temperature	Oil recovery control	Indoor freeze-up protection control	Liquid pipe temperature control	Liquid pipe temperature control for stopped rooms	Dew prevention control for indoor rotor
When power is turned ON	Fully closed when power is turned ON	×	×	×	×	×	×	×	×	×
Cooling, 1 room operation	Open control when starting	×	×	×	○	○	○	×	×	×
	(Control of target discharge pipe temperature)	×	×	○	○	○	○	×	×	○
Cooling, 2 rooms operation to Cooling, 4 rooms operation	Control when the operating room is changed	×	×	×	○	○	○	×	×	○
	(Control of target discharge pipe temperature)	○	×	○	○	○	○	×	×	○
Stop	Pressure equalizing control	×	×	×	×	×	×	×	×	×
Heating, 1 room operation (only for heat pump model)	Open control when starting	×	×	×	○	×	×	×	×	×
	(Control of target discharge pipe temperature)	×	○ All rooms ×	○	○	×	×	○ All rooms ○	○ All rooms ×	×
Heating, 2 rooms operation to Heating, 4 rooms operation (only for heat pump model)	Control when the operating room is changed	×	×	×	○	×	×	×	×	×
	(Control of target discharge pipe temperature)	×	○ All rooms ×	○	○	×	×	○ All rooms ○	○ All rooms ×	×
	(Defrost control FD=1) (only for heat pump model)	×	×	×	×	×	×	×	×	×
Stop	Pressure equalizing control	×	×	×	×	×	×	×	×	
Heating operation (only for heat pump model)	Open control when starting	×	×	×	○	×	×	×	×	×
	Control of discharge pipe thermistor disconnection	×	○ All rooms ×	×	×	×	×	○ All rooms ○	○ All rooms ×	×
Stop	Pressure equalizing control	×	×	×	×	×	×	×	×	

(R3056)

3.11.1 Fully Closing with Power ON

Initialize the electronic expansion valve when turning on the power, set the opening position and develop pressure equalizing.

The electronic expansion valves are closed further with 720 pulse, and then opened with 150 pulse.

3.11.2 Pressure Equalization Control

When the compressor is stopped, open and close the electronic expansion valve and develop pressure equalization.

3.11.3 Opening Limit

Outline Limit a maximum and minimum opening of the electronic expansion valve in the operating room.

Detail

- ◆ A maximum electronic expansion valve opening in the operating room: 450 pulses
 - ◆ A minimum electronic expansion valve opening in the operating room: 75 pulses
- The electronic expansion valve is fully closed in the room where cooling is stopped and is opened with fixed opening during defrosting.

3.11.4 Gas Pipe Isothermal Control During Cooling

When the units are operating in multiple rooms, detect the gas piping temperature and correct the electronic expansion valve opening so that the temperature of the gas pipe in each room becomes identical.

- ◆ When the gas pipe temperature > the average gas pipe temperature,
 - open the electronic expansion valve in that room
- ◆ When the gas pipe temperature < the average gas pipe temperature,
 - close the electronic expansion valve in that room

The temperatures are monitored every 40 seconds.

3.11.5 SC Control

Outline

Heat Pump Only

Detect the temperature of liquid pipe and heat exchanger of the rooms and compensate the electronic expansion valve opening so that the SC of each room becomes the target SC.

- ◆ When the actual SC is > target SC, open the electronic expansion valve of the room.
 - ◆ When the actual SC is < target SC, close the electronic expansion valve of the room.
-

Detail

Start Functioning Conditions

After finishing the open control (810 seconds after the beginning of the operation), control all the electronic expansion valve in the operating room.

Determine Electronic Expansion Valve Opening

Adjust the electronic expansion valve so that the temperature difference between the maximum heat exchanger temperature of connected room and the temperature of liquid pipe thermistor becomes constant.

3.11.6 Starting Operation Control / Changing Operation Room

Control the electronic expansion valve opening when the system is starting or the operating room is changed, and prevent the system to be super heated or moistened.

3.11.7 Disconnection of the Discharge Pipe Thermistor

Outline

Detect a disconnected discharge pipe thermistor by comparing the discharge pipe temperature with the condensation temperature. If any is disconnected, open the electronic expansion valve according to the outdoor air temperature and the operating frequency and operate for a specified time, and then stop.

After 3 minutes of waiting, restart the unit and check if any is disconnected. If any is disconnected stop the system after operating for a specified time. If the disconnection is detected 4 times in succession, then the system will be down.

Detail

Detect Disconnection

If a 780-second timer for open control becomes over, and a 9-minute timer for the compressor operation continuation is not counting time, the following adjustment must be made.

1. When the operation mode is cooling
When the discharge pipe temperature is lower than the outdoor heat exchanger temperature, the discharge pipe thermistor disconnection must be ascertained.
2. When the operation mode is heating (only for heat pump model)
When the discharge pipe temperature is lower than the max temperature of operating room heat exchanger, the discharge pipe thermistor disconnection must be ascertained.

Adjustment when the thermistor is disconnected

When compressor stop repeats specified time, the system should be down.

3.11.8 Control when frequency is changed

When the target pipe temperature control is active, if the target frequency is changed for a specified value in a certain time period, cancel the target discharge pipe temperature control and change the opening of the target electronic expansion valve according to the shift.

3.11.9 High Temperature of the Discharge Pipe

When the compressor is operating, if the discharge pipe temperature exceeds a certain value, open the electronic expansion valve and remove the refrigerant to the low pressure side and lower discharge temperature.

3.11.10 Oil Recovery Function

Outline


The electronic expansion valve opening in the cooling stopped room must be set as to open for a certain time at a specified interval so that the oil in the cooling stopped room may not be accumulated.

Detail

During cooling operation, every 1 hour continuous operation, the electronic expansion valves in the operation stopped room must be opened by 80 pulses for specified time.

3.11.11 Target Discharge Pipe Temperature Control

Obtain the target discharge pipe temperature from the indoor and outdoor heat exchange temperature, and adjust the electronic expansion valve opening so that the actual discharge pipe temperature become close to that temperature. (Indirect SH control using the discharge pipe temperature)



(R6959)

Determine a correction value of the electronic expansion valve compensation and drive it according to the deflection of the target discharge temperature and actual discharge temperature, and the discharge temperature variation by the 20 sec.

3.12 Malfunctions

3.12.1 Sensor Malfunction Detection

Sensor malfunction may occur either in the thermistor or current transformer (CT) system.

Relating to Thermistor Malfunction

1. Outdoor heat exchanger thermistor
2. Discharge pipe thermistor
3. Fin thermistor
4. Gas pipe thermistor
5. Outdoor air temperature thermistor
6. Liquid pipe thermistor

Relating to CT Malfunction

When the output frequency is more than 55 Hz and the input current is less than 0.5A, carry out abnormal adjustment.

3.12.2 Detection of Overload and Over Current

Outline

In order to protect the inverter, detect an excessive output current, and for protecting compressor, monitor the OL operation.

Detail


- ◆ If the OL (compressor head) temperature exceeds 130°C (2YC45), the compressor gets interrupted.

3.12.3 Insufficient Gas Control


Outline

If a power consumption is below the specified value in which the frequency is higher than the specified frequency, it must be regarded as gas insufficient.

In addition to such conventional function, if the discharge temperature is higher than the target discharge pipe temperature, and more than the specified temperature, and the electronic expansion valve is fully open (450 pulses) more than the specified time, it is considered as an insufficient gas.



With the conventional function, a power consumption is weak comparing with that in the normal operation when gas is insufficient, and gas insufficiency is detected by checking a power consumption.



When operating with insufficient gas, although the rise of discharge pipe temperature is great and the electronic expansion valve is open, it is presumed as an insufficient gas if the discharge pipe temperature is higher than the target discharge pipe temperature.

Detail**Judgment by Input Current**

When an output frequency is exceeds 55 Hz and the input current is less than specified value, the adjustment is made for insufficient gas.

Judgment by Discharge Pipe Temperature

When discharge pipe temperature is 20°C higher than target value and the electronic expansion valve opening is 450 plus (max.), the adjustment is made for insufficient gas.

3.12.4 Preventing Indoor Freezing

During cooling, if the heat exchanger temperature in the operation stopped room becomes below the specified temperature for the specified time, open the electronic expansion valve in the operation stopped room as specified, and carry out the fully closed operation. After this, if freezing abnormality occurs more than specified time, the system shall be down as the system abnormality.

3.13 Forced Operation Mode**Outline**

Forced operating mode includes functions such as; forced cooling, forced heating, incorrect wiring, incorrect piping check.

Operating mode must be selected by operating the forced operation switch (SW1 on service PCB).

Detail**Forced Cooling, Forced Heating (Only for Heat Pump Model)**

Item	Forced Cooling	Forced Heating
Forced operation allowing conditions	1) The indoor unit is not abnormal, but the indoor unit which is not in the freezing prohibiting zone is present in more than 1 room.	1) The indoor unit is not abnormal. The indoor unit which is not in the peak-cut prohibited zone is present in more than 1 room.
	2) The outdoor unit is not abnormal and not in the 3-minute stand-by mode.	←
	3) The operating mode of the outdoor unit is the stop mode.	←
	4) The slide selection switch of the forced operation is the cooling mode. The forced operation is allowed when the above "and" conditions are met.	4) The slide selection switch of the forced operation is the heating mode. The forced operation is allowed when the above "and" conditions are met.
Starting / adjustment	If the forced operation switch is pressed as the above conditions are met.	←
1) Determine operating room	All rooms	One of the available units runs. Priority is given to the youngest number's room in alphabetical order. (A > B > C > D)
2) Command frequency	◆ 2YC45: 42 Hz	◆ 2YC45: 37 Hz (Outdoor air temp:0°C)
3) Electronic expansion valve opening	It depends on the capacity of the operating indoor unit.	←
4) Outdoor unit adjustment	Compressor is in operation.	←
5) Indoor unit adjustment	The command of forced operation is transmitted to the indoor unit.	←
End	1) When the forced operation switch is pressed again.	←
	2) The operation is to end automatically after 15 min.	←
Others	The protect functions are prior to all others in the forced operation.	←

3.14 Wiring-Error Check

Outline

The convenient Wiring Error Check function is designed for the microcomputer to correct wiring errors itself.

If local wiring is unclear in the case of buried piping, for example, just press the wiring error check switch that is behind the right-hand panel of the outdoor unit. Even if the connections for Room A and Room B are confused, the system may run without a hassle. Note that this check function does not work in the following cases.

- ◆ For about 1 minute after the power is turned on (during initial setup).
- ◆ For 3-minute standby period after the compressor has stopped.
- ◆ When the outdoor air temperature is below 5°C.
- ◆ If the indoor unit is in trouble (also in case of all-room transmission failure).

When the piping and wiring are perfect, there is no need to use this function.

Operation

1. Remove the 2 screws from the service panel (right side panel) and detach the panel.
2. Press the wiring error check switch on the service monitor PCB, and the wiring error check function is activated.
3. In about 10-15 minutes, the checking will end automatically.
4. When the checking is over, the service monitor LED indicators start flashing.

LED	1	2	3	4	Judgment
Status	All flashing at once				Self-correction impossible
	Flashing one after another				Self-correction complete

Self-correction complete...The LED indicators 1 ~ 4 flash one after another.

Self-correction impossible...The LED indicators flash all at the same time.

- ◆ Transmission failure occurs at any of the indoor units.
- ◆ The indoor unit heat exchanger thermistor is disconnected.
- ◆ An indoor unit is in trouble (if a trouble occurs during the wiring error checking).

Emergency stop...Any of the LED indicators 1 ~ 4 stays on.



Note:

1. After self-correction completed, LED 3 and LED 4 are not displayed for 2 rooms, LED 4 is not displayed for 3 rooms.
2. It takes about 10-15 minutes (after pressing the wiring error check switch) to complete the checking. (Wrong wiring between the upper and lower units cannot be self-corrected.)
3. Wrongly connected liquid and gas pipes cannot be self-corrected either. Be sure to make the liquid pipe and the gas pipe in pairs.
4. To forced-terminate the wiring error check procedure halfway, press the wiring error check switch again.
In this case, the microcomputer's memory gets back to its initial status (Room A wiring → Port A piping, Room B wiring → Port B piping).
5. In replacing the outdoor unit PCB, be sure to use this function.
6. Make the power slide setting after doing the wiring error checking. (Otherwise, if the wiring is reversed, the air-conditioners being connected are set up in the reverse way.)

Basic Knowledge


- ◆ This function works in this way. Refrigerant is let flow from Port A and on. The temperatures of the indoor unit heat exchanger thermistors are detected one by one to check up the matching between the pipes and wiring.
- ◆ With this function on, freezing (crackling) noise may be heard from the indoor unit. This is not a problem. (This is because the heat exchange temperature is made to drop below 0°C in order to increase the detection accuracy.)
- ◆ The indoor fan is made to turn on and off at the same time.

Checking the current setting data on the microcomputer memory


Those data can be checked by looking at the service monitor LED indicators, when the wiring error checking is over, during forced operation, at the stop of the system. The LED indicators stop flashing when the forced operation is over.
 LED1...Room A wiring, LED2...Room B wiring
 1st flashing LED...Port A piping, 2nd flashing LED...Port B piping
 The first stay-on LED means the room that is connected with Port A. The next stay-on LED means the one connected with Port B.

Example

Let's suppose the LED indicators are flashing as follows.



The above means that Port A is connected with Port B and Port B with Room A (or self-corrected this way.)



3.15 Additional Function

3.15.1 Priority Room Setting

Electronic expansion valves are controlled to provide the unit designated as the priority room with the capacity of other room units.


(Distribution of capacity: Priority room unit --- ΔD Max., other room units --- $\Delta D - \alpha$)

- ◆ Setting method
Turn off the circuit breaker before changing the setting.
Only one room can be set as the priority room.
- ◆ Control start conditions
Priority room setting is made.
AND
“Powerful” signal from the priority room unit is received.



Note: The operation mode of the priority room unit has precedence.

- ◆ Cancellation of control
The control function is canceled when the “Powerful” operation mode is switched off or 20 minutes elapse after “Powerful Operation” started.



The prioritised room will be heated/cooled much more quickly

(R1396)

3.15.2 POWERFUL Operation Mode

Compressor operating frequency is increased to PI Max. (Max. Hz of operating room unit ΣS) and outdoor unit airflow rate is increased.

3.15.3 Cooling / Heating Mode Lock

Use the S15 connector to set the unit to only cool or heat.

Setting to only heat (H): Short-circuit pins 1 and 3 of the connector <S15>.


Setting to only cool (C): short-circuit pins 3 and 5 of the connector <S15>.

The following specifications apply to the connector housing and pins.

JST products Housing: VHR-5N

Pin: SVH-21T-1, 1

Note that forced operation is also possible in COOL / HEAT mode.



3.15.4 ECONO-mode-proof Setting

Outline

When installing in hotels, you can make ECONO mode ineffective on the outdoor unit.

Operation

The ECONO mode can be switched over between "effective" and "ineffective" by pressing the forced operation switch (SW1) and wiring error check switch (SW3) at the same time and holding them for 5 seconds while the compressor is stopped. The LEDs are lit in turn for 15 seconds to show the ECONO mode status.

The factory setting is "effective".

	effective → ineffective	ineffective → effective
LED flashing order	4 → 3 → 2 → 1	1 → 2 → 3 → 4

Part 5

Operation Manual

1. System Configuration.....	104
1.1 Operation Instructions	104
2. Instruction.....	105
2.1 FTK(X)S, FTXG, CTXG, FDK(X)S, FLK(X)S Series	105
2.2 FVXS Series.....	181
2.3 FHQ Series.....	212

1. System Configuration

1.1 Operation Instructions

After the installation and test operation of the room air conditioner have been completed, it should be operated and handled as described below. Every user would like to know the correct method of operation of the room air conditioner, to check if it is capable of cooling (or heating) well, and to know a clever method of using it.

In order to meet this expectation of the users, giving sufficient explanations taking enough time can be said to reduce about 80% of the requests for servicing. However good the installation work is and however good the functions are, the customer may blame either the room air conditioner or its installation work because of improper handling. The installation work and handing over of the unit can only be considered to have been completed when its handling has been explained to the user without using technical terms but giving full knowledge of the equipment.

2. Instruction

2.1 FTK(X)S, FTXG, CTXG, FDK(X)S, FLK(X)S Series

2.1.1 Manual Contents and Reference Page



Model Series	Wall Mounted Type			
	FTK(X)S20/25/35/50D	FTK(X)S20/25/35C	FTK(X)S50/60/71F	FTXG25/35E CTXG50E
Read before Operation				
Safety Precautions	106	106	106	106
Names of Parts	108	111	114	117
Preparation before Operation ★	126	126	126	126
Operation				
AUTO, DRY, COOL, HEAT, FAN Operation ★	129	129	129	129
Adjusting the Air Flow Direction	131	132	135	137
POWERFUL Operation ★	141	141	141	141
OUTDOOR UNIT QUIET Operation ★	142	142	142	142
ECONO Operation	143	—	—	—
HOME LEAVE Operation ★	—	144	144	—
INTELLIGENT EYE Operation	146	145	146	152
TIMER Operation ★	154	154	154	154
Note for Multi System	156	156	156	156
Care				
Care and Cleaning	158	161	164	167
Trouble Shooting				
Trouble Shooting	177	177	177	177
Drawing No.	3P194516-2B	3P194444-1B	3P190111-1B	C : 3P166453-1C






Model Series	Duct Connected Type		Floor/Ceiling Suspended Dual Type
	FDK(X)S25/35C	FDK(X)S50/60C FDK(X)S25/35E	FLK(X)S25/35/50/60B
Read before Operation			
Safety Precautions	106	106	106
Names of Parts	120	120	123
Preparation before Operation ★	126	126	126
Operation			
AUTO, DRY, COOL, HEAT, FAN Operation ★	129	129	129
Adjusting the Air Flow Direction	—	—	137
POWERFUL Operation ★	141	141	141
OUTDOOR UNIT QUIET Operation ★	142	142	142
ECONO Operation	—	—	—
HOME LEAVE Operation ★	144	144	144
INTELLIGENT EYE Operation	—	—	—
TIMER Operation ★	154	154	154
Note for Multi System	156	156	156
Care			
Care and Cleaning	170	172	174
Trouble Shooting			
Trouble Shooting	177	177	177
Drawing No.	3P196326-8B	3P196326-9B	3P194444-5B

★ : Illustrations are for wall mounted type FTK(X)S50/60/71F as representative.


2.1.2 Safety precautions


- Keep this manual where the operator can easily find them.
- Read this manual attentively before starting up the unit.
- For safety reason the operator must read the following cautions carefully.
- This manual classifies precautions into WARNING and CAUTION. Be sure to follow all precautions below: they are all important for ensuring safety.

 WARNING If you do not follow these instructions exactly, the unit may cause property damage, personal injury or loss of life.	 CAUTION If you do not follow these instructions exactly, the unit may cause minor or moderate property damage or personal injury.
---	---



- | | |
|---|---|
| <ul style="list-style-type: none">  Never do.  Be sure to earth the air conditioner.  Never touch the air conditioner (including the remote control) with a wet hand. | <ul style="list-style-type: none">  Be sure to follow the instructions.  Never cause the air conditioner (including the remote control) to get wet. |
|---|---|




WARNING

- In order to avoid fire, explosion or injury, do not operate the unit when harmful, among which flammable or corrosive gases, are detected near the unit. 
 - It is not good for health to expose your body to the air flow for a long time.
 - Do not put a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury.
 - Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself. Incorrect work will cause electric shocks, fire etc.
- For repairs and reinstallation, consult your Daikin dealer for advice and information.

- The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant happens to leak into the room, make sure it does not come in contact with any flame as of gas heaters, kerosene heaters or gas range. 
- If the air conditioner is not cooling (heating) properly, the refrigerant may be leaking, so call your dealer. When carrying out repairs accompanying adding refrigerant, check the content of the repairs with our service staff.
- Do not attempt to install the air conditioner by your self. Incorrect work will result in water leakage, electric shocks or fire. For installation, consult the dealer or a qualified technician.
- In order to avoid electric shock, fire or injury, if you detect any abnormally such as smell of fire, stop the operation and turn off the breaker. And call your dealer for instructions.

CAUTION

- The air conditioner must be earthed. Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line. 
- In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art. 
- Never expose little children, plants or animals directly to the air flow.
- Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not block air inlets nor outlets. Impaired air flow may result in insufficient performance or trouble.

- Do not stand or sit on the outdoor unit. Do not place any object on the unit to avoid injury, do not remove the fan guard.
 - Do not place anything under the indoor or outdoor unit that must be kept away from moisture. In certain conditions, moisture in the air may condense and drip.
 - After a long use, check the unit stand and fittings for damage.
 - Do not touch the air inlet and aluminum fins of outdoor unit. It may cause injury.
 - The appliance is not intended for use by young children or infirm persons without supervision.
 - Young children should be supervised to ensure that they do not play with the appliance.
-
- To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air conditioner. 
 - Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.
 - Do not connect the air conditioner to a power supply different from the one as specified. It may cause trouble or fire.
 - Depending on the environment, an earth leakage breaker must be installed. Lack of an earth leakage breaker may result in electric shocks.
 - Arrange the drain hose to ensure smooth drainage. Incomplete draining may cause wetting of the building, furniture etc.
 - Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit.
Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smoke or fire when making contact with electrical parts.
-
- Do not operate the air conditioner with wet hands. 
-
- Do not wash the indoor unit with excessive water, only use a slightly wet cloth.
 - Do not place things such as vessels containing water or anything else on top of the unit. 
Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.
-

Installation site

- To install the air conditioner in the following types of environments, consult the dealer.
 - Places with an oily ambient or where steam or soot occurs.
 - Salty environment such as coastal areas.
 - Places where sulfide gas occurs such as hot springs.
 - Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage.

Consider nuisance to your neighbours from noises

- For installation, choose a place as described below.
 - A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
 - A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours.

Electrical work

- For power supply, be sure to use a separate power circuit dedicated to the air conditioner.


System relocation

- Relocating the air conditioner requires specialized knowledge and skills. Please consult the dealer if relocation is necessary for moving or remodeling


2.1.3 Names of Parts

FTK(X)S 20/25/35/50 D

■ Indoor Unit



■ Outdoor Unit



■ Indoor Unit

1. **Air filter**
2. **Titanium Apatite Photocatalytic Air-Purifying Filter:**
 - These filters are attached to the inside of the air filters.
3. **Air inlet**
4. **Front panel**
5. **Panel tab**
6. **Room temperature sensor:**
 - It senses the air temperature around the unit.
7. **INTELLIGENT EYE sensor:**
 - It detects the movements of people and automatically switches between normal operation and energy saving operation.
8. **Display**
9. **Air outlet**
10. **Flaps (horizontal blades)**
11. **Louvers (vertical blades):**
 - The louvers are inside of the air outlet.

12. Indoor Unit ON/OFF switch:

- Push this switch once to start operation. Push once again to stop it.
- This switch is useful when the remote control is missing.
- the operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
F(C)TKS	COOL	22°C	AUTO
F(C)TXS	AUTO	25°C	AUTO

13. Operation lamp (green)

14. TIMER lamp (yellow)

15. INTELLIGENT EYE lamp (green)

16. Signal receiver


- It receives signals from the remote control.
- When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changedbeep
 - Operation stopbeeeeeeep

■ Outdoor Unit

17. **Air inlet:** (Back and side)
18. **Air outlet**
19. **Refrigerant piping and inter-unit cable**
20. **Drain hose**
21. **Earth terminal:**
 - It is inside of this cover.

Appearance of the outdoor unit may differ from some models.

■ Remote control




- | | |
|---|--|
| <p>1. Signal transmitter:</p> <ul style="list-style-type: none"> • It sends signals to the indoor unit. <p>2. Display:</p> <ul style="list-style-type: none"> • It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation) <p>3. ECONO button:
ECONO operation</p> <p>4. POWERFUL button:
POWERFUL operation</p> <p>5. TEMPERATURE adjustment buttons:</p> <ul style="list-style-type: none"> • It changes the temperature setting. <p>6. ON/OFF button:</p> <ul style="list-style-type: none"> • Press this button once to start operation.
Press once again to stop it. <p>7. MODE selector button:</p> <ul style="list-style-type: none"> • It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN) | <p>8. QUIET button: OUTDOOR UNIT QUIET operation</p> <p>9. FAN setting button:</p> <ul style="list-style-type: none"> • It selects the air flow rate setting. <p>10. SWING button:</p> <ul style="list-style-type: none"> • Adjusting the Air Flow Direction <p>11. COMFORT AIRFLOW button:</p> <ul style="list-style-type: none"> • COMFORT AIRFLOW operation <p>12. SENSOR button:</p> <ul style="list-style-type: none"> • INTELLIGENT EYE operation <p>13. ON TIMER button</p> <p>14. OFF TIMER button</p> <p>15. TIMER Setting button:</p> <ul style="list-style-type: none"> • It changes the time setting. <p>16. TIMER CANCEL button:</p> <ul style="list-style-type: none"> • It cancels the timer setting. <p>17. CLOCK button</p> <p>18. RESET button:</p> <ul style="list-style-type: none"> • Restart the unit if it freezes. • Use a thin object to push. |
|---|--|


Names of Parts

FTK(X)S 20/25/35 C

■ Indoor Unit



Outdoor Unit



Indoor Unit

1. **Air filter**
2. **Air purifying filter with photocatalytic deodorizing function:**
 - These filters are attached to the inside of the air filters.
3. **Air inlet**
4. **Front panel**
5. **Panel tab**
6. **Room temperature sensor:**
 - It senses the air temperature around the unit.
7. **INTELLIGENT EYE sensor:**
 - It detects the movements of people and automatically switches between normal operation and energy saving operation.
8. **Display**
9. **Air outlet**
10. **Flaps (horizontal blades)**
11. **Louvers (vertical blades):**
 - The louvers are inside of the air outlet.

12. Indoor Unit ON/OFF switch:

- Push this switch once to start operation. Push once again to stop it.
- This switch is useful when the remote control is missing.
- the operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
FTKS	COOL	22°C	AUTO
FTXS	AUTO	25°C	AUTO

13. Operation lamp (green)

14. TIMER lamp (yellow)

15. HOME LEAVE lamp (red)

16. Signal receiver


- It receives signals from the remote control.
- When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changedbeep
 - Operation stopbeeeeeeep

Outdoor Unit

17. **Air inlet:** (Back and side)
18. **Air outlet**
19. **Refrigerant piping and inter-unit cable**
20. **Drain hose**
21. **Earth terminal:**
 - It is inside of this cover.
22. **Outside air temperature sensor:**
 - (Back side) it senses the ambient temperature around the unit.

Appearance of the outdoor unit may differ from some models.

■ Remote control




- | | |
|---|--|
| <p>1. Signal transmitter:</p> <ul style="list-style-type: none"> It sends signals to the indoor unit. <p>2. Display:</p> <ul style="list-style-type: none"> It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation) <p>3. HOME LEAVE button:
HOME LEAVE operation</p> <p>4. POWERFUL button:
POWERFUL operation</p> <p>5. TEMPERATURE adjustment buttons:</p> <ul style="list-style-type: none"> It changes the temperature setting. <p>6. ON/OFF button:</p> <ul style="list-style-type: none"> Press this button once to start operation.
Press once again to stop it. <p>7. MODE selector button:</p> <ul style="list-style-type: none"> It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN) | <p>8. QUIET button: OUTDOOR UNIT QUIET operation</p> <p>9. FAN setting button:</p> <ul style="list-style-type: none"> It selects the air flow rate setting. <p>10. SWING button</p> <p>11. SENSOR button:</p> <ul style="list-style-type: none"> INTELLIGENT EYE operation <p>12. ON TIMER button</p> <p>13. OFF TIMER button</p> <p>14. TIMER Setting button:</p> <ul style="list-style-type: none"> It changes the time setting. <p>15. TIMER CANCEL button:</p> <ul style="list-style-type: none"> It cancels the timer setting. <p>16. CLOCK button</p> <p>17. RESET button:</p> <ul style="list-style-type: none"> Restart the unit if it freezes. Use a thin object to push. |
|---|--|


Names of Parts

FTK(X)S 50/60/71 F

■ Indoor Unit



■ Outdoor Unit



■ Indoor Unit

1. Air filter
2. Titanium Apatite Photocatalytic Air-Purifying Filter
3. Air inlet
4. Front panel
5. Panel tab
6. INTELLIGENT EYE sensor:
 - It detects the movements of people and automatically switches between normal operation and energy saving operation.
7. Room temperature sensor:
 - It senses the air temperature around the unit.
8. Display
9. Air outlet
10. Flaps (horizontal blades)
11. Louvers (vertical blades):
 - The louvers are inside of the air outlet.
12. Operation lamp (green)
13. TIMER lamp (yellow)

14. HOME LEAVE lamp (red)
 - Lights up when you use HOME LEAVE Operation.
15. Indoor Unit ON/OFF switch:
 - Push this switch once to start operation. Push once again to stop it.
 - This switch is useful when the remote control is missing.
 - the operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
FTKS	COOL	22°C	AUTO
FTXS	AUTO	25°C	AUTO


16. Signal receiver
 - It receives signals from the remote control.
 - When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changedbeep
 - Operation stopbeeeep

■ Outdoor Unit

17. Air inlet: (Back and side)
18. Air outlet
19. Refrigerant piping and inter-unit cable
20. Drain hose
21. Earth terminal:
 - It is inside of this cover.

Appearance of the outdoor unit may differ from some models.

Remote control



1. Signal transmitter:

- It sends signals to the indoor unit.

2. Display:

- It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation)

3. HOME LEAVE button:

HOME LEAVE operation

4. POWERFUL button:

POWERFUL operation

5. TEMPERATURE adjustment buttons:

- It changes the temperature setting.

6. ON/OFF button:

- Press this button once to start operation.
Press once again to stop it.

7. MODE selector button:

- It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN)

8. QUIET button: OUTDOOR UNIT QUIET operation

9. FAN setting button:

- It selects the air flow rate setting.

10. SENSOR button: INTELLIGENT EYE operation

11. SWING button

- Flap (Horizontal blade)

12. SWING button

- Louver (Vertical blades)

13. ON TIMER button

14. OFF TIMER button

15. TIMER Setting button:

- It changes the time setting.

16. TIMER CANCEL button:

- It cancels the timer setting.

17. CLOCK button


18. RESET button:

- Restart the unit if it freezes.
- Use a thin object to push.


Names of Parts

FTXG 25/35 E, CTXG 50 E

■ Indoor Unit



■ Outdoor Unit



■ Indoor Unit

1. Air filter
2. Titanium Apatite Photocatalytic Air-Purifying Filter:
 - These filters are attached to the inside of the air filters.
3. Air inlet
4. Front panel
5. Supporting plate:
 - The supporting plate is used to support the front panel during maintenance.
6. Panel tab
7. Flaps (horizontal blades)
8. Air outlet
9. Louvers (vertical blades):
 - The louvers are inside of the air outlet.
10. Outlet vent panel
11. Display

12. Indoor Unit ON/OFF switch:

- Push this switch once to start operation. Push once again to stop it.
- This switch is useful when the remote control is missing.
- the operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
F(C)TXG	AUTO	25°C	AUTO

13. Room temperature sensor:

- it senses the air temperature around the unit.

14. Operation lamp (green)

15. Timer lamp (Yellow)

16. INTELLIGENT EYE lamp (green)

17. INTELLIGENT EYE sensor:

- It detects the movements of people and automatically switches between normal operation and energy saving operation.

18. Signal receiver


- It receives signals from the remote control.
- When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changedbeep
 - Operation stopbeeeeeep

■ Outdoor Unit

- | | |
|---|--|
| <ol style="list-style-type: none"> 19. Air inlet: (Back and side) 20. Air outlet 21. Refrigerant piping and inter-unit cable | <ol style="list-style-type: none"> 22. Drain hose 23. Earth terminal: <ul style="list-style-type: none"> • It is inside of this cover. |
|---|--|

Appearance of the outdoor unit may differ from some models.

■ Remote control




- | | |
|--|---|
| <p>1. Signal transmitter:</p> <ul style="list-style-type: none"> It sends signals to the indoor unit. <p>2. Display:</p> <ul style="list-style-type: none"> It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation) <p>3. SENSOR button:
INTELLIGENT EYE operation</p> <p>4. POWERFUL button:
POWERFUL operation</p> <p>5. TEMPERATURE adjustment buttons:</p> <ul style="list-style-type: none"> It changes the temperature setting. <p>6. ON/OFF button:</p> <ul style="list-style-type: none"> Press this button once to start operation.
Press once again to stop it. <p>7. MODE selector button:</p> <ul style="list-style-type: none"> It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN) | <p>8. SILENT button: OUTDOOR UNIT SILENT operation</p> <p>9. FAN setting button:</p> <ul style="list-style-type: none"> It selects the air flow rate setting. <p>10. SWING button</p> <ul style="list-style-type: none"> Flap (Horizontal blade) <p>11. SWING button</p> <ul style="list-style-type: none"> Louver (Vertical blades) <p>12. COMFORT AIRFLOW mode button</p> <p>13. ON TIMER button</p> <p>14. OFF TIMER button</p> <p>15. TIMER Setting button:</p> <ul style="list-style-type: none"> It cancels the time setting. <p>16. TIMER CANCEL button:</p> <ul style="list-style-type: none"> It cancels the timer setting. <p>17. CLOCK button</p> |
|--|---|


Names of Parts

FDK(X)S 25/35/50/60 C, FDK(X)S 25/35 E

■ Indoor Unit



■ Outdoor Unit



■ Indoor Unit

1. **Air outlet**
2. **Air outlet grille:**
 - (Field supply) Appearance of the Air inlet grille may differ with some models.
3. **Display, Control panel**
4. **Suction grille:**
 - (option) Appearance of the Air outlet grille an Air inlet grille may differ with some models.
5. **Air inlet**
6. **Room temperature sensor:**
 - The louvers are inside of the air outlet.
7. **Operation lamp (green)**
8. **TIMER lamp (Yellow)**
9. **HOME LEAVE lamp (red):**
 - Lights up when you use HOME LEAVE operation.

10. Indoor Unit ON/OFF switch:

- Push this switch once to start operation. Push once again to stop it.
- This switch is useful when the remote control is missing.
- **the operation mode refers to the following table.**


	Mode	Temperature setting	Air flow rate
F(C)DKS	COOL	22°C	AUTO
F(C)DXS	AUTO	25°C	AUTO

■ Outdoor Unit

11. **Air inlet:** (Back and side)
12. **Refrigerant piping and inter-unit cable**
13. **Drain hose**
14. **Earth terminal:**
 - It is inside of this cover.
15. **Air outlet**

Appearance of the outdoor unit may differ from some models.

■ Remote control




- | | |
|---|--|
| <p>1. Signal transmitter:</p> <ul style="list-style-type: none"> It sends signals to the indoor unit. <p>2. Display:</p> <ul style="list-style-type: none"> It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation) <p>3. HOME LEAVE button:
HOME LEAVE operation</p> <p>4. POWERFUL button:
POWERFUL operation</p> <p>5. TEMPERATURE adjustment buttons:</p> <ul style="list-style-type: none"> It changes the temperature setting. <p>6. ON/OFF button:</p> <ul style="list-style-type: none"> Press this button once to start operation.
Press once again to stop it. <p>7. MODE selector button:</p> <ul style="list-style-type: none"> It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN) | <p>8. QUIET button: OUTDOOR UNIT QUIET operation</p> <p>9. FAN setting button:</p> <ul style="list-style-type: none"> It selects the air flow rate setting. <p>10. ON TIMER button</p> <p>11. OFF TIMER button</p> <p>12. TIMER Setting button:</p> <ul style="list-style-type: none"> It changes the time setting. <p>13. TIMER CANCEL button:</p> <ul style="list-style-type: none"> It cancels the timer setting. <p>14. CLOCK button</p> <p>15. RESET button:</p> <ul style="list-style-type: none"> Restart the unit if it freezes. Use a thin object to push. |
|---|--|

Names of Parts

FLK(X)S 25/35/50/60 B

■ Indoor Unit

The indoor unit can be installed either to the ceiling or to a wall. The descriptions contained in this manual show the case when installation is being carried out to the ceiling. (The methods of operation used are the same when installing to a wall.)




■ Opening the front panel

How to open the front panel

CAUTION

- Before opening the front panel, be sure to stop the operation and turn the breaker OFF.

■ Outdoor Unit



■ Indoor Unit

1. **Louvers (vertical blades):**
 - The louvers are inside of the air outlet.
2. **Air outlet**
3. **Flaps (horizontal blades)**
4. **Panel tab**
5. **Air inlet**
6. **Display**
7. **Air filter**
8. **Photocatalytic deodorizing filter or Air purifying filter:**
 - These filters are attached to the inside of the air filters.
9. **Front panel**
10. **Operation lamp (green)**
11. **TIMER lamp (Yellow)**
12. **HOME LEAVE lamp (red).**
 - Lights up when you use HOME LEAVE Operation.

13. **Indoor Unit ON/OFF switch:**
 - Push this switch once to start operation. Push once again to stop it.
 - This switch is useful when the remote control is missing.
 - Push the switch using an object with a sharp tip, such as a pen.
 - the operation mode refers to the following table.

	Mode	Temperature setting	Air flow rate
FLKS	COOL	22°C	AUTO
FLXS	AUTO	25°C	AUTO


14. **Signal receiver**
 - It receives signals from the remote control.
 - When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changedbeep
 - Operation stopbeeeeeeep

■ Outdoor Unit

15. **Air inlet:** (Back and side)
16. **Air outlet**
17. **Refrigerant piping and inter-unit cable**
18. **Drain hose**
19. **Earth terminal:**
 - It is inside of this cover.

Appearance of the outdoor unit may differ from some models.

■ Remote control




- | | |
|---|---|
| <p>1. Signal transmitter:</p> <ul style="list-style-type: none"> It sends signals to the indoor unit. <p>2. Display:</p> <ul style="list-style-type: none"> It displays the current settings.
(In this illustration, each section is shown with all its displays ON for the purpose of explanation) <p>3. HOME LEAVE button:
HOME LEAVE operation</p> <p>4. POWERFUL button:
POWERFUL operation</p> <p>5. TEMPERATURE adjustment buttons:</p> <ul style="list-style-type: none"> It changes the temperature setting. <p>6. ON/OFF button:</p> <ul style="list-style-type: none"> Press this button once to start operation.
Press once again to stop it. <p>7. MODE selector button:</p> <ul style="list-style-type: none"> It selects the operation mode.
(AUTO/DRY/COOL/HEAT/FAN) | <p>8. QUIET button: OUTDOOR UNIT QUIET operation</p> <p>9. FAN setting button:</p> <ul style="list-style-type: none"> It selects the air flow rate setting. <p>10. SWING button</p> <p>11. ON TIMER button</p> <p>12. OFF TIMER button</p> <p>13. TIMER Setting button:</p> <ul style="list-style-type: none"> It changes the time setting. <p>14. TIMER CANCEL button:</p> <ul style="list-style-type: none"> It cancels the timer setting. <p>15. CLOCK button</p> <p>16. RESET button:</p> <ul style="list-style-type: none"> Restart the unit if it freezes. Use a thin object to push. |
|---|---|

2.1.4 Preparation Before Operation

■ To set the batteries

1. Slide the front cover to take it off.
2. Set two dry batteries (AAA).
3. Set the front cover as before.




ATTENTION

■ About batteries

- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- When the system is not used for a long time, take the batteries out.
- We recommend replacing once a year, although if the remote control display begins to fade or if reception deteriorates, please replace with new alkali batteries. Do not use manganese batteries.
- The attached batteries are provided for the initial use of the system. The usable period of the batteries may be short depending on the manufactured date of the air conditioner.


■ To operate the remote control

- To use the remote control, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote control, such as a curtain, the unit will not operate.
- Do not drop the remote control. Do not get it wet.
- The maximum distance for communication is about 4m.



■ To fix the remote control holder on the wall

1. Choose a place from where the signals reach the unit.
2. Fix the holder to a wall, a pillar, etc. with the screws supplied with the holder.
3. Place the remote control in the remote control holder.



- To remove, pull it upwards.

ATTENTION


- About remote control
 - Never expose the remote control to direct sunlight.
 - Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
 - Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
 - If the remote control signals happen to operate another appliance, move that appliance to some-where else, or consult the shop.

■ To set the clock

1. Press "CLOCK button".
0:00 is displayed.
⌚ blinks.
2. Press "TIMER setting button" to set the clock to the present time.
Holding down "▲" or "▼" button rapidly increases or decreases the time display.
3. Press "CLOCK button".
:blinks.

■ Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)



NOTES

■ Tips for saving energy

- Be careful not to cool (heat) the room too much. Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

Recommended temperature setting
For cooling: 26°C – 28°C
For heating: 20°C – 24°C

■ Please note

- The air conditioner always consumes 15-35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.

Mode	Initial setting	Selectable range
COOL	Outdoor temperature: [2/3/MXS] –10 to 46°C [4/5MK(X)S] –10 to 46°C [RK(X)S] –10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the out-door unit only.) • Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature: [2/3/4/5MXS] –15 to 15.5°C [RXS] –15 to 18°C Indoor temperature: 10 to 30°C	<ul style="list-style-type: none"> • A safety device may work to stop the operation.
DRY	Outdoor temperature: [2/3/MXS] –10 to 46°C [4/5MK(X)S] –10 to 46°C [RK(X)S] –10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. • Condensation may occur on the indoor unit and drip.

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

2.1.5 Auto Dry Cool Heat Fan Operation

The air conditioner operates with the operation mode of your choice. From the next time on, the air conditioner will operate with the same operation mode.

■ To start operation

1. Press “MODE selector button” and select a operation mode.

- Each pressing of the button advances the mode setting in sequence.

Ⓐ : AUTO

☐ : DRY

❄ : COOL



☀ : HEAT

🌀 : FAN



2. Press “ON/OFF button” .

- The OPERATION lamp lights up.



■ To stop operation

3. Press “ON/OFF button” again.

- Then OPERATION lamp goes off.


■ To change the temperature setting

4. Press “TEMPERATURE adjustment button”.

DRY or FAN mode	AUTO or COOL or HEAT mode
The temperature setting is not variable.	Press “▲” to raise the temperature and press “▼” to lower the temperature.
	Set to the temperature you like

■ To change the air flow rate setting

5. Press "FAN setting button".

DRY mode	AUTO or COOL or HEAT or FAN mode
The air flow rate setting is not variable	Five levels of air flow rate setting from " " to " " plus " " " " are available. 

- Indoor unit quiet operation

When the air flow is set to " ", the noise from the indoor unit will become quieter.

Use this when making the noise quieter.

The unit might lose capacity when the air flow rate is set to a weak level.

NOTES

■ Note on HEAT operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

■ Note on COOL operation

- This air conditioner cools the room by blowing the hot air in the room outside, so if the outside temperature is high, performance drops.

■ Note on DRY operation

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and fan strength, so manual adjustment of these functions is unavailable.

■ Note on AUTO operation

- In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, you can manually select the operation mode and setting you like.

■ Note on air flow rate setting



- At smaller air flow rates, the cooling (heating) effect is also smaller.


2.1.6 Adjusting the air flow direction

FTK(X)S 20/25/35/50 D

You can adjust the air flow direction to increase your comfort.

■ To adjust the horizontal blades (flaps)

1. Press “SWING button”.
 The display on the LCD and the flaps will begin to swing.
2. When the flaps have reached the desired position, press “SWING button” once more.
 The flaps will stop moving.
 disappears from the LCD.




■ To adjust the vertical blades (louvers)

Hold the knob and move the louvers.


(You will find a knob on the left-side and the right-side blades.)

- When the unit is installed in the corner of a room, the direction of the louvers should be facing away from the wall. If they face the wall, the wall will block off the wind, causing the cooling (or heating) efficiency to drop.



■ To start COMFORT AIRFLOW operation

1. Press “COMFORT AIRFLOW button”.


- The flap position will change, preventing air from blowing directly on the occupants of the room.
- “” is displayed on the LCD.

(COOL/DRY) The flap will go up.

(HEAT) The flap will go down.

■ To cancel the COMFORT AIRFLOW operation

2. Press “COMFORT AIRFLOW button” again.

- The flaps will return to the memory position from before COMFORT AIRFLOW mode.
- “” disappears from the LCD.

Notes on COMFORT AIRFLOW operation


- POWERFUL operation and COMFORT AIRFLOW operation cannot be used at the same time. Priority is given to POWERFUL operation.

Notes on flaps and louvres angles

- When “**SWING button**” is selected, the flaps swinging range depends on the operation mode. (See the figure.)

■ ATTENTION

- Always use a remote control to adjust the flaps angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvres. Inside the air outlet, a fan is rotating at a high speed.






Adjusting the air flow direction

FTK(X)S 20/25/35 C

You can adjust the air flow direction to increase your comfort.

■ To adjust the horizontal blades (flaps)


1. Press "SWING button".
 The display on the LCD and the flaps will begin to swing.
2. When the flaps have reached the desired position, press "SWING button" once more.
 The flaps will stop moving.
 disappears from the LCD.



■ To adjust the vertical blades (louvers)

Hold the knob and move the louvers.

(You will find a knob on the left-side and the right-side blades.)




Notes on flaps and louvers angles

- When “**SWING button**” is selected, the flaps swinging range depends on the operation mode. (See the figure.)

■ ATTENTION

- Always use a remote control to adjust the flaps angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvers. Inside the air outlet, a fan is rotating at a high speed.








Adjusting the air flow direction

FTK(X)S 50/60/71 F





You can adjust the air flow direction to increase your comfort.

■ To adjust the horizontal blades (flaps)





1. Press "SWING button ".
 - "  "The display on the LCD and the flaps will begin to swing.
2. When the flaps have reached the desired position, press "SWING button  " once more.
 - The flaps will stop moving.
 - "  "disappears from the LCD.




■ To adjust the vertical blades (louvers)

3. Press "SWING button ".
 - "  " is displayed on the LCD.
4. When the louvers have reached the desired position, press the "SWING button  " once more.
 - The louvers will stop moving.
 - "  " disappears from the LCD.

■ To 3-D Airflow

1. 3. Press the “SWING button ” and the “SWING button ”:
the “” and “” display will light up and the flap and louvers will move in turn.

■ To cancel 3-D Airflow


2. 4. Press either the “SWING button ” or the “SWING button ”.

Notes on louvers angles

■ ATTENTION

- Always use a remote control to adjust the louvers angles. Inside the air outlet, a fan is rotating at a high speed.

Notes on flap angle



•When “**SWING button**” is selected, the flaps swinging range depends on the operation mode. (See the figure.)

Three-Dimensional (3-D) Airflow

•Using three-dimensional airflow circulates cold air, which tends to collect at the bottom of the room, and hot air, which tends to collect near the ceiling, throughout the room, preventing areas of cold and hot developing.

■ ATTENTION



- Always use a remote control to adjust the flaps angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvers. Inside the air outlet, fan is rotating at a high speed.


Adjusting the air flow direction

FTXG 25/35 E, CTXG 50 E


You can adjust the air flow direction to increase your comfort.

■ To adjust the horizontal blades (flaps)





1. Press “SWING button”.
 The display on the LCD.
2. When the flaps have reached the desired position, press “SWING button” once more.
 The flaps will stop moving.
 disappears from the LCD.



■ To adjust the vertical blades (louvers)

3. Press “SWING button ”.
 - “  ” is displayed on the LCD.
4. When the louvers have reached the desired position, press the “SWING button  ” once more.
 - The louvers will stop moving.

■ To 3-D Airflow


3. Press the “SWING button  ” and the “SWING button  ”:
 the “  ” and “  ” display will light up and the flap and louvers will move in turn.

■ To cancel 3-D Airflow

4. Press either the “SWING button  ” or the “SWING button  ”.


■ To start COMFORT AIRFLOW operation

5. Press “COMFORT AIRFLOW button”.


- The flap orientation will change, preventing air from blowing directly on the occupants of the room.
 - “” is displayed on LCD.
- <COOL/DRY> The flap will go up.
<HEAT> The flap will go down.

■ To cancel COMFORT AIRFLOW operation

1. Press “COMFORT AIRFLOW button” again.

- The flaps will return to the memory position from before COMFORT AIRFLOW mode.
- “” disappears from the LCD.

Notes on flaps and louvers angles

- When “SWING button ” is selected, the flaps swinging range depends on the operation mode. (See the figure.)

Three-Dimensional (3-D) Airflow

- Using three-dimensional airflow circulates cold air, which tends to collect at the bottom of the room, and hot air, which tends to collect near the ceiling, throughout the room, preventing areas of cold and hot developing.


Three-Dimensional (3-D) Airflow

- The air flow set automatically.
- The air direction is as shown in the figure at right.


■ ATTENTION

- Always use a remote control to adjust the flaps angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Always use a remote controller to adjust the louvers angles.


In COOL or DRY mode



In HEAT or FAN mode



In COMFORT AIRFLOW mode






Adjusting the air flow direction

FLK(X)S 25/35/50/60 B

You can adjust the air flow direction to increase your comfort.


■ To adjust the horizontal blades (flaps)

1. Press "SWING button".
 The display on the LCD and the flaps will begin to swing.
2. When the flaps have reached the desired position, press "SWING button" once more.
 The flaps will stop moving.
 disappears from the LCD.



■ To adjust the vertical blades (louvers)

- When adjusting the louver, use a robust and stable stool and watch your steps carefully. Hold the knob and move the louvers. (You will find a knob on the left side and the right side blades.)




Notes on flap and louvers angles.

- Unless [SWING] is selected, you should set the flap at a near-horizontal angle in COOL or DRY mode to obtain the best performance.
- In COOL or DRY mode, if the flap is fixed at a downward position, the flap automatically moves in about 60 minutes to prevent condensation on it.

■ ATTENTION

- Always use a remote control to adjust the flap angle. If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.
- Be careful when adjusting the louvers. Inside the air outlet, a fan is rotating at a high speed.



2.1.7 POWERFUL Operation


POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity.

■ To start POWERFUL operation

1. Press "POWERFUL button".
 - POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
 - When using POWERFUL operation, there are some functions which are not available.
 - "❄️" is displayed on the LCD

■ To cancel POWERFUL operation

2. Press "POWERFUL button" again.
 - "❄️" disappears from the LCD.



NOTES

■ Notes on POWERFUL operation

- POWERFUL Operation cannot be used together with QUIET Operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL Operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and the "❄️" disappears from the LCD.
- **In COOL and HEAT mode**
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting. The temperature and air flow settings are not variable.
- **In DRY mode**
The temperature setting is lowered by 2.5°C and the air flow rate is slightly increased.
- **In FAN mode**
The air flow rate is fixed to the maximum setting.
- **When using priority-room setting**
See "Note for multi system".

2.1.8 OUTDOOR UNIT QUIET Operation


OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

■ To start OUTDOOR UNIT QUIET operation

1. Press "QUIET button".
 - "  " is displayed on the LCD.


■ To cancel OUTDOOR UNIT QUIET operation

2. Press "QUIET button" again.
 - "  " disappears from the LCD.



NOTES


■ Note on OUTDOOR UNIT QUIET operation

- If using a multi system, this function will work only when the OUTDOOR UNIT QUIET operation is set on all operated indoor units.
However, if using priority-room setting, see "Note for multi system".
- This function is available in COOL, HEAT, and AUTO modes.
(This is not available in FAN and DRY mode.)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.
Priority is given to the function of whichever button is pressed last.
- If operation is stopped using the remote control or the main unit ON/OFF switch when using OUTDOOR UNIT QUIET operation, "  " will remain on the remote control display.


2.1.9 ECONO Operation


ECONO operation is a function which enables efficient operation by lowering the maximum power consumption value.

■ To start ECONO operation


1. Press "ECONO button".
 - "  " is displayed on the LCD.

■ To cancel ECONO operation

2. Press "ECONO button" again.
 - "  " disappears from the LCD.



NOTES


- ECONO Operation can only be set when the unit is running.
Pressing the operation stop button causes the settings to be canceled, and the "  " disappears from the LCD.
- ECONO operation is a function which enables efficient operation by limiting the power consumption of the outdoor unit (operating frequency).
- ECONO operation functions in AUTO, COOL, DRY and HEAT modes.
- POWERFUL operation and ECONO operation cannot be used at the same time.
Priority is given to POWERFUL operation.
- Power consumption may not drop even if ECONO operation is used, when the level of power consumption is already low.

2.1.10 HOME LEAVE Operation

HOME LEAVE operation is a function which allows you to record your preferred temperature and air flow rate settings.


■ To start HOME LEAVE operation

1. Press "HOME LEAVE button".
 - "🏠" is displayed on the LCD.
 - The HOME LEAVE lamp lights up.



■ To cancel HOME LEAVE operation

2. Press "HOME LEAVE button" again.
 - "🏠" disappears from the LCD.
 - The HOME LEAVE lamp goes off.



Before using HOME LEAVE operation

■ To set the temperature and air flow rate for HOME LEAVE operation

When using HOME LEAVE operation for the first time, please set the temperature and air flow rate for HOME LEAVE operation. Record your preferred temperature and air flow rate.

	Initial setting		Selectable range	
	temperature	Air flow rate	temperature	Air flow rate
Cooling	25°	⏏	18-32°C	5 step, ⏏ and ⏏
Heating	25°	⏏	10-30°C	5 step, ⏏ and ⏏

1. Press "HOME LEAVE button". Make sure "🏠" is displayed in the remote control display.
2. Adjust the set temperature with "▲" or "▼" as you like.
3. Adjust the air flow rate with "FAN" setting button as you like.

Home leave operation will run with these settings the next time you use the unit. To change the recorded information, repeat steps 1 – 3.

■ What's the HOME LEAVE operation?


Is there a set temperature and air flow rate which is most comfortable, a set temperature and air flow rate which you use the most? HOME LEAVE operation is a function that allows you to record your favorite set temperature and air flow rate. You can start your favorite operation mode simply by pressing the HOME LEAVE button on the remote control. This function is convenient in the following situations.

■ Useful in these cases

1. Use as an energy-saving mode

Set the temperature 2-3°C higher (cooling) or lower (heating) than normal. Setting the fan strength to the lowest setting allows the unit to be used in energy-saving mode. Also convenient for use while you are out or sleeping.


• Every day before you leave the house...



When you go out, push the "HOME LEAVE Operation" button, and the air conditioner will adjust capacity to reach the preset temperature for HOME LEAVE Operation.




When you return, you will be welcomed by a comfortably air conditioned room.



Push the "HOME LEAVE Operation" button again, and the air conditioner will adjust capacity to the set temperature for normal operation.


• Before bed...



Set the unit to HOME LEAVE Operation before leaving the living room when going to bed.



The unit will maintain the temperature in the room at a comfortable level while you sleep.



When you enter the living room in the morning, the temperature will be just right. Disengaging HOME LEAVE Operation will return the temperature to that set for normal operation. Even the coldest winters will pose no problem!

2. Use as a favorite mode

Once you record the temperature and air flow rate settings you most often use, you can retrieve them by pressing HOME LEAVE button. You do not have to go through troublesome remote control operations.

NOTES


- Once the temperature and air flow rate for HOME LEAVE operation are set, those settings will be used whenever HOME LEAVE operation is used in the future. To change these settings, please refer to the "Before using HOME LEAVE operation" section above.
- HOME LEAVE operation is only available in COOL and HEAT mode. Cannot be used in AUTO, DRY, and FAN mode.
- HOME LEAVE operation runs in accordance with the previous operation mode (COOL or HEAT) before using HOME LEAVE operation.
- HOME LEAVE operation and POWERFUL operation cannot be used at the same time. Last button that was pressed has priority.
- The operation mode cannot be changed while HOME LEAVE operation is being used.
- When operation is shut off during HOME LEAVE operation, using the remote control or the indoor unit ON/OFF switch, "🏠" will remain on the remote control display.

2.1.11 INTELLIGENT EYE Operation


FTK(X)S 20/25/35/50 D

“INTELLIGENT EYE” is the infrared sensor which detects the human movement.



■ To start INTELLIGENT EYE operation

1. Press “SENSOR button”.
 - “  ” is displayed on the LCD.

■ To cancel the INTELLIGENT EYE operation

2. Press “SENSOR button” again.
 - “  ” disappears from the LCD.

[EX.]




“INTELLIGENT EYE” is useful for Energy Saving

■ Energy saving operation

- Change the temperature -2°C in heating / $+2^{\circ}\text{C}$ in cooling / $+2^{\circ}\text{C}$ in dry mode from set temperature.
- Decrease the air flow rate slightly in fan operation. (In FAN mode only)

Notes on “INTELLIGENT EYE”

- Application range is as follows.



- Sensor may not detect moving objects further than 7m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during powerful operation.
- Night set mode will not go on while you use INTELLIGENT EYE operation.

CAUTION


- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect objects it shouldn't as well as not detect objects it should.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

INTELLIGENT EYE Operation


FTK(X)S 20/25/35 C

“INTELLIGENT EYE” is the infrared sensor which detects the human movement.



■ To start INTELLIGENT EYE operation

1. Press “SENSOR button”.
 - “” is displayed on the LCD.

■ To cancel the INTELLIGENT EYE operation


2. Press “SENSOR button” again.
 - “” disappears from the LCD.

[EX.]



■ To adjust the angle of the INTELLIGENT EYE SENSOR

- You can adjust the angle of the INTELLIGENT EYE sensor to increase the detection area. (Adjustable angle: 15° to right and left of centre)
- Gently push and slide the sensor to adjust the angle.
- After adjusting the angle, wipe the sensor gently with a clean cloth, being careful not to scratch the sensor.




“INTELLIGENT EYE” is useful for Energy Saving

■ Energy saving operation

- Change the temperature -2°C in heating / $+2^{\circ}\text{C}$ in cooling / $+2^{\circ}\text{C}$ in dry mode from set temperature.
- Decrease the air flow rate slightly in fan operation. (In FAN mode only)

Notes on “INTELLIGENT EYE”

- Application range is as follows.



- Sensor may not detect moving objects further than 5m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during powerful operation.
- Night set mode will not go on while you use INTELLIGENT EYE operation.


⚠ CAUTION

- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect objects it shouldn't as well as not detect objects it should.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

FTK(X)S 50/60/71 F

“INTELLIGENT EYE” is the infrared sensor which detects the human movement.

■ To start INTELLIGENT EYE operation

1. Press “SENSOR button”.
 - “” is displayed on the LCD.

■ To cancel the INTELLIGENT EYE operation

2. Press “SENSOR button” again.
 - “” disappears from the LCD.

[EX.]

When somebody in the room

- Normal operation.




When nobody in the room

- 20 min. after, start energy saving operation.



Somebody back in the room

- Back to normal operation.




“INTELLIGENT EYE” is useful for Energy Saving

■ Energy saving operation

- Change the temperature -2°C in heating / $+2^{\circ}\text{C}$ in cooling / $+2^{\circ}\text{C}$ in dry mode from set temperature.
- Decrease the air flow rate slightly in fan operation. (In FAN mode only)

Notes on “INTELLIGENT EYE”

- Application range is as follows.



- Sensor may not detect moving objects further than 7m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during powerful operation.
- Night set mode will not go on during you use INTELLIGENT EYE operation.

CAUTION


- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect objects it shouldn't as well as not detect objects it should.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

INTELLIGENT EYE Operation


FTXG 25/35 E, CTXG 50 E

“INTELLIGENT EYE” is the infrared sensor which detects the human movement.

■ To start INTELLIGENT EYE operation

1. Press “SENSOR button”.
 - “” is displayed on the LCD.


■ To cancel the INTELLIGENT EYE operation

2. Press “SENSOR button” again.
 - “” disappears from the LCD.

[EX.]

When somebody in the room

- Normal operation.
- The INTELLIGENT EYE lamp Lights up.






When somebody in the room

- 20 min. after, start energy saving operation.
- The INTELLIGENT EYE lamp goes off.




Somebody back in the room

- Normal operation.
- The INTELLIGENT EYE lamp Lights up.


“INTELLIGENT EYE” is useful for Energy Saving

■ Energy saving operation

- Change the temperature -2°C in heating / $+2^{\circ}\text{C}$ in cooling / $+2^{\circ}\text{C}$ in dry mode from set temperature.
- Decrease the air flow rate slightly in fan operation. (In FAN mode only)

Notes on “INTELLIGENT EYE”

- Application range is as follows.



- Sensor may not detect moving objects further than 7m away. (Check the application range)
- Sensor detection sensitivity changes according to indoor unit location, the speed of passersby, temperature range, etc.
- The sensor also mistakenly detects pets, sunlight, fluttering curtains and light reflected off of mirrors as passersby.
- INTELLIGENT EYE operation will not go on during powerful operation.
- Night set mode will not go on during you use INTELLIGENT EYE operation.

CAUTION


- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area. This sensor can detect objects it shouldn't as well as not detect objects it should.
- Do not hit or violently push the INTELLIGENT EYE sensor. This can lead to damage and malfunction.

2.1.12 TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.


■ To use OFF TIMER operation

- Check that the clock is correct.
If not, set the clock to the present time.
- 1. Press “OFF TIMER button”.
0:00 is displayed.
⊖-| blinks.
- 2. Press “TIMER Setting button” until the time setting reaches the point you like.
 - Every pressing of either button increases or decreases the time setting by 10 minutes.
Holding down either button changes the setting rapidly.
- 3. Press “OFF TIMER button” again.
 - The TIMER lamp lights up.



■ To cancel the OFF TIMER operation

4. Press “CANCEL button”.
 - The TIMER lamp goes off.




NOTES


- When TIMER is set, the present time is not displayed.
- Once you set ON, OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote control batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user. (maximum approx. 10 minutes)

■ NIGHT SET MODE

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.
1. Press “ON TIMER button”.
 - 6:00 is displayed.
 - “” blinks.
 2. Press “TIMER Setting button” until the time setting reaches the point you like.
 - Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
 3. Press “ON TIMER button” again.
 - The TIMER lamp lights up..





■ To cancel ON TIMER operation

4. Press “CANCEL button”.
 - The TIMER lamp goes off.

■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.



ATTENTION

- In the following cases, set the timer again.
 - After a breaker has turned OFF.
 - After a power failure.
 - After replacing batteries in the remote control.

2.1.13 Note for Multi System


<<What is a “Multi System”? >>

This system has one outdoor unit connected to multiple indoor units.

■ Selecting the Operation Mode

1. With the Priority Room Setting present but inactive or not present

When more than one indoor unit is operating, priority is given to the first unit that was turned on. In this case, set the units that are turned on later to the same operation mode (*1) as the first unit.



Otherwise, they will enter the Standby Mode, and the operation lamp will flash; this does not indicate malfunction.

(*1)

- COOL, DRY and FAN mode may be used at the same time.
- AUTO mode automatically selects COOL mode or HEAT mode based on the room temperature. Therefore, AUTO mode is available when selecting the same operation mode as that of the room with the first unit to be turned on.

<CAUTION>

Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.

If the operation mode of the first room is **FAN Mode**, then using **Heating Mode** in any room after this will give priority to **heating**. In this situation, the air conditioner running in **FAN Mode** will go on standby, and the operation lamp will flash.

2. With the Priority Room Setting active

See “Priority Room Setting” on the next page.

■ NIGHT QUIET Mode (Available only for cooling operation)

NIGHT QUIET Mode requires initial programming during installation. Please consult your retailer or dealer for assistance. NIGHT QUIET Mode reduces the operation noise of the outdoor unit during the night time hours to prevent annoyance to neighbors.

- The NIGHT QUIET Mode is activated when the temperature drops 5°C or more below the highest temperature recorded that day. Therefore, when the temperature difference is less than 5°C, this function will not be activated.
- NIGHT QUIET Mode reduces slightly the cooling (heating) efficiency of the unit.

■ OUTDOOR UNIT QUIET Operation

1. With the Priority Room Setting present but inactive or not present

When using the OUTDOOR UNIT QUIET operation feature with the Multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controls.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using their remote control. However OUTDOOR UNIT QUIET operation display remains on the remote control for other rooms. We recommend you release all rooms using their remote controls.

2. With the Priority Room Setting active

See “Priority Room Setting” on the next page.

■ Cooling / Heating Mode Lock (Available only for heat pump models)

The Cooling / Heating Mode Lock requires initial programming during installation. Please consult your retailer or dealer for assistance. The Cooling / Heating Mode Lock sets the unit forcibly to either Cooling or Heating Mode. This function is convenient when you wish to set all indoor units connected to the Multi system to the same operation mode.

Note for Multi System

■ Priority Room Setting

The Priority Room Setting requires initial programming during installation. Please consult your retailer or dealer for assistance.

The room designated as the Priority Room takes priority in the following situations:

1. Operation Mode Priority

As the operation mode of the Priority Room takes precedence, the user can select a different operation mode from other rooms.

(Example)

* Room A is the Priority Room in the examples.

When COOL mode is selected in Room A while operating the following modes in Room B, C and D:

Operation mode in Room B, C and D	Status of Room B, C and D when the unit in Room A is in COOL mode
COOL or DRY or FAN	Current operation mode maintained
HEAT	The unit enters Standby Mode. Operation resumes when the Room A unit stops operating.
AUTO	If the unit is set to COOL mode, operation continues. If set to HEAT mode, it enters Standby Mode. Operation resumes when the Room A unit stops operating.

2. Priority when POWERFUL operation is used

(Example)

* Room A is the Priority Room in the examples.

The indoor units in Rooms A,B,C and D are all operating. If the unit in Room A enters POWERFUL operation, operation capacity will be concentrated in Room A. In such a case, the cooling (heating) efficiency of the units in Rooms B,C and D may be slightly reduced.

3. Priority when using OUTDOOR UNIT SILENT operation

(Example)

* Room A is the Priority Room in the examples.

Just by setting the unit in Room A to SILENT operation, the air conditioner starts OUTDOOR UNIT SILENT operation.

You don't have to set all the operated indoor units to QUIET operation.

2.1.14 Care and cleaning

FTK(X)S 20/25/35/50 D



CAUTION

Before cleaning, be sure to stop the operation and turn the breaker OFF.

UNITS

■ Indoor unit, Outdoor unit and Remote control

1. Wipe them with dry soft cloth.

■ Front panel

1. **Open the front panel.**

- Hold the panel by the tabs on the two sides and lift it until it stops with a click.

2. **Remove the front panel.**




- Lift the front panel up, slide it slightly to the right, and remove it from the horizontal axle.

3. **Clean the front panel.**

- Wipe it with a soft cloth soaked in water.
- Only neutral detergent may be used.
- In case of washing the panel with water, dry it with cloth, dry it up in the shade after washing.

4. **Attach the front panel.**

- Set the 2 keys of the front panel into the slots and push them in all the way.
- Close the front panel slowly and push the panel at the 3 points. (1 on each side and 1 in the middle).




CAUTION


- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40 °C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front panel is securely fixed.

FILTERS


1. **Open the front panel.**
2. **Pull out the air filters.**
 - Push a little upwards the tab at the center of each air filter, then pull it down.



3. **Take off the Titanium Apatite Photocatalytic Air-Purifying Filter.**
 - Hold the recessed parts of the frame and unhook the four claws.
4. **Clean or replace each filter.**
 - See figure.




5. **Set the air filter Titanium Apatite Photocatalytic Air-Purifying Filter as they were and close the front panel.**
 - Insert claws of the filters into slots of the front panel. Close the front panel slowly and push the panel at the 3 points. (1 on each side and 1 in the middle.)




■ Air Filter

1. **Wash the air filters with water or clean them with vacuum cleaner.**
 - If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
 - It is recommended to clean the air filters every two weeks.



■ Titanium Apatite Photocatalytic Air-Purifying Filter

The Titanium Apatite Photocatalytic Air-Purifying Filter can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.



[Maintenance]

1. **Remove dust with a vacuum cleaner and wash lightly with water.**
2. **If it is very dirty, soak it for 10 to 15 minutes in water mixed with a neutral cleaning agent.**
3. **Do not remove filter from frame when washing with water.**
4. **After washing, shake off remaining water and dry in the shade.**
5. **Since the material is made out of paper, do not wring out the filter when removing water from it.**

[Replacement]

1. **Remove the tabs on the filter frame and replace with a new filter.**
 - Dispose of the old filter as flammable waste.

NOTES

- Operation with dirty filters:
 - (1) cannot deodorize the air. (2) cannot clean the air.
 - (3) results in poor heating or cooling. (4) may cause odour.
- To order Titanium Apatite Photocatalytic Air-Purifying Filter contact to the service shop where you bought the air conditioner.
- Dispose of old filters as burnable waste.

Item	Part No.
Titanium Apatite Photocatalytic Air-Purifying Filter. (without frame) 1 set	KAF970A46

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation
• If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

1. Operate the “FAN only” for several hours on a fine day to dry out the inside.
 - Press “MODE selector button” and select “FAN” operation.
 - Press “ON/OFF button” and start operation.
2. After operation stops, turn off the breaker for the room air conditioner.
3. Clean the air filters and set them again.
4. Take out batteries from the remote control.
 - When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation.

FTK(X)S 20/25/35 C

**CAUTION** Before cleaning, be sure to stop the operation and turn the breaker OFF.




UNITS

■ Indoor unit, outdoor unit and remote control

1. Wipe them with dry soft cloth.

■ Front panel

1. **Open the front panel.**
 - Hold the panel by the tabs on the two sides and lift it until it stops with a click.
2. **Remove the front panel.**
 - Supporting the front panel with one hand, release the lock by sliding down the knob with the other hand.
 - To remove the front panel, pull it toward yourself with both hands.
3. **Clean the front panel.**
 - Wipe it with a soft cloth soaked in water.
 - Only neutral detergent may be used.
 - In case of washing the panel with water, dry it with cloth, dry it up in the shade after washing.
4. **Attach the front panel.**
 - Set the 3 keys of the front panel into the slots and push them in all the way
 - Close the front panel slowly and push the panel at the 3 points (1 on each side and 1 in the middle.)
 - Check to see if the rotating axis in the upper center section is moving.




CAUTION


- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40°C, benzene, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front panel is securely fixed.

Filters

1. **Open the front panel.**
2. **Pull out the air filters.**
 - Push a little upwards the tab at the center of each air filter, then pull it down.
3. **Take off the air purifying filter with photocatalytic deodorizing function.**
 - Hold the recessed parts of the frame and unhook the four claws.




4. **Clean or replace each filter.**
 - See figure.
5. **Set the air filter and the air purifying filter with photocatalytic deodorizing function as they were and close the front panel.**
 - Insert claws of the filters into slots of the front panel. Close the front panel slowly and push the panel at the 3 points. (1 on each side and 1 in the middle.)




■ Air Filter

1. **Wash the air filters with water or clean them with vacuum cleaner.**
 - If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
 - It is recommended to clean the air filters every two weeks.



■ Air purifying filter with photocatalytic deodorizing function. (gray)

The Air Purifying filter with photocatalytic deodorizing function can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.



[Maintenance]

1. **Remove dust with a vacuum cleaner and wash lightly with water.**
2. **If it is very dirty, soak it for 10 to 15 minutes in water mixed with a neutral cleaning agent.**
3. **Do not remove filter from frame when washing with water.**
4. **After washing, shake off remaining water and dry in the shade.**
5. **Since the material is made out of paper, do not wring out the filter when removing water from it.**

[Replacement]

1. **Remove the tabs on the filter frame and replace with a new filter.**
 - Dispose of the old filter as flammable waste.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation <ul style="list-style-type: none"> If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

- Operate the “FAN only” for several hours on a fine day to dry out the inside.**
 - Press “MODE selector button” and select “FAN” operation.
 - Press “ON/OFF button” and start operation.
- After operation stops, turn off the breaker for the room air conditioner.**
- Clean the air filters and set them again.**
- Take out batteries from the remote controller.**
 - When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation.

NOTES

- Operation with dirty filters:
 - cannot deodorize the air.
 - cannot clean the air.
 - results in poor heating or cooling.
 - may cause odour.
- To order Titanium Apatite Photocatalytic Air-Purifying Filter contact the service shop where you bought the air conditioner.
- Dispose of old filters as non-flammable waste.

Item	Part No.
Air purifying filter with photocatalytic deodorizing function. (with frame) 1 set	KAF918A43
Air purifying filter with photocatalytic deodorizing function. (without frame) 1 set	KAF918A44

Care and cleaning

FTK(X)S 50/60/71 F



CAUTION

Before cleaning, be sure to stop the operation and turn the breaker OFF.

UNITS


■ Indoor unit, Outdoor unit and Remote control

1. Wipe them with dry soft cloth.

■ Front panel


1. Open the front panel.

- Hold the panel by the tabs on the two sides and lift it until it stops with a click.




2. Remove the front panel.

- Open the front panel further while sliding it to either the left or right and pulling it toward you. This will disconnect the rotation dowel on one side. Then disconnect the rotation dowel on the other side in the same manner.



3. Clean the front panel.

- Wipe it with a soft cloth soaked in water.
- Only neutral detergent may be used.
- In case of washing the grille with water, dry it with cloth, dry it up in the shade after washing.



4. Attach the front panel.

- Align the rotation dowels on the left and right of the front panel with the slots, then push them all the way in.
- Close the front panel slowly.
(Press the panel at both sides and the center).




CAUTION


- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front grille, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front grille, support the grille securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40 °C, benzene, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front grille is securely fixed.

FILTERS


1. **Open the front panel.**
2. **Pull out the air filters.**
 - Push a little upwards the tab at the center of each air filter, then pull it down.



3. **Take off the air purifying filter with photocatalytic deodorizing function.**
 - Press the top of the air-cleaning filter onto the tabs (3 tabs at top). Then press the bottom of the filter up slightly, and press it onto the tabs (3 at bottom).




4. **Clean or replace each filter.**
See figure.
5. **Set the air filter and the Titanium Apatite Photocatalytic Air-Purifying Filter as they were and close the front panel.**
 - Press the front panel at both sides and the center.



■ Air Filter

1. **Wash the air filters with water or clean them with vacuum cleaner.**
 - If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
 - It is recommended to clean the air filters every two weeks.



■ Titanium Apatite Photocatalytic Air-purifying Filter

The Titanium Apatite Photocatalytic Air-Purifying Filter can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.

[Maintenance]

1. **Remove dust with a vacuum cleaner and wash lightly with water.**
2. **If it is very dirty, soak it for 10 to 15 minutes in water mixed with a neutral cleaning agent.**
3. **After washing, shake off remaining water and dry in the shade.**
4. **Since the material is made out of paper, do not wring out the filter when removing water from it.**

[Replacement]

1. **Remove the tabs on the filter frame and replace with a new filter.**
 - Dispose of the old filter as flammable waste.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation. • If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

1. **Operate the “FAN only” for several hours on a fine day to dry out the inside.**
 - Press “MODE” button and select “FAN” operation.
 - Press “ON/OFF” button and start operation.
2. **After operation stops, turn off the breaker for the room air conditioner.**
3. **Clean the air filters and set them again.**
4. **Take out batteries from the remote control.**
 - When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation.

NOTES

- Operation with dirty filters:
 - (1) cannot deodorize the air. (2) cannot clean the air.
 - (3) results in poor heating or cooling. (4) may cause odour.
- To order Titanium Apatite Photocatalytic Air-Purifying Filter contact to the service shop there you bought the air conditioner.
- Dispose of old filters as non-flammable waste.

Item	Part No.
Titanium Apatite Photocatalytic Air-Purifying Filter (without frame) 1 set	KAF952B42

FTXG 25/35 E, CTXG 50 E

2.1.15 Care and Cleaning



CAUTION

Before cleaning, be sure to stop the operation and turn the breaker OFF.

Always shut down the unit (and close the panel) before doing any work. Opening the panel during operation may cause the panel to fall off.

UNITS


■ Indoor unit, Outdoor unit and Remote control

1. Wipe them with dry soft cloth.

■ Front panel


1. Open the front panel.

- Press the two places on the left and right of the front panel.



2. Remove the front panel.

- With the front panel open so that it is almost horizontal, slide it to the right. The revolving axis on the left will come off. The revolving axis on the right can be removed by sliding the front panel to the left.




3. Clean the front panel

- Wipe it with a soft cloth soaked in water.
- Only neutral detergent may be used.
- In case of washing the front panel dry it with cloth, dry it up in the shade after washing.

4. Attach the front panel.

- Place the revolving axes on either side of the front panel into the holes and slowly close. (Press either side of the front panel.)




CAUTION


- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40°C, benzene, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front panel is securely fixed.

FILTERS


1. **Open the front panel.**
 - Open the front panel by placing a finger on the panel tab on either side of the front panel and the secure it using the supporting plate on the right.
2. **Pull out the air filters.**
 - Push a little upwards the tab at the center of each air filter, then pull it down.
3. **Take off the Titanium Apatite Photocatalytic Air-Purifying Filter.**
 - Hold the recessed parts of the frame and unhook the four claws.
4. **Clean or replace each filter.**
 - See figure.



Supporting plate




5. **Set the air filter and the Titanium Apatite Photocatalytic Air-Purifying Filter as they were and close the front panel.**
 - Be sure to insert the two tabs below.
 - Return the supporting plate to its previous position.
 - Press either side of the front panel.




■ Air Filter

1. **Wash the air filters with water or clean them with vacuum cleaner.**
 - If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
 - It is recommended to clean the air filters every two weeks.



■ Titanium Apatite Photocatalytic Air-Purifying Filter (gray)

The Air purifying filter with photocatalytic deodorizing function can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.



[Maintenance]

1. Remove dust with a vacuum cleaner and wash lightly with water.
2. If it is very dirty, soak it for 10 to 15 minutes in water mixed with a neutral cleaning agent.
3. Do not remove filter from frame when washing with water.
4. After washing, shake off remaining water and dry in the shade.
5. Since the material is made out of paper, do not wring out the filter when removing water from it.

[Replacement]

1. Remove the tabs on the filter frame and replace with a new filter.
 - Dispose of the old filter as flammable waste.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation. <ul style="list-style-type: none"> If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

- Operate the "FAN only" for several hours on a fine day to dry out the inside.**
 - Press "MODE" button and select "FAN" operation.
 - Press "ON/OFF" button and start operation.
- After operation stops, turn off the breaker for the room air conditioner.**
- Clean the air filters and set them again.**
- Take out batteries from the remote control.**
 - When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation.

NOTES

- Operation with dirty filters:
 - (1) cannot deodorize the air. (2) cannot clean the air.
 - (3) results in poor heating or cooling. (4) may cause odour.
- To order Air-Purifying Filter with photocatalytic deodorizing functioning contact to the service shop where you bought the air conditioner.
- Dispose of old filters as non-burnable and photocatalytic deodorizing filters as burnable waste.

Item	Part No.
Titanium Apatite Photocatalytic Air-Purifying Filter. (with frame) 1 set	KAF952B41
Titanium Apatite Photocatalytic Air-Purifying Filter. (without frame) 1 set	KAF952B42

Care and Cleaning

FDK(X)S 25/35 C



CAUTION

- Only a qualified service person is allowed to perform maintenance.
- Before cleaning, be sure to stop the operation and turn the breaker OFF.


■ Cleaning the air filter

1. Removing the air filter.

- Rear suction
Pull the bottom side of the air filter backwards, over the 3 bends.
- Bottom suction
Pull the filter over the 3 bends situated at the backside of the unit.


2. Cleaning the air filter.

- Remove dust from the air filter using a vacuum cleaner and gently rinse them in cool water. Do not use detergent or hot water to avoid filter shrinking or deformation. After cleaning dry them in the shade.



3. Replacing the air filter.

- Rear suction
Hook the filter behind the flap situated at the top of the unit and push the other side gently over the 3 bends.
- Bottom suction
Hook the filter behind the flap situated at the middle of the unit and push the other side gently over the 3 bends.



■ Cleaning the drain pan

- Clean the drain pan periodically, or drain piping may be clogged with dust and may result in water leakage. Ask your DAIKIN dealer to clean them.
- Prepare a cover locally to prevent any dust in the air around the indoor unit from getting in the drain pan, if there is a great deal of dust present.



CAUTION

- Do not operate the air conditioner without filters, this to avoid dust accumulation inside the unit.
- Do not remove the air filter except when cleaning. Unnecessary handling may damage the filter.
- Do not use gasoline, benzine, thinner, polishing powder, liquid insecticide. It may cause discoloring or warping.
- Do not let the indoor unit get wet. It may cause an electric shock or a fire.
- Operation with dusty air filters lowers the cooling and heating capacity and wastes energy.
- The suction grille is option.
- Do not use water or air of 50°C or higher for cleaning air filters and outside panels.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
--

Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.

Check that the drain comes smoothly out of the drain hose during COOL or DRY operation
--

<ul style="list-style-type: none"> • If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.
--

■ Before a long idle period

1. **Operate the "FAN only" for several hours on a fine day to dry out the inside.**
 - Press "MODE selector button" and select "FAN" operation.
 - Press "ON/OFF button" and start operation.
2. **After operation stops, turn off the breaker for the room air conditioner.**
3. **Clean the air filters and set them again.**
4. **Take out batteries from the remote control.**
 - When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation.

Care and Cleaning

FDK(X)S 50/60 C, FDK(X)S 25/35 E



CAUTION

- Only a qualified service person is allowed to perform maintenance.
- Before cleaning, be sure to stop the operation and turn the breaker OFF.


■ Cleaning the air filter

1. Removing the air filter.

- Rear suction
Pull the bottom side of the air filter backwards, over the bends. (2 bends for 25/35 type, 3 bends for 50/60 type)
- Bottom suction
Pull the filter over the bends (2 bends for 25/35 type, 3 bends for 50/60 type) situated at the backside of the unit.


2. Cleaning the air filter.

- Remove dust from the air filter using a vacuum cleaner and gently rinse them in cool water. Do not use detergent or hot water to avoid filter shrinking or deformation. After cleaning dry them in the shade.



3. Replacing the air filter.

- Rear suction
Hook the filter behind the flap situated at the top of the unit and push the other side gently over the bends. (2 bends for 25/35 type, 3 bends for 50/60 type)
- Bottom suction
Hook the filter behind the flap situated at the middle of the unit and push the other side gently over the bends. (2 bends for 25/35 type, 3 bends for 50/60 type)



■ Cleaning the drain pan

- Clean the drain pan periodically, or drain piping may be clogged with dust and may result in water leakage. Ask your DAIKIN dealer to clean them.
- Prepare a cover locally to prevent any dust in the air around the indoor unit from getting in the drain pan, if there is a great deal of dust present.



CAUTION

- Do not operate the air conditioner without filters, this to avoid dust accumulation inside the unit.
- Do not remove the air filter except when cleaning. Unnecessary handling may damage the filter.
- Do not use gasoline, benzene, thinner, polishing powder, liquid insecticide. It may cause discoloring or warping.
- Do not let the indoor unit get wet. It may cause an electric shock or a fire.
- Operation with dusty air filters lowers the cooling and heating capacity and wastes energy.
- The suction grille is option.
- Do not use water or air of 50°C or higher for cleaning air filters and outside panels.
- Ask your DAIKIN dealer how to clean it.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation.
• If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

1. **Operate the "FAN only" for several hours on a fine day to dry out the inside.**
 - Press "MODE selector button" and select "FAN" operation.
 - Press "ON/OFF button" and start operation.
2. **Clean the air filters and set them again.**
3. **Take out batteries from the remote control.**
4. **Turn OFF the breaker for the room air conditioner.**
 - When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation.

Care and Cleaning

FLK(X)S 25/35/50/60 B



CAUTION

Before cleaning, be sure to stop the operation and turn the breaker OFF.

UNITS


■ Indoor unit, Outdoor unit and Remote control

1. Wipe them with dry soft cloth.

■ Front panel

1. Open the front panel.

- Hold the panel by the tabs on the two sides and lift it until it stops.




2. Clean the front panel.

- Wipe it with a soft cloth soaked in water.
- Only neutral detergent may be used.
- In case of washing the panel with water, dry it with cloth, dry it up in the shade after washing.

3. Close the front panel.

- Push the panel at the 5 points indicated by ↑.
- Operation without air filters may result in troubles as dust will accumulate inside the indoor unit.




CAUTION

- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40°C, benzene, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front grille is securely fixed.

FILTERS

1. Open the front grille.




2. Pull out the air filter.


- Push upwards the tab at the center of each air filter, then pull it down.

3. Take off the air purifying filter, Photocatalytic deodorizing filter.

- Hold the recessed parts of the frame and unhook the four claws.



Air purifying filter or Photocatalytic deodorizing filter




4. Clean or replace each filter.

- See figure.

5. Set the air filter, air purifying filter and photocatalytic deodorizing filter as they were and close the front panel.


- Insert claws of the filters into slots of the front panel.
- Push the panel at the 5 points.



■ Air Filter

1. Wash the air filters with water or clean them with vacuum cleaner.

- If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
- It is recommended to clean the air filters every two weeks.




■ Air Purifying Filter (green)

(Replace approximately once every 3 months.)

1. Detach the filter element and attach a new one.

- Insert with the green side up.
- It is recommended to replace the air purifying filter every three months.



■ Photocatalytic Deodorizing Filter (gray)

[Maintenance]

1. Dry the photocatalytic deodorizing filter in the sun.

- After removing the dust with a vacuum cleaner, place the filter in the sun for approximately 6 hours. By drying the photocatalytic deodorizing filter in the sun, its deodorizing and antibacterial capabilities are regenerated.
- Because the filter material is paper, it can not be cleaned with water.
- It is recommended to dry the filter once every 6 months.

[Replacement]

1. Detach the filter element and attach a new one.

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.
Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.
Check that the drain comes smoothly out of the drain hose during COOL or DRY operation. • If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

1. **Operate the “FAN only” for several hours on a fine day to dry out the inside.**
 - Press “MODE button” and select “FAN” operation.
 - Press “ON/OFF button” and start operation.
2. **After operation stops, turn off the breaker for the room air conditioner.**
3. **Clean the air filters and set them again.**
4. **Take out batteries from the remote control.**
 - When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation.

NOTES

- Operation with dirty filters :
 - (1) cannot deodorize the air.
 - (2) cannot clean the air.
 - (3) results in poor heating or cooling.
 - (4) may cause odour.
- The air purifying filter and Photocatalytic deodorizing filter cannot be reused, even if washed.
- In principle, there is no need to replace the photocatalytic deodorizing filter. Remove the dust periodically with a vacuum cleaner. However, it is recommended to replace the filter in the following cases.
 - (1) The paper material is torn or broken during cleaning.
 - (2) The filter has become extremely dirty after long use.
- To order air purifying filter or Photocatalytic deodorizing filter, contact to the service shop where you bought the air conditioner.
- Dispose of old air filters as non-burnable waste and Photocatalytic deodorizing filters as burnable waste.

Item	Part No.
Photocatalytic deodorizing filter (with frame)	KAZ917B41
Photocatalytic deodorizing filter (without frame)	KAZ917B42
Air purifying filter (with frame)	KAF925B41
Air purifying filter (without frame)	KAF925B42

2.1.16 Troubleshooting

These cases are not troubles

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
Operation does not start soon. <ul style="list-style-type: none"> • When ON/OFF button was pressed soon after operation was stopped. • When the mode was reselected. 	<ul style="list-style-type: none"> • This is to protect the air conditioner. You should wait for about 3 minutes.
Hot air does not flow out soon after the start of heating operation.	<ul style="list-style-type: none"> • The air conditioner is warming up. You should wait for 1 to 4 minutes. (The system is designed to start discharging air only after it has reached a certain temperature.)
The heating operation stops suddenly and a flowing sound is heard.	<ul style="list-style-type: none"> • The system is taking away the frost on the outdoor unit. You should wait for about 4 to 12 minutes.
The outdoor unit emits water or steam.	<ul style="list-style-type: none"> ■ In HEAT mode <ul style="list-style-type: none"> • The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation. ■ In COOL or DRY mode <ul style="list-style-type: none"> • Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
Mists come out of the indoor unit.	<ul style="list-style-type: none"> ■ This happens when the air in the room is cooled into mist by the cold air flow during cooling operation. ■ This is because the air in the room is cooled by the heat exchanger and becomes mist during defrost operation.
The indoor unit gives out odour.	<ul style="list-style-type: none"> ■ This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)
The outdoor fan rotates while the air conditioner is not in operation.	<ul style="list-style-type: none"> ■ After operation is stopped: <ul style="list-style-type: none"> • The outdoor fan continues rotating for another 60 seconds for system protection. ■ While the air conditioner is not in operation: <ul style="list-style-type: none"> • When the outdoor temperature is very high, the outdoor fan starts rotating for system protection.
The operation stopped suddenly. (OPERATION lamp is on)	<ul style="list-style-type: none"> ■ For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.

Check again

Please check again before calling a repair person.


Case	Check
The air conditioner does not operate. (OPERATION lamp is off)	<ul style="list-style-type: none"> • Hasn't a breaker turned OFF or a fuse blown? • Isn't it a power failure? • Are batteries set in the remote control? • Is the timer setting correct?
Cooling (Heating) effect is poor.	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? • Is the temperature setting appropriate? • Are the windows and doors closed? • Are the air flow rate and the air direction set appropriately?
Operation stops suddenly. (OPERATION lamp flashes)	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote control. If the lamp still flashes, call the service shop where you bought the air conditioner. • Are operation modes all the same for indoor units connected to outdoor units in the multi system? If not, set all indoor units to the same operation mode and confirm that the lamps flash. Moreover, when the operation mode is in "AUTO", set all indoor unit operation modes to "COOL" or "HEAT" for a moment and check again that the lamps are normal. If the lamps stop flashing after the above steps, there is no malfunction.
An abnormal functioning happens during operation.	<ul style="list-style-type: none"> • The air conditioner may malfunction with lightning or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote control.

Call the service shop immediately.

 **WARNING**


- When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF. Continued operation in an abnormal condition may result in troubles, electric shocks or fire. Consult the service shop where you bought the air conditioner.
- Do not attempt to repair or modify the air conditioner by yourself. Incorrect work may result in electric shocks or fire. Consult the service shop where you bought the air conditioner.

If one of the following symptoms takes place, call the service shop immediately.



<ul style="list-style-type: none"> ■ After a power failure The air conditioner automatically resumes operation in about 3 minutes. You should just wait for a while. 	<ul style="list-style-type: none"> ■ Lightning If lightning may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.
---	---

Disposal requirements



Your air conditioning product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the air conditioning system, treatment of the refrigerant, of oil and of other parts must be done by a qualified installer in accordance with relevant local and national legislation.

Air conditioners must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health; Please contact the installer or local authority for more information.

Batteries must be removed from the remote control and disposed of separately in accordance with relevant local and national legislation.

We recommend periodical maintenance.


In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner. The maintenance cost must be born by the user.

Fault diagnosis.

FAULT DIAGNOSIS BY REMOTE CONTROL

In the ARC433 series, the temperature display sections on the main unit indicate corresponding codes.

1. When the **TIMER CANCEL** button is held down for 5 seconds, a “00” indication flashes on the temperature display section.



2. Press the **TIMER CANCEL** button repeatedly until a continuous beep is produced.

- The code indication changes as shown below, and notifies with a long beep.

	CODE	MEANING
SYSTEM	00	NORMAL
	U0	REFRIGERANT SHORTAGE
	U2	DROP VOLTAGE OR MAIN CIRCUIT OVERVOLTAGE
	U4	FAILURE OF TRANSMISSION (BETWEEN INDOOR UNIT AND OUTDOOR UNIT)
INDOOR UNIT	A1	INDOOR PCB DEFECTIVENESS
	A5	HIGH PRESSURE CONTROL OR FREEZE-UP PROTECTOR
	A6	FAN MOTOR FAULT
	C4	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	C9	FAULTY SUCTION AIR TEMPERATURE SENSOR
OUTDOOR UNIT	EA	COOLING-HEATING SWITCHING ERROR
	E5	OL STARTED
	E6	FAULTY COMPRESSOR START UP
	E7	DC FAN MOTOR FAULT
	E8	OPERATION HALT DUE TO DETECTION OF INPUT OVER CURRENT
	F3	HIGH TEMPERATURE DISCHARGE PIPE CONTROL
	F6	HIGH PRESSURE CONTROL (IN COOLING)
	H6	OPERATION HALT DUE TO FAULTY POSITION DETECTION SENSOR
	H8	CT ABNORMALITY
	H9	FAULTY SUCTION AIR TEMPERATURE SENSOR
	J3	FAULTY DISCHARGE PIPE TEMPERATURE SENSOR
	J6	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	L4	HIGH TEMPERATURE AT INVERTER CIRCUIT HEATSINK
	L5	OUTPUT OVERCURRENT
	P4	FAULTY INVERTER CIRCUIT HEATSINK TEMPERATURE SENSOR



NOTES

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the **TIMER CANCEL** button down for 5 seconds. The code display also cancel itself if the button is not pressed for 1 minute.

2.2 FVXS Series

2.2.1 Safety Precautions

- Keep this manual where the operator can easily find them.
- Read this manual attentively before starting up the unit.
- For safety reason the operator must read the following cautions carefully.
- This manual classifies precautions into WARNINGS and CAUTIONS. Be sure to follow all precautions below: they are all important for ensuring safety.

 WARNING If you do not follow these instructions exactly, the unit may cause property damage, personal injury or loss of life.	 CAUTION If you do not follow these instructions exactly, the unit may cause minor or moderate property damage or personal injury.
---	---



Never do.



Be sure to earth the air conditioner.



Never touch the air conditioner (including the remote control) with a wet hand.




Be sure to follow the instructions.




Never cause the air conditioner (including the remote control) to get wet.




WARNING

- In order to avoid fire, explosion or injury, do not operate the unit when harmful, among which flammable or corrosive gases, are detected near the unit. 
- It is not good for health to expose your body to the air flow for a long time.
- Do not put a finger, a rod or other objects into the air outlet or inlet. As the fan is rotating at a high speed, it will cause injury.
- Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself. Incorrect work will cause electric shocks, fire etc.


For repairs and reinstallation, consult your Daikin dealer for advice and information.


- The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant happens to leak into the room, make sure it does not come in contact with any flame as of gas heaters, kerosene heaters or gas range. 
- If the air conditioner is not cooling (heating) properly, the refrigerant may be leaking, so call your dealer. When carrying out repairs accompanying adding refrigerant, check the content of the repairs with our service staff.
- Do not attempt to install the air conditioner by yourself. Incorrect work will result in water leakage, electric shocks or fire. For installation, consult the dealer or a qualified technician.
- In order to avoid electric shock, fire or injury, if you detect any abnormally such as smell of fire, stop the operation and turn off the breaker. And call your dealer for instructions.
- Depending on the environment, an earth leakage breaker must be installed. Lack of an earth leakage breaker may result in electric shocks or fire


- The air conditioner must be earthed. Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line. 




CAUTION

- In order to avoid any quality deterioration, do not use the unit for cooling precision instruments, food, plants, animals or works of art. 
- Never expose little children, plants or animals directly to the air flow.
- Do not place appliances which produce open fire in places exposed to the air flow from the unit or under the indoor unit. It may cause incomplete combustion or deformation of the unit due to the heat.
- Do not block air inlets nor outlets. Impaired air flow may result in insufficient performance or trouble.
- Do not stand or sit on the outdoor unit. Do not place any object on the unit to avoid injury, do not remove the fan guard.
- Do not place anything under the indoor or outdoor unit that must be kept away from moisture. In certain conditions, moisture in the air may condense and drip.
- After a long use, check the unit stand and fittings for damage.
- Do not touch the air inlet and aluminum fins of outdoor unit. It may cause injury.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.

- To avoid oxygen deficiency, ventilate the room sufficiently if equipment with burner is used together with the air conditioner. 
- Before cleaning, be sure to stop the operation, turn the breaker off or pull out the supply cord.
- Do not connect the air conditioner to a power supply different from the one as specified. It may cause trouble or fire.
- Arrange the drain hose to ensure smooth drainage. Incomplete draining may cause wetting of the building, furniture etc.
- Do not place objects in direct proximity of the outdoor unit and do not let leaves and other debris accumulate around the unit.
Leaves are a hotbed for small animals which can enter the unit. Once in the unit, such animals can cause malfunctions, smok on fire when making contact with electrical parts.

- Do not operate the air conditioner with wet hands. 

- Do not wash the indoor unit with excessive water, only use a slightly wet cloth. 
- Do not place things such as vessels containing water or anything else on top of the unit. Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.

Installation site

- To install the air conditioner in the following types of environments, consult the dealer.
 - Places with an oily ambient or where steam or soot occurs.
 - Salty environment such as coastal areas.
 - Places where sulfide gas occurs such as hot springs.
 - Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage.

Consider nuisance to your neighbours from noises

- For installation, choose a place as described below.
 - A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
 - A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours.

Electrical work


- For power supply, be sure to use a separate power circuit dedicated to the air conditioner.

System relocation

- Relocating the air conditioner requires specialized knowledge and skills. Please consult the dealer if relocation is necessary for moving or remodeling.


2.2.2 Names of parts

Indoor Unit



Opening the front panel


How to open the front panel: (page 26.)



CAUTION

- Before opening the front grille, be sure to stop the operation and turn the breaker OFF.
- Do not touch the metal parts on the inside of the indoor unit, as it may result in injury.

■ Outdoor Unit



■ Indoor Unit

1. **Titanium Apatite Photocatalytic Air-Purifying Filter:**
 - These filters are attached to the inside of the air filters.
2. **Air outlet**
3. **Display**
4. **Front panel**
5. **Louvers (vertical blades):** (page 12.)
 - The louvers are inside of the air outlet.
6. **Air inlet**
7. **Air filter**
8. **Flaps (horizontal blade):** (page 12.)
9. **Operation lamp (green)**
10. **TIMER lamp (yellow):** (page 17.)

11. **Indoor Unit ON/OFF switch:**

- Push this switch once to start operation. Push once again to stop it.
- The operation mode refers to the following table.

Model	Mode	Temperature setting	Air flow rate
COOLING ONLY	COOL	22°C	AUTO
HEAT PUMP	AUTO	25°C	AUTO

- This switch is useful when the remote control is missing.
12. **Signal receiver:**
- It receives signals from the remote control.
 - When the unit receives a signal, you will hear a short beep.
 - Operation startbeep-beep
 - Settings changed.....beep
 - Operation stopbeeeep

13. **Air outlet selection switch:** (page 13)

14. **Room temperature sensor:**

- It senses the air temperature around the unit.

■ Outdoor Unit

15. **Air inlet:** (Back and side)
16. **Refrigerant piping and inter-unit cable**
17. **Drain hose**


18. **Earth terminal:**

- It is inside of this cover.

19. **Air outlet**

Appearance of the outdoor unit may differ from some models.

Remote control



1. Signal transmitter:

- It sends signals to the indoor unit.

2. Display:

- It displays the current settings. (In this illustration, each section is shown with all its displays ON for the purpose of explanation.)

3. FAN setting button:

It selects the air flow rate setting.

4. POWERFUL button:

POWERFUL operation (page 14.)

5. ON/OFF button:

- Press this button once to start operation. Press once again to stop it.

6. TEMPERATURE adjustment buttons:

- It changes the temperature setting.

7. MODE selector button:

- It selects the operation mode. (AUTO/DRY/COOL/HEAT/FAN)

8. QUIET button:

OUTDOOR UNIT QUIET operation

9. ECONO button:

ECONO operation (page 16.)

10. SWING button:

- Adjusting the Air Flow Direction (page 12.)

11. WEEKLY button:

WEEKLY TIMER operation (page 19.)

12. PROGRAM button:

WEEKLY TIMER operation (page 19.)

13. COPY button:

WEEKLY TIMER operation (page 19.)

14. BACK button:

WEEKLY TIMER operation (page 19.)

15. NEXT button:

WEEKLY TIMER operation (page 19.)

16. SELECT button:

- It cancels the timer setting. (page 17.)

17. OFF TIMER button:

- (page 17.)

18. ON TIMER button:

- (page 18.)

19. TIMER CANCEL button:

- It cancels the timer setting. (page 17, 18.)
- It cannot be used for the WEEKLY TIMER operation.


20. CLOCK button:

- (page 8.)

2.2.3 Preparation Before Operation


■ To set the batteries

1. Slide the front cover to take it off.
2. Set two dry batteries (AAA).
3. Set the front cover as before.




■ To operate the remote control

- To use the remote control, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote control, such as a curtain, the unit will not operate.
- Do not drop the remote control. Do not get it wet.
- The maximum distance for communication is about 7m.



To fix the remote control holder on the wall

1. Choose a place from where the signals reach the unit.
2. Fix the holder to a wall, a pillar, or similar location with the screws procured locally.
3. Place the remote control in the remote control holder.



- To remove, pull it upwards.

ATTENTION

■ About batteries

- When replacing the batteries, use batteries of the same type, and replace the two old batteries together.
- When the system is not used for a long time, take the batteries out.
- We recommend replacing once a year, although if the remote control display begins to fade or if reception deteriorates, please replace with new alkali batteries. Using manganese batteries reduces the lifespan.
- The attached batteries are provided for the initial use of the system. The usable period of the batteries may be short depending on the manufactured date of the air conditioner.


■ About remote control

- Never expose the remote control to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote control signals happen to operate another appliance, move that appliance to some-where else, or consult the shop.

Preparation Before Operation

■ To set the clock

1. Press "CLOCK button".
0:00 is displayed.
MON ☉ blinks.
2. Press "SELECT button" to set the current day of the week.
3. Press "CLOCK button".
☉ blinks.
4. Press "SELECT button" to set the clock to the present time.
Holding down "▲" or "▼" button rapidly increases or decreases the time display.
5. Press "CLOCK button".
Always point the remote control at the indoor unit when pushing the buttons when setting the indoor unit's internal clock.
:blinks.



NOTE

- If the indoor unit's internal clock is not set to the correct time, the WEEKLY TIMER will not operate punctually.

■ Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)

NOTES

■ Tips for saving energy

- Be careful not to cool (heat) the room too much. Keeping the temperature setting at a moderate level helps save energy.
- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling (heating) effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

Recommended temperature setting
For cooling: 26°C – 28°C
For heating: 20°C – 24°C

■ Please note

- The air conditioner always consumes 15-35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.

Mode	Initial setting	Selectable range
COOL	Outdoor temperature: [2MK(X)S40/50] 10 to 46°C [2MK(X)S52] –10 to 46°C [3/4/5MK(X)S] –10 to 46°C [RK(X)S] –10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the out-door unit only.) • Condensation may occur on the indoor unit and drip.
HEAT	Outdoor temperature: [2MXS40] –10 to 24°C [2MXS52] –15 to 24°C [3/4/5MXS] –15 to 15.5°C [RXS] –15 to 24°C Indoor temperature: 10 to 30°C	<ul style="list-style-type: none"> • A safety device may work to stop the operation.
DRY	Outdoor temperature: [2MK(X)S40/50] 10 to 46°C [2MXS50/52] –10 to 46°C [3/4/5MK(X)S] –10 to 46°C [RK(X)S] –10 to 46°C Indoor temperature: 18 to 32°C Indoor humidity: 80% max.	<ul style="list-style-type: none"> • A safety device may work to stop the operation. • Condensation may occur on the indoor unit and drip.

- Operation outside this humidity or temperature range may cause a safety device to disable the system.

2.2.4 Auto Dry Cool Heat Fan Operation

The air conditioner operates with the operation mode of your choice. From the next time on, the air conditioner will operate with the same operation mode.

■ To start operation

1. Press "MODE selector button" and select a operation mode.

- Each pressing of the button advances the mode setting in sequence.



Ⓐ : AUTO

Ⓑ : DRY

❄ : COOL



☀ : HEAT

🌀 : FAN



2. Press "ON/OFF button".

- The OPERATION lamp lights up.



■ To stop operation

3. Press "ON/OFF button" again.
 - Then OPERATION lamp goes off.






■ To change the temperature setting

4. Press "TEMPERATURE adjustment button".


DRY or FAN mode	AUTO or COOL or HEAT mode
The temperature setting is not variable.	Press "▲" to raise the temperature and press "▼" to lower the temperature.
	Set to the temperature you like

■ To change the air flow rate setting

5. Press “FAN setting button”.

DRY mode	AUTO or COOL or HEAT or FAN mode
The air flow rate setting is not variable	Five levels of air flow rate setting from “  ” to “  ” plus “  ” “  ” are available.
	

- Indoor unit quiet operation

When the air flow is set to “”, the noise from the indoor unit will become quieter.

Use this when making the noise quieter.

The unit might lose capacity when the air flow rate is set to a weak level.

NOTES

■ Note on heat operation

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

■ Note on COOL operation

- This air conditioner cools the room by blowing the hot air in the room outside, so if the outside temperature is high, performance drops.

■ Note on DRY operation

- The computer chip works to rid the room of humidity while maintaining the temperature as much as possible. It automatically controls temperature and fan strength, so manual adjustment of these functions is unavailable.

■ Note on AUTO operation

- In AUTO operation, the system selects an appropriate operation mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, you can manually select the operation mode and setting you like.




■ Note on air flow rate setting


- At smaller air flow rates, the cooling (heating) effect is also smaller.

2.2.5 Adjusting the air flow direction

You can adjust the air flow direction to increase your comfort.

■ To adjust the horizontal blades (flaps)


1. Press "SWING button ".
 - "  " The display on the LCD and the flaps will begin to swing.
2. When the flaps have reached the desired position, press "SWING button" once more.
 - The flaps will stop moving.
 - "  " disappears from the LCD.



■ To adjust the vertical blades (louvres)

Hold the knob and move the louver.

(You will find a knob on the left-side and the right-side blades.)




Notes on flaps and louvers angles

- Unless "SWING" is selected, you should set the flap at a near-horizontal angle in heat mode and at an upward position in COOL or DRY mode to obtain the best performance

■ ATTENTION

- When adjusting the flap by hand, turn off the unit, and use the remote controller to restart the unit.
- Be careful when adjusting the louvers. Inside the air outlet, a fan is rotating at a high speed.




■ Air flow selection

- Make air flow selection according to what suits you.

When setting the air flow selection switch to 

- Air conditioner automatically decides the appropriate blowing pattern depending on the operating mode/situation.

Operating mode	Situation	Blowing pattern
COOL mode	<ul style="list-style-type: none"> • When the room has become fully cool, or when one hour has passed since turning on the air conditioner. 	<ul style="list-style-type: none"> • So that air does not come into direct contact with people, air is blown upper air outlet, room temperature is equalised.
	<ul style="list-style-type: none"> • At start of operation or other times when the room is not fully cooled. 	<div style="text-align: center;">  </div> <ul style="list-style-type: none"> • Air is blown from the upper and lower air outlets for high speed cooling during COOL mode, and for filling the room with warm air during HEAT mode.
HEAT mode	<ul style="list-style-type: none"> • At times other than below. (Normal time.) 	
	<ul style="list-style-type: none"> • At start or when air temperature is low. 	<ul style="list-style-type: none"> • So that air does not come into direct contact with people. Air is blown upper air outlet.

- During Dry mode, so that cold air does not come into direct contact with people, air is blown upper air outlet.

When setting the air outlet selection switch to 

- Regardless of the operating mode or situation, air blows from the upper air outlet.
- Use this switch when you do not want air coming out of the lower air outlet. (While sleeping etc..)


 CAUTION

- Do not try to adjust the flap by hand.
- When adjusting by hand, the mechanism may not operate properly or condensation may drip from air outlets.

2.2.6 POWERFUL Operation


POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity

■ To start POWERFUL operation

1. Press “POWERFUL button”.
 - POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
 - When using POWERFUL operation, there are some functions which are not available.
 - “” is displayed on the LCD.


■ To cancel POWERFUL operation

2. Press “POWERFUL button” again.
 - “” disappears from the LCD.



NOTES

■ Notes on POWERFUL operation

- POWERFUL Operation cannot be used together with ECONO or QUIET Operation. Priority is given to the function of whichever button is pressed last.
- POWERFUL Operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and the “” disappears from the LCD.
- **In COOL and HEAT mode**
To maximize the cooling (heating) effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting. The temperature and air flow settings are not variable.
- **In DRY mode**
The temperature setting is lowered by 2.5°C and the air flow rate is slightly increased.
- **In FAN mode**
The air flow rate is fixed to the maximum setting.
- **When using priority-room setting**
See “Note for multi system”.

2.2.7 OUTDOOR UNIT QUIET Operation


OUTDOOR UNIT QUIET operation lowers the noise level of the outdoor unit by changing the frequency and fan speed on the outdoor unit. This function is convenient during night.

■ To start OUTDOOR UNIT QUIET operation

1. Press "QUIET button".
 - "🔇" is displayed on the LCD.

■ To cancel OUTDOOR UNIT QUIET operation

2. Press "QUIET button" again.
 - "🔇" disappears from the LCD.



NOTES


■ Note on OUTDOOR UNIT QUIET operation

- If using a multi system, this function will work only when the OUTDOOR UNIT QUIET operation is set on all operated indoor units. However, if using priority-room setting, see "Note for multi system"
- This function is available in COOL, HEAT, and AUTO modes.
(This is not available in FAN and DRY mode.)
- POWERFUL operation and OUTDOOR UNIT QUIET operation cannot be used at the same time.
Priority is given to the function of whichever button is pressed last.
- If operation is stopped using the remote control or the main unit ON/OFF switch when using OUTDOOR UNIT SILENT operation, "🔇" remain on the remote control display.


2.2.8 ECONO Operation


ECONO operation is a function which enables efficient operation by lowering the maximum power consumption value.

■ To start ECONO operation


1. Press "ECONO button".
 - "  " is displayed on the LCD.

■ To cancel ECONO operation

2. Press "ECONO button" again.
 - "  " disappears from the LCD.



NOTES

- ECONO Operation can only be set when the unit is running. Pressing the operation stop button causes the settings to be canceled, and the "  " disappears from the LCD.
- ECONO operation is a function which enables efficient operation by limiting the power consumption of the outdoor unit (operating frequency).
- ECONO operation functions in AUTO, COOL, DRY and HEAT modes.
- POWERFUL operation and ECONO operation cannot be used at the same time. Priority is given to the function of whichever button is pressed last.
- Power consumption may not drop even if ECONO operation is used, when the level of power consumption is already low.

2.2.9 TIMER Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.


■ To use OFF TIMER operation

- Check that the clock is correct.
If not, set the clock to the present time.(page 8.)
- 1. Press “OFF TIMER button”.
0:00 is displayed.
OFF blinks.
- 2. Press “SELECT Setting button” until the time setting reaches the point you like.
 - Every pressing of either button increases or decreases the time setting by 10 minutes.
Holding down either button changes the setting rapidly.
- 3. Press “OFF TIMER button” again.
 - The TIMER lamp lights up.



■ To cancel the OFF TIMER operation

- 4. Press “CANCEL button”.
 - The TIMER lamp goes off.



NOTES

- When TIMER is set, the present time is not displayed.
- Once you set ON, OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote control batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user. (maximum approx. 10 minutes)


■ NIGHT SET MODE

When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL, 2.0°C down in HEAT) to prevent excessive cooling (heating) for your pleasant sleep.

Preparation Before Operation

■ To use ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time.(page 8)
1. Press “ON TIMER button”.
 - 6:00 is displayed.
 - “ON” blinks.
 2. Press “SELECT button” until the time setting reaches the point you like.
 - Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.
 3. Press “ON TIMER button” again.
 - The TIMER lamp lights up.





■ To cancel ON TIMER operation

4. Press “CANCEL button”.
 - The TIMER lamp goes off.

■ To combine ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.




ATTENTION

- In the following cases, set the timer again.
 - After a breaker has turned OFF.
 - After a power failure.
 - After replacing batteries in the remote control.

2.2.10 WEEKLY TIMER Operation

Up to 4 timer settings can be saved each day of the week.


■ To use WEEKLY TIMER operation

- Make sure the day of the week and time are set. If not, set the day of the week and time. (page 8.)
 - The following procedure is to make a reservation on Monday for Tuesday 6:00 am/27°C.
1. Press “ button”.
- The day of the week and the reservation number will be displayed.
 - 1 to 4 settings can be made per day.





2. Press “SELECT button” to select the desired day of the week and reservation number.
- Pressing the “SELECT button” changes the reservation number and the day of the week.





3. Press “NEXT button”.
- The day of the week will be set.
 - “ WEEKLY” and “ON” blink.




4. Press “SELECT button” to select the desired mode.
- “ WEEKLY” and “ON” or “OFF” will flash.




- To go to the next reservation setting, select “no setting”.
5. Press “NEXT button”.
- The weekly mode will be set.
 - “ WEEKLY” and “6:00” blink.




6. Press “SELECT button” to select the desired time.
- The time can be set between 0:00 and 23:50 in 10 minute intervals.
 - Press “BACK button” to return to the mode setting..




■ To use WEEKLY TIMER operation


7. Press “NEXT button”.
 - The time will be set.
 - “ WEEKLY” and the temperature blink.



8. Press “SELECT button” to select the desired temperature.
 - The temperature can be set between 10°C and 32°C.
 - To return to the time setting, press “BACK button”
 - The set temperature is only displayed when the mode setting is on.


9. Press “NEXT button”.
 - The temperature will be set.
 - The temperature will be set and go to the next reservation setting
 - Set the following using the same procedures.
10. Press “ button” to complete the setting.


- Point the remote control toward the air conditioner and press the buttons to operate. The air conditioner will beep and the operation lamp will flash.



■ To cancel WEEKLY TIMER operation



11. Press “WEEKLY button” to deactivate the WEEKLY operation.

- The “ WEEKLY” will disappear from the display.
- The TIMER lamp goes off.
- To reactivate the WEEKLY TIMER operation, press the “WEEKLY button” again.




NOTES

■ WEEKLY TIMER

- Do not forget to set the time on the remote control first.
- The day of the week, time and ON/OFF can be set with WEEKLY TIMER. For ON-TIMER, settings other than the above are based on the remote control settings just before the operation.
- The “WEEKLY button” activates or deactivates the reservation.
- To set WEEKLY TIMER, press “” button” and make a reservation according to the procedures.
- Only the time and set temperature set with the weekly timer are sent with the “” button”. Set the weekly timer only after setting the operation mode, the fan strength, and the fan direction ahead of time.
- Up to 4 settings per day and up to 28 settings per week can be reserved with WEEKLY TIMER. If a reservation deactivated with “WEEKLY button” is activated once again, the last reservation made will be used.
- Cooling: The unit operates at 18°C even if it is set at 10 to 17°C.
- Heating: The unit operates at 30°C even if its set at 31 to 32°C.
- Shutting the breaker off, power outages, and other similar events will render operation of indoor unit’s internal clock inaccurate. Reset the clock. (page 8.)
- The “BACK button” can be used only for the mode, time and temperature settings. It cannot be used to go back to the reservation number.

WEEKLY TIMER Operation

■ Confirm a reservation

- The reservation can be confirmed.
- Press “ button”.
 - The day of the week and the reservation number will be displayed.



- Press “SELECT button” to select the desired day of the week and reservation number to be confirmed.
- Pressing the “SELECT button” displays the reservation details.




- Press “ button”.
- Reservation confirmation complete.

■ Canceling all reservations

- Hold the “WEEKLY button” for 5 seconds.
- Be sure to direct the remote control toward the main unit and check for a receiving tone.
- This operation is not effective while WEEKLY TIMER is being set.
- All reservations will be canceled.


■ Confirm a reservation


- This function can be used for canceling reservations for each day of the week
 - It can be used while confirming or setting reservations.
- Select the day of the week to be canceled with the “SELECT button”.
 - Hold the “WEEKLY button” for 5 seconds.
 - The selected reservation will be canceled.




■ Setting WEEKLY TIMER using copy mode

- A reservation made once can be easily copied and the same settings used for another day of the week


1. Press “” button”.
2. Press “SELECT button” to confirm the day of the week to be copied.





3. Press “COPY button”.
- This activates copy mode.
- Copy whole reservation of the selected day of the week.
4. Press “SELECT button” to select the destination day of the week.



5. Press “COPY button”.
- The reservation will be copied to the selected day of the week. The whole reservation of the selected day of the week will be copied.
- The reservation can be copied to another day of the week in succession.



6. Press “” button”.
- Exit copy mode.



NOTES

■ COPY MODE

- The entire reservation of the source day of the week is copied in the copy mode. Detailed settings can be made after the copy is completed.
- Both WEEKLY TIMER and ON/OFF timer cannot be used at the same time. The ON/OFF timer has priority if it is set while WEEKLY TIMER is still active. WEEKLY TIMER is activated after the reserved ON/OFF timer is completed.

2.2.11 Note for Multi System


<<What is a “Multi System”? >>

This system has one outdoor unit connected to multiple indoor units.

■ Selecting the Operation Mode

1. With the Priority Room Setting present but inactive or not present

When more than one indoor unit is operating, priority is given to the first unit that was turned on. In this case, set the units that are turned on later to the same operation mode (*1) as the first unit.



Otherwise, they will enter the Standby Mode, and the operation lamp will flash; this does not indicate malfunction.

(*1)

- COOL, DRY and FAN mode may be used at the same time.
- AUTO mode automatically selects COOL mode or HEAT mode based on the room temperature. Therefore, AUTO mode is available when selecting the same operation mode as that of the room with the first unit to be turned on.

<CAUTION>

Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.

If the operation mode of the first room is **FAN Mode**, then using **Heating Mode** in any room after this will give priority to **heating**. In this situation, the air conditioner running in **FAN Mode** will go on standby, and the operation lamp will flash.

2. With the Priority Room Setting active

See “Priority Room Setting” on the next page.

■ NIGHT QUIET Mode (Available only for cooling operation)

NIGHT QUIET Mode requires initial programming during installation. Please consult your retailer or dealer for assistance. NIGHT QUIET Mode reduces the operation noise of the outdoor unit during the night time hours to prevent annoyance to neighbors.

- The NIGHT QUIET Mode is activated when the temperature drops 5°C or more below the highest temperature recorded that day. Therefore, when the temperature difference is less than 5°C, this function will not be activated.
- NIGHT QUIET Mode reduces slightly the cooling (heating) efficiency of the unit.

■ OUTDOOR UNIT QUIET Operation

1. With the Priority Room Setting present but inactive or not present

When using the OUTDOOR UNIT QUIET operation feature with the Multi system, set all indoor units to OUTDOOR UNIT QUIET operation using their remote controls.

When clearing OUTDOOR UNIT QUIET operation, clear one of the operating indoor units using their remote control. However OUTDOOR UNIT QUIET operation display remains on the remote control for other rooms. We recommend you release all rooms using their remote controls.

2. With the Priority Room Setting active

See “Priority Room Setting” on the next page.

■ Cooling / Heating Mode Lock (Available only for heat pump models)

The Cooling / Heating Mode Lock requires initial programming during installation. Please consult your retailer or dealer for assistance. The Cooling / Heating Mode Lock sets the unit forcibly to either Cooling or Heating Mode. This function is convenient when you wish to set all indoor units connected to the Multi system to the same operation mode.

■ Priority Room Setting

The Priority Room Setting requires initial programming during installation. Please consult your retailer or dealer for assistance.

The room designated as the Priority Room takes priority in the following situations:

1. Operation Mode Priority

As the operation mode of the Priority Room takes precedence, the user can select a different operation mode from other rooms.

(Example)

* Room A is the Priority Room in the examples.

When COOL mode is selected in Room A while operating the following modes in Room B, C and D:

Operation mode in Room B, C and D	Status of Room B, C and D when the unit in Room A is in COOL mode
COOL or DRY or FAN	Current operation mode maintained
HEAT	The unit enters Standby Mode. Operation resumes when the Room A unit stops operating.
AUTO	If the unit is set to COOL mode, operation continues. If set to HEAT mode, it enters Standby Mode. Operation resumes when the Room A unit stops operating.

2. Priority when POWERFUL operation is used

(Example)

* Room A is the Priority Room in the examples.

The indoor units in Rooms A,B,C and D are all operating. If the unit in Room A enters POWERFUL operation, operation capacity will be concentrated in Room A. In such a case, the cooling (heating) efficiency of the units in Rooms B,C and D may be slightly reduced.

3. Priority when using OUTDOOR UNIT QUIET operation

(Example)

* Room A is the Priority Room in the examples.

Just by setting the unit in Room A to SILENT operation, the air conditioner starts OUTDOOR UNIT SILENT operation.

You don't have to set all the operated indoor units to QUIET operation.

2.2.12 Care and cleaning

! **CAUTION** Before cleaning, be sure to stop the operation and turn the breaker OFF.




UNITS

■ Indoor unit, Outdoor unit and Remote control

1. Wipe them with dry soft cloth.

■ Front panel

1. **Open the front panel.**
 - Slide the two stoppers on the left and right sides inward until they click.
2. **Remove the front panel.**
 - Remove the string.
 - Allowing the front panel to fall forward will enable you to remove it.
3. **Clean the front panel.**
 - Wipe it with a soft cloth soaked in water.
 - Only neutral detergent may be used.
 - In case of washing the panel with water, dry it with cloth, dry it up in the shade after washing.
4. **Attach the front panel.**
 - Insert the front panel into the grooves of the unit (3 places).
 - Attach the string to the right, inner-side of the front grille.
 - Close the panel slowly.







! CAUTION

- Don't touch the metal parts of the indoor unit. If you touch those parts, this may cause an injury.
- When removing or attaching the front panel, use a robust and stable stool and watch your steps carefully.
- When removing or attaching the front panel, support the panel securely with hand to prevent it from falling.
- For cleaning, do not use hot water above 40 °C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes, nor other hand stuff.
- After cleaning, make sure that the front panel is securely fixed.


FILTERS

1. **Open the front panel. (page 26.)**
2. **Remove the air filters.**
 - Press the claws on the right and left of the air filter down slightly, then pull upward.
3. **Take off the Titanium Apatite Photocatalytic Air-Purifying Filter.**
 - Hold the tabs of the frame, and remove the claws in 4 places.
4. **Clean or replace each filter.**
 - See figure.
5. **Set the air filter Titanium Apatite Photocatalytic Air-Purifying Filter as they were and close the front panel.**
 - Operation without air filters may result in troubles as dust will accumulate inside the indoor unit.




■ Air Filter

1. **Wash the air filters with water or clean them with vacuum cleaner.**
 - If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.
 - It is recommended to clean the air filters every two weeks.



■ Titanium Apatite Photocatalytic Air-Purifying Filter

The Titanium Apatite Photocatalytic Air-Purifying Filter can be renewed by washing it with water once every 6 months. We recommend replacing it once every 3 years.



[Maintenance]

1. **Vacuum dusts, and soak in warm water or water for about 10 to 15 minutes if dirt is heavy.**
2. **Do not remove filter from frame when washing with water.**
3. **After washing, shake off remaining water and dry in the shade.**
4. **Since the material is made out of paper, do not wring out the filter when removing water from it.**

[Replacement]

1. **Remove the tabs on the filter frame and replace with a new filter.**
 - Dispose of the old filter as flammable waste.

NOTE

- Operation with dirty filters:
 - (1) cannot deodorize the air. (2) cannot clean the air.
 - (3) results in poor heating or cooling. (4) may cause odour.
- To order Titanium Apatite Photocatalytic Air-Purifying Filter contact to the service shop where you bought the air conditioner.
- Dispose of old filters as flammable waste.

Item	Part No.
Titanium Apatite Photocatalytic Air-Purifying Filter. (without frame) 1 set	KAF968A42

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.

Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.

Check that the drain comes smoothly out of the drain hose during COOL or DRY operation

- If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

■ Before a long idle period

1. **Operate the “FAN only” for several hours on a fine day to dry out the inside.**
 - Press “MODE selector button” and select “FAN” operation.
 - Press “ON/OFF button” and start operation.
2. **After operation stops, turn off the breaker for the room air conditioner.**
3. **Clean the air filters and set them again.**
4. **Take out batteries from the remote control.**

NOTE

- When a multi outdoor unit is connected, make sure the heating operation is not used at the other room before you use the fan operation. (page 24.)

2.2.13 Troubleshooting

These cases are not troubles

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
Operation does not start soon. <ul style="list-style-type: none"> When ON/OFF button was pressed soon after operation was stopped. When the mode was reselected. 	<ul style="list-style-type: none"> This is to protect the air conditioner. You should wait for about 3 minutes.
Hot air does not flow out soon after the start of heating operation.	<ul style="list-style-type: none"> The air conditioner is warming up. You should wait for 1 to 4 minutes. (The system is designed to start discharging air only after it has reached a certain temperature.)
The heating operation stops suddenly and a flowing sound is heard.	<ul style="list-style-type: none"> The system is taking away the frost on the outdoor unit. You should wait for about 4 to 12 minutes.
The outdoor unit emits water or steam.	<ul style="list-style-type: none"> In HEAT mode <ul style="list-style-type: none"> The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation. In COOL or DRY mode <ul style="list-style-type: none"> Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
Mists come out of the indoor unit.	<ul style="list-style-type: none"> This happens when the air in the room is cooled into mist by the cold air flow during cooling operation. This is because the air in the room is cooled by the heat exchanger and becomes mist during defrost operation.
The indoor unit gives out odour.	<ul style="list-style-type: none"> This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)
The outdoor fan rotates while the air conditioner is not in operation.	<ul style="list-style-type: none"> After operation is stopped: <ul style="list-style-type: none"> The outdoor fan continues rotating for another 60 seconds for system protection. While the air conditioner is not in operation: <ul style="list-style-type: none"> When the outdoor temperature is very high, the outdoor fan starts rotating for system protection.
The operation stopped suddenly. (OPERATION lamp is on)	<ul style="list-style-type: none"> For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.

Check again

Please check again before calling a repair person.


Case	Check
The air conditioner does not operate. (OPERATION lamp is off)	<ul style="list-style-type: none"> • Hasn't a breaker turned OFF or a fuse blown? • Isn't it a power failure? • Are batteries set in the remote control? • Is the timer setting correct?
Cooling (Heating) effect is poor.	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? • Is the temperature setting appropriate? • Are the windows and doors closed? • Are the air flow rate and the air direction set appropriately?
Operation stops suddenly. (OPERATION lamp flashes)	<ul style="list-style-type: none"> • Are the air filters clean? • Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote control. If the lamp still flashes, call the service shop where you bought the air conditioner. • Are operation modes all the same for indoor units connected to outdoor units in the multi system? If not, set all indoor units to the same operation mode and confirm that the lamps flash. Moreover, when the operation mode is in "AUTO", set all indoor unit operation modes to "COOL" or "HEAT" for a moment and check again that the lamps are normal. If the lamps stop flashing after the above steps, there is no malfunction.
An abnormal functioning happens during operation.	<ul style="list-style-type: none"> • The air conditioner may malfunction with lightning or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote control.
The remote control allows selection of "heating" even though the unit is cooling only model.	<ul style="list-style-type: none"> • When selecting heating, warning beeps are heard, the main unit operating lamp (green) blinks for 5 seconds, and the current operating status is maintained. check the specifications of the outdoor unit. If the outdoor unit is cooling only model using the cooling only/heat pump switch on the remote control. If you do not know how to switch the setting, contact the service shop where you purchased the air conditioner.
The remote control allows selection of "heating" even though the unit is cooling only model.	
Heating cannot be selected, even though the unit is heat pump model.	<ul style="list-style-type: none"> • Set the remote control so that it is for a heat pump model by using the cooling only/heat pump switch on the remote control. If you do not know how to switch the setting, contact the service shop where you purchased the air conditioner.

Call the service shop immediately.

 **WARNING**

- When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF. Continued operation in an abnormal condition may result in troubles, electric shocks or fire. Consult the service shop where you bought the air conditioner.
- Do not attempt to repair or modify the air conditioner by yourself. Incorrect work may result in electric shocks or fire. Consult the service shop where you bought the air conditioner.

If one of the following symptoms takes place, call the service shop immediately.

<ul style="list-style-type: none"> ■ The power cord is abnormally hot or damaged. ■ An abnormal sound is heard during operation. ■ The safety breaker, a fuse, or the earth leakage breaker cuts off the operation frequently. ■ A switch or a button often fails to work properly. ■ There is a burning smell. ■ Water leaks from the indoor unit. 		<p>Turn the breaker OFF and call the service shop.</p>
---	---	--

<ul style="list-style-type: none"> ■ After a power failure The air conditioner automatically resumes operation in about 3 minutes. You should just wait for a while. 	<ul style="list-style-type: none"> ■ Lightning If lightning may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.
---	---

Disposal requirements



Your air conditioning product is marked with this symbol. This means that electrical and electronic products shall not be mixed with unsorted household waste.

Do not try to dismantle the system yourself: the dismantling of the air conditioning system, treatment of the refrigerant, of oil and of other parts must be done by a qualified installer in accordance with relevant local and national legislation.

Air conditioners must be treated at a specialized treatment facility for re-use, recycling and recovery. By ensuring this product is disposed of correctly, you will help to prevent potential negative consequences for the environment and human health; Please contact the installer or local authority for more information.

Batteries must be removed from the remote control and disposed of separately in accordance with relevant local and national legislation.

We recommend periodical maintenance.


In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner. The maintenance cost must be born by the user.

Fault diagnosis.

FAULT DIAGNOSIS BY REMOTE CONTROL

In the ARC433A series, the temperature display sections on the main unit indicate corresponding codes.

1. When the **TIMER CANCEL** button is held down for 5 seconds, a “00” indication flashes on the temperature display section.



2. Press the **TIMER CANCEL** button repeatedly until a continuous beep is produced.


- The code indication changes as shown below, and notifies with a long beep.

	CODE	MEANING
SYSTEM	00	NORMAL
	UA	INDOOR-OUTDOOR UNIT COMBINATION FAULT
	U2	DROP VOLTAGE OR MAIN CIRCUIT OVERVOLTAGE
	U4	FAILURE OF TRANSMISSION (BETWEEN INDOOR UNIT AND OUTDOOR UNIT)
INDOOR UNIT	A1	INDOOR PCB DEFECTIVENESS
	A5	HIGH PRESSURE CONTROL OR FREEZE-UP PROTECTOR
	A6	FAN MOTOR FAULT
	C4	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	C9	FAULTY SUCTION AIR TEMPERATURE SENSOR
OUTDOOR UNIT	EA	COOLING-HEATING SWITCHING ERROR
	E1	CIRCUIT BOARD FAULT
	E5	OL STARTED
	E6	FAULTY COMPRESSOR START UP
	E7	DC FAN MOTOR FAULT
	E8	OVERCURRENT INPUT
	F3	HIGH TEMPERATURE DISCHARGE PIPE CONTROL
	F6	HIGH PRESSURE CONTROL (IN COOLING)
	H0	SENSOR FAULT
	H6	OPERATION HALT DUE TO FAULTY POSITION DETECTION SENSOR
	H8	DC CURRENT SENSOR FAULT
	H9	FAULTY SUCTION AIR TEMPERATURE SENSOR
	J3	FAULTY DISCHARGE PIPE TEMPERATURE SENSOR
	J6	FAULTY HEAT EXCHANGER TEMPERATURE SENSOR
	L3	ELECTRICAL PARTS HEAT FAULT
	L4	HIGH TEMPERATURE AT INVERTER CIRCUIT HEATSINK
	L5	OUTPUT OVERCURRENT
P4	FAULTY INVERTER CIRCUIT HEATSINK TEMPERATURE SENSOR	


NOTES

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the **TIMER CANCEL** button down for 5 seconds. The code display also cancel itself if the button is not pressed for 1 minute.

2.3 FHQ Series




1




2

[1]



3




4


1. What to do before operation

This operation manual is for the following systems with standard control. Before initiating operation, contact your Daikin dealer for the operation that corresponds to your system.

• **Pair system or Simultaneous operation system**



• **Multi system**



NOTE

- If the unit you purchased is controlled by an infrared remote control, also refer to the infrared remote control's operation manual.

If your installation has a customized control system, ask your Daikin dealer for operation that corresponds to your system.

- **Heat pump type**
This system provides cooling, heating, automatic, program dry, and fan operation modes.
- **Cooling only type**
This system provides cooling, program dry, and fan operation modes.

Precautions for group control system or two remote control control system

This system provides two other control systems beside individual control (one remote control controls one indoor unit) system. Confirm the following if your unit is of the following control system type.

- **Group control system**
One remote control controls up to 16 indoor units.
All indoor units are equally set.
- **Two remote controls control system**
Two remote controls control one indoor unit
(In case of group control system, one group of indoor units)
The unit is individually operated.

NOTE

- Contact your Daikin dealer in case of changing the combination or setting of group control and two remote controls control system.

Names and functions of parts

Refer to figure 2 on page [1]


a	Indoor unit
b	Outdoor unit • The external appearance of the outdoor unit varies depending on its capacity class. The outdoor unit shown in the figure is for reference to indicate features. Contact your Daikin Dealer and verify which outdoor unit you have.
c	Remote control
d	Inlet air
e	Discharged air
f	Air outlet
g	Air flow flap (at air outlet)
h	Refrigerant piping, connection electric wire
i	Drain pipe
j	Suction grille The built-in air filter removes dust and dirt.
k	Ground wire Wire to ground from the outdoor unit to prevent electrical shocks.


2. Safety considerations

We recommend that you read this instruction manual carefully before use to gain full advantage of the function of the air conditioner, and to avoid malfunction due to erroneous handling.

This air conditioner comes under the term “appliances not accessible to the general public”.

- **The precautions described below are WARNING and CAUTION. These are very important precautions concerning safety. Be sure to observe all of them without fail.**

 **CAUTION** ... These are the matters with possibilities leading to serious consequences such as death or serious injury due to erroneous handling.

 **CAUTION** ... These are the matters with possibilities leading to injury or material damage due to erroneous handling including probabilities leading to serious consequences in some cases.

- **After reading, keep this manual at a place where any user can read at any time. Furthermore, make certain that this operation manual is handed to a new user when he takes over the operation.**

WARNING

Avoid exposure of your body directly to the cold air for a long time, or avoid excessive exposure of your body to the cold air.

Otherwise, your physical condition may be deteriorated and/or your health may be ruined.

When the air conditioner is in abnormal conditions (smell of something burning, etc), unplug the power cord from the outlet, and contact the dealer where you purchased the air conditioner.

Continued operation under such circumstances may result in a failure, electric shock, and fire.

Ask your dealer for installation of the air conditioner. Incomplete installation performed by yourself may result in a failure, a water leakage, electric shock, and fire.

Ask your dealer for improvement, repair and maintenance.

Incomplete improvement, repair, and maintenance may result in a failure, a water leakage, electric shock, and fire.

Do not insert your finger, a stick, etc., into the air inlet, outlet, and fan blades.

A fan in high-speed running may result in injury.

For refrigerant leakage, consult your dealer.

When the air conditioner is to be installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant dose not exceed the limiting concentration even when it leaks. If the refrigerant leaks exceeding the level of limiting concentration, an oxygen deficiency accident may happen.

For installation of separately sold component parts, ask a specialist.

Be sure to use the separately sold component parts designated by our company.

Incomplete installation performed by yourself may result in a failure, a water leakage, electric shock, and fire.

Ask your dealer to move and reinstall the air conditioner.

Incomplete installation may result in a failure, a water leakage, electric shock, and fire.

The refrigerant in the air conditioner is safe and normally does not leak. If the refrigerant leaks inside the room, the contact with a fire of a burner, a heater or a cooker may result in a harmful gas.

Do not use the air conditioner until when a service person confirms to finish repairing the portion where the refrigerant leaks.

CAUTION

Do not use the air conditioner for other purposes.

Do not use the air conditioner for a special application such as the storage of foods, animals and plants, precision machines, and art objects as otherwise the deterioration of quality may result.

Do not remove the air outlet of the outdoor unit.

The fan may get exposed and result in injury.

When the air conditioner is used in combination with burners or heaters, perform sufficient ventilation.

Insufficient ventilation may result in an oxygen deficiency accident.

Check and make sure that foundation blocks are not damaged after a long use.

If they are left in a damaged condition, the unit may fall and result in injury.

Neither place a flammable spray bottle near the air conditioner nor perform spraying.

Doing so may result in a fire.

To clean the air conditioner, stop operation, and unplug the power cord from the outlet.

Otherwise, an electric shock and injury may result.

Do not operate the air conditioner with a wet hand.

An electric shock may result.

Do not place items that might be damaged by water under the indoor unit.

Water may condensate and drip if the humidity reaches 80% or if the drain exit gets clogged.

Do not place a burner or heater at a place directly exposed to the wind from the air conditioner.

Incomplete combustion of the burner or heater may result.

Do not allow a child to mount on the outdoor unit or avoid placing any object on it.

Falling or tumbling may result in injury.

Do not expose animals and plants directly to the wind from the air conditioner.

Adverse influence to animals and plants may result.

Do not wash the air conditioner with water.

An electrical shock or fire may result.

Do not install the air conditioner at any place where flammable gas may leak out.

If the gas leaks out and stays around the air conditioner, a fire may break out.

Be sure to install an earth leakage breaker.

Unless it is installed, an electric shock may result.

Be sure the air conditioner is electrically grounded.

Do not connect the grounding conductor to a gas pipe, water pipe, lightning arrester and the grounding conductor for a telephone.

Imperfect grounding work may result in an electric shock.

Execute complete drain piping for perfect drainage.

Incomplete piping may result in a water leakage.

The appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure that they do not play with the appliance.

3. Operation range

If the temperature or the humidity is beyond the following conditions, safety devices may work and the air conditioner may not operate, or sometimes, water may drop from the indoor unit.

COOLING

OUTDOOR UNIT	INDOOR		OUTDOOR TEMPERATURE
	TEMPERATURE	HUMIDITY	
R35•45•60	DB	18 to 33	80% or below
	WB	18 to 24	
RY35•45•60	DB	18 to 33	80% or below
	WB	12 to 24	
R71•100•125 RP71•100•125 REP71•100•125	DB	21 to 35	80% or below
	WB	14 to 25	
RY71•100•125 RYP71•100•125 RYEP71•100•125	DB	18 to 35	80% or below
	WB	12 to 25	
RZP71•100•125	DB	21 to 35	80% or below
	WB	14 to 25	
RQ71•100•125	DB	18 to 37	80% or below
	WB	12 to 28	
RR71•100•125	DB	18 to 37	80% or below
	WB	12 to 28	
RZQ71•100•125•125	DB	18 to 37	80% or below
	WB	12 to 28	
RS50•60 RKS35•50•60 RXS35•50•60	DB	21 to 32	80% or below
	WB	14 to 23	
3MKS50 4MKS58•75•90 3MXS52•2MXS52 4MXS68•80	DB	21 to 32	80% or below
	WB	14 to 23	
RMKS112•140•160 RMKS112•140•160	DB	21 to 32	80% or below
	WB	14 to 23	

HEATING

OUTDOOR UNIT	INDOOR TEMPERATURE		OUTDOOR TEMPERATURE	
	RY35•45•60	DB	15 to 27	DB
WB				-10 to 15.5
RY71•100•125 RYP71•100•125 RYEP71•100•125	DB	15 to 27	DB	-9 to 21
			WB	-10 to 15.5
RZP71•100•125	DB	15 to 27	DB	-14 to 21
			WB	-15 to 15.5
RQ71•100•125	DB	10 to 27	DB	-9 to 21
			WB	-10 to 15
RZQ71•100•125•140	DB	10 to 27	DB	-19.5 to 21
			WB	-20 to 15.5
RXS35•50•60	DB	10 to 30	DB	-14 to 24
			WB	-15 to 18
3MXS52•2MXS52 •4MXS68•80	DB	10 to 30	DB	-14 to 21
			WB	-15 to 15.5
RMXS112•140•160	DB	10 to 30	DB	-14 to 21
			WB	-15 to 15.5

DB: Dry bulb temperature (°C)

WB: Wet bulb temperature (°C)

The setting temperature range of the remote control is 16°C to 32°C.

4. INSTALLATION SITE

Regarding places for installation

- **Is the air conditioner installed at a well-ventilated place where there are no obstacles around?**
- **Do not use the air conditioner in the following places.**
 - a. Filled with much mineral oil such as cutting oil.
 - b. Where there is much salt such as a beach area.
 - c. Where sulfured gas exists such as a hot-spring resort.
 - d. Where there are considerable voltage fluctuations such as a factory or plant.
 - e. Vehicles and vessels.
 - f. Where there is much spray of oil and vapor such as a cookery, etc.
 - g. Where there are machines generating electromagnetic waves.
 - h. Filled with acid and/or alkaline steam or vapor
- **Is a snow protection measure taken?**
For details, consult your dealer.

Regarding wiring

- All wiring must be performed by an authorized electrician.
To do wiring, ask your dealer. Never do it by yourself.
- Make sure that a separate power supply circuit is provided for this air conditioner and that all electrical work is carried out by qualified personnel according to local laws and regulations.

Pay attention to running noises, too



- Are the following places selected?
 - a. A place that can sufficiently withstand the weight of the air conditioner with less running noises and vibrations.
 - b. A place where the hot wind discharged from the air outlet of outdoor unit and the running noises.
- Are you sure that there are no obstacles near the air outlet of the outdoor unit?
Such obstacles may result in declined performance and increased running noises.
- If abnormal noises occur in use, stop the operation of the air conditioner, and then consult your dealer or our service station.











Regarding drainage of drain piping

- Is the drain piping executed to perform complete drainage?
If proper drainage is not carried out from the outdoor drain pipes during air-conditioning operation, chances are that dust and dirt are clogged in the pipe. This may result in a water leakage from the indoor unit. Under such circumstances, stop the operation of the air conditioner, and then consult your dealer or our service station.

5. NAME AND FUNCTION OF EACH SWITCH AND DISPLAY ON THE REMOTE CONTROL

Refer to figure 1 on page [1]

1	ON/OFF BUTTON Press the button and the system will start. Press the button again and the system will stop.
2	OPERATION LAMP (RED) The lamp lights up during operation.
3	DISPLAY “” (UNDER CENTRALIZED CONTROL) When this display shows, the system is UNDER CENTRALIZED CONTROL.
4	DISPLAY “” (VENTILATION/AIR CLEANING) This display shows that the total heat exchange and the air cleaning unit are in operation (These are optional accessories).

5	DISPLAY “” (OPERATION MODE) This display shows the current OPERATION MODE. For cooling only type, “  ” (Auto) and “  ” (Heating) are not installed.
6	DISPLAY “ TEST” (INSPECTION/TEST OPERATION) When the INSPECTION/TEST OPERATION BUTTON is pressed, the display shows the system mode is in.
7	DISPLAY “” (PROGRAMMED TIME) This display shows the PROGRAMMED TIME of the system start or stop.
8	DISPLAY “” (SET TEMPERATURE) This display shows the set temperature.
9	DISPLAY “” (FAN SPEED) This display shows the set fan speed.
10	DISPLAY “” (AIR FLOW FLAP) Refer to “AIR FLOW DIRECTION ADJUST”.
11	DISPLAY “” (TIME TO CLEAN AIR FIL-TER) Refer to “HOW TO CLEAN THE AIR FILTER”.
12	DISPLAY “” (DEFROST) Refer to “DEFROST OPERATION”.
13	NON-FUNCTIONING DISPLAY If that particular function is not available, pressing the button may display the words “NOT AVAILABLE” for a few seconds. When running multiple units simultaneously The “NOT AVAILABLE” message will only be appear if none of the indoor units is equipped with the function. If even one unit is equipped with the function, the display will not appear.
14	TIMER MODE START/STOP BUTTON Refer to “PROGRAM TIMER OPERATION”.
15	TIMER ON/OFF BUTTON Refer to “PROGRAM TIMER OPERATION”.
16	INSPECTION/TEST OPERATION BUTTON This button is used only by qualified service persons for maintenance purposes.
17	PROGRAMMING TIME BUTTON Use this button for programming “START and/or STOP” time.
18	TEMPERATURE SETTING BUTTON Use this button for SETTING TEMPERATURE.
19	FILTER SIGN RESET BUTTON Refer to HOW TO CLEAN THE AIR FILTER.

20	FAN SPEED CONTROL BUTTON Press this button to select the fan speed, HIGH or LOW, of your choice.
21	OPERATION MODE SELECTOR BUTTON Press this button to select OPERATION MODE.
22	AIR FLOW DIRECTION ADJUST BUTTON Refer to "AIR FLOW DIRECTION ADJUST".
NOTE	
<ul style="list-style-type: none"> For the sake of explanation, all indications are shown on the display in Figure 1 contrary to actual running situations. 	

6. Operation procedure

Refer to figure 1 on page [1]

- Operating procedure varies with heat pump type and cooling only type. Contact your Daikin dealer to confirm your system type.
- To protect the unit, turn on the main power switch 6 hours before operation.
- If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

Cooling, heating, automatic, fan, and program dry operation

Operate in the following order.

1 **Operation mode selector**

Press **OPERATION MODE SELECTOR** button several times and select the **OPERATION MODE** of your choice as follows.

- COOLING OPERATION.....“ ”
- HEATING OPERATION.....“ ”
- AUTOMATIC OPERATION.....“ ”
 - In this operation mode, COOL/HEAT changeover is automatically conducted.
- FAN OPERATION.....“ ”
- DRY OPERATION.....“ ”
 - The function of this program is to decrease the humidity in your room with the minimum temperature decrease.
 - Micro computer automatically determines TEMPERATURE and FAN SPEED.
 - This system does not go into operation if the room temperature is below 16°C.

Refer to figure 3 on page [1]

- For cooling only type, "COOLING", "FAN" and "DRY" operation are able to select.

2 **ON/OFF**

Press **ON/OFF** button

OPERATION lamp lights up or goes off and the system starts or stops OPERATION.

[EXPLANATION OF HEATING OPERATION]

DEFROST OPERATION

- As the frost on the coil of an outdoor unit increase, heating effect decreases and the system goes into DEFROST OPERATION.
- The indoor unit fan stops and the remot control display shows “ ”.
- After 6 to 8 minutes (maximum 10 minutes) of DEFROST OPERATION, the system returns to HEATING OPERATION.

Regarding outside air temperature and heating capacity

- The heating capacity of the air conditioner declines as the outside air temperature falls.
In such a case, use the air conditioner in combination with other heating systems.
- A warm air circulating system is employed, and therefore it takes some time until the entire room is warmed up after the start of operation.
- An indoor fan runs to discharge a gentle wind automatically until the temperature inside the air conditioner reaches a certain level. At this time, the remote control displays “ ”. Leave it as it stands and wait for a while.
- When the warm air stays under the ceiling and your feet are cold, we recommend that you use a circulator (a fan to circulate the air inside the room). For details, consult your dealer.


Adjustment

For programming TEMPERATURE, FAN SPEED and AIR FLOW DIRECTION, follow the procedure shown below.



Temperature setting

Press TEMPERATURE SETTING button and program the setting temperature.



Each time this button is pressed, setting temperature rises 1°C

Each time thus button is pressed, setting temperature lowers 1°C

- The setting is impossible for fan operation.

NOTE

- The setting temperature range of the remote control is 16°C to 32°C.



Fan speed control

Press FAN SPEED CONTROL button.

High or Low fan speed can be selected.

Micro computer may sometimes control the fan speed in order to protect the unit.




Air flow direction adjust

There are 2 ways of adjusting the air discharge angle.

1. A. up and down adjustment
2. B. Left and right direction

Fig. 1




A.UP AND DOWN DIRECTION.

- The movable limit of the flap is changeable. Contact your Daikin dealer for details.

Press the AIR FLOW DIRECTION ADJUST button


to select the air direction as following.



The AIR FLOW FLAP display swings as shown left and the air flow direction continuously varies. (Automatic swing setting)



Press AIR FLOW DIRECTION ADJUST button to select the air direction of your choice.



The AIR FLOW FLAP display stops swinging and the air flow direction is fixed (Fixed air flow direction setting).

Movement of the air flow flap

For the following conditions, micro computer controls the air flow direction so it may be different from the display.

Operation mode	Cooling	Heating
Operation condition	<ul style="list-style-type: none"> • When room temperature is higher than the set temperature 	<ul style="list-style-type: none"> • When room temperature is set higher than the set temperature • At defrost operation
	<ul style="list-style-type: none"> • When operating continuously at downward air flow direction 	

Operation mode includes automatic operation.

A.UP AND RIGHT DIRECTION.

- Adjusting air flow direction in the left and right direction.(Refer to fig. 1)

NOTE

- Only make adjustment after you have stopped the air flow direction swing in a position where adjustments are possible.Your hand may get caught if you attempt to make adjustments while the unit is swinging.

Program timer operation

Operate in the following order.

- The timer is operated in the following two ways.
- Programming the stop time (⊕ ▶ ○) ... The system stops operating after the set time has elapsed.
- Programming the start time (⊕ ▶ |) ... The system starts operating after the set time has elapsed.
- The timer can be programmed a maximum of 72 hours.
- The start and the stop time can be simultaneously programmed.

1 Timer mode START/STOP

Press the **TIMER MODE START/STOP** button several times and select the mode on the display.


The display flashes.

For setting the timer stop ... "⊕ ▶ ○"

For setting the timer start ... "⊕ ▶ |"

2 Programming time

Press the **PROGRAMMING TIME** button and set the time for stopping or starting the system.



When this button is pressed, the time advances by 1 hour.

When this button is pressed, the time goes backward by 1 hour.

3 Timer ON/OFF

Press the **TIMER ON/OFF** button.

The timer setting procedure ends.

The display "⊕ ▶ ○ or ⊕ ▶ |" changes from flashing light to a constant light.


Refer to figure 4 on page [1]

NOTE

- When setting the timer OFF and On at the same time, repeat the above procedure from **1** to **3** once again.
- When the timer is programmed to stop the system after 3 hours and start the system after 4 hours, the system will stop after 3 hours and then 1 hour later the system will start.
- After the timer is programmed, the display shows the remaining time.
 - Press the **TIMER ON/OFF** button once again to cancel programming. the display vanishes.

7. Optimum operation

Observe the following precautions to ensure the system operates.

- Adjust the room temperature properly for a comfortable environment. Avoid excessive heating or cooling.
- Prevent direct sunlight from entering a room during cooling operation by using curtains or blinds.
- Ventilate the room regularly.
Using the unit for long periods of time requires attentive ventilation of the room.
- Keep doors and windows closed. If the doors and windows remain open, room air will flow out and cause to decrease the effect of cooling and heating.
- Do not place other heaters directly below the indoor unit. They may deform due to the heat.
- Never place objects near the air inlet and the air outlet of the unit. It may cause deterioration in the effect or stop in the operation.
- Turn off the main power supply switch when it is not used for long periods of time. When the main power switch is turned on, some watts of electricity is being used even if the system is not operating. Turn off the main power supply switch for saving energy. When reoperating, turn on the main power supply switch 6 hours before operation for smooth running (Refer to MAINTENANCE)
- When the display shows "  " (TIME TO CLEAN AIR FILTER), ask a qualified service person to clean the filters (Refer to MAINTENANCE).

**8. Maintenance
(For service personnel)**

Only a qualified service person is allowed to perform maintenance

IMPORTANT!

- Before obtaining access to terminal devices, all power supply circuits must be interrupted
- To clean the air conditioner, be sure to stop operation, and turn the power switch off. Otherwise, an electric shock and injury may result.
- Do not wash the air conditioner with water. Doing so may result in an electric shock.
- Be careful with a scaffold or staging. Caution must be exercised because of work at a high place.

Fig. 2




Fig. 3




Fig. 4






Fig. 5



How to clean the air filter

Clean the air filter when the display shows “” (TIME TO CLEAN AIR FILTER).

It will display that it will operate for a set amount of time. Increase the frequency of cleaning if the unit is installed in a room where the air is extremely contaminated.

If the dirt becomes impossible to clean, change the air filter (Air filter for exchange is optional)

- 1. Open the suction grille**
Slide both knobs simultaneously as shown and then pull them downward.
(Follow the same procedure for closing.)
(Refer to Fig. 2)
- 2. Remove the air filter**
Push the 2 tabs up, and slowly lower the grille.
(Refer to Fig. 3)
- 3. Clean the air filter**
Use a vacuum cleaner **A)** or wash the air filter with water **B).**

A) Using a vacuum cleaner



B) Washing with water

When the air filter is very dirty, use soft brush and neutral detergent.



Remove water and dry in the shade.

NOTE 

- Do not wash the air conditioner with hot water of more than 50°C, as doing so may result in discoloration and/or deformation.
 - Do not expose it to fire, as doing so may result in burning.
- 4. Fix the air filter**
Set the hatch of the air filter to the fook of the suction grille, and fix the air filter.
(Refer to Fig. 5)
 - 5. Close the suction grille.**
Refer to item No. 1.
 - 6. After turing on the power, press FILTER SIGN RESET button.**
The “TIME TO CLEAN AIR FILTER” display vanishes.

How to clean air outlet and outside panels

- Clean with soft cloth.
- When it is difficult to remove stains, use water or neutral detergent.

NOTE

- Do not use gasoline, benzene, thinner, polishing powder, liquid insecticide. It may cause discoloring or warping.
- Do not let the indoor unit get wet. It may cause an electric shock or a fire.
- Do not use water or air of 50°C or higher for cleaning air filters and outside panels.

How to clean the suction grille

1. Open the suction grille.

Slide both knobs and then pull them downward.
(Do the same procedure for closing.)

2. Remove the air filter.

Refer to "HOW TO CLEAN THE AIR FILTER".

(Refer to Fig. 3)

3. Remove the suction grille.

Open the suction grille and pull the clips on the back of the suction grille forward.

(Refer to Fig. 4)

4. Clean the suction grille.

Wash with a soft bristle brush and neutral detergent or water, and dry thoroughly.



When very grimy

Directly apply the type of detergent used for cleaning ventilation fans or ovens, wait 10 minutes, and then rinse with water.

NOTE

- Do not wash the air conditioner with hot water of more than 50°C, as doing so may result in discoloration and/or deformation.
- 5. **Fix the air filter.**
Refer to "HOW TO CLEAN THE AIR FILTER".
- 6. **Fix the suction grille.**
Refer to item No. 3.
- 7. **Shut the suction grille.**
Refer to item No. 1.

Start up after a long stop

Confirm the following

- Check that the air inlet and outlet are not blocked. Remove any obstacle.
- Check if the earth is connected.
Might there be a broken wire somewhere?
Contact your dealer if there are any problems.

Clean the air filter and outside panels

- After cleaning the air filter, make sure to attach it.

Turn on the main power supply switch

- The display on the remote control will be shown when the power is turned on.
- To protect the unit, turn on the main power switch at least 6 hours before operation.

What to do when stopping the system for a long period

Turn on FAN OPERATION for half a day and dry the unit.

- Refer to "6. Operation procedure".

Cut off the power supply.

- When the main power switch is turned on, some watts of electricity is being used even if the system is not operating. Turn off the main power supply switch for saving energy.
- The display on the remote control will vanish when the main power switch is turned off.

Clean the air filter and the exterior.

- Be sure to replace the air filter to its original place after cleaning. Refer to "Maintenance".

9. NOT MALFUNCTION OF THE AIR CONDITIONER

The following symptoms do not indicate air conditioner malfunction

I. The system does not operate

- **The system does not restart immediately after the ON/OFF button is pressed.**


If the OPERATION lamp lights, the system is in normal condition.

It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.

- **The system does not restart immediately when TEMPERATURE SETTING button is returned to the former position after pushing the button.**

If the OPERATION lamp lights, the system is in normal condition.

It does not restart immediately because a safety device operates to prevent overload of the system. After 3 minutes, the system will turn on again automatically.

- **The system does not start when the display shows “” (UNDER CENTRALIZED CONTROL) and it flashes for few seconds after pressing an operation button.**

This is because the system is under centralized control. Flashes on the display indicates that the system cannot be controlled by the remote control.

- **The system does not start immediately after the power supply is turned on.**
Wait one minute until the micro computer is prepared for operation.
- **The outdoor unit is stopped.**
This is because the room temperature has reached the set temperature. The indoor unit switches to fan operation.

II. When “” (UNDER CENTRALIZED CONTROL) is displayed and operation is different from the remote control display.

This is because operating mode is controlled by a micro computer, as shown below, depending on the operating mode of the other connected indoor units when using in a multi system.

- **If the operating mode does not match that of the other indoor units which are already running, the indoor unit goes into standby mode (the fan stops and the air flow flaps become horizontal).**
The unit will go into the above mode if either cooling, dry, or fan operation mode are set together with heating mode.

NOTE

- Normally, the operation mode in the room where the unit is first run is given priority, but the following situations are exceptions, so please keep this in mind.
 - a. If the operation mode of the first room is **FAN Mode**, then using **Heating Mode** in any room after this will give priority to heating. In this situation, the air conditioner running in FAN Mode will go on standby.
 - b. With the Priority Room Setting active.
Contact your Daikin dealer for the operation that corresponds to your system.
- **If the total capacity of operating indoor units exceeds the limit, the indoor unit will assume the STANDBY state (FAN and AIR FLOW DIRECTION will be left as set). (This only applies to cooling only type.)**
- **If another indoor unit commences a HEATING operation after this indoor unit is running in COOLING mode, this indoor unit may switch to DRY operation (fan on low, air flow flap set at horizontal).**

III. The fan speed is different from the setting.

- **Pressing the fan speed control button does not change the fan speed.**
When the room temperature reaches the set temperature in heating mode, the power supply from the outdoor unit is stopped and the indoor unit will operate on the low fan setting. (If using the multi system, the fan will alternate between off and low.)
This is to prevent the cool air from being blown directly onto anyone in the room.

IV. Air blow direction is not as specified.

- **Actual air blow direction is not as shown on the remote control.**
- **Automatic swing setting does not work.**
Refer to “AIR FLOW DIRECTION ADJUST.”

V. White mist comes out of a unit

- **When humidity is high during cooling operation (In oily of dusty places)**
If the inside of an indoor unit is extremely contaminated, the temperature distribution inside a room becomes uneven. It is necessary to clean the inside of the indoor unit. Ask your Daikin dealer for details on cleaning the unit. This operation requires a qualified service person.
- **When the system is changed over to HEATING OPERATION after DEFROST OPERATION.**
Moisture generated by DEFROST becomes steam and exists.

VI. Noise of air conditioners

- **A ringing sound after the unit is started.**
This sound is generated by the temperature regulator working.
It will quiet down after about a minute.
- **A continuous flow “Shuh” sound is heard when the system is in COOLING or DEFROST OPERATION.**
This is the sound of refrigerant gas flowing through both indoor and outdoor units.
- **A “Shuh” sound which is heard at the start or immediately after the stop of operation or which is heard at the start or immediately after the stop of DEFROST OPERATION.**
This is the noise of refrigerant caused by flow stop and flow change.
- **A continuous flowing sound “Shah” or a trickling sound “Jyuru Jyuru” are heard when the system is in COOLING OPERATION or at a stop.**
The noise is heard when the drain pump is in operation.
- **A “Pishi-Pishi” squeaking sound is heard when the system is in operation or after the stop of operation.**
Expansion and contraction of plastic parts caused by temperature change makes this noise.

VII. Dust from the units

- **Dust may blow out from the unit after starting operation from long resting time.**
Dust absorbed by the unit blows out.

VIII. The units give off odors

The unit absorbs the smell of rooms, furniture, cigarettes, etc., and then emits them.

IX. The liquid crystal of the remote control show “88”

- **It happens immediately after the main power supply switch is turned on.**
This shows that the remote control is in normal condition. This continues temporary.

10. Trouble shooting


I. If one of the following malfunctions occurs, take the measures shown below and contact your Daikin dealer.


The system must be repaired by a qualified service person.

⚠ WARNING

When the air conditioner is in abnormal conditions (smell of something burning, etc.), unplug the power cord from the outlet, and contact your dealer

Continued operation under such circumstances may result in a failure, electric shock, and fire.

- If a safety device such as a fuse, a breaker, or an earth leakage breaker frequently actuates, or ON/OFF switch does not properly work.
Measure: Turn off the main power switch
- If water leaks from unit.
Measure: Stop the operation.
- If the display “” (INSPECTION), “UNIT No.,” and the OPERATION lamp flash and the “MALFUNCTION CODE” appears.



Measure: Notify and inform the model name and what the malfunction code indicates to your Daikin dealer.

II. If the system does not properly operate except for the above mentioned case, and none of the above mentioned malfunctions is evident, investigate the system according to the following procedures.

- 1. If the system does not operate at all.**
 - Check if there is a power failure.
Wait until power is restored. If power failure occurs during operation, the system automatically restarts immediately after the power supply recovers.
 - Check if the fuse has blown or breaker has worked.
Change the fuse or set the breaker.
- 2. If the system stops operating after operating the system.**
 - Check if the air inlet or outlet of outdoor or indoor unit is blocked by obstacles.
Remove the obstacle and make it well-ventilated.
 - Check if the air filter is clogged.
Ask a qualified service person to clean the air filters (Refer to MAINTENANCE).
- 3. The system operates but it does not sufficiently cool or heat.**
 - If the air inlet or outlet of the indoor or the outdoor unit is

blocked with obstacles.

Remove the obstacle and make it well-ventilated.

- If the air filter is clogged.
Ask a qualified service person to clean the air filters (Refer to MAINTENANCE).
- If the set temperature is not proper (Refer to ADJUSTMENT).
- If the FAN SPEED button is set to LOW SPEED (Refer to ADJUSTMENT).
- If the air flow angle is not proper (Refer to AIR FLOW DIRECTION ADJUST).
- If the doors or the windows are open.
Shut the doors or windows to prevent wind from coming in.
- If direct sunlight enters the room (when cooling).
Use curtains or blinds.
- When there are too many inhabitants in the room (when cooling).
Cooling effect decreases if heat gain of the room is too large.
- If the heat source of the room is excessive (when cooling).
Cooling effect decreases if heat gain of the room is too large.

Part 6

Service Diagnosis

1. Caution for Diagnosis.....	226
1.1 Troubleshooting with Operation Lamp	226
2. Problem Symptoms and Measures	228
3. Service Check Function	229
3.1 Check Method 1	229
3.2 Check Method 2	231
4. Code Indication on the Remote Control	233
4.1 Error Codes and Description of Fault	233
5. Troubleshooting	234
5.1 Indoor Units	234
5.2 Outdoor Units	235
5.3 Indoor Unit PCB Abnormality	236
5.4 Freeze-up Protection Control or High Pressure Control.....	237
5.5 Fan Motor or Related Abnormality	239
5.6 Thermistor or Related Abnormality (Indoor Unit).....	242
5.7 Front Panel Open / Close Fault.....	243
5.8 Signal Transmission Error (between Indoor and Outdoor Unit)	244
5.9 Unspecified Voltage (between Indoor and Outdoor Units).....	246
5.10 Freeze-up Protection Control	247
5.11 Outdoor Unit PCB Abnormality.....	249
5.12 OL Activation (Compressor Overload)	250
5.13 Compressor Lock	251
5.14 DC Fan Lock	252
5.15 Input Over Current Detection	253
5.16 Discharge Pipe Temperature Control.....	255
5.17 High Pressure Control in Cooling	256
5.18 Compressor Sensor System Abnormality	258
5.19 Position Sensor Abnormality	260
5.20 CT or Related Abnormality	261
5.21 Thermistor or Related Abnormality (Outdoor Unit).....	263
5.22 Electrical Box Temperature Rise	265
5.23 Radiation Fin Temperature Rise	267
5.24 Output Over Current Detection.....	269
5.25 Insufficient Gas.....	271
5.26 Low-voltage Detection or Over-voltage Detection.....	273
5.27 Signal Transmission Error (on Outdoor Unit PCB).....	274
5.28 Anti-icing Function in Other Rooms / Unspecified Voltage (between Indoor and Outdoor Units).....	275
6. Check	276
6.1 How to Check.....	276

1. Caution for Diagnosis

1.1 Troubleshooting with Operation Lamp


The operation lamp flashes when any of the following errors is detected.

1. When a protection device of the indoor or outdoor unit is activated or when the thermistor malfunctions, disabling equipment operation.
2. When a signal transmission error occurs between the indoor and outdoor units.


In either case, conduct the diagnostic procedure described in the following pages.

Location of Operation Lamp


In case of
FTK(X)S 20/25/35/50 D Series




In case of
FTK(X)S 20/25/35 C Series




In case of
FTK(X)S 50/60/71 F Series




In case of
FTXG 25/35 E, CTXG 50 E Series




In case of
FDK(X)S 25/35/50/60 C Series
FDK(X)S 25/35 E Series



In case of
FVXS 25/35/50 F Series



In case of
FLK(X)S 25/35/50/60 B Series



(Q0341)

**Caution:**

Operation stops suddenly. (Operation lamp blinks.)
Cause of above trouble could be "Operation mode conflict".
Check followings;

Are the operation modes all the same for indoor units connected to Multi system outdoor unit?
If not set all indoor units to the same operation mode and confirm that the operation lamp is not blinking.


Moreover, when the operation mode is in "Auto", set all indoor unit operation mode to "Cool" or "Heat" and check again if the operation lamp is normal.

If the lamp stops blinking after the above steps, there is no malfunction.

★Operation stops and operation lamp blinks only for indoor unit which the different operation mode is set later. (The first set operation mode has priority.)

Troubleshooting with the LED Indication

Outdoor Unit



(Q0343)

There are green and red LEDs on the PCB. The flashing green LED indicates normal equipment condition, and the OFF condition of the red LED indicates normal equipment condition.
(Troubleshooting with the green LED)

The LED A (green) of the outdoor unit indicate microcomputer operation condition.

Even after the error is cancelled and the equipment operates in normal condition, the LED indication remains.

2. Problem Symptoms and Measures

Problem Symptom	Check Item	Details of Measure	Page No. to be referred
None of the units operates.	Check the power supply.	Check to make sure that the rated voltage is supplied.	—
	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 15.5°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below -10 °C	—
	Diagnosis with indoor unit LED indication	—	234
	Diagnosis with outdoor unit LED indication	—	235
	Check the remote control addresses.	Check to make sure that address settings for the remote control and indoor unit are correct.	—
Operation sometimes stops.	Check the power supply.	A power failure of 2 to 10 cycles can stop air conditioner operation. (Operation lamp OFF)	—
	Check the outdoor air temperature.	Heating operation cannot be used when the outdoor air temperature is 15.5°C or higher (only for heat pump model), and cooling operation cannot be used when the outdoor air temperature is below -10°C	—
	Diagnosis with indoor unit LED indication	—	234
	Diagnosis with outdoor unit LED indication	—	235
Some indoor units do not operate.	Check the type of the indoor units.	Check to make sure that the indoor unit type is compatible with the outdoor unit.	—
	Diagnosis with indoor unit LED indication	—	234
	Diagnosis with outdoor unit LED indication	—	235
Equipment operates but does not cool, or does not heat (only for heat pump model).	Check for wiring and piping errors in the indoor and outdoor units connection wires and pipes.	Conduct the wiring/piping error check described on the product diagnosis nameplate.	—
	Check for thermistor detection errors.	Check to make sure that the main unit's thermistor has not dismantled from the pipe holder.	—
	Check for faulty operation of the electronic expansion valve.	Set the units to cooling operation, and compare the temperatures of the liquid side connection pipes of the connection section among rooms to check the opening and closing operation of the electronic expansion valves of the individual units.	—
	Diagnosis with indoor unit LED indication	—	234
	Diagnosis with outdoor unit LED indication	—	235
	Diagnosis by service port pressure and operating current	Check for insufficient gas.	282
Large operating noise and vibrations	Check the output voltage of the power transistor.	—	283
	Check the power transistor.	—	—
	Check the installation condition.	Check to make sure that the required spaces for installation (specified in the Engineering Data book, etc.) are provided.	—


3. Service Check Function

3.1 Check Method 1

The temperature display sections on the main unit indicate corresponding codes.

ARC433 Series

1. When the timer cancel button is held down for 5 seconds, a "00" indication flashes on the temperature display section.



2. Press the timer cancel button repeatedly until a continuous beep is produced.
 - The code indication changes in the sequence shown below, and notifies with a long beep.

No.	Code	No.	Code	No.	Code
1	00	12	C7	23	H0
2	U4	13	H8	24	E1
3	F3	14	J3	25	P4
4	E6	15	A3	26	L3
5	L5	16	A1	27	L4
6	A6	17	C4	28	H6
7	E5	18	C5	29	H7
8	F6	19	H9	30	U2
9	C9	20	J6	31	UH
10	U0	21	UR	32	ER
11	E7	22	A5	33	AH

<In case of ARC433B70, 71>

No.	Code	No.	Code	No.	Code
1	00	12	F6	23	A1
2	U4	13	C7	24	E1
3	L5	14	A3	25	UR
4	E6	15	H8	26	UH
5	H6	16	H9	27	P4
6	H0	17	C9	28	L3
7	A6	18	C4	29	L4
8	E7	19	C5	30	H7
9	U0	20	J3	31	U2
10	F3	21	J6	32	ER
11	A5	22	E5	33	AH




Note:

1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

ARC452A Series

1. When the timer cancel button is held down for 5 seconds, a “00” indication flashes on the temperature display section.



(R6757)

2. Press the timer cancel button repeatedly until a continuous beep is produced.
 - The code indication changes in the sequence shown below, and notifies with a long beep.

No.	Code	No.	Code	No.	Code
1	00	13	C7	25	UR
2	U4	14	R3	26	UH
3	L5	15	H8	27	P4
4	E6	16	H9	28	L3
5	H6	17	C9	29	L4
6	H0	18	C4	30	H7
7	R6	19	C5	31	U2
8	E7	20	J3	32	ER
9	U0	21	J6	33	RH
10	F3	22	E5	34	FR
11	R5	23	R1		
12	F6	24	E1		




Note:


1. A short beep and two consecutive beeps indicate non-corresponding codes.
2. To cancel the code display, hold the timer cancel button down for 5 seconds. The code display also cancels itself if the button is not pressed for 1 minute.

3.2 Check Method 2


1. Enter the diagnosis mode.
Press the 3 buttons (TEMP▲,TEMP▼, MODE) simultaneously.




- The digit of the number of tens blinks.
- ★Try again from the start when the digit does not blink.




2. Press the TEMP button.
Press TEMP▲ or TEMP▼ and change the digit until you hear the sound of “beep” or “pi pi”.




3. Diagnose by the sound.
 - ★“pi” : The number of tens does not accord with the error code.
 - ★“pi pi” : The number of tens accords with the error code.
 - ★“beep” : The both numbers of tens and units accord with the error code. (→ See 7.)
4. Enter the diagnosis mode again.
Press the MODE button.




- The digit of the number of units blinks.



5. Press the TEMP button.
Press TEMP▲ or TEMP▼ and change the digit until you hear the sound of “beep”.



6. Diagnose by the sound.
 - ★“pi” : The both numbers of tens and units do not accord with the error code.
 - ★“pi pi” : The number of tens accords with the error code.
 - ★“beep” : The both numbers of tens and units accord with the error code.
7. Determine the error code.
The digits indicated when you hear the “beep” sound are error code.
(Error codes and description → Refer to page 233.)
8. Exit from the diagnosis mode.
Press the MODE button.



4. Code Indication on the Remote Control

4.1 Error Codes and Description of Fault

	Code Indication	Description of Problem
System	<i>00</i>	Normal
	<i>U0</i>	Insufficient gas
	<i>U2</i>	Low-voltage detection or over-voltage detection
	<i>U4</i>	Signal transmission error (between indoor and outdoor units)
	<i>U7</i>	Signal transmission error (on outdoor unit PCB)
	<i>UA</i>	Unspecified voltage (between indoor and outdoor units)
	<i>UH</i>	Anti-icing function in other rooms
Indoor Unit	<i>R1</i>	Indoor unit PCB abnormality
	<i>R5</i>	Freeze-up protection function or high pressure control
	<i>R6</i>	Fan motor or related abnormality
	<i>C4</i>	Heat exchanger temperature thermistor abnormality
	<i>C7</i>	Front panel open / close fault
	<i>C9</i>	Room temperature thermistor abnormality
Outdoor Unit	<i>R5</i>	Freeze-up protection control
	<i>E1</i>	Outdoor unit PCB abnormality
	<i>E5</i>	OL activation (compressor overloaded)
	<i>E6</i>	Compressor lock
	<i>E7</i>	DC fan lock
	<i>E8</i>	Input over current detection
	<i>F3</i>	Discharge pipe temperature control
	<i>F6</i>	High pressure control in cooling
	<i>H0</i>	Compressor sensor system abnormality
	<i>H5</i>	Position sensor abnormality
	<i>H8</i>	CT or related abnormality
	<i>H9</i>	Outdoor air thermistor or related abnormality
	<i>J3</i>	Discharge pipe thermistor or related abnormality
	<i>J6</i>	Heat exchanger thermistor or related abnormality
	<i>J8</i>	Liquid pipe thermistor or related abnormality
	<i>J9</i>	Gas pipe thermistor or related abnormality
	<i>L3</i>	Electrical box temperature rise
	<i>L4</i>	Radiation fin temperature rise
	<i>L5</i>	Output over current detection
	<i>P4</i>	Radiation fin thermistor or related abnormality

5. Troubleshooting

5.1 Indoor Units

- : Not used for troubleshooting

* : Varies depending on the cases.

Indication on the remote control	Description of the Fault		Details of fault (Refer to the indicated page.)
<i>00</i>	Indoor unit in normal condition (Conduct a diagnosis of the outdoor unit.)		—
<i>R1</i>	Indoor unit PCB abnormality		236
<i>R5</i>	Freeze-up protection control or high pressure control (heat pump model only)		237
<i>R6</i>	Fan motor or related abnormality	AC motor (Wall : 20~35 C series, Duct, Floor / Ceiling)	239
		DC motor (Wall : 20~50 D, E series, Floor)	240
<i>C4</i>	Heat exchanger thermistor or related abnormality		242
<i>C7</i>	Front panel open / close fault (FTXG-E series, CTXG-E series)		243
<i>C9</i>	Room temperature thermistor abnormality		242
<i>U4</i>	Signal transmission error (between indoor and outdoor units)		244
<i>UR</i>	Unspecified voltage (between indoor and outdoor units)		246

5.2 Outdoor Units

☉: ON, ●: OFF, ◐: Blinks

Green : Flashes when in normal condition

Red : OFF in normal condition

- : Not used for troubleshooting

* : Varies depending on the cases.

Outdoor Unit LED Indication					Indication on the remote control	Description of The Fault	Reference Page
Green	Red						
A	1	2	3	4			
◐	●	●	●	●	00	Outdoor unit in normal condition (Conduct a diagnosis of the indoor unit.)	—
					UR	Unspecified voltage (between indoor and outdoor units)	275
					UH	Anti-icing function in other rooms	275
◐	●	●	☉	☉	(UD)	Insufficient gas	271
◐	☉	●	●	☉	U2	Low-voltage detection or over-voltage detection	273
◐	●	☉	☉	☉	U7	Signal transmission error (on outdoor unit PCB)	274
◐	☉	●	☉	☉	R5	Freeze-up protection control	247
◐	☉	☉	☉	●	E1	Outdoor unit PCB abnormality	249
◐	☉	●	☉	●	(E5)	OL activation (compressor overload)	250
◐	●	☉	☉	●	(E6)	Compressor lock	251
◐	☉	☉	☉	☉	E7	DC fan lock	252
◐	●	☉	●	☉	E8	Input over current detection	253
◐	☉	●	☉	●	F3	Discharge pipe temperature control	255
◐	☉	●	☉	☉	F6	High pressure control in cooling	256
◐	☉	☉	●	●	H0	Compressor sensor system abnormality	258
					H8	CT or related abnormality	261
◐	☉	☉	●	●	H5	Position sensor abnormality	260
					H9	Outdoor air thermistor or related abnormality	263
					J3	Discharge pipe thermistor or related abnormality	263
					J6	Heat exchanger thermistor or related abnormality	263
					J8	Liquid pipe thermistor or related abnormality	263
					J9	Gas pipe thermistor or related abnormality	263
◐	☉	☉	●	☉	P4	Radiation fin thermistor or related abnormality	263
					L3	Electrical box temperature rise	265
◐	●	●	●	☉	L4	Radiation fin temperature rise (Protection of driver overheating)	267
◐	●	●	☉	●	L5	Output over current detection	269



Note:

- The indications in the parenthesis () in the remote control display column are displayed only when system-down occurs.
- When a sensor error occurs, check the remote control display to determine which sensor is malfunctioning.
If the remote control does not indicate the error type, conduct the following operation.
*Turn the power switch off and back on again. If the same LED indication appears again immediately after the power is turned on, the fault is in the thermistor.
*If the above condition does not result, the fault is in the CT.
- The indoor unit error indication may take the precedence in the remote control display.

5.3 Indoor Unit PCB Abnormality


Remote Control Display *A1*


Method of Malfunction Detection Evaluation of zero-cross detection of power supply by indoor unit.

Malfunction Decision Conditions When there is no zero-cross detection in approximately 10 continuous seconds.


- Supposed Causes**
- Faulty indoor unit PCB
 - Faulty connector connection

Troubleshooting

 **Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R1400)

 **Note:** Connector Nos. vary depending on models.
Control connector

Model Type	Connector No.
Wall Mounted Type 20 / 25 / 35 class	Terminal strip~Control PCB
Wall Mounted Type 50 / 60 / 71 class	Terminal strip~Control PCB
Duct Connected Type	Terminal strip~Control PCB
Floor / Ceiling Suspended Dual Type	S37
Floor Standing Type	Terminal strip~Control PCB

5.4 Freeze-up Protection Control or High Pressure Control

Remote Control
Display

RS

**Method of
Malfunction
Detection**

- High pressure control (heat pump model only)
During heating operations, the temperature detected by the indoor heat exchanger thermistor is used for the high pressure control (stop, outdoor fan stop, etc.)
- The freeze-up protection control (operation halt) is activated during cooling operation according to the temperature detected by the indoor unit heat exchanger thermistor.

**Malfunction
Decision
Conditions**

- High pressure control
During heating operations, the temperature detected by the indoor heat exchanger thermistor is above 65°C
- Freeze-up protection
When the indoor unit heat exchanger temperature is below 0°C during cooling operation.

**Supposed
Causes**

- Operation halt due to clogged air filter of the indoor unit.
- Operation halt due to dust accumulation on the indoor unit heat exchanger.
- Operation halt due to short-circuit.
- Detection error due to faulty indoor unit heat exchanger thermistor.
- Detection error due to faulty indoor unit PCB.


Troubleshooting



Check No.06
Refer to P.279



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



Note: If the outside temperature is below -10°C in the cooling mode, the system may get interrupted with error *R5* displayed. The system will be reset itself, but this stop will be put in the error history memory.

5.5 Fan Motor or Related Abnormality

5.5.1 AC Motor

Remote Control Display *RG*


Method of Malfunction Detection
The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation.


Malfunction Decision Conditions
When the detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.

- Supposed Causes**
- Operation halt due to short circuit inside the fan motor winding.
 - Operation halt due to breaking of wire inside the fan motor.
 - Operation halt due to breaking of the fan motor lead wires.
 - Operation halt due to faulty capacitor of the fan motor.
 - Detection error due to faulty control PCB.

Troubleshooting


Check No.16
Refer to P.285

 **Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



5.5.2 DC Motor

Remote Control
Display

AE

Method of
Malfunction
Detection

The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor operation.

Malfunction
Decision
Conditions

When the detected rotation speed does not reach the demanded rotation speed of the target tap, and is less than 50% of the maximum fan motor rotation speed.

Supposed
Causes

- Operation halt due to short circuit inside the fan motor winding.
- Operation halt due to breaking of wire inside the fan motor.
- Operation halt due to breaking of the fan motor lead wires.
- Operation halt due to faulty capacitor of the fan motor.
- Detection error due to faulty indoor unit PCB (1).

Troubleshooting



Check No.01
Refer to P.276




Check No.02
Refer to P.276



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R6961)

5.6 Thermistor or Related Abnormality (Indoor Unit)

Remote Control Display **Ⓔ4,Ⓔ9**

Method of Malfunction Detection The temperatures detected by the thermistors are used to determine thermistor errors.


Malfunction Decision Conditions When the thermistor input is more than 4.96 V or less than 0.04 V during compressor operation*.
 * (reference)
 When above about 212°C (less than 120 ohms) or below about -50°C (more than 1,860 kohms).

Note: The values vary slightly in some models.

- Supposed Causes**
- Faulty connector connection
 - Faulty thermistor
 - Faulty PCB

Troubleshooting

Check No.06
Refer to P.279



Ⓔ4 : Heat exchanger temperature thermistor
 Ⓔ9 : Room temperature thermistor

5.7 Front Panel Open / Close Fault

Remote Control Display E7

Method of Malfunction Detection


Malfunction Decision Conditions

- The system will be shut down when the error occurs twice.

Supposed Causes

- Malfunction of the reduction motor
- Malfunction or deterioration of the front panel mechanism
- Malfunction of the limit switch

Troubleshooting



(R3313)



Note: You cannot operate the unit by the remote control when the front panel mechanism breaks down.

<To the dealers: temporary measure before repair>

1. Pull the plug out or turn the breaker off.
2. Remove the decorative plate.
3. Remove the slot-in panel.
4. Put the plug in or turn the breaker on.
(Wait until the initialization finishes.)
5. Operate the unit by the indoor unit ON/OFF switch.

5.8 Signal Transmission Error (between Indoor and Outdoor Unit)

Remote Control
Display

U4

Method of
Malfunction
Detection

The data received from the outdoor unit in indoor unit-outdoor unit signal transmission is checked whether it is normal.

Malfunction
Decision
Conditions

When the data sent from the outdoor unit cannot be received normally, or when the content of the data is abnormal.


Supposed
Causes

- Faulty outdoor unit PCB.
- Faulty indoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wiring error.
- Indoor unit-outdoor unit signal transmission error due to disturbed power supply waveform.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units (wire No. 2).
- Short circuit inside the fan motor winding.

Troubleshooting


Check No.10
 Refer to P.282
**Caution**

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R6471)

5.9 Unspecified Voltage (between Indoor and Outdoor Units)


Remote Control Display *UR*

Method of Malfunction Detection The supply power is detected for its requirements (different from pair type and multi type) by the indoor / outdoor transmission signal.

Malfunction Decision Conditions The pair type and multi type are interconnected.






- Supposed Causes**
- Wrong models interconnected
 - Wrong indoor unit PCB mounted
 - Indoor unit PCB defective
 - Wrong outdoor unit PCB mounted or defective

Troubleshooting



5.10 Freeze-up Protection Control

Remote Control Display *RS*

Outdoor Unit LED Display A  1  2  3  4 

Method of Malfunction Detection Indoor unit icing, during cooling operation, is detected by checking the temperatures sensed by the indoor unit heat exchanger thermistor and room temperature thermistor that are located in a shut-down room.

Malfunction Decision Conditions In the cooling mode, the following conditions (A) and (B) are kept together for 5 minutes.
 (A) Indoor unit heat exchanger temperature $\leq -1^{\circ}\text{C}$
 (B) Indoor unit heat exchanger temperature \leq Room temperature -10°C

If the freeze-up protection control is activated 4 times continuously, the system will be shut down.

(The 4-time counter will reset itself if any of the following errors does not occur for 60 minutes: OL, radiation fin temperature rise, gas shortage, and compressor startup.)

Supposed Causes

- Wrong wiring or piping
- EV malfunctioning in each room
- Short-circuit
- Indoor unit heat exchanger thermistor defective
- Room temperature thermistor defective

Troubleshooting



Check No.04
Refer to P.277




Check No.06
Refer to P.279



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R4715)

5.11 Outdoor Unit PCB Abnormality

Remote Control
Display

E1

Outdoor Unit LED
Display

A ● 1 ○ 2 ○ 3 ○ 4 ●

Method of
Malfunction
Detection

- Detect within the programme of the microcomputer that the programme is in normal running order.

Malfunction
Decision
Conditions

- When the programme of the microcomputer is in abnormal running order.

Supposed
Causes


- Out of control of microcomputer caused by external factors
 - Noise
 - Momentary fall of voltage
 - Momentary power loss
- Defective outdoor unit PCB

Troubleshooting



Caution





Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R5142)

5.12 OL Activation (Compressor Overload)

Remote Control Display *E5*

Outdoor Unit LED Display A  1  2  3  4

Method of Malfunction Detection A compressor overload is detected through compressor OL.

Malfunction Decision Conditions

- If the compressor OL is activated twice, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

* The operating temperature condition is not specified.

Supposed Causes

- Refrigerant shortage
- Four way valve malfunctioning
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective


Troubleshooting


Check No.04
 Refer to P.277


Check No.05
 Refer to P.278





Check No.06
 Refer to P.279


Check No.11
 Refer to P.282



5.13 Compressor Lock

Remote Control Display **EE**

Outdoor Unit LED Display A  1  2  3  4

Method of Malfunction Detection A compressor lock is detected by checking the compressor running condition through the position detection circuit.


Malfunction Decision Conditions

- Judging from current waveform generated when high-frequency voltage is applied to the compressor.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 5 minutes (normal)

Supposed Causes






- Compressor locked

Troubleshooting



5.14 DC Fan Lock

Remote Control *E7*
Display

Outdoor Unit LED Display A  1  2  3  4 


Method of Malfunction Detection A fan motor line error is detected by checking the high-voltage fan motor rpm being detected by the Hall IC.

- Malfunction Decision Conditions**
- The fan does not start in 30 seconds even when the fan motor is running.
 - The system will be shut down if the error occurs 16 times.
 - Clearing condition: Continuous run for about 5 minutes (normal)

- Supposed Causes**
- Fan motor breakdown
 - Harness or connector disconnected between fan motor and PCB or in poor contact
 - Foreign matters stuck in the fan

Troubleshooting


Check No.15
Refer to P.284



5.15 Input Over Current Detection

Remote Control Display *EE*

Outdoor Unit LED Display A  1  2  3  4

Method of Malfunction Detection Malfunction is detected by checking the input current value.

Malfunction Decision Conditions

- The following condition continues for 2.5 seconds.
Input current $\geq 20\text{A}$ (typical value)
- The compressor halts if the error occurs, and restarts automatically after 3 minutes stand-by.

Supposed Causes

- Over-current due to compressor failure
- Over-current due to defective power transistor
- Over-current due to defective inverter main circuit electrolytic capacitor
- Over-current due to defective outdoor unit PCB
- Error detection due to outdoor unit PCB
- Over-current due to short-circuit

Troubleshooting



Check No.07
Refer to P.280



Check No.08
Refer to P.281




Check No.14
Refer to P.284



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.






* An input over-current may result from wrong internal wiring. If the wires have been disconnected and reconnected for part replacement, for example, and the system is interrupted by an input over-current, take the following procedure.



(R5144)

5.16 Discharge Pipe Temperature Control

Remote Control Display **F3**

Outdoor Unit LED Display A  1  2  3  4 

Method of Malfunction Detection
The discharge pipe temperature control (stop, frequency drooping, etc.) is checked with the temperature being detected by the discharge pipe thermistor.




Malfunction Decision Conditions
2YC45
If the temperature being detected by the discharge pipe thermistor rises above 120°C, the compressor will stop. (The error is cleared when the temperature has dropped below 107°C.)


- If the compressor stops 6 times straight due to abnormal discharge pipe temperature, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed Causes

- Refrigerant shortage
- Four way valve malfunctioning
- Discharge pipe thermistor defective (heat exchanger or outdoor temperature thermistor defective)
- Outdoor unit PCB defective
- Water mixed in the local piping
- Electronic expansion valve defective
- Stop valve defective






Troubleshooting

- 
Check No.04
Refer to P.277
- 
Check No.06
Refer to P.279
- 
Check No.11
Refer to P.282



5.17 High Pressure Control in Cooling

Remote Control Display *FB*

Outdoor Unit LED Display A  1  2  3  4 

Method of Malfunction Detection High-pressure control (stop, frequency drop, etc.) is activated in the cooling mode if the temperature being sensed by the heat exchanger thermistor exceeds the limit.

Malfunction Decision Conditions


- Activated when the temperature being sensed by the heat exchanger thermistor rises above 65°C.
- The error is cleared when the temperature drops below 50°C.

Supposed Causes

- The installation space is not large enough.
- Faulty outdoor unit fan
- Faulty electronic expansion valve
- Faulty outdoor unit heat exchanger thermistor
- Faulty outdoor unit PCB
- Faulty stop valve
- Dirty heat exchanger


Troubleshooting


Check No.04
 Refer to P.277


Check No.06
 Refer to P.279


Check No.07
 Refer to P.280







Check No.09
 Refer to P.281



(R4701)

5.18 Compressor Sensor System Abnormality

Remote Control Display *HO*

Outdoor Unit LED Display A  1  2  3  4 

Method of Malfunction Detection

- Fault condition is identified by the supply voltage and the DC voltage which is detected before the compressor startup.
- Fault condition is identified by compressor current which is detected right after the compressor startup.


Malfunction Decision Conditions

- The detected value of the supply voltage and the DC voltage is obviously low or high.
- The compressor current doesn't run when the compressor is started.

Supposed Causes

- Reactor disconnection
- Compressor disconnection
- Outdoor unit PCB defective
- Compressor defective

Troubleshooting



5.19 Position Sensor Abnormality

Remote Control *HE*
Display

Outdoor Unit LED Display A 1 2 3 4

Method of Malfunction Detection
A compressor startup failure is detected by checking the compressor running condition through the position detection circuit.

- Malfunction Decision Conditions**
- The compressor fails to start in about 15 seconds after the compressor run command signal is sent.
 - Clearing condition: Continuous run for about 5 minutes (normal)
 - The system will be shut down if the error occurs 8 times.

- Supposed Causes**
- Compressor relay cable disconnected
 - Compressor itself defective
 - Outdoor unit PCB defective
 - Stop valve closed
 - Input voltage out of specification

Troubleshooting




Check No.13
Refer to P.283



Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.

Check No. 13
Check for short-circuit.








(R5145)

5.20 CT or Related Abnormality

Remote Control
Display

H8

Outdoor Unit LED
Display

A  1  2  3  4 

Method of
Malfunction
Detection

A CT or related error is detected by checking the compressor running frequency and CT-detected input current.

Malfunction
Decision
Conditions

- The compressor running frequency is below 55 Hz and the CT input is below 0.1 V. (The input current is also below 0.5 A.)
- If this error repeats 4 times, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed
Causes

- Power transistor defective
- Internal wiring broken or in poor contact
- Reactor defective
- Outdoor unit PCB defective

Troubleshooting





Check No.12
Refer to P.283



Caution






Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



* Inverter checker
Part No.: 1225477

(R5146)


5.21 Thermistor or Related Abnormality (Outdoor Unit)

Remote Control Display	<i>P4, J3, J6, J8, J9, H9</i>
Outdoor Unit LED Display	A  1  2  3  4 
Method of Malfunction Detection	This type of error is detected by checking the thermistor input voltage to the microcomputer. [A thermistor error is detected by checking the temperature being detected by each thermistor.]
Malfunction Decision Conditions	When the thermistor input is above 4.96 V or below 0.04 V with the power on, the <i>J3</i> error is judged if the discharge pipe thermistor temperature is smaller than the condenser thermistor temperature, or the system will be shut down if all the units are judged with the <i>J8</i> error.
Supposed Causes	<ul style="list-style-type: none"> ■ Connector in poor contact ■ Thermistor defective ■ Outdoor unit PCB defective ■ Indoor unit PCB defective ■ Condenser thermistor defective in the case of <i>J3</i> error (outdoor unit heat exchanger thermistor in the cooling mode, or indoor unit heat exchanger thermistor in the heating mode)

Troubleshooting



Check No.06
Refer to P.279








- P4 : Radiation fin thermistor
- J3 : Discharge pipe thermistor
- J5 : Outdoor unit heat exchanger thermistor
- J8 : Liquid pipe thermistor
- J9 : Gas pipe thermistor
- H9 : Outdoor temperature thermistor

5.22 Electrical Box Temperature Rise

Remote Control
Display

L3

Outdoor Unit LED
Display

A  1  2  3  4 

Method of
Malfunction
Detection

An electrical box temperature rise is detected by checking the radiation fin thermistor with the compressor off.

Malfunction
Decision
Conditions

- With the compressor off, the radiation fin temperature is above 100°C.
 - The error is cleared when the temperature drops below 70°C.
-

Supposed
Causes

- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective


Troubleshooting



Check No.07
Refer to P.280



Check No.09
Refer to P.281





5.23 Radiation Fin Temperature Rise

Remote Control
Display

L4

Outdoor Unit LED
Display

A  1 ● 2 ● 3 ● 4 

Method of
Malfunction
Detection

A radiation fin temperature rise is detected by checking the radiation fin temperature being detected by the fin thermistor with the compressor on.

Malfunction
Decision
Conditions

- The radiation fin temperature with the compressor on is above 103°C.
- The error is cleared when the temperature drops below 95°C.
- If a radiation fin temperature rise takes place 255 times successively, the system will be shut down.
- The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed
Causes

- Fin temperature rise due to defective outdoor unit fan
- Fin temperature rise due to short-circuit
- Fin thermistor defective
- Connector in poor contact
- Outdoor unit PCB defective

Troubleshooting



Check No.07
Refer to P.280




Check No.09
Refer to P.281



Caution



Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R5148)

5.24 Output Over Current Detection

Remote Control Display *L5*

Outdoor Unit LED Display A  1 ● 2 ● 3  4 ●

Method of Malfunction Detection An output over-current is detected by checking the current that flows in the inverter DC section.

Malfunction Decision Conditions

- A position signal error occurs while the compressor is running.
- A speed error occurs while the compressor is running.
- An output over-current input is fed from the output over-current detection circuit to the microcomputer.
- The system will be shut down if the error occurs 16 times.
- Clearing condition: Continuous run for about 5 minutes (normal)

Supposed Causes

- Over-current due to defective power transistor
- Over-current due to wrong internal wiring
- Over-current due to abnormal supply voltage
- Over-current due to defective PCB
- Error detection due to defective PCB
- Over-current due to closed stop valve
- Over-current due to compressor failure
- Over-current due to poor installation condition

Troubleshooting



Check No.07
Refer to P.280




Check No.08
Refer to P.281



Check No.13
Refer to P.283







Caution Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R5149)

5.25 Insufficient Gas

Remote Control Display 

Outdoor Unit LED Display A  1  2  3  4

Method of Malfunction Detection

Gas shortage detection I:

Gas shortage is detected by checking the input current value and the compressor running frequency. If the gas is short, the input current is smaller than the normal value.

Gas shortage detection II:

Gas shortage is detected by checking the discharge temperature and the opening of the electronic expansion valve. If the gas is short, the discharge temperature tends to rise.

Malfunction Decision Conditions

Gas shortage detection I (typical value):

The following conditions continue for 7 minutes.

- ◆ DC current $\leq 0.035 \times \text{output frequency} + 0.5$
- ◆ Output frequency > 55 (Hz)

Gas shortage detection II:

The following conditions continue for 80 seconds.

- ◆ Target opening of the electronic expansion valve ≥ 450 (pulse)
- ◆ Cooling: discharge temperature $> 255 / 256 \times \text{target discharge temperature} + 20$ (°C)
Heating: discharge temperature $> 255 / 256 \times \text{target discharge temperature} + 40$ (°C)

If a gas shortage error takes place 4 times straight, the system will be shut down. The error counter will reset itself if this or any other error does not occur during the following 60-minute compressor running time (total time).

Supposed Causes

- Refrigerant shortage (refrigerant leakage)
- Poor compression performance of compressor
- Discharge pipe thermistor disconnected, or indoor unit or outdoor unit heat exchanger thermistor disconnected, room or outside air temperature thermistor disconnected
- Stop valve closed
- Electronic expansion valve defective

Troubleshooting



Check No.04
Refer to P.277




Check No.06
Refer to P.279







Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.




(R5150)

5.26 Low-voltage Detection or Over-voltage Detection

Remote Control Display	U2
Outdoor Unit LED Display	A  1  2  3  4
Method of Malfunction Detection	An abnormal voltage rise or drop is detected by checking the detection circuit or DC voltage detection circuit.
Malfunction Decision Conditions	<ul style="list-style-type: none"> ■ An over-voltage signal is fed from the over-voltage detection circuit to the microcomputer, or the voltage being detected by the DC voltage detection circuit is judged to be below 150 V for 0.1 second. ■ The system will be shut down if the error occurs 16 times. ■ Clearing condition: Continuous run for about 60 minutes (normal)
Supposed Causes	<ul style="list-style-type: none"> ■ Supply voltage not as specified ■ Over-voltage detector or DC voltage detection circuit defective ■ PAM control part(s) defective




Troubleshooting



(R5151)

5.27 Signal Transmission Error (on Outdoor Unit PCB)

Remote Control Display **U7**

Outdoor Unit LED Display A  1  2  3  4

Method of Malfunction Detection Communication error between microcomputer mounted on the main PCB and PM1.

Malfunction Decision Conditions

- When the data sent from the PM1 can not be received successively for 9 sec.
- The abnormality is determined if the above fault conditions occurs once
- Fault counter is reset when the data from the PM1 can be successfully received.

Supposed Causes


- Defective outdoor unit PCB

Troubleshooting



Caution

Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R5152)

5.28 Anti-icing Function in Other Rooms / Unspecified Voltage (between Indoor and Outdoor Units)

Remote Control Display *UR, UH*


Outdoor Unit LED Display A 


Method of Malfunction Detection A wrong connection is detected by checking the combination of indoor and outdoor units on the microcomputer.

- Malfunction Decision Conditions**
- Operation halt due to the anti-icing function in other rooms
 - Operation halt due to unspecified internal and/or external voltages
 - Operation halt due to mismatching of indoor and outdoor units

- Supposed Causes**
- Operation halt due to the anti-icing function in other rooms
 - Wrong connections at the indoor unit
 - PCB wrongly connected

Troubleshooting

 **Caution** Be sure to turn off power switch before connect or disconnect connector, or parts damage may be occurred.



(R3066)



6. Check

6.1 How to Check

6.1.1 Fan Motor Connector Output Check

Check No.01


1. Check connector connection.
2. Check motor power supply voltage output (pins 4-7 and 4-8).
3. Check motor control voltage (pins 4-3).
4. Check rotation command voltage output (pins 4-2).
5. Check rotation pulse input (pins 4-1).



(R4684)

Check No.02

1. Check connector connection.
2. Check motor control voltage output (pins 2-1).




(R1073)

6.1.2 Limit Switch Continuity Check

Check No.03

Remove the front grille. The limit switch is located at the left side of the drain pan assembly. Check the continuity of the switch connection.



Shutter status	Open	Closed
Continuity	Continuity	No continuity

(Q0363)

- * The shutter can be opened and closed with hand. Keep the shutter open and closed all the way for each continuity check steps.

6.1.3 Electronic Expansion Valve Check

Check No.04

Conduct the followings to check the electronic expansion valve (EV).

1. Check to see if the EV connector is correctly inserted in the PCB. Compare the EV unit and the connector number.
2. Turn the power off and back on again, and check to see if all the EVs generate latching sound.
3. If any of the EVs does not generate latching noise in the above step 2, disconnect that connector and check the conductivity using a tester.
Check the conductivity between pins 1, 3 and 6, and between pins 2, 4 and 5. If there is no conductivity between the pins, the EV coil is faulty.
4. If no EV generates latching sound in the above step 2, the outdoor unit PCB is faulty.
5. If the conductivity is confirmed in the above step 2, mount a good coil (which generated latching sound) in the EV unit that did not generate latching sound, and check to see if that EV generates latching sound.
*If latching sound is generated, the outdoor unit PCB is faulty.
*If latching sound is not generated, the EV unit is faulty.





Note: Please note that the latching sound varies depending on the valve type.

Valve Body Condition (Symptom)	Check Method / Measure
<p>(1) Valve body catches at fully opened or half opened position. (Symptom)</p> <p>Cooling: ■Water leakage at the no-operation unit ■Flow noise of refrigerant in the no-operation unit ■Operation halt due to icing protection</p> <p>Heating: ■The unit does not heat ■Refrigerant flow rate vary by unit (Discharge air temperatures are different by room) ■Peak cut</p>	<p>Reset power supply and conduct cooling operation unit by unit.</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Check the liquid pipe temperature of no-operation unit.</div> <div style="text-align: center;"> <p>Is it almost same as the outside air temperature?</p> <p>NO →</p> <p>YES ↓</p> </div> <p>Replace the EVn of the room. (R1431)</p>
<p>(2) Valve body catches at complete close position. (Symptom)</p> <p>Cooling: ■The only unit having problem does not cool the room . ■When the only faulty unit is in operation, the unit makes pump down. (The low pressure of the unit becomes vacuum) ■IT is activated. ■Abnormal discharge pipe temperature</p> <p>Heating: Insufficient gas due to liquid refrigerant stagnation inside the faulty indoor unit</p> <p>(Only for heat pump model) ■The unit does not heat the room. ■IT is activated. ■Abnormal discharge pipe temperature</p>	<p>Reset power supply and conduct cooling operation unit by unit.</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Check the low pressure</div> <div style="text-align: center;"> <p>Does the pressure become into vacuum zone?</p> <p>NO →</p> <p>YES ↓</p> </div> <p>Replace the EVn of the room (R1432)</p>
<p>(3) Valve does not open fully. (Symptom)</p> <p>■The unit does not cool nor heat (only for heat pump model.) ■IT is actuated. ■Abnormal discharge pipe temperature</p>	<p>Check the number of rotation of shaft if it is 5 and half from full open to complete close using manual coil for electronic expansion valve. When the number of rotation of shaft is less than the above value, the valve may catch anywhere of the body.</p>

6.1.4 Four Way Valve Performance Check

Check No.05



(R5153)


6.1.5 Thermistor Resistance Check

Check No.06


Remove the connectors of the thermistors on the PCB, and measure the resistance of each thermistor using tester.

The relationship between normal temperature and resistance is shown in the graph and the table below.

Temperature (°C)	Thermistor R25°C=20kΩ B=3950
-20	211.0 (kΩ)
-15	150
-10	116.5
-5	88
0	67.2
5	51.9
10	40
15	31.8
20	25
25	20
30	16
35	13
40	10.6
45	8.7
50	7.2




(R25=20kΩ、B=3950)



(R1437)


6.1.6 Installation Condition Check

Check No.07




6.1.7 Discharge Pressure Check

Check No.08



6.1.8 Outdoor Unit Fan System Check (With DC Motor)

Check No.09



6.1.9 Power Supply Waveforms Check



Check No.10

Measure the power supply waveform between pins 1 and 3 on the terminal board, and check the waveform disturbance.

- Check to see if the power supply waveform is a sine wave (Fig.1).
- Check to see if there is waveform disturbance near the zero cross (sections circled in Fig.2)

[Fig.1]

[Fig.2]




(R1736)

(R1444)

6.1.10 Inverter Units Refrigerant System Check

Check No.11




(R1445)

6.1.11 Capacitor Voltage Check

Check No.12

Before this checking, be sure to check the main circuit for short-circuit.

- Checking the capacitor voltage
- With the circuit breaker still on, measure the voltage according to the drawing of the model in question. Be careful never to touch any live parts.



(R5154)

6.1.12 Power Transistor Check

Check No.13

- Checking the power transistor
- Never touch any live parts for at least 10 minutes after turning off the circuit breaker.
- If unavoidably necessary to touch a live part, make sure the power transistor's supply voltage is below 50 V using the tester.
- For the UVW, make measurements at the Faston terminal on the board or the relay connector.


Tester's negative terminal	Power transistor (+)	UVW	Power transistor (-)	UVW
Tester's positive terminal	UVW	Power transistor (+)	UVW	Power transistor (-)
Normal resistance	Several kohms to several Mohms			
Abnormal resistance	0 or ∞			

6.1.13 Main Circuit Electrolytic Capacitor Check

Check No.14

- Checking the main circuit electrolytic capacitor
- Never touch any live parts for at least 10 minutes after turning off the circuit breaker.
- If unavoidably necessary to touch a live part, make sure there is no DC voltage using the tester.
- Check the continuity with the tester. Reverse the pins and make sure there is continuity.

Keep the tester in the resistance measuring range.



When the pointer swings, it means the capacitor functions.



If the pointer does not swing at all, or if it swings all the way but does not return, it means the capacitor malfunction.

(Q0367)

6.1.14 Turning Speed Pulse Input on the Outdoor Unit PCB Check

Check No.15

<Propeller fan motor>


Make sure the voltage of $320 \pm 30V$ is being applied.

- (1) Stop the operation first and then the power, and disconnect the connector S70.
- (2) Make sure there is about DC 320 V between pins 4 and 7.
- (3) With the system and the power still off, reconnect the connector S70.
- (4) Make a turn of the fan motor with a hand, and make sure the pulse (0-15 V) appears twice at pins 1 and 4.

If the fan motor protection fuse is blown out, the outdoor-unit fan may also be in trouble. Check the fan too.

If the voltage in Step (2) is not applied, it means the PCB is defective. Replace the PCB.

If the pulse in Step (4) is not available, it means the Hall IC is defective. Replace the DC fan motor. If there are both the voltage (2) and the pulse (4), replace the PCB.



(R5223)

* Propeller fan motor : S70

6.1.15 Hall IC Check

Check No.16



1. Check the connector connection.
2. With the power ON, operation OFF, and the connector connected, check the following.
 - *Output voltage of about 5 V between pins 1 and 3.
 - *Generation of 3 pulses between pins 2 and 3 when the fan motor is operating.

Failure of (1) → faulty PCB → Replace the PCB.

Failure of (2) → faulty Hall IC → Replace the fan motor.

Both (1) and (2) result → Replace the PCB.

The connector has 3 pins, and there are two patterns of lead wire colors.



[R1900]

Part 7

Removal Procedure

1. Outdoor Unit.....	288
1.1 Removal of the Panels and Plates	288
1.2 Removal of the Electrical Box	292
1.3 Removal of the PCB.....	300
1.4 Removal of the Propeller Fan / Fan Motor	306
1.5 Removal of the Sound Blanket.....	308
1.6 Removal of Electronic Expansion Valve Coil, Four Way Valve Coil and Thermistor	312
1.7 Removal of the Distributor	315
1.8 Removal of the Four Way Valve.....	316
1.9 Removal of the Compressor.....	317

1. Outdoor Unit

1.1 Removal of the Panels and Plates





Procedure










Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Procedure	Points
1	External appearance.	<p>(R5494)</p>	<ul style="list-style-type: none"> Take care not to cut your finger by the fins of the heat exchanger.
2	Loosen the 4 screws (2 on both sides) of the top panel.	<p>(R5496)</p>	

Step	Procedure	Points
3	Loosen the 6 screws of the front panel.	
	 <p>(R5497)</p>	
4	Loosen the 2 screws (each 1 in front and back) of the clamp plate.	
	 <p>Clamp plate</p> <p>(R5498)</p>	
5	Slide the clamp plate to the left to undo the hooks and remove the plate.	
	 <p>(R5499)</p>	
6	Undo the upper 2 hooks to remove the front panel.	
	 <p>(R5500)</p>	<ul style="list-style-type: none"> Align the position of hole of the upper hook to pull the front panel out.

Step	Procedure	Points
7	<p>Lift the front panel up to remove the left side hooks and open the panel.</p>  <p>(R5501)</p>	
8	<p>The front panel has the 3 hooks on the left.</p>  <p>Hooks</p> <p>(R5502)</p>	
9	<p>The front panel has the 1 hook on the right.</p>  <p>Hook</p> <p>(R5503)</p>	

Step	Procedure	Points
10	Loosen the 4 screws of the discharge grille.	
	 <p>(R5504)</p>	
11	Loosen the 2 screws of the stop valve cover. And then slide the cover downward to remove.	
	 <p>Stop valve cover</p> <p>(R5505)</p>	
	 <p>(R5506)</p>	
	 <p>(R5508)</p>	<p>■ When assembling, make sure to catch the 5 hooks.</p>




1.2 Removal of the Electrical Box





Procedure








Warning



Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.





Step	Procedure	Points
1. Disconnect the connecting wires		★ Illustrations are for 3 room model. (4MK(X)S-F models have 4 ports)
1	<p>Inside structure.</p>  	
2	<p>Disconnect the connecting wires.</p> 	<ul style="list-style-type: none"> ■ Connecting wires of the A, B, C, D port <ul style="list-style-type: none"> (1) - Black Power supply (2) - White Power supply (3) - Red Transmission ■ Power Supply wires <ul style="list-style-type: none"> (L) - Black (N) - White ■ Fasten the wires on the terminal board with screws.





Step	Procedure	Points
2.	Disconnect the each harnesses	
1	<p>Detach the fixing tape for the electrical box (cover).</p>  <p>(R5512)</p>	
2	<p>Undo the 4 hooks at the ▲ mark of the drip proof cover.</p>  <p>(R5513)</p>	
3	<p>Lift the cover up to remove.</p>  <p>(R5514)</p>	
4	<p>Disconnect the connector for fan motor [S70] from the PCB.</p>  <p>(R5515)</p>	<p>■ The shape of [S70] wire is different depending on the models.</p>



Step	Procedure	Points
5	The figure shows the arrangement of the wire harness for fan motor.	
	<p>(R5517)</p> <p>(R5518)</p>	
6	Disconnect the connectors for electronic expansion valve coil. [S20] - White [S21] - Red [S22] - Blue [S23] - Yellow	<ul style="list-style-type: none"> ■ The number of the connectors are different according to the number of the connected indoor units.
	<p>(R5519)</p>	
7	Undo the wire clip.	
	<p>(R5520)</p>	

Step	Procedure	Points
8	Disconnect the connector for overload protector [S40].	
		
9	Remove the OL wire harness and the compressor wire harness together from the partition plate.	
		
10	Use long-nose pliers or the like to pull out the clamp.	
		<ul style="list-style-type: none"> ■ Detach the clamp. ■ Just pull the push-mount type out of position.
		
11	Disconnect the connector for relay harness of compressor.	
		

Step		Procedure	Points
12	<p>Disconnect the each connector.</p> <p>[S90] : Outdoor air, heat exchanger, discharge pipe thermistor</p> <p>[S92] : Gas pipe thermistor</p> <p>[S93] : Liquid pipe thermistor</p>	 <p>The first diagram (R5523) shows a hand pulling connector [S90] away from the terminal block. The second diagram (R5524) shows a hand pulling connector [S92] away. The third diagram (R5525) shows a hand pulling connector [S93] away. Arrows in each diagram indicate the direction of removal.</p>	
13	<p>Disconnect the connector for four way valve [S80].</p>	 <p>The diagram (R5526) shows a hand pulling connector [S80] away from the terminal block. An arrow indicates the direction of removal.</p>	

Step	Procedure	Points
<p>14</p>	<p>The figure shows the arrangement of the wire harness under the electrical box.</p>  <p>(R5527)</p>	
<p>15</p>	<p>Undo the wire clip for the thermistor lead wire.</p>  <p>(R5528)</p>	
<p>3. Remove the electrical box</p>		
<p>1</p>	<p>Loosen the 2 screws of the earth terminal.</p>  <p>(R5529)</p>	
<p>4.</p>	<p>Disconnect the power supply connecting wires</p> <p>1</p> <p>Loosen the screws on the terminal board and disconnect the wires of A, B, C, and D port.</p>  <p>(R5530)</p>	<p>★ Illustrations are for 3 room model.</p>

Step	Procedure	Points
	 <p>(R5531)</p>  <p>Wiring fixture (R5532)</p>  <p>(R5533)</p>  <p>(R5534)</p>	
2	<p>Detach the outdoor air thermistor.</p>	
3	<p>Loosen the screw on the right side of the electrical box.</p>	

Step	Procedure	Points	Points
4	Loosen the 1 screw in front of the electrical box.	 <p>(R5535)</p>	
5	Lift up the electrical box to remove.	 <p>(R5536)</p>	

1.3 Removal of the PCB





Procedure











Warning





Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.





Step	Procedure	Points
1.	Remove the service PCB	★ Illustrations are for 3 room model.
1	External appearance of the service PCB and the terminal board.	
2	Loosen the 1 screw of the terminal board and open it.	
3	Disconnect the connector [S52] and [S102] from the service PCB.	




Step	Procedure	Points
4	<p>Widen the upper hook and pull the service PCB upward to remove.</p>  <p>(R5541)</p> <p>(R5542)</p>	
2. Remove the control PCB		
1	<p>Disconnect the each connectors on the terminal board.</p>  <p>(R5543)</p>	
2	<p>Disconnect the 2 connectors for reactor.</p>  <p>(R5544)</p>	
3	<p>Loosen the 3 screws of the PCB.</p>  <p>(R5545)</p>	

Step	Procedure	Procedure	Points
4	Undo the 3 hooks on the reactor side and slide the control PCB.	 <p>(R5547)</p>	
5	Undo the relay harness for compressor from the hook.	 <p>(R5548)</p>	
6	Lift up the control PCB to remove.	 <p>(R5549)</p>	<ul style="list-style-type: none"> ■ In working, be careful not to break the control PCB with the excessive force because the PCB and the radiation fin are adhered to one another. ■ When assembling, make sure to use the silicon material. ■ Silicon material Part No.: 1172698
7	Each wire harness.	 <p>(R5550)</p>	

Step	Procedure	Points
8	Names of parts on the control PCB.	<p>■ See page 56 for detail.</p> 
9	Loosen the 2 screws of the radiation fin.	 
10	Loosen the 3 screws of the reactor and the 1 screw of the clamp.	

Step	Procedure	Points
3. Disconnect the wire harnesses	 <p>(R5555)</p>  <p>(R5556)</p>	
4. Remove the terminal board	<p>1 Open the electrical box and remove the terminal board.</p>  <p>(R5557)</p>  <p>(R5558)</p>	<p>★ Illustrations are for 3 room model.</p>

Step	Procedure	Points
	 <p>(R5559)</p>	

1.4 Removal of the Propeller Fan / Fan Motor






Procedure



Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Procedure	Points
1	Remove the fan motor fixing plate.	<p>(R5560)</p>	<ul style="list-style-type: none"> ■ Remove the outer panels and plates. ■ Remove the electrical box.
2	Take out the fan motor fixing plate toward yourself.	<p>(R5561)</p>	<p>(R5564)</p> <ul style="list-style-type: none"> ■ When assembling, fit the lower hooks.
3	Loosen the washer fitted nut to remove the propeller fan.	<p>(R5562)</p> <p>(R5563)</p>	<p>(R5565)</p> <ul style="list-style-type: none"> ■ When assembling, align ▼ mark of the propeller fan with D-cut section of the motor shaft. ■ When assembling, make sure ● mark of the fan motor goes up.

Step	Procedure	Procedure	Points
4	Undo the 2 fixing hooks of the lead wire. Loosen the 4 screws of the fan motor.	 <p>(R5566)</p>  <p>(R5567)</p>  <p>(R5568)</p>	 <p>Lead wire Propeller fan (R3249)</p> <ul style="list-style-type: none"> ■ When assembling, put the lead wire through the back of the motor. (so as not to be entangled with the propeller fan)
5	Detach the 4 screws and 4 rubber vibration isolators.	 <p>(R5569)</p>	

1.5 Removal of the Sound Blanket





Procedure













Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the right side panel	<p>(R5570)</p>	<ul style="list-style-type: none"> ■ Remove the outer panels and plates. ■ Remove the electrical box.
1 Loosen the 3 screws on the right of the right side panel.		
2 Loosen the 2 screws on the back.	<p>(R5571)</p>	
2 Loosen the 2 screws on the back.		
3 Remove the packing. There is a hook on the back.	<p>Packing</p> <p>(R5572)</p>	
3 Remove the packing. There is a hook on the back.		

Step	Procedure	Points
4	<p>Pull up the right side panel.</p>  <p>(R5573)</p>	
5	<p>Loosen the 2 screws of the wiring fixture.</p>  <p>(R5574)</p>	
2. Remove the partition plate		
1	<p>Loosen the 2 screws to remove the partition plate.</p>  <p>(R5575)</p>	
2	<p>Detach the clamp of the relay harness for the compressor.</p>  <p>(R5576)</p>	

Step	Procedure	Procedure	Points
3	Pull up the partition plate.	 <p>(R5577)</p>	 <p>(R5580)</p> <ul style="list-style-type: none"> When assembling, make sure to catch the lower hook of the partition plate.
3.	Remove the sound blanket		<ul style="list-style-type: none"> Illustrations are different depending on the models.
1	Lift up the sound blanket (top-upper) to remove.	 <p>(R5579)</p>	 <p>(R6964)</p> <ul style="list-style-type: none"> Since the piping ports on the sound blanket are torn easily, remove the blanket carefully.
2	Remove the sound blanket (top-lower).	 <p>(R5582)</p>	 <p>(R6965)</p>

Step	Procedure	Points
3	<p>Undo the fixing strings, open the sound blanket (body) and pull it out.</p>  <p>(R5583)</p>	 <p>(R6966)</p>
4	<p>Open the sound blanket (inner) and pull it out.</p>  <p>Sound blanket (inner)</p> <p>(R5584)</p>	 <p>(R6967)</p>

1.6 Removal of Electronic Expansion Valve Coil, Four Way Valve Coil and Thermistor



Procedure





Warning

Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the electronic expansion valve coil	<div data-bbox="555 450 1002 1032"> </div> <p style="text-align: right;">(R5588)</p>	<p>★ Illustrations are for 3 room model.</p>
2. Remove the four way valve coil	<div data-bbox="507 1093 1066 1496"> </div> <p style="text-align: right;">(R5589)</p>	

Step	Procedure	Points
<p>3. Remove the liquid/gas pipe thermistor</p>	<p>1 Open the putty and remove the liquid pipe thermistor. [S90] : Outdoor air thermistor Heat exchanger thermistor Discharge pipe thermistor [S92] : Gas pipe thermistor Room A (Black) Room B (Gray) Room C (Brown) Room D (Red) [S93] : Liquid pipe thermistor Room A (Black) Room B (Gray) Room C (Yellow) Room D (Blue)</p> <p>2 Open the putty and remove the gas pipe thermistor.</p>	<ul style="list-style-type: none"> ■ Meet the edge of the thermistor and clip. ■ The number of ports is different according to the models.
<p>4. Remove the heat exchanger thermistor</p>	<p>1 Remove the heat exchanger thermistor.</p>	 






Step	Procedure	Points
<p>5. Remove the discharge pipe thermistor</p>	<p>1 Undo the clip and remove the discharge pipe thermistor.</p> 	<ul style="list-style-type: none"> ■ Meet the edge of the thermistor and clip. ■ Be careful not to loose the clip for the discharge pipe thermistor.
<p>6. Remove the assembly of thermistor.</p>	<p>1 The figure shows the arrangement of the assembly of thermistor.</p> 	

1.7 Removal of the Distributor

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.





Step	Procedure	Procedure	Points
1	Remove the putty.	 <p>(R5595)</p>  <p>(R5596)</p>	<p> Warning Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)</p> <p> Caution Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas welding rod.</p> <p> Caution From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to recover the refrigerant gas with the recovery system.</p>

1.8 Removal of the Four Way Valve

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.





Step	Procedure	Points
<p>■ Be sure to apply nitrogen replacement when heating up the brazed part.</p>	 <p style="text-align: right;">(R5597)</p>	<p>Cautions for restoration</p> <ol style="list-style-type: none"> 1. Restore the piping by non-oxidation brazing. In case of you cannot use the nitrogen gas, restore as quickly as possible. 2. It is required to prevent the carbonization of the oil inside the four way valve and the deterioration of the gaskets affected by heat. For the sake of this, wrap the four way valve with wet cloth and provide water so that the cloth will not be dried and avoid excessive heating. (Keep below 120°C)
<p>1 Loosen the 1 screw to remove the four way valve coil.</p> <p>2 Heat up the 4 brazed part of the four way valve. First, disconnect the part "a".</p> <p>■ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.</p>	 <p style="text-align: right;">(R5598)</p>	<p>■ Be careful so as not to break the pipes by pressing it excessively by pliers when withdrawing it.</p> <p>In case of the difficulty with gas brazing machine</p> <ol style="list-style-type: none"> 1. Disconnect the brazed part where is easy to disconnect and restore. 2. Cut pipes on the main unit by a miniature copper tube cutter in order to make it easy to disconnect.
<p>3 Disconnect the part "d".</p>	 <p style="text-align: right;">(R5599)</p>	<p>i Note: Do not use a metal saw for cutting pipes by all means because the sawdust come into the circuit.</p>
<p>4 Disconnect the part "b" and "c".</p>	 <p style="text-align: right;">(R5600)</p>	







1.9 Removal of the Compressor

Procedure



Warning Be sure to wait 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1.	Remove the terminal cover	Make a note.
1	Remove the terminal cover.	<ul style="list-style-type: none"> ■ Be careful so as not to burn the compressor terminals or the name plate.
2	Disconnect the flag-shaped terminals.	<p>Warning</p> <p>Since it may happen that refrigeration oil in the compressor will catch fire, prepare wet cloth so as to extinguish fire immediately.</p>
3	Detach the compressor lead wire.	<p>Warning</p> <p>Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)</p>
4	Detach the overload protector.	<p>Caution</p> <p>Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas welding rod.</p>
1	 <p>(R5601)</p>	
2	 <p>(R5602)</p>	
3	 <p>(R5603)</p>	
4	 <p>(R5604)</p>	

Step		Procedure	Points
5	Remove the 2 sheets of putty.	 <p style="text-align: right;">(R5605)</p>	<p>Warning  Ventilate when refrigerant leaks during the work. (If refrigerant contacts fire, it will cause to arise toxic gas.)</p>
6	There is one nut fixing the compressor. Remove the nut with an open-end spanner.	 <p style="text-align: right;">(R5606)</p>	
■	Before working, make sure that the refrigerant is empty in the circuit.		
■	Be sure to apply nitrogen replacement when heating up the brazed part.		
7	Heat up the brazed part of the discharge side and disconnect (part "a").	 <p style="text-align: right;">(R5607)</p>	
8	Heat up the brazed part of the suction side and disconnect (part "b").	 <p style="text-align: right;">(R5607)</p>	
9	Lift the compressor up to remove.	 <p style="text-align: right;">(R5608)</p>	

Part 8 Others

1. Others	320
1.1 Test Run from the Remote Control	320
1.2 Jumper Settings	321

1. Others

1.1 Test Run from the Remote Control

For Heat pump

In cooling mode, select the lowest programmable temperature; in heating mode, select the highest programmable temperature.

- Trial operation may be disabled in either mode depending on the room temperature.
- After trial operation is complete, set the temperature to a normal level.
(26°C to 28°C in cooling mode, 20°C to 24°C in heating mode)
- For protection, the system disables restart operation for 3 minutes after it is turned off.

For Cooling Only

Select the lowest programmable temperature.


- Trial operation in cooling mode may be disabled depending on the room temperature. Use the remote control for trial operation as described below.
- After trial operation is complete, set the temperature to a normal level (26°C to 28°C).
- For protection, the machine disables restart operation for 3 minutes after it is turned off.

Trial Operation and Testing

1. Measure the supply voltage and make sure that it falls in the specified range.
 2. Trial operation should be carried out in either cooling or heating mode.
 3. Carry out the test operation in accordance with the Operation Manual to ensure that all functions and parts, such as louver movement, are working properly.
- The air conditioner requires a small amount of power in its standby mode. If the system is not to be used for some time after installation, shut off the circuit breaker to eliminate unnecessary power consumption.
 - If the circuit breaker trips to shut off the power to the air conditioner, the system will restore the original operation mode when the circuit breaker is opened again.

Trial operation from Remote Control

- (1) Press ON/OFF button to turn on the system.
- (2) Simultaneously press center of TEMP button and MODE buttons.
- (3) Press MODE button twice.
(“T” will appear on the display to indicate that Trial Operation mode is selected.)
- (4) Trial run mode terminates in approx. 30 minutes and switches into normal mode. To quit a trial operation, press ON/OFF button.



(R4294)

1.2 Jumper Settings


1.2.1 When Two Units are Installed in One Room

When two indoor units are installed in one room, the two infrared remote controls can be set for different addresses.

How to set the different addresses

- Control PCB of the indoor unit
 - (1) Remove the electrical box.
 - (2) Cut the address jumper JA on the control PCB.

- Infrared remote control
 - (1) Slide the front cover and take it off.
 - (2) Cut the address jumper J4.




1.2.2 Jumper Setting

Jumper (On indoor PCB)	Function	When connected (factory set)	When cut
JC	Power failure recovery function	Auto start	Unit does not resume operation after recovering from a power failure. Timer ON-OFF settings are cleared.
JB	Fan speed setting when compressor is OFF on thermostat. (effective only at cooling operation)	Fan speed setting ; Remote control setting	Fan rpm is set to "0" <Fan stop>


1.2.3 Adjusting the Angle of the Intelligent Eye Sensor

FTK(X)S20-35C

- Once installation of the indoor unit is complete, adjust the angle of the Intelligent eye sensor to ensure the detection area properly covers the room.
(Adjustable angle : 15° to right and left of center)



- Gently push and slide the sensor to adjust the angle. Aim so that the sensor is pointing to the center of the room, or to the part of the room that is most frequently used.



Moving the sensor to the left Moving the sensor to the right
(R1730)

- After adjusting the angle, gently wipe the sensor with a clean cloth, being careful not to scratch the sensor.



Caution

- Do not hit or violently push the Intelligent eye sensor. This can lead to damage and malfunction.
- Do not place large objects near the sensor. Also keep heating units or humidifiers outside the sensor's detection area.

Part 9 Appendix


1. Piping Diagrams.....	324
1.1 Indoor Units.....	324
1.2 Outdoor Units.....	330
2. Wiring Diagrams.....	331
2.1 Indoor Units.....	331
2.2 Outdoor Units.....	336

1. Piping Diagrams

1.1 Indoor Units


1.1.1 Wall Mounted Type

FTKS20D3VMW(L), FTKS25D3VMW(L),
FTKS35D3VMW(L)




4D050757A

FTKS50D2V1W(L)




4D051577

FTKS20CAVMB, FTKS25CAVMB,
FTKS35CAVMB




4D033698E

FTKS50FV1B, FTKS60FV1B




4D054932A

FTKS71FV1B




4D050919E

FTXG25EV1BW(S), FTXG35EV1BW(S)




4D045301B

CTXG50EV1BW(S)




4D050924

FTXS20D3VMW(L), FTXS25D3VMW(L), FTXS35D3VMW(L)




4D047912F

FTXS50D2V1W(L)




4D047913D

FTXS20CAVMB, FTXS25CAVMB, FTXS35CAVMB




4D049319A

FTXS50FV1B, FTXS60FV1B



4D040081Q


FTXS71FV1B



4D040082P

1.1.2 Duct Connected Type


FDKS25CAVMB, FDKS35CAVMB, FDKS50CVMB, FDKS60CVMB, FDKS25EAVMB, FDKS35EAVMB
 FDXS25CAVMB, FDXS35CAVMB, FDXS50CVMB, FDXS60CVMB, FDXS25EAVMB, FDXS35EAVMB




1.1.3 Floor / Ceiling Suspended Dual Type

FLKS25BAVMB, FLKS35BAVMB

FLKS50BAVMB, FLKS60BAVMB





4D034012E



4D048723A

FLXS25BAVMB, FLXS35BAVMB

FLXS50BAVMB, FLXS60BAVMB





4D048722A

4D048724A

1.1.4 Floor Standing Type

FVXS25FV1B, FVXS35FV1B

FVXS50FV1B




4D056137

4D056138

1.1.5 Ceiling Suspended Type

FHQ35/50/60BVV1B



Indoor unit


MODEL	A	B
FHQ35BHV1B□ FHQ35BVV1B FCQ35BVE□ FCQ35C7VEB	6.4	9.5
FHQ50, 60BHV1B□ FHQ50, 60BVV1B FCQ50, 60BVE□ FBQ60BV1□ FBQ60BVL□ FCQ50, 60C7VEB	6.4	12.7
FUQ71, 100, 125BHV1B□ FUQ71, 100, 125BVV1B FHQ71, 100, 125BHV1B□ FHQ71, 100, 125BVV1B FAQ71, 100BHV1B□ FAQ71, 100BVV1B FXUQ70, 100, 125MV1 FHQ71, 100, 125BAV3B FCQ71, 100, 125, 140DV3B□ FCQ71, 100, 125, 140DAV3B FCQ71BVE□ FBQ71BV1□ FBQ71BVL□ FCQ71, 100, 125, 140C7VEB□ FCQH71, 100, 125, 140C7VEB	9.5	15.9

4D037995G

1.2 Outdoor Units


1.2.1 Cooling Only

4MKS75F2V1B



1.2.2 Heat Pump

4MXS68F2V1B




2. Wiring Diagrams

2.1 Indoor Units


2.1.1 Wall Mounted Type

FTKS20D3VMW(L), FTKS25D3VMW(L), FTKS35D3VMW(L)
 FTXS20D3VMW(L), FTXS25D3VMW(L), FTXS35D3VMW(L)




3D051268A

FTKS50D2V1W(L), FTXS50D2V1W(L)




3D051652

FTKS20CAVMB, FTKS25CAVMB, FTKS35CAVMB
FTXS20CAVMB, FTXS25CAVMB, FTXS35CAVMB




3D033599G

FTKS50FV1B, FTKS60FV1B, FTKS71FV1B
FTXS50FV1B, FTXS60FV1B, FTXS71FV1B



3D038530N


FTXG25EV1BW(S), FTXG35EV1BW(S), CTXG50EV1BW(S)



3D050493

2.1.2 Duct Connected Type


FDKS25CAVMB, FDKS35CAVMB, FDKS50CVMB, FDKS60CVMB, FDKS25EAVMB, FDKS35EAVMB
 FDXS25CAVMB, FDXS35CAVMB, FDXS50CVMB, FDXS60CVMB, FDXS25EAVMB, FDXS35EAVMB



3D045012K

2.1.3 Floor / Ceiling Suspended Dual Type


FLKS25BAVMB, FLKS35BAVMB, FLKS50BAVMB, FLKS60BAVMB
 FLXS25BAVMB, FLXS35BAVMB, FLXS50BAVMB, FLXS60BAVMB



3D033909E

2.1.4 Floor Standing Type

FVXS25FV1B, FVXS35FV1B, FVXS50FV1B





3D055953

2.1.5 Ceiling Suspended Type

FHQ35/50/60BVV1B

A1P	PRINTED CIRCUIT BOARD	BS1	PUSH BUTTON(ON/OFF)
C1	CAPACITOR(MF)	H1P	LIGHT EMITTING DIODE (ON-RED)
F1U	FUSE(F5A 250V)	H2P	LIGHT EMITTING DIODE (TIMER-GREEN)
HAP	LIGHT EMITTING DIODE (SERVICE MONITOR GREEN)	H3P	LIGHT EMITTING DIODE (FILTER SIGN-RED)
KAR	MAGNETIC RELAY(M1S)	H4P	LIGHT EMITTING DIODE (DEFROST-ORANGE)
KPR	MAGNETIC RELAY(M1P)	SS1	SELECTOR SWITCH (MAIN/SUB)
M1F	MOTOR(INDOOR FAN)	SS2	SELECTOR SWITCH (WIRELESS ADDRESS SET)
M1S	MOTOR(SWING FLAP)		CONNECTOR FOR OPTIONAL PARTS
Q1M	THERIO SWITCH(MF EMBEDDED)	X15A	CONNECTOR(FLOAT SWITCH)
R1T	THERMISTOR(AIR)	X25A	CONNECTOR(DRAIN PUMP)
R2T	THERMISTOR(COIL-1)	X33A	CONNECTOR (ADAPTOR FOR WIRING)
R3T	THERMISTOR(COIL-2)	X35A	CONNECTOR (GROUP CONTROL ADAPTOR)
S1Q	LIMIT SWITCH(SWING FLAP)	X40A	CONNECTOR (ON/OFF INPUT FROM OUTSIDE)
T1R	TRANSFORMER(220-240V/22V)	X60A	CONNECTOR (INTERFACE ADAPTOR FOR SKY AIR SERIES)
V1TR	PHASE CONTROL CIRCUIT	X61A	CONNECTOR (INTERFACE ADAPTOR FOR SKY AIR SERIES)
X1M	TERMINAL BLOCK		
X2M	TERMINAL BLOCK		
(RC)	SIGNAL RECEIVER CIRCUIT		
(TC)	SIGNAL TRANSMISSION CIRCUIT		
	WIRED REMOTE CONTROLLER		
R1T	THERMISTOR(AIR)		
SS1	SELECTOR SWITCH(MAIN/SUB)		
	WIRELESS REMOTE CONTROLLER (RECEIVER/DISPLAY UNIT)		
A3P	PRINTED CIRCUIT BOARD		
A4P	PRINTED CIRCUIT BOARD		




3D037842D

2.2 Outdoor Units

2.2.1 Cooling Only

4MKS75F2V1B




- | | | | | | | | |
|----------------------|-----------------------------------|--------------|------------------|-----|-------------------------------------|-------------|------------------------------|
| Z1C-Z6C | : FERRITE CORE | MRM10, MRM20 | : MAGNETIC RELAY | L | : LIVE | M1C | : COMPRESSOR MOTOR |
| X1M-X5M | : TERMINAL STRIP | MRC/W | : THERMISTOR | N | : NEUTRAL | M1F | : FAN MOTOR |
| Y1E-Y4E | : ELECTRONIC EXPANSION VALVE COIL | R1T-R11T | : THERMISTOR | SW1 | : FORCED OPERATION ON/OFF SW (SW1) | L1R | : REACTOR |
| V2, V3, V5, V9, V100 | : VARISTOR | S2-S102 | : CONNECTOR | SW2 | : SELECT SW (SW2) | Q1L | : OVERLOAD PROTECTOR |
| SA2 | : SURGE ARRESTER | LED1-LED4 | : PILOT LAMP | SW3 | : WIRING ERROR CHECK SW (SW3) | PM1 | : POWER MODULE |
| FU1, FU2, FU3 | : FUSE | LEDA | | SW4 | : PRIORITY ROOM SETTING SW (SW4) | PCB1, 2 | : PRINTED CIRCUIT BOARD |
| AC1, AC2 | | | | SW5 | : NIGHT QUIET MODE SETTING SW (SW5) | SHEET METAL | : TERMINAL STRIP FIXED PLATE |
| U, V, W, X11A | | | | | | | |
| E1, E2 | : CONNECTOR | | | | | | |
| HR1, HR2 | | | | | | | |

3D055885

2.2.2 Heat Pump

4MXS68F2V1B



- | | | | | | | | |
|----------------------|-----------------------------------|--------------|------------------|-----|-------------------------------------|-------------|---------------------------------|
| Z1C-Z6C | : FERRITE CORE | MRM10, MRM20 | : MAGNETIC RELAY | L | : LIVE | M1C | : COMPRESSOR MOTOR |
| X1M-X5M | : TERMINAL STRIP | MRC/W | : THERMISTOR | N | : NEUTRAL | M1F | : FAN MOTOR |
| Y1E-Y4E | : ELECTRONIC EXPANSION VALVE COIL | R1T-R11T | : THERMISTOR | SW1 | : FORCED OPERATION ON/OFF SW (SW1) | L1R | : REACTOR |
| V2, V3, V5, V9, V100 | : VARISTOR | S2-S102 | : CONNECTOR | SW2 | : SELECT SW (SW2) | Q1L | : OVERLOAD PROTECTOR |
| SA2 | : SURGE ARRESTER | LED1-LED4 | : PILOT LAMP | SW3 | : WIRING ERROR CHECK SW (SW3) | PM1 | : POWER MODULE |
| FU1, FU2, FU3 | : FUSE | LEDA | | SW4 | : PRIORITY ROOM SETTING SW (SW4) | PCB1, 2 | : PRINTED CIRCUIT BOARD |
| AC1, AC2 | | | | SW5 | : NIGHT QUIET MODE SETTING SW (SW5) | Y1R | : REVERSING SOLENOID VALVE COIL |
| U, V, W, X11A | | | | | | SHEET METAL | : TERMINAL STRIP FIXED PLATE |
| E1, E2 | : CONNECTOR | | | | | | |
| HR1, HR2 | | | | | | | |

3D055495

Index

Numerics

3 minutes stand-by 86

A

A1 236
 A5 237, 247
 A6 239, 240
 AC1 56
 AC2 56
 address setting jumper 38, 40, 43, 45, 47, 49, 52
 adjusting the air flow direction 131, 191
 air purifying filter 76
 air purifying filter with photocatalytic deodorizing
 function 76
 anti-icing function in other rooms 275
 AUTO · DRY · COOL · HEAT · FAN operation
 129, 189
 automatic air flow control 65
 automatic operation 67
 auto-restart 38, 45
 auto-restart function 76
 auto-swing 62

B

buzzer PCB 44

C

C4 242
 C7 243
 C9 242
 capacitor voltage check 283
 care and cleaning 158, 205
 centralized control 38, 40, 43, 45, 47, 49
 changing operation room 94
 check
 capacitor voltage check 283
 discharge pressure check 281
 electronic expansion valve check 277
 fan motor connector output check 276
 four way valve performance check 278
 Hall IC check 285
 installation condition check 280
 inverter units refrigerant system check 282
 limit switch continuity check 276
 main circuit electrolytic capacitor check 284
 outdoor unit fan system check (with DC motor)
 281
 power supply waveforms check 282
 power transistor check 283
 thermistor resistance check 279
 turning speed pulse input on the outdoor unit PCB
 check 284
 check No.01 276
 check No.02 276
 check No.03 276

check No.04 277
 check No.05 278
 check No.06 279
 check No.07 280
 check No.08 281
 check No.09 281
 check No.10 282
 check No.11 282
 check No.12 283
 check No.13 283
 check No.14 284
 check No.15 284
 check No.16 285
 compressor 317
 compressor lock 251
 compressor overload 250
 compressor protection function 87
 compressor sensor system abnormality 258
 connectors 38, 40, 43, 45, 47, 49, 52, 56
 control PCB 47, 301
 control PCB (indoor unit) 39, 42, 44, 46, 50, 53
 cooling / heating mode lock 101
 CT or related abnormality 261

D

DC fan lock 252
 defrost control 91
 diagnosis mode 231
 discharge grille 291
 discharge pipe 95
 discharge pipe control 88
 discharge pipe temperature control 95, 255
 discharge pipe thermistor 78, 80, 95
 discharge pressure check 281
 display PCB 39, 44, 48, 51, 53
 distributor 315

E

E1 249
 E5 250
 E6 251
 E7 252
 E8 253
 econo mode 70
 econo operation 143, 195
 econo-mode-proof setting 101
 electrical box 292
 electrical box temperature rise 265
 electronic expansion valve check 277
 electronic expansion valve coil 312
 electronic expansion valve control 92
 error codes
 A1 236
 A5 237, 247
 A6 239, 240

C4	242	front panel control	64
C7	243	front panel mechanism	45, 243
C9	242	front panel open/close fault	243
E1	249	FU1	38, 40, 43, 45, 47, 49, 52, 56
E5	250	FU2	56
E6	251	FU3	56
E7	252	functions	2
E8	253	fuse	38, 40, 43, 45, 47, 49, 52, 56
F3	255	G	
F6	256	gas pipe isothermal control during cooling	94
H0	258	gas pipe thermistor	78, 80
H6	260	H	
H8	261	H0	258
H9	263	H6	260
J3	263	H8	261
J6	263	H9	263
J8	263	HA	38, 43, 45
J9	263	Hall IC	65, 239, 240
L3	265	Hall IC check	285
L4	267	HAP	54
L5	269	heating peak-cut control	89
P4	263	high pressure control	237
U0	271	high pressure control in cooling	256
U2	273	HOME LEAVE operation	73, 144
U4	244	hot start function	75
U7	274	HR1	56
UA	246, 275	HR2	56
UH	275	I	
error codes and description of fault	233	indoor heat exchanger thermistor	79, 81
F		indoor unit PCB abnormality	236
F3	255	input current control	88
F6	256	input over current detection	253
fan control	90	installation condition check	280
fan motor	306	instruction	105
fan motor connector output check	276	insufficient gas	271
fan motor or related abnormality		insufficient gas control	96
AC motor	239	INTELLIGENT EYE	71
DC motor	240	INTELLIGENT EYE operation	146
fan speed control	65	INTELLIGENT EYE sensor	322
fan speed setting	38, 40, 43, 45, 47, 49, 52	INTELLIGENT EYE sensor PCB	39, 42, 44, 46
filter		inverter POWERFUL operation	74
air purifying filter with photocatalytic deodorizing		inverter principle	60
function	76	inverter units refrigerant system check	282
air-purifying filter	76	J	
mold proof air filter (prefilter)	76	J3	263
photocatalytic deodorizing filter	76	J4	321
titanium apatite photocatalytic air-purifying filter		J6	263
.....	76	J8	263
forced operation mode	97	J9	263
forced operation ON/OFF switch		JA	38, 40, 43, 45, 47, 49, 52, 321
.....	38, 40, 43, 45, 47, 52, 56	JB	38, 40, 43, 45, 47, 49, 52, 321
four way valve	316	JC	38, 40, 43, 45, 47, 49, 52, 321
four way valve coil	312	jumper setting	321
four way valve operation compensation	86	L	
four way valve performance check	278	L3	265
four way valve switching	86	L4	267
freeze-up protection control	89, 237, 247		
frequency control	83		
frequency principle	60		
front panel	289		

- L5269
LED A.....38, 40, 43, 45, 47, 49, 52, 56
LED138, 40, 43, 47, 49, 52, 56
LED238, 40, 43, 45, 47, 49, 52, 56
LED338, 40, 43, 45, 47, 49, 56
LED445, 56
limit switch45, 243
limit switch continuity check276
liquid compression protection function 290
liquid pipe thermistor79
low-voltage detection273
- M**
main circuit electrolytic capacitor check284
main PCB (outdoor unit).....57
main structural parts.....77
mode hierarchy82
mold proof air filter (prefilter)76
motor
 reduction motor.....45
multi system156, 203
- N**
names of parts108, 183
night set mode.....69
- O**
oil recovery function95
OL activation250
ON/OFF button on indoor unit.....75
opening limit.....94
operation lamp226
outdoor air thermistor298
outdoor heat exchanger thermistor78, 80
outdoor unit fan system check (with DC motor)281
outdoor unit PCB abnormality249
outdoor unit quiet operation142, 194
output over current detection269
over current96
overload96
over-voltage detection.....273
- P**
P4.....263
PCB (ceiling suspended type).....55
photocatalytic deodorizing filter76
PI control84
piping diagrams.....324
position sensor abnormality260
power failure recovery function
 38, 40, 43, 45, 47, 49, 52
power supply PCB.....50
power supply waveforms check282
power transistor check283
power-airflow dual flaps62
POWERFUL operation.....141, 193
POWERFUL operation mode.....100
preheating operation86
preparation before operation.....126, 186
pressure equalization control94
preventing indoor freezing.....97
- printed circuit board (PCB)
 buzzer PCB.....44
 ceiling suspended type55
 control PCB.....47, 301
 control PCB (indoor unit) ... 39, 42, 44, 46, 50, 53
 display PCB39, 44, 48, 51, 53
 INTELLIGENT EYE sensor PCB ... 39, 42, 44, 46
 main PCB (outdoor unit)57
 power supply PCB50
 removal procedure.....300
 sensor PCB.....53
 service monitor PCB.....58
 service PCB53, 300
 signal receiver PCB39, 42, 44, 46, 51
printed circuit board connector wiring diagram.....38
priority room setting.....100
problem symptoms and measures228
programme dry function66
propeller fan306
- R**
radiation fin temperature rise267
reduction motor45, 243
remote control230
removal procedure
 compressor317
 distributor315
 electrical box292
 electronic expansion valve coil312
 fan motor.....306
 four way valve316
 four way valve coil312
 panels and plates.....288
 PCB300
 propeller fan.....306
 sound blanket308
 thermistor.....312
right side panel.....308
RTH138, 40, 43, 45, 47
- S**
S138, 40, 43, 45, 47, 52
S10.....56
S101.....56
S102.....56, 300
S15.....56
S20.....56, 294
S2138, 40, 43, 45, 47, 49, 52, 56, 294
S22.....56, 294
S23.....56, 294
S24.....49
S25.....49
S26.....38, 40, 43, 47, 49, 52
S27.....38, 40, 43, 49, 52
S28.....38, 43
S29.....38, 43
S31.....49
S32.....38, 40, 43, 45, 47, 49
S35.....38, 40, 43
S36.....38, 40, 43, 45, 49
S37.....43, 49

S38.....	43
S40.....	56, 295
S41.....	45, 52
S42.....	52
S46.....	45, 52
S47.....	45, 52
S48.....	52
S49.....	45, 52
S51.....	45, 56
S52.....	56, 300
S6.....	38, 40, 43, 49
S7.....	40, 47, 49
S70.....	56, 293
S8.....	43
S80.....	56, 296
S90.....	56, 296, 313
S92.....	56, 296, 313
S93.....	56, 296, 313
safety precautions.....	106, 181
SC control.....	94
self-diagnosis digital display.....	76
sensor malfunction detection.....	96
sensor PCB (indoor unit).....	53
service check function.....	229
service monitor PCB.....	58
service PCB.....	53, 300
signal receiver PCB.....	39, 42, 44, 46, 51
signal receiving sign.....	75
signal transmission error.....	244
signal transmission error (on outdoor unit PCB).....	274
sound blanket.....	308
specifications.....	14
starting control	
indoor unit.....	64
starting operation control.....	94
stop valve cover.....	291
SW1.....	38, 43, 45, 47, 49, 52, 56
SW2.....	49, 52, 56
SW3.....	56
SW4.....	52, 56
SW5.....	56
SW7.....	40
T	
target discharge pipe temperature control.....	95
terminal board.....	304
test run from the remote control.....	320
thermistor	
discharge pipe thermistor.....	78, 80, 95, 314
gas pipe thermistor.....	78, 80, 313
heat exchanger thermistor.....	313
indoor heat exchanger thermistor.....	79, 81
liquid pipe thermistor.....	79, 313
outdoor air thermistor.....	313
outdoor heat exchanger thermistor.....	78, 80
thermistor or related abnormality (indoor unit).....	242
thermistor or related abnormality (outdoor unit).....	263
thermistor resistance check.....	279
thermostat control.....	68
TIMER operation.....	154, 196
titanium apatite photocatalytic air-purifying filter.....	76
top panel.....	288
troubleshooting.....	177
indoor units.....	234
outdoor units.....	235
troubleshooting with the LED indication.....	227
troubleshooting with the operation lamp.....	226
turning speed pulse input on the outdoor unit PCB	
check.....	284
U	
U0.....	271
U2.....	273
U4.....	244
U7.....	274
UA.....	246, 275
UH.....	275
unspecified voltage (between indoor and outdoor	
units).....	246, 275
V	
V1.....	38, 40, 43, 45, 47, 49, 52
V100.....	56
V2.....	56
V3.....	56
V5.....	56
V9.....	56
varistor.....	38, 40, 43, 45, 47, 49, 52, 56
W	
WEEKLY TIMER operation.....	76, 198
wide-angle louvers.....	62
wiring diagrams.....	331
wiring-error check.....	98
X	
X14A.....	54
X15A.....	54
X17A.....	54
X18A.....	54
X19A.....	54
X20A.....	54
X24A.....	54
X25A.....	54
X26A.....	54
X27A.....	54
X29A.....	54
X33A.....	54
X35A.....	54
X40A.....	54
X5A.....	54
X60A.....	54
X61A.....	54

Drawings & Flow Charts

A		
anti-icing function in other rooms	275	
automatic air flow control	65	
automatic operation	67	
auto-swing	62	
B		
buzzer PCB	44	
C		
capacitor voltage check	283	
check No.01	276	
check No.02	276	
check No.03	276	
check No.04	277	
check No.05	278	
check No.06	279	
check No.07	280	
check No.08	281	
check No.09	281	
check No.10	282	
check No.11	282	
check No.12	283	
check No.13	283	
check No.14	284	
check No.15	284	
check No.16	285	
comfort airflow mode	62	
compressor lock	251	
compressor overload	250	
compressor protection function	87	
compressor sensor system abnormality	258	
control PCB (indoor unit)	39, 41, 42, 44, 46, 47, 50, 53	
cooling / heating mode lock	101	
CT or related abnormality	261	
D		
DC fan lock	252	
defrost control	91	
diagnosis mode	231	
discharge pipe control	88	
discharge pipe temperature control	255	
discharge pressure check	281	
display PCB	39, 44, 48, 51, 53	
E		
econo mode	70	
electrical box temperature rise	265	
electronic expansion valve check	277	
electronic expansion valve control	92	
F		
fan motor connector output check	276	
fan motor or related abnormality		
ac motor	239	
DC motor	240	
four way valve performance check	278	
freeze-up protection control	89, 237, 247	
frequency control	83	
frequency principle	60	
front panel open/close fault	243	
function of thermistor		
cooling only model	80	
heat pump model	78	
H		
Hall IC check	285	
heating peak-cut control	89	
high pressure control	237	
high pressure control in cooling	256	
HOME LEAVE operation	73	
hot start function	75	
I		
indoor unit PCB abnormality	236	
input current control	88	
input over current detection	253	
installation condition check	280	
insufficient gas	271	
insufficient gas control	96	
INTELLIGENT EYE	71	
INTELLIGENT EYE sensor	322	
INTELLIGENT EYE sensor PCB	39, 42, 44, 46	
inverter features	61	
inverter POWERFUL operation	74	
inverter units refrigerant system check	282	
J		
jumper settings	321	
L		
limit switch continuity check	276	
location of operation lamp	226	
low-voltage detection	273	
M		
main circuit electrolytic capacitor check	284	
main PCB (outdoor unit)	57	
main structural parts	77	
mode hierarchy	82	
N		
night set mode	69	
O		
OL activation	250	
ON/OFF button on indoor unit	75	
outdoor unit fan system check (with DC motor) ..	281	

outdoor unit PCB abnormality	249	programme dry function	66
output over current detection	269	R	
over-voltage detection	273	radiation fin temperature rise	267
P		remote control	229, 230
PCB (ceiling suspended type)	55	S	
piping diagrams		sensor PCB	53
4MKS75F2V1B	330	service monitor PCB	58
4MXS68F2V1B	330	service PCB	53
CTXG50EV1BW(S)	325	signal receiver PCB	39, 42, 44, 46, 51
FDKS25CAVMB	327	signal transmission error	244
FDKS25EAVMB	327	signal transmission error (on outdoor unit PCB) .	274
FDKS35CAVMB	327	starting control flow	64
FDKS35EAVMB	327	starting timing chart	64
FDKS50CVMB	327	T	
FDKS60CVMB	327	target discharge pipe temperature control	95
FDXS25CAVMB	327	test operation from remote control	320
FDXS25EAVMB	327	thermistor or related abnormality (indoor unit)	242
FDXS35CAVMB	327	thermistor or related abnormality (outdoor unit) ..	263
FDXS35EAVMB	327	thermistor resistance check	279
FDXS50CVMB	327	thermostat control	68
FDXS60CVMB	327	troubleshooting with the LED indication	227
FHQ35/50/60BVV1B	329	turning speed pulse input on the outdoor unit PCB	
FLKS25BAVMB	327	check	284
FLKS35BAVMB	327	U	
FLKS50BAVMB	327	unspecified voltage (between indoor and outdoor	
FLKS60BAVMB	327	units)	246, 275
FLXS25BAVMB	328	W	
FLXS35BAVMB	328	wiring diagrams	
FLXS50BAVMB	328	4MKS75F2V1B	336
FLXS60BAVMB	328	4MXS68F2V1B	336
FTKS20CAVMB	324	CTXG50EV1BW(S)	333
FTKS20D3VMW(L)	324	FDKS25CAVMB	333
FTKS25CAVMB	324	FDKS25EAVMB	333
FTKS25D3VMW(L)	324	FDKS35CAVMB	333
FTKS35CAVMB	324	FDKS35EAVMB	333
FTKS35D3VMW(L)	324	FDKS50CVMB	333
FTKS50D2V1W(L)	324	FDKS60CVMB	333
FTKS50FV1B	324	FDXS25CAVMB	333
FTKS60FV1B	324	FDXS25EAVMB	333
FTKS71FV1B	325	FDXS35CAVMB	333
FTXG25EV1BW(S)	325	FDXS35EAVMB	333
FTXG35EV1BW(S)	325	FDXS50CVMB	333
FTXS20CAVMB	326	FDXS60CVMB	333
FTXS20D3VMW(L)	325	FHQ35/50/60BVV1B	335
FTXS25CAVMB	326	FLKS25BAVMB	334
FTXS25D3VMW(L)	325	FLKS35BAVMB	334
FTXS35CAVMB	326	FLKS50BAVMB	334
FTXS35D3VMW(L)	325	FLKS60BAVMB	334
FTXS50D2V1W(L)	326	FLXS25BAVMB	334
FTXS50FV1B	326	FLXS35BAVMB	334
FTXS60FV1B	326	FLXS50BAVMB	334
FTXS71FV1B	326	FLXS60BAVMB	334
FVXS25FV1B	328	FTKS20CAVMB	332
FVXS35FV1B	328	FTKS20D3VMW(L)	331
FVXS50FV1B	328	FTKS25CAVMB	332
position sensor abnormality	260	FTKS25D3VMW(L)	331
power supply PCB	50	R	
power supply waveforms check	282	radiation fin temperature rise	267
power transistor check	283	remote control	229, 230
priority room setting	100	S	
		sensor PCB	53
		service monitor PCB	58
		service PCB	53
		signal receiver PCB	39, 42, 44, 46, 51
		signal transmission error	244
		signal transmission error (on outdoor unit PCB) .	274
		starting control flow	64
		starting timing chart	64
		T	
		target discharge pipe temperature control	95
		test operation from remote control	320
		thermistor or related abnormality (indoor unit)	242
		thermistor or related abnormality (outdoor unit) ..	263
		thermistor resistance check	279
		thermostat control	68
		troubleshooting with the LED indication	227
		turning speed pulse input on the outdoor unit PCB	
		check	284
		U	
		unspecified voltage (between indoor and outdoor	
		units)	246, 275
		W	
		wiring diagrams	
		4MKS75F2V1B	336
		4MXS68F2V1B	336
		CTXG50EV1BW(S)	333
		FDKS25CAVMB	333
		FDKS25EAVMB	333
		FDKS35CAVMB	333
		FDKS35EAVMB	333
		FDKS50CVMB	333
		FDKS60CVMB	333
		FDXS25CAVMB	333
		FDXS25EAVMB	333
		FDXS35CAVMB	333
		FDXS35EAVMB	333
		FDXS50CVMB	333
		FDXS60CVMB	333
		FHQ35/50/60BVV1B	335
		FLKS25BAVMB	334
		FLKS35BAVMB	334
		FLKS50BAVMB	334
		FLKS60BAVMB	334
		FLXS25BAVMB	334
		FLXS35BAVMB	334
		FLXS50BAVMB	334
		FLXS60BAVMB	334
		FTKS20CAVMB	332
		FTKS20D3VMW(L)	331
		FTKS25CAVMB	332
		FTKS25D3VMW(L)	331

FTKS35CAVMB	332
FTKS35D3VMW(L)	331
FTKS50D2V1W(L)	331
FTKS50FV1B	332
FTKS60FV1B	332
FTKS71FV1B	332
FTXG25EV1BW(S)	333
FTXG35EV1BW(S)	333
FTXS20CAVMB	332
FTXS20D3VMW(L)	331
FTXS25CAVMB	332
FTXS25D3VMW(L)	331
FTXS35CAVMB	332
FTXS35D3VMW(L)	331
FTXS50D2V1W(L)	331
FTXS50FV1B	332
FTXS60FV1B	332
FTXS71FV1B	332
FVXS25FV1B	334
FVXS35FV1B	334
FVXS50FV1B	334
wiring-error check	98

In all of us,
a green heart



Daikin's unique position as a manufacturer of air conditioning equipment, compressors and refrigerants has led to its close involvement in environmental issues. For several years Daikin has had the intension to become a leader in the provision of products that have limited impact on the environment. This challenge demands the eco design and development of a wide range of products and an energy management system, resulting in energy conservation and a reduction of waste.



Daikin Europe N.V. is approved by LRQA for its Quality Management System in accordance with the ISO9001 standard. ISO9001 pertains to quality assurance regarding design, development, manufacturing as well as to services related to the product.



ISO14001 assures an effective environmental management system in order to help protect human health and the environment from the potential impact of our activities, products and services and to assist in maintaining and improving the quality of the environment.




Daikin units comply with the European regulations that guarantee the safety of the product.



Daikin Europe N.V. is participating in the EUROVENT Certification Programme. Products are as listed in the EUROVENT Directory of Certified Products.

The present publication is drawn up by way of information only and does not constitute an offer binding upon Daikin Europe N.V.. Daikin Europe N.V. has compiled the content of this publication to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Daikin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this publication. All content is copyrighted by Daikin Europe N.V..



DAIKIN EUROPE N.V.
Naamloze Vennootschap
Zandvoordestraat 300
B-8400 Oostende - Belgium
www.daikin.eu
BTW: BE 0412 120 336
RPR Oostende



SIENBE12-713