





INSTALLATION MANUAL

Split System air conditioners


FBQ35C7VEB
FBQ50C7VEB
FBQ60C7VEB
FBQ71C7VEB
FBQ100C7VEB
FBQ125C7VEB
FBQ140C7VEB




1




2




3




4




5




6a




6b




6c




7a




7b




7b




7b




8




9



7c



10



11

CE - DECLARATION-OF-CONFORMITY
CE - KONFORMITÄTSERKLÄRUNG
CE - DECLARATION-DE-CONFORMITE
CE - CONFORMITEITSVERKLARING

CE - DECLARACION-DE-CONFORMIDAD
CE - DICHIARAZIONE-DI-CONFORMITA
CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ

CE - DECLARAÇÃO-DE-CONFORMIDADE
CE - ЗАЯВЛЕНИЕ-О-СООТВЕТСТВИИ
CE - OPFYLDELSESERKLÆRING
CE - FÖRSÄKRAN-OM-ÖVERENSTÄMMELSE

CE - ERKLÆRING OM-SAMSVAR
CE - ILMOITUS-YHDENMUKAISUUDESTA
CE - PROHLÁŠENÍ-O-SHOĐĚ

CE - IZJAVA-O-USKLAĐENOSTI
CE - MEGFELELŐSÉGINYILATKOZAT
CE - DEKLARACJA-ZGODNOŚCI
CE - DECLARAȚIE-DE-CONFORMITATE

CE - IZJAVA O SKLADNOSTI
CE - VASTAVUSDEKLARATSIOON
CE - ДЕКЛАРАЦИЯ-ЗА-СЪОТВЕТСТВИЕ

CE - ATTIKTIES-DEKLARĀCIJA
CE - ATBILSTĪBAS-DEKLARĀCIJA
CE - VYHLÁSENIE-ZHODY
CE - UYUMLULUK-BILDIRISI

Daikin Europe N.V.

01	GB	declares under its sole responsibility that the air conditioning models to which this declaration relates:
02	DE	erklärt auf seine alleinige Verantwortung daß die Modelle der Klimaanlage für diese Erklärung bestimmt ist:
03	FR	déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration:
04	NL	verklaart hierbij op zijn exclusieve verantwoordelijkheid dat de airconditioning units waarop deze verklaring betrekking heeft:
05	PT	declara aqui a sua única responsabilidade que os modelos de ar condicionado a que esta declaração se refere:
06	IT	dichiaro sotto la mia responsabilità che i condizionatori modello a cui è riferita questa dichiarazione:
07	GR	αναγγέλλω με αποκλειστική της ευθύνη ότι τα παρόντα συστήματα αερίων κλιματισμού ανήκουν σε αυτά της παρούσας δήλωσης:
08	P	declara sous sa seule responsabilité que les modèles de air conditionné à que esta declaración se refiere:

[illegible]

17 **PL** deklaracje na Waszej wypowiedzi opowietrzności, że modele klimatyzatorów, których dotyczy niniejsza deklaracja

18 **DE** werden für propiie furspende ich apparate de aer conditional la zraz se referi acasutä declaratie.

19 **FR** v zvo ogovornostu zjavja, da so model klimatich naprav, na katere se drava nasla.

20 **IT** Kimbato oma italeku vstusitel, e italedeve deklaratsioni ala kuivutid klimatizatsioe mueltid.

21 **EN** deklaracija na zraz odgovornosti, e zvoignenie klimatiziranih naprav, za koro e ometo razm deklaratsija.

22 **LT** viskas zraz atsakomyje šelbia, kad rod kondicionavim pretaisi modeliai, kuriems yra taikoma ši deklaracija.

23 **LV** ar gihni atbildību atpelnca, ka itāks oskaidlino modeļu gaisa kondicionētāji, uz kuriem attiecas šī deklarācija.

24 **SK** vyhlasenie na vashu zodpovednost, ze tieto klimatizatory, na ktoré sa vzťahuje toto vyhlásenie.

25 **TR** lamamen kend sorumluluğunda onak zraz bu bildirimi ilgili odogu klima modelleminin sagladigi gih odolugunu bu

$$= 1, 1, 2, 3, \dots, 9$$

Instructions:

- 01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with the following instructions:
- 02 werden folgenden Norm(en) oder einen anderen Normdokument oder dokumenten entspricht/en, unter der Voraussetzung, dass sie gemäß unseren Anweisungen eingesetzt werden:
- 03 sont conformés à la/aux norme(s) ou autre(s) document(s) normatif(s), pour autant qu'ils soient utilisés conformément à nos instructions:
- 04 conform de volgende norm(en) of één of meer andere bindende documenten zijn, op voorwaarde dat ze worden gebruikt overeenkomstig onze instructies:
- 05 están en conformidad con la/s siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras instrucciones:
- 06 sono conformi alle/i seguente/i standard(s) o altro(i) documento(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni:
- 07 είναι σύμφωνα με το/ι ακόλουθο(α) πρότυπο(α) ή άλλο(α) έγγραφο(α) κανονιστικό, υπό την προϋπόθεση ότι χρησιμοποιούνται σύμφωνα με τις οδηγίες μας:

[illegible]

- 16 meglejalek az alábbi szabvány(ok)nak egyébként hiányzó dokumentum(ok)nak, ha azok az előírt szexuális használatát
- 17 szolgálják, vagyoni / neszámjegyek normái / egyéb dokumentum normalizációja, pod variankim se izjavljamo za zgodnost z našimi
instrukcijami.
- 18 študi in conformitate cu următorul (următoarele) standard(e) sau alte documente(n) normative), cu condiția ca acestea să fie utilizate în
conformitate cu institutiunile noastre
- 19 skladno z naslednjimi standardi in drugimi normativi, pod pogojem, da se uporabljajo v skladu z našimi navodili;
- 20 skeden na vastavases jargimitehi standarditehi / ali tiste norme/kasete dokumentelnege, ku neid kasovskase vastavati meie juhendile:
- 21 съгласно вимоги / наступящих нормативных документов, при условии, что се използват съгласно нашите
инструкции;
- 22 allikahis žemiau norādītu standartus / (arba) kūs norādītu dokumentus sa pašā, kad jau norādījumi pēgā mūšā norādījumus;
- 23 tavaldis ar labotasi razdaļa nodrošinājumu, abas sekosiem standartiem un citiem normatīviem dokumentiem.
- 24 su z vzhodu z naslednjimi normativnimi / ali drugim dokumentiranimi dokumentacijami, za predpostavko, že so používajú v súlade
s našimi navodmi;
- 25 üritün, ilâmlarımız göre kullanılması koşuluyla aşağıdaki standartlar ve norm belirlen belgelerle uyumludur

EN60335-2-40,

01 following the provisions of:	19 об условявания додър:
02 gemäß den Vorschriften der:	20 vastavali riikidele:
03 conformément aux stipulations des:	21 ceneauku krajov aze:
04 overeenkomstig de bepalingen van:	22 liikentis nustaib, pakeikumi:
05 según las disposiciones de:	23 erevotgi prastab, kas noiekabas:
06 secondo le prescrizioni per:	24 odrazavaja ustanovena:
07 de acordo com o previsto em:	25 bunun tegulama uygun olarak:
08 в соответствии с положениями:	17 zgodnie z postanowieniami Dyrektora:
	18 in urma prevederilor:
	10 under tillagelse af bestemmelserne i:
	11 enligt villkoren i:
	12 qiti i hoididit li bestemmelseine i:
	13 qiti i hoididit maatrayksiti:
	14 za dodaten maatrayksiti:
	15 na oobrazheniye predpisu:
	16 kveiti odredena:
	17 kveiti azai:

01 Directive
02 Directive
03 Directive
04 Rectifying
05 Directive
06 Directive
07 Directive
08 Directive
09 Directive

Low Voltage 2006/95/EC
Machinery 98/37/EC
Electromagnetic Compatibility 2004/108/EC *

- 10 Direktive, med senere ændringer.
- 11 Direktive, med senere ændringer.
- 12 Direktiv, med foretagne ændringer.
- 13 Direktive, med tilføjede ændringer.
- 14 Direktive, selv om kun en af mulighederne.
- 15 Særlig, som er afsluttet.
- 16 Særlig, som er afsluttet.
- 17 Særlig, som er afsluttet.
- 18 Særlig, som er afsluttet.
- 19 Direktive i visse sammenhænge.
- 20 Direktiv, som er afsluttet.
- 21 Direktive, som er afsluttet.
- 22 Direktive, som er afsluttet.
- 23 Direktive, som er afsluttet.
- 24 Særlig, som er afsluttet.
- 25 Særlig, som er afsluttet.

01	Note *	as seti in <A> and judged positively by according to the Certificat <C>	06	Nota *	delaheati nei <A> e giudicato positivamente da secondo il Certificat <C>
02	Hinweis *	wie in der <A> aufgeführt und von positiv beurteilt gemäß Certificat <C>	07	Знакмен *	опис, відомий згідно з <A> як позитивний знак, що схвалює на підставі Сертифікату <C>
03	Remarque *	tel que défini dans <A> et évalué positivement par conformément au Certificat <C>	08	Nota *	якщо встановлено в <A> є позитивним і оцінено за погодженням з відповідно до Сертифікату <C>
04	Bemerk *	zodals vermeld in <A> en positief beoordeeld door overeenkomstig Certificat <C>	09	Примечание *	якщо вказано в <A> в позитивній оцінці згідно з Сертифікатом <C>
05	Nota *	como se establece en <A> y es valorado positivamente por de acuerdo con el Certificat <C>	10	Безпечка *	показувати позитивний результат за Сертифікатом <C>

11	Information *	enligt <A> och påbörjats av enligt Certifikat <A>
12	Merk *	som del frånkommer i <A> och till glänsom positiv bedömning av följde Serifikat <A>
13	Huon *	joka on esitetty asidaksi <A> ja oika on hyväksynyt Serifikatin <A> mukaisesti.
14	Poznańka *	jak bylo ujedno z <A> na podstawie z sołtatu s oswiedceni <A>
15	Napomena *	kako je izloženo u <A> i pozitivno ocjenjeno od strane prema Certifikatu <A>
16	Megjegyzés *	a) z <A> alapján, a) z igazolva a megjelölés a) z <A> tanúsítvány szerint.
17	Uwaga *	zgodnie z dokumentacją <A>, pozytywną opinią Swiadectwem <A>
18	Notā *	apskums ar šiem stabilīti <A> šā apseid, pozitīvi ir informācija no Certifikāta <A>
19	Opomba *	kat je doobeno v <A> in odobreno s strani v skladu s certifikatom <A>
20	Märkus *	nāpu un nādaud dokumentā <A> šā heals kadeidul jāgi vāstāval serifikādi <A>

16	Mejgjesjës	ajzj <4> ajsjajn ajz <4> ajzajla a mjeshelesj, ajzj <4> tamsivjaj shërrit
17	Unga*	zgjehje z dokumënjat <4> pozhytywa opinjá <4> Swiedeczná <4>
18	Notá*	asaj omi este sbajtj in <4> s apesajl pozityv de <4> in formatimje cu Certificat <4>
19	Opomba*	koj je dóbnoy <4> in dóbnoy s strani <4> v skladu s certifikatòm <4>
20	Márkus*	nagu om nájdajdu dokumëntis <4> ja beakis kidebul <4> jargi vstajvi sertifikacile <4>
21	Zacënkëja	katëto je kërkimëje v <4> shënkëjeje nómëntimëto om <4> sëmëncio
22	Paštëta*	kapj nashajta <4> in kapj bëgjajna in <4> pagaj Sertifikatá <4>
23	Përlëmes*	ka nashajta <4> an abishtëj <4> poqë vërlëmjim sashajta arj Sertifikatá <4>
24	Poznamëja*	akjo bëtë uedërje v <4> a pozitivë <4> shëllëz s sërëfëntimëj <4>
25	Not*	<4> a sërëfëntimëj gbi ve <4> gëre <4> tararimëj olur depërdëntimëj gbi.

21	Zelenexha *	като е в тополе в <♠> и целено попознато от <♠> сипало
22	Cepinixata <♠>	Сепиницата <♠>
23	Pastha *	кап нустаха <♠> и кап легания нустаха <♠> пепи Серифат <♠>
24	Piazmes *	па нортис <♠> на алтисит <♠> позитлаж верлежам сасана серифат <♠>
25	Pzaniama *	ка бола увелел <♠> а позитне зисел <♠> силел <♠> севелитин <♠>
26	Not *	<♠> та белмиди гни <♠> Серификана горе <♠> тариндан олуму дарак деперидиндиги гни.

<A>	DAIKIN.TCF021F1/07-2008
	KEMA
<C>	2024351-QUA/EMC02-4565




Jiro Tomita
Director Quality
Ostend, 3rd

Ostend, 3rd of November 2008

Zandvoordestraat 300, B-8400 Oostende, Belgium

DAIKIN EUROPE N.V.

CONTENTS

	Page
Before installation	1
Selecting installation site	2
Preparations before installation	2
Indoor unit installation	3
Refrigerant piping work	3
Drain piping work	4
Electric wiring work	6
Wiring example and how to set the remote controller	6
Wiring example	7
Installation of the decoration panel	8
Test operation	8
Wiring diagram	9



READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION. KEEP THIS MANUAL IN A HANDY PLACE FOR FUTURE REFERENCE.

IMPROPER INSTALLATION OR ATTACHMENT OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORT-CIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.

IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DAIKIN DEALER FOR ADVICE AND INFORMATION.

BEFORE INSTALLATION











- Leave the unit inside its packaging until you reach the installation site. Where unpacking is unavoidable, use a sling of soft material or protective plates together with a rope when lifting, this to avoid damage or scratches to the unit.
- Refer to the installation manual of the outdoor unit for items not described in this manual.
- Caution concerning refrigerant series R410A:
The connectable outdoor units must be designed exclusively for R410A.

Precautions

- Do not install or operate the unit in rooms mentioned below.
 - Places with mineral oil, or filled with oil vapour or spray like in kitchens. (Plastic parts may deteriorate.)
 - Where corrosive gas like sulphurous gas exists. (Copper tubing and brazed spots may corrode.)
 - Where volatile flammable gas like thinner or gasoline is used.
 - Where machines generating electromagnetic waves exist. (Control system may malfunction.)
 - The unit should be installed at least 2.5 m from the floor.
 - Where the air contains high levels of salt such as air near the ocean and where voltage fluctuates a lot (e.g. in factories). Also in vehicles or vessels.
- Do not install accessories on the casing directly. Drilling holes in the casing may damage electrical wires and consequently cause fire.

Accessories

Check if the following accessories are included with your unit.

 Metal clamp 1 piece	 Drain hose 1 piece	 Washer for hanging bracket 8 pieces	 Medium sealing pad 2 pieces
 Large sealing pad 1 piece	Insulation for fitting  for gas pipe 1 piece  for liquid pipe 1 piece		 Installation and operation manual
 Screws for duct flanges 1 set 16 pieces.			 Wire for common power supply 2 pieces.

Screws for fixing panels are attached to the air inlet panel.

Optional accessories

- Select an optional remote controller according to customer request and install in an appropriate place.
Refer to catalogues and technical literature for selecting a suitable remote controller.
- When installing bottom suction: air inlet panel and canvas connection for the air inlet panel.

For the following items, take special care during construction and check after installation is finished

Tick ✓ when checked	
<input type="checkbox"/>	Is the indoor unit fixed firmly? The unit may drop, vibrate or make noise.
<input type="checkbox"/>	Is the gas leak test finished? It may result in insufficient cooling or heating.
<input type="checkbox"/>	Is the unit fully insulated and checked for air leaks? Condensate water may drip.
<input type="checkbox"/>	Does drainage flow smoothly? Condensate water may drip.
<input type="checkbox"/>	Does the power supply voltage correspond to that shown on the name plate? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Are wiring and piping correct? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Is the unit safely grounded? Dangerous at electric leakage.
<input type="checkbox"/>	Is the wiring size according to specifications? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Is nothing blocking the air outlet or inlet of either the indoor or outdoor units? It may result in insufficient cooling or heating.
<input type="checkbox"/>	Are refrigerant piping length and additional refrigerant charge noted down? The refrigerant charge in the system might not be clear. This to avoid confusion for future maintenance and serving of the installation.
<input type="checkbox"/>	Are the air filters fixed properly (when installing with rear duct)? Maintenance of the air filters can be impossible.
<input type="checkbox"/>	Is the external static pressure set? It may result in insufficient cooling or heating.

Notes to the installer

- Read this manual carefully to ensure correct installation. Be sure to instruct the customer how to properly operate the system and show him/her the enclosed operation manual.
- Explain to the customer what system is installed on the site. Be sure to fill out the appropriate installation specifications in the chapter "What to do before operation" of the operation manual.

SELECTING INSTALLATION SITE (See figure 1 and 2)

- Select an installation site where the following conditions are fulfilled and that meets your customer's approval.
 - Where optimum air distribution can be ensured.
 - Where nothing blocks air passage.
 - Where condensate water can be properly drained.
 - Where the false ceiling is not noticeably on an incline.
 - Where sufficient clearance for maintenance and service can be ensured.
 - Where there is no risk of flammable gas leaking.
 - Where piping between indoor and outdoor units is possible within the allowable limit. (Refer to the installation manual of the outdoor unit.)
 - This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.
 - Keep indoor unit, outdoor unit, power supply wiring and transmission wiring at least 1 meter away from televisions and radios. This is to prevent image interference and noise interference in those electrical appliances. (Electric noise may be generated depending on the conditions under which the electric wave is generated, even if 1 meter is kept.)
 - When installing the wireless remote controller kit, the distance between wireless remote controller and indoor unit might be shorter if there are fluorescent lights who are electrically started in the room. The indoor unit must be installed as far as possible away from fluorescent lights.
 - Do not place objects that are susceptible to moisture directly beneath the indoor or outdoor units. Under certain conditions, condensation on the main unit or refrigerant pipes, air filter dirt or drain blockage may cause dripping, resulting in fouling or failure of the object concerned.

- Ensure that a protective guard is installed on air suction and air outlet side to prevent that the fan blades or heat exchanger be touched.
The protection must comply with relevant European and national regulations.
- Use suspension bolts for installation. Check whether the ceiling is strong enough to support the weight of the indoor unit. If there is a risk, reinforce the ceiling before installing the unit.
 - Service space
 - Drain pipe
 - Power supply wiring port
 - Transmission wiring port
 - Maintenance drain outlet
 - Gas pipe
 - Liquid pipe

PREPARATIONS BEFORE INSTALLATION

- Relation of ceiling opening to unit and suspension bolt position. (See figure 5)

Model	A (mm)	B (mm)
35+50	700	750
60+71	1000	1050
100~140	1400	1450

- Indoor unit
- Pipe
- Suspension bolt pitch (x4)
- Suspension bolt pitch distance

For installation, choose one of the possibilities as listed further.

Standard rear suction (See figure 6a)

- Ceiling surface
- Ceiling opening
- Service access panel (optional accessory)
- Air filter
- Air inlet duct
- Duct service opening
- Interchangeable plate

Installation with rear duct and duct service opening (See figure 6b)


Installation with rear duct, no duct service opening (See figure 6c)

NOTE



Before installation of the unit (in case of installation with duct, but no duct service opening): modify the position of the air filters.


- Remove the air filter(s) at the outside of the unit
- Remove the interchangeable plate
- Install the air filter(s) from the inside of the unit
- Reinstall the interchangeable plate



NOTE

When installing an air inlet duct, select fixing screws that shall stick out maximum 5 mm at the inside of the flange to protect the air filter from damage during maintenance of the filter.

- 1 Air inlet duct
- 2 Inside of the flange
- 3 Fixing screw



Mounting the air inlet panel with a canvas connection (See figure 7a)

Mounting the air inlet panel directly (See figure 7b)

- 1 Ceiling surface
- 2 Ceiling opening
- 3 Air inlet panel (Optional accessory)
- 4 Indoor unit (Back side)
- 5 Canvas connection for air inlet panel (Optional accessory)

Model	A (mm)
35+50	760
60+71	1060
100~140	1460

Bottom suction (See figure 7c)

NOTE

The unit can be used with bottom suction by replacing the interchangeable plate by the air filter holding plate.

- 1 Air filter holding plate with air filter(s)
- 2 Interchangeable plate

NOTE

For other installation than standard installation, contact your Daikin dealer for details.

2. The fan speed for this indoor unit is preset to provide standard external static pressure.
If higher or lower external static pressure is required, reset the external static pressure by changing the initial setting from the remote controller.
Refer to "External static pressure setting" on page 7.
3. Install the suspension bolts.
(Use M10 size bolt for the suspension bolt.) Use anchors for existing ceilings, and a sunken insert, sunken anchors or other field supplied parts for new ceilings to reinforce the ceiling in order to bear the weight of the unit.

Installation example

(See figure 3)

- 1 Anchor
- 2 Ceiling slab
- 3 Long nut or turn-buckle
- 4 Suspension bolt
- 5 Indoor unit

NOTE

All the above parts are field supplied.

INDOOR UNIT INSTALLATION

When installing optional accessories (except for the air inlet panel), read also the installation manual of the optional accessories. Depending on the field conditions, it may be easier to install optional accessories before the indoor unit is installed.

1. Install the indoor unit temporarily.
 - Attach the hanger bracket to the suspension bolt. Be sure to fix it securely by using a nut and washer from the upper and lower sides of the hanger bracket. (See figure 4)
 - 1 Nut (field supply)
 - 2 Washer for hanger bracket (supplied with the unit)
 - 3 Tighten (double nut)
2. Check if the unit is horizontally levelled.
 - Do not install the unit tilted. The indoor unit is equipped with a built-in drain pump and float switch.
(If the unit is tilted against condensate flow, the float switch may malfunction and cause water to drip.)
 - Check if the unit is levelled at all four corners with a water level or a water-filled vinyl tube as shown in figure 9.
 - 1 Water level
 - 2 Vinyl tube
3. Tighten the upper nut.

REFRIGERANT PIPING WORK

For refrigerant piping of outdoor unit, refer to the installation manual supplied with the outdoor unit.

Execute heat insulation work completely on both sides of the gas piping and the liquid piping. Otherwise, this can sometimes result in water leakage.


Before rigging tubes, check which type of refrigerant is used.



All field piping must be provided by a licensed refrigeration technician and must comply with the relevant local and national codes.

- Use a pipe cutter and flare suitable for the used refrigerant.
- To prevent dust, moisture or other foreign matter from infiltrating the tube, either pinch the end, or cover it with tape.
- Use copper alloy seamless pipes (ISO 1337).
- The outdoor unit is charged with refrigerant.
- To prevent water leakage, execute heat insulation work completely on both sides of the gas and liquid piping. When using a heat pump, the temperature of the gas piping can reach up to approximately 120°C, use insulation which is sufficiently heat resistant.
- Be sure to use both a spanner and torque wrench together when connecting or disconnecting pipes to/from the unit.

- 1 Torque wrench
- 2 Spanner
- 3 Piping union
- 4 Flare nut




- Do not mix anything other than the specified refrigerant, such as air, etc..., inside the refrigerant circuit.
- Use annealed material only for flare connections.

- Refer to [Table 1](#) for the dimensions of flare nut spaces and the appropriate tightening torque. (Overtightening may damage the flare and cause leaks.)

Table 1


Pipe gauge	Tightening torque (N·m)	Flare dimension A (mm)	Flare shape
Ø6.4	15~17	8.7~9.1	
Ø9.5	33~39	12.8~13.2	
Ø12.7	50~60	16.2~16.6	
Ø15.9	63~75	19.3~19.7	

- When connecting the flare nut, coat the flare inner surface with ether oil or ester oil and initially tighten 3 or 4 turns by hand before tightening firmly.



- If the refrigerant gas leaks during the work, ventilate the area. A toxic gas is emitted by the refrigerant gas being exposed to a fire.
- Make sure there is no refrigerant gas leak. A toxic gas may be released by the refrigerant gas leaking indoor and being exposed to flames from an area heater, cooking stove, etc.
- Finally, insulate as shown in the figures below.


Piping insulation procedure



For local insulation, be sure to insulate local piping all the way into the pipe connections inside the unit.
Exposed piping may cause condensation or may cause burns when touched.

Cautions for brazing


- Be sure to carry out a nitrogen blow when brazing. Brazing without carrying out nitrogen replacement or releasing nitrogen into the piping will create large quantities of oxidized film on the inside of the pipes, adversely affecting valves and compressors in the refrigerating system and preventing normal operation.
- When brazing while inserting nitrogen into the piping, nitrogen must be set to 0.02 MPa with a pressure-reducing valve (=just enough so that it can be felt on the skin).



- Refrigerant piping
- Part to be brazed
- Taping
- Hands valve
- Pressure-reducing valve
- Nitrogen


DRAIN PIPING WORK

Rig the drain piping as shown in the figure and take measures against condensation. Improperly rigged piping could lead to leaks and eventually wet furniture and belongings.



- Hanging bar

- Install the drain pipes.
 - Keep piping as short as possible and slope it downwards at a gradient of at least 1/100 so that air may not remain trapped inside the pipe.
 - Keep pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter).
 - Push the supplied drain hose as far as possible over the drain socket.
 - Tighten the metal clamp until the screw head is less than 4 mm from the metal clamp part as indicated in the illustration.



- Drain socket (attached to the unit)
- Drain hose (supplied with the unit)
- Metal clamp (supplied with the unit)
- Drain piping (field supply)
- Large sealing pad (supplied with the unit)

- Wrap the supplied large sealing pad over the metal clamp and drain hose to insulate and fix it with clamps.

- Insulate the complete drain piping inside the building (field supply).
- If the drain hose cannot be sufficiently set on a slope, fit the hose with drain raising piping (field supply).

■ How to perform drain piping

(See figure 10)

- 1 Ceiling slab
- 2 Hanger bracket
- 3 Adjustable range
- 4 Drain raising pipe
- 5 Drain hose (supplied with the unit)
- 6 Clamp metal (supplied with the unit)

- 1 Connect the drain hose to the drain raising pipes, and insulate them.
- 2 Connect the drain hose to the drain outlet on the indoor unit, and tighten it with the clamp.

Installation	A (mm)
Rear suction installation	231
When canvas duct is installed	350-530
When air inlet panel is directly installed	231

■ Precautions

- Install the drain raising pipes at a height of less than 625 mm.
- Install the drain raising pipes at a right angle to the indoor unit and no more than 300 mm from the unit.
- To prevent air bubbles, install the drain hose level or slightly tilted up (≤ 75 mm).



NOTE

The incline of attached drain hose should be 75 mm or less so that the drain socket does not have to withstand additional force.

To ensure a downward slope of 1:100, install hanging bars every 1 to 1.5 m.

When unifying multiple drain pipes, install the pipes as shown in figure 11. Select converging drain pipes whose gauge is suitable for the operating capacity of the unit.

- 1 T-joint converging drain pipes

Testing of drain piping

After piping work is finished, check if drainage flows smoothly.

- Add approximately 1 l of water gradually through the air discharge outlet. Check for water leaks. Method of adding water. See figure 8.

- 1 Water inlet
- 2 Portable pump
- 3 Water inlet cover
- 4 Bucket (adding water through water inlet)
- 5 Drain outlet for maintenance (with rubber drain plug)
- 6 Refrigerant pipes




Caution for drain socket

Do not remove the drain pipe plug. Water might leak out.

The drain outlet is only used to discharge water if the drain pump is not used or before maintenance. Gently put in and out the drain plug. Excessive force may deform the drain socket of the drain pan.


■ Pulling out the plug



1 Drain plug

Do not wiggle the plug up and down

■ Pushing in the plug



1 Drain plug

2 Crosshead screwdriver

Set the plug and push it by using a crosshead screwdriver


First perform electric wiring work as instructed in "Electric wiring work" on page 6 and how to set the remote controller as explained in "Wiring example and how to set the remote controller" on page 6.

When electric wiring work is finished

Check drainage flow during COOL running, explained in "Test operation" on page 8.

When electric wiring work is not finished

- Remove the switch box cover and connect the single-phase power supply and the remote controller to the terminals. (Refer to chapter "Electric wiring work" on page 6 for switch box attachment/detachment) (Refer to figure 12 and 13)
- Connect the single-phase power supply to connections 1 and 2 (as shown in the figure) on the power supply terminal board and confirm drain operation.




- Be aware that the fan will turn during the operation.
- After confirming drainage, turn off the power.

- 1 Switch box cover
- 2 Transmission wiring port
- 3 Power supply wiring port
- 4 Wiring diagram
- 5 Switch box
- 6 Plastic clamp
- 7 Remote controller wiring
- 8 Terminal board for unit transmission wiring
- 9 Power supply wiring
- 10 Indoor PCB board 1
- 11 Power supply terminal board
- 12 Transmission wiring between units
- 13 Indoor PCB board 2
- 14 Indoor PCB board 3 (only for 60~140 units)

ELECTRIC WIRING WORK

General instructions

- All field supplied parts and materials and electric works must conform to local codes.
- Use copper wire only.
- Follow the "Wiring diagram" attached to the unit body to wire the outdoor unit, indoor units and the remote controller. For details on hooking up the remote controller, refer to the "Installation manual of the remote controller".
- All wiring must be performed by an authorized electrician.
- Attach the earth leakage circuit breaker and fuse to the power supply line.
- A main switch or other means for disconnection, having a contact separation in all poles, must be incorporated in the fixed wiring in accordance with relevant local and national legislation. Note that the operation will restart automatically if the main power supply is turned off and then turned back on again.
- Refer to the installation manual delivered with the outdoor unit for the size of power supply electric wire connected to the outdoor unit, the capacity of the earth leakage breaker and fuse and for wiring instructions.
- Be sure to ground the air conditioner.
- Do not connect the ground wire to:
 - gas pipes: might cause explosions or fire if gas leaks.
 - telephone ground wires or lightning rods: might cause abnormally high electric potential in the ground during lightning storms.
 - plumbing pipes: no grounding effect if hard vinyl piping is used.
- Make sure electrical wires are stripped equally.



Electrical characteristics

Model	Hz	Volts	Voltage range	Power supply	
				MCA	MFA
35	50/60	220-240/220	±10%	1.2	16 A
50				1.2	
60				1.1	
71				1.1	
100				1.6	
125				2.1	
140				2.1	

MCA: Min. circuit Amps (A)

MFA: Max. Fuse Amps (A)



For details, refer to "Electrical data" in the technical data book.

Specifications for field wire

Wire	Size (mm ²)	Length
Between indoor units	H05VV-U4G ^{(a),(b)}	2.5
Unit-Remote controller	Sheathed wire (2 wire) ^(c)	0.75-1.25
		Max. 500 m ^(d)

- (a) Shows only in case of protected pipes. Use H07RN-F in case of no protection.
 (b) Run transmission wiring between the indoor and outdoor units through a conduit to protect against external forces, and feed the conduit through the wall together with refrigerant piping.
 (c) Use double insulation wire for remote controller (sheath thickness: ≥1 mm) or run wires through a wall or conduit so that the user cannot come in contact with them.
 (d) This length shall be the total extended length in the system of the group control.

WIRING EXAMPLE AND HOW TO SET THE REMOTE CONTROLLER


How to connect wiring

Remove the switch box cover as shown in [figure 13](#), and make the connections.

- 1 Switch box cover
- 2 Switch box low voltage wiring inlet
- 3 Switch box high voltage wiring inlet
- 4 Wiring diagram
- 5 Switch box

Precautions

1. Observe the notes mentioned below when wiring to the power supply terminal board.
 - Use a round crimp-style terminal for insulation sleeve for connection to the terminal block for wiring the units. When none are available, follow the instructions below.



- 1 Round crimp-style terminal
- 2 Attach insulation sleeve
- 3 Wiring

- Do not connect wires of different gauge to the same power supply terminal. (Looseness in the connection may cause overheating.)
- When connecting wires of the same gauge, connect them according to the figure.



Use the specified electric wire. Connect the wire securely to the terminal. Lock the wire down without applying excessive force to the terminal. Use torques according to the table below.

Tightening torque (N·m)	
Terminal block for unit transmission and remote controller	0.9
Terminal block for power supply	1.2

- When attaching the control box lid, make sure not to pinch any wires.
 - After all wiring connections are done, fill in any gaps in the casing wiring holes with putty or insulation material (field supply) thus to prevent small animals or dirt from entering the unit from outside and causing short circuits in the control box.
2. Do not connect wires of different gauge to the same grounding terminal. Looseness in the connection may deteriorate the protection.
 3. Remote controller cords and wires connecting the units should be located at least 50 mm away from power supply wiring. Not following this guideline may result in malfunction due to electrical noise.
 4. For the remote controller wiring, refer to the "Installation manual of the remote controller" supplied with the remote controller.



The customer has the ability to select the remote controller thermistor.

5. Never connect the power supply wiring to the terminal board for transmission wiring. This mistake could damage the entire system.

6. Use only specified wires and tightly connect wires to the terminals. Be careful that wires do not place external stress on the terminals. Keep wiring in neat order so that they do not obstruct other equipment such as popping open the switch box cover. Make sure the cover closes tight. Incomplete connections could result in overheating, and in the worse case, electric shock or fire.

WIRING EXAMPLE

- Fit the power supply wiring of each system with a switch and fuse as shown in figure 14 and figure 15.

- 1 Power supply
- 2 Main switch
- 3 Fuse
- 4 Outdoor unit
- 5 Indoor unit
- 6 Remote controller (optional accessory)

Complete system example (3 systems)

When using 1 remote controller for 1 indoor unit. (Normal operation) (See figure 14 and figure 15)


Use with 2 remote controllers (See figure 16)^(a)

For group control (See figure 17)^(a)


NOTE It is not necessary to designate an indoor unit address when using group control. The address is automatically set when the power is activated.

NOTE To comply with EN/IEC 61000-3-12^(b), following rules must be considered:

- If the minimum circuit Amps of the outdoor unit is ≤16 A, use the common power supply wire delivered with the unit. (See figure 14)



- If the minimum circuit Amps of the outdoor unit is >16 A, use separate power supplies. (See figure 15)



Make sure a correct fuse is used to protect the indoor unit.

Refer to the wiring diagram for connections. For more details, refer to the electrical data.

- (a) Shown in figure is with common power supply
- (b) European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to low-voltage systems with input current >16 A and ≤75 A per phase.

Field setting

Field setting must be made from the remote controller in accordance with the installation condition.

- Setting can be made by changing the "Mode number", "FIRST CODE No." and "SECOND CODE No.".
- For setting and operation, refer to "Field setting" in the installation manual of the remote controller.

Setting for optional accessories

In case of connecting optional accessories, refer to the operation manuals provided with the optional accessories and establish necessary settings.

External static pressure setting

Settings for external static pressure can be achieved in 2 ways:

Using the airflow automatic adjustment function

Airflow automatic adjustment is the volume of blow-off air that has been automatically adjusted to the rated quantity.

- 1 Make sure the test run is done with a dry coil.
If the coil is not dry, run the unit for 2 hours with fan only to dry the coil.
- 2 Check if the power supply wiring to the air conditioning unit is completed along with the duct installation.
If a closing damper is installed in the air conditioning unit, make sure that it is open.
Also check if the air filter is properly attached into the air passage on the air suction side of the air conditioning unit.
- 3 If there is more than one air inlet and outlet, adjust the dampers so that the airflow rate of each air inlet and outlet is conform with the designed airflow rate.
Make sure the air conditioning unit is in fan operation mode. Press and set the airflow adjustment button on the remote controller to change the airflow rate to H or L.
- 4 Setting the airflow automatic adjustment settings.

When the air conditioning unit is running in fan operation mode perform the next steps:

- stop the air conditioning unit,
- go to field setting mode,
- select mode No. 21 (or 11 in case of group setting),
- set the first code No. to "7",
- set the second code No. to "03".

Return to normal operating mode after setting these settings and press the ON/OFF operation button. The operation lamp will light up and the air conditioning unit will start the fan operation for airflow automatic adjustment.



Do not adjust the dampers during fan operation for airflow automatic adjustment.

After 1 to 8 minutes, the air conditioning unit stops operating automatically when the fan operation for airflow automatic adjustment has been carried out, the operation lamp will be off.

Mode No.	First code No.	Second code No.	Setting content
11 (21)	7	01	Airflow adjustment is OFF
		02	Completion of airflow adjustment
		03	Start of airflow adjustment

Precautions

1. A single switch can be used to supply power to units on the same system. However, branch switches and branch circuit breakers must be selected carefully.
2. For a group control remote controller, choose the remote controller that suits the indoor unit which has the most functions.

- 5 When the air conditioning unit has stopped, check on an indoor unit if the second code No. of mode No. 21 is set to "02".

If the air conditioning unit does not stop operating or the second code No. is not "02", repeat step 4.

If the outdoor unit is not turned on, the display on the remote controller will show "U4" or "UH" (refer to "Test operation" on page 8). However, you can continue setting this function because these messages are only applicable to outdoor units.

After setting this function, be sure to turn on the outdoor unit before performing the test operation on the outdoor unit.

If any other error display occurs on the display of the remote controller, refer to "Test operation" on page 8 and the operation manual of the outdoor unit. Check the defective point.



- If there is no change after airflow adjustment in the ventilation paths, be sure to perform setting the automatic airflow adjustment again.
- Contact your dealer if there is no change after performing airflow adjustment in the ventilation paths, after performing the test operation of the outdoor unit or when the air conditioning unit is moved to another location.
- If booster fans, an outdoor air processing unit or HRV via duct are used, do not use automatic airflow adjustment control with a remote controller.
- If the ventilation paths have been changed, perform the setting of the airflow automatic adjustment again as described above from step 3 onwards.

Using the remote controller

Check on an indoor unit if the second code of mode No. 21 is set to "01" (= factory setting). Change the second code according to the external static pressure of the duct to be connected as shown in table 2.

NOTE

The second code No. is set to "03" by default.



Table 2

Mode No.	First code No.	Second code No.	External static pressure (Pa)						
			FBQ						
			35	50	60	71	100	125	140
13 (23)	6	03	30	30	30	30	40	50	50
		04	35	35	40	40	50	55	55
		05	40	40	50	50	60	60	60
		06	45	45	60	60	70	70	70
		07	50	50	70	70	80	80	80
		08	60	60	80	80	90	90	90
		09	70	70	90	90	100	100	100
		10	80	80	100	100	110	110	110
		11	90	90	—	—	120	120	120
		12	100	100	—	—	—	—	—

Setting air filter sign

- Remote controllers are equipped with liquid crystal display air filter signs to display the time to clean air filters.
- Change the SECOND CODE No. According to Table 3 depending on the amount of dirt or dust in the room. (SECOND CODE No. is factory set to "01" for filter contamination-light.)

Table 3

Setting	Spacing time of display air filter sign (long life type)	Mode No.	First code No.	Second code No.
Air filter contamination - light	±2500 hrs	10 (20)	0	01
Air filter contamination - heavy	±1250 hrs			02

Control by 2 Remote Controllers (Controlling 1 indoor unit by 2 remote controllers)

When using 2 remote controllers, one must be set to "MAIN" and the other to "SUB".

INSTALLATION OF THE DECORATION PANEL

Refer to the installation manual attached to the decoration panel.

After installing the decoration panel, ensure that there is no space between the unit body and decoration panel.

TEST OPERATION

Refer to the section of "For the following items, take special care during construction and check after installation is finished" on page 2.

- After finishing the construction of refrigerant piping, drain piping, and electric wiring, conduct test operation accordingly to protect the unit.
- 1 Open the gas side stop valve.
 - 2 Open the liquid side stop valve.
 - 3 Electrify crank case heater for 6 hours.
 - 4 Set to cooling operation with the remote controller and start operation by pushing ON/OFF button.
 - 5 Press Inspection/Test Operation button 4 times and operate at Test Operation mode for 3 minutes.
 - 6 Press Inspection/Test Operation button and operate normally.
 - 7 Confirm function of unit according to the operation manual.

NOTE



If the main power supply is turned off during operation, operation will restart automatically after the power turns back on again.

WIRING DIAGRAM

--■□■--	: FIELD WIRING
□□	: CONNECTOR
●	: WIRE CLAMP
⊕	: PROTECTIVE EARTH (SCREW)
L	: LIVE
N	: NEUTRAL

BLK	: BLACK	ORG	: ORANGE
BLU	: BLUE	PNK	: PINK
BRN	: BROWN	RED	: RED
GRN	: GREEN	WHT	: WHITE
GRY	: GREY	YLW	: YELLOW

A1P	PRINTED CIRCUIT BOARD
A2P	PRINTED CIRCUIT BOARD (FAN)
A3P	PRINTED CIRCUIT BOARD (CAPACITOR) (only for 60~140 units)
C1,C2,C3	CAPACITOR
F1U,F2U	FUSE (T, 5 A, 250 V)
F3U,F4U	FUSE (T, 6.3 A, 250 V)
HAP	LIGHT EMITTING DIODE (SERVICE MONITOR - GREEN)
KPR,K1R	MAGNETIC RELAY
L1R	REACTOR
M1F	MOTOR (FAN)
M1P	MOTOR (DRAIN PUMP)
PS	SWITCHING POWER SUPPLY
Q1DI	EARTH LEAK DETECTOR
RC	SIGNAL RECEIVER CIRCUIT
R1	RESISTOR (CURRENT LIMITING)
R2	CURRENT SENSING DEVICE
R3,R4	RESISTOR (ELECTRIC DISCHARGE)
R1T	THERMISTOR (SUCTION AIR)
R2T	THERMISTOR (LIQUID)

R3T	THERMISTOR (GAS)
R5T	THERMISTOR NTC (CURRENT LIMITING)
SS1	SELECTOR SWITCH (EMERGENCY)
S1L	FLOAT SWITCH
TC	SIGNAL TRANSMISSION CIRCUIT
V1R	DIODE BRIDGE
V2R	POWER MODULE
X1M	TERMINAL STRIP (POWER SUPPLY)
X2M	TERMINAL STRIP (CONTROL)
Z1C	NOISE FILTER (FERRITE CORE)
Z1F	NOISE FILTER

CONNECTOR OPTIONAL ACCESSORY

X28A	CONNECTOR (POWER SUPPLY FOR WIRING)
X33A	CONNECTOR (FOR WIRING)
X35A	CONNECTOR (ADAPTOR)

WIRED REMOTE CONTROLLER


R1T	THERMISTOR (AIR)
SS1	SELECTOR SWITCH (MAIN/SUB)

WIRED REMOTE CONTROLLER	:
(OPTIONAL ACCESSORY)	:
SWITCH BOX (INDOOR)	:
TRANSMISSION WIRING	:
CENTRAL REMOTE CONTROLLER	:
INPUT FROM OUTSIDE	:
COMMON POWER SUPPLY	:


NOTE




1. USE COPPER CONDUCTORS ONLY.
2. WHEN USING THE CENTRAL REMOTE CONTROLLER, SEE MANUAL FOR CONNECTION TO THE UNIT.
3. WHEN CONNECTING THE INPUT WIRES FROM OUTSIDE, FORCED "OFF" OR "ON/OFF" CONTROL OPERATION CAN BE SELECTED BY THE REMOTE CONTROLLER. SEE INSTALLATION MANUAL FOR MORE DETAILS.
4. REFER TO INSTALLATION MANUAL.



12




13




14

15



16



17

