



# Installation manual

## Split system air conditioners

FBA35A2VEB  
FBA50A2VEB  
FBA60A2VEB  
FBA71A2VEB  
FBA100A2VEB  
FBA125A2VEB  
FBA140A2VEB

Installation manual  
Split system air conditioners

English

CE - DECLARACION DE CONFORMIDAD  
 CE - DICHLARAZIONE DI CONFORMITA  
 CE - DECLARATION OF CONFORMITY  
 CE - CONFORMITEITSVERKLARING

CE - DECLARACAO DE CONFORMIDADE  
 CE - ЗАЯВЛЕНИЕ О СООТВЕТСТВИИ  
 CE - OVERENSSTEMMELSESERKLÆRING  
 CE - FÖRSÄKRAN OM ÖVERENSSTÄMMELSE

CE - ERKLÄRUNG ÜBER ÜBEREINSTIMMUNG  
 CE - ЛУДЖИТИЈА У РАДНОЈ СИТУАЦИЈИ  
 CE - DECLARACIJA ZGODNOSTI  
 CE - PROHLÁŠENÍ SHODY

CE - IZJAVA O SKLADNOSTI  
 CE - MEGFELHETŐSÉGI NYILATKOZÁS  
 CE - DECLARACIJA ZGODNOSTI  
 CE - DECLARAȚIE DE CONFORMITATE

CE - IZJAVA O SKLADNOSTI  
 CE - VASTAVNOSTI IZJAVILOST  
 CE - ДЕКЛАРАЦІЯ ПРО СООТВІТСТІВІСТЬ  
 CE - UYGUNLUK BEYANI

CE - ATTIKTES, DEKLARACIJA  
 CE - АТІТІС, ДЕКЛАРАЦІЯ  
 CE - VYHLÁŠENÍ SHODY  
 CE - UYGUNLUK BEYANI

**Daikin Industries Czech Republic s.r.o.**

- 01 (en) declares under its sole responsibility that the air conditioning models to which this declaration relates
- 02 (en) erklärt auf seine alleinige Verantwortung, daß die Modelle der Klimaanlage für die diese Erklärung bestimmt ist:
- 03 (en) déclare sous sa seule responsabilité que les appareils dont conditionne les par la présente déclaration:
- 04 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 05 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 06 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 07 (en) ovdzija na odgovornost svojih, da so modeli klima uradna na klope svoje izjave odnosi:
- 08 (en) declara sous sa seule responsabilité que les modèles de air conditionné a que essa déclaration se relate:

- 09 (en) заявляет, исключительку под свою ответственность, что модели кондиционеров воздуха, к которым относится настоящее заявление:
- 10 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 11 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 12 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 13 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 14 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 15 (en) ovdzija na odgovornost svojih, da so modeli klima uradna na klope svoje izjave odnosi:
- 16 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:

- 17 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 18 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 19 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 20 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 21 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 22 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 23 (en) ovdzija na odgovornost svojih, da so modeli klima uradna na klope svoje izjave odnosi:
- 24 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:

- 17 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 18 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 19 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 20 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 21 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 22 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 23 (en) ovdzija na odgovornost svojih, da so modeli klima uradna na klope svoje izjave odnosi:
- 24 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:

**FBA35A2VEB, FBA50A2VEB, FBA60A2VEB, FBA71A2VEB, FBA100A2VEB, FBA125A2VEB, FBA140A2VEB,**

- 01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:
- 02 (en) overensstemmer med følgende standard(er) eller andre normgivende dokument(er), under forudsætning af at disse bruges i henhold til våre instruksjoner:
- 03 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 04 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 05 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 06 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 07 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 08 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:

- 08 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 09 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 10 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 11 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 12 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 13 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 14 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 15 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:

- 16 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 17 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 18 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 19 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 20 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 21 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 22 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 23 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:

**EN60335-2-40,**

- 01 (en) under egne ansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 02 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 03 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 04 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 05 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 06 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 07 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 08 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:

- 08 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 09 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 10 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 11 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 12 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 13 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 14 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 15 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:

- 16 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 17 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 18 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 19 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 20 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 21 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 22 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 23 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:

- 01 Note\* as set out in <B> and judged positively by <B>
- 02 Hinweis\* wie in <B> angegeben und von <B> positiv beurteilt gemäß <B>
- 03 Remarque\* tel que défini dans <B> et évalué positivement par <B>
- 04 Bemerk\* zoals vermeld in <B> en positief beoordeeld door <B>
- 05 Nota\* como se establece en <B> y es valorado positivamente por <B>
- 06 Note\* defined in <B> and judged positively by <B>
- 07 Merk\* som det er beskrevet i <B> og vurderet positivt af <B>
- 08 Huom\* joka on esitetty <B>:n mukaisesti ja on arvioitu positiivisesti <B>:n toimesta
- 09 Poznámka\* jak je uvedeno v <B> a pozitivně zhodnotil <B>
- 10 Napomena\* kako je izloženo u <B> i pozitivno ocijenjeno od strane <B>

- 11 Informator\* enigi <B> och godkänns av <B> enligt Certifikat <B>
- 12 Merk\* som det er beskrevet i <B> og vurderet positivt af <B>
- 13 Huom\* joka on esitetty <B>:n mukaisesti ja on arvioitu positiivisesti <B>:n toimesta
- 14 Poznámka\* jak je uvedeno v <B> a pozitivně zhodnotil <B>
- 15 Napomena\* kako je izloženo u <B> i pozitivno ocijenjeno od strane <B>
- 16 Megjegyzés\* az <B> alapján az <B> igazolta a megfelelést, az <B> tanúsítvány szerint
- 17 Uvege\* zgodnie z opisaniami w <B> pozytywnie oceniono przez <B>
- 18 Noia\* care este stabilit în <B> și apreciat pozitiv de <B>
- 19 Opomba\* kolje oobčeno v <B> in odobreno s strani <B>
- 20 Märkus\* nagu on näidatud dokumentis <B> ja heaks kiidetud <B> järgi vastavalt sertifikaadile <B>

- 21 Zabeleška\* izjavo o skladnosti s <B> in o skladnosti s <B> izdalo posredništvo od <B>
- 22 Pasaba\* certifikat <B>
- 23 Pismo\* certifikat <B>
- 24 Poznámka\* jak je uvedeno v <B> a pozitivně zhodnotil <B>
- 25 Nota\* como se establece en <B> y es valorado positivamente por <B>
- 01 Directives as amended
- 02 Direktiven med forbehold ændringer
- 03 Direktives telles que modifiées
- 04 Richtlijnen zoals gewijzigd
- 05 Directives según se emendado
- 06 Direktive, come da modifika
- 07 Οδηγίες, όπως έχουν τροποποιηθεί
- 08 Direktivas, conforme alteração em
- 09 Директиви, як змінювалися
- 10 Direktiver, med senere ændringer
- 11 Direktiven med forbehold ændringer
- 12 Direktives telles que modifiées
- 13 Richtlijnen zoals gewijzigd
- 14 in plaats van
- 15 Spregica, kako je izmenjeno
- 16 irányelvek és módosítások rendelkezései
- 17 z początkowym poprawkami
- 18 Direktiver, cu amendamente respective
- 19 Direktiva z ismi spremembami
- 20 Direktivi kos mudifikacjia
- 21 Директиви, с реурма ременения
- 22 Direktives su pagidzims
- 23 Direktivas un lo paplidzims
- 24 Spregica, y planoni rezi
- 25 Директиви, с измененнями

- 01\*\* DICz\*\* is authorised to complete the Technical Construction File
- 02\*\* DICz\*\* hat die Berechtigung die Technische Konstruktionsakte zusammenzustellen
- 03\*\* DICz\*\* est autorisée à compléter le Dossier de Construction Technique
- 04\*\* DICz\*\* is bevoegd om het Technisch Constructiesdossier samen te stellen
- 05\*\* DICz\*\* está autorizado a completar el Archivo de Construcción Técnica
- 06\*\* DICz\*\* är behörig att redigera i Filen i Teknisk Konstruktionsfil
- 07\*\* H DICz\*\* fikon konstrukcijskimu van ovu izjavu, toj izjavu i potpisati
- 08\*\* A DICz\*\* está autorizada a completar a documentação técnica de fabrico
- 09\*\* Konstativ DICz\*\* projevovaneho ocenava, Komitet revizovaneho dokumenta
- 10\*\* DICz\*\* je autorizován k úplnému technickému konstruktivnímu
- 11\*\* DICz\*\* má povolenie do zberania (opracovania) dokumentácie konštrukčnej
- 12\*\* DICz\*\* har tilläse till å komplette den tekniske konstruktionsfilen

- 13\*\* DICz\*\* má povolenie do zberania (opracovania) dokumentácie konštrukčnej
- 14\*\* Společnost DICz\*\* má oprávnění ke kompletaci souboru technické dokumentace
- 15\*\* DICz\*\* je ovlašten za izradu Databaze o tehnickoj konstrukciji
- 16\*\* A DICz\*\* je pooblaščen za zbiranje (obdelavo) dokumentacije konstrukcijske
- 17\*\* DICz\*\* má povolenie do zberania (opracovania) dokumentácie konštrukčnej
- 18\*\* DICz\*\* este autorizată să completeze Dosarul tehnic de construcție
- 19\*\* DICz\*\* je pooblaščen za sestavo datoteke s tehnično mapo
- 20\*\* DICz\*\* má povolenie do zberania (opracovania) dokumentácie konštrukčnej
- 21\*\* DICz\*\* je ovlašten za izradu Databaze o tehnickoj konstrukciji
- 22\*\* DICz\*\* je pooblaščen za zbiranje (obdelavo) dokumentacije konstrukcijske
- 23\*\* DICz\*\* má povolenie do zberania (opracovania) dokumentácie konštrukčnej
- 24\*\* Společnost DICz\*\* má oprávnění ke kompletaci souboru technické dokumentace
- 25\*\* DICz\*\* je ovlašten za izradu Databaze o tehnickoj konstrukciji

- <A> DAIKIN.TCF.033A3/03-2017
- <B> DEKRA (NE0344)
- <C> 2178265.0551-EMC
- 16 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 17 (en) erklærer under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 18 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:
- 19 (en) vedkär herby på egen eksklusivt ansvar för att de airconditioning units värdar ända verkliga beträkling herby:
- 20 (en) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 21 (en) δηλώνει με αποκλειστική του ευθύνη ότι τα προϊόντα των κλιματιστικών ομοειδών του παρόντος δήλωσης:
- 22 (en) declares under eneansvar, at klimaanlægmodelerne, som denne erklæring vedrører:
- 23 (en) déclare sur sa seule responsabilité, que les modèles de climatisation dont conditionne les par la présente déclaration:

\*\*\*DICz = Daikin Industries Czech Republic s.r.o.



Tetsuya Baba  
 Managing Director  
 Pízen, 2nd of May 2017

*[Handwritten Signature]*

**DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.**

U Nové Hospody 1/155, 301 00 Plzeň Skvrňany,  
 Czech Republic

# Table of Contents

<b>1</b>	<b>About the documentation</b>	<b>3</b>
1.1	About this document.....	3
<b>2</b>	<b>About the box</b>	<b>3</b>
2.1	Indoor unit .....	3
2.1.1	To remove the accessories from the indoor unit.....	3
<b>3</b>	<b>About the units and options</b>	<b>4</b>
3.1	System layout.....	4
<b>4</b>	<b>Preparation</b>	<b>4</b>
4.1	Preparing installation site .....	4
4.1.1	Installation site requirements of the indoor unit .....	4
<b>5</b>	<b>Installation</b>	<b>5</b>
5.1	Mounting the indoor unit.....	5
5.1.1	Precautions when mounting the indoor unit.....	5
5.1.2	Guidelines when installing the indoor unit.....	5
5.1.3	Guidelines when installing the ducting.....	6
5.1.4	Guidelines when installing the drain piping .....	6
5.2	Connecting the refrigerant piping .....	8
5.2.1	To connect the refrigerant piping to the indoor unit ....	8
5.3	Connecting the electrical wiring.....	8
5.3.1	Guidelines when connecting the electrical wiring .....	8
5.3.2	Specifications of standard wiring components.....	9
5.3.3	To connect the electrical wiring on the indoor unit.....	9
<b>6</b>	<b>Configuration</b>	<b>10</b>
6.1	Field settings .....	10
<b>7</b>	<b>Commissioning</b>	<b>11</b>
7.1	Checklist before commissioning .....	11
7.2	To perform a test run .....	11
7.3	Error codes when performing a test run .....	12
<b>8</b>	<b>Disposal</b>	<b>12</b>
<b>9</b>	<b>Technical data</b>	<b>12</b>
9.1	Wiring diagram .....	13

## 1 About the documentation

### 1.1 About this document

#### **i** INFORMATION

Make sure that the user has the printed documentation and ask him/her to keep it for future reference.

#### Target audience

Authorised installers

#### **i** INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry, and on farms, or for commercial and household use by lay persons.

#### Documentation set

This document is part of a documentation set. The complete set consists of:

- **General safety precautions:**
  - Safety instructions that you must read before installing
  - Format: Paper (in the box of the indoor unit)

- **Indoor unit installation manual:**
  - Installation instructions
  - Format: Paper (in the box of the indoor unit)
- **Installer reference guide:**
  - Preparation of the installation, good practices, reference data,...
  - Format: Digital files on <http://www.daikineurope.com/support-and-manuals/product-information/>

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

The original documentation is written in English. All other languages are translations.


#### Technical engineering data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

## 2 About the box

### 2.1 Indoor unit

#### 2.1.1 To remove the accessories from the indoor unit




- a Installation manual
- b Operation manual
- c General safety precautions
- d Washers for hanger bracket
- e Screws for duct flanges
- f Metal clamp
- g Sealing pads: Large (drain pipe), medium 1 (gas pipe), medium 2 (liquid pipe)
- h Drain hose
- i Long sealing
- j Insulation piece: Small (liquid pipe)
- k Insulation piece: Large (gas pipe)
- l Tie wraps



## 3 About the units and options

### 3 About the units and options

#### 3.1 System layout






- a Indoor unit
- b Outdoor unit
- c User interface
- d Suction air
- e Discharge air
- f Refrigerant piping + interconnection cable
- g Drain pipe
- h Earth wiring



- a Service space
- b Drain pipe
- c Power supply wiring port
- d Transmission wiring port
- e Maintenance drain outlet
- f Gas pipe
- g Liquid pipe

#### Installation options:



- A Standard rear suction
- B Installation with rear duct and duct service opening
- C Installation with rear duct, no duct service opening
- a Ceiling surface
- b Ceiling opening
- c Service access panel (optional accessory)
- d Air filter
- e Air inlet filter
- f Duct service opening
- g Interchangeable plate

## 4 Preparation

### 4.1 Preparing installation site

- Provide sufficient space around the unit for servicing and air circulation.
- Choose the installation location with sufficient place for carrying the unit in and out of the site.



#### WARNING

Do NOT install the air conditioner at any place where flammable gas may leak out. If the gas leaks out and stays around the air conditioner, a fire may break out.

#### 4.1.1 Installation site requirements of the indoor unit



#### INFORMATION

The sound pressure level is less than 70 dBA.

- Use **suspension bolts** for installation.
- **Spacing.** Mind the following requirements:

## 5 Installation

### 5.1 Mounting the indoor unit

#### 5.1.1 Precautions when mounting the indoor unit

##### **i** INFORMATION

Also read the precautions and requirements in the following chapters:


- General safety precautions
- Preparation

#### 5.1.2 Guidelines when installing the indoor unit


##### **i** INFORMATION

**Optional equipment.** When installing optional equipment, also read the installation manual of the optional equipment. Depending on the field conditions, it might be easier to install the optional equipment first.


- **In case of installation with duct, but no duct service opening.** Modify the position of the air filters.



- 1 Remove the air filter(s) from the outside of the unit.
  - 2 Remove the interchangeable plate.
  - 3 Install the air filter(s) on the inside of the unit.
  - 4 Reinstall the interchangeable plate.
- When installing an air inlet duct, select fixing screws that stick out 5 mm on the inside of the flange to protect the air filter from damage during maintenance of the filter.



- **Ceiling strength.** Check whether the ceiling is strong enough to support the weight of the unit. If there is a risk, reinforce the ceiling before installing the unit.
- **Installation options:**




Model	f (mm)
35~50	760
60~71	1060
100~140	1460

- A Mounting the air inlet with a canvas connection  
B Mounting the air inlet panel directly  
a Ceiling surface  
b Ceiling opening  
c Air inlet panel (optional accessory)  
d Indoor unit (back side)  
e Canvas connection for air inlet panel (optional accessory)



##### NOTICE


The unit can be used with bottom suction by replacing the interchangeable plate by the air filter holding plate.



- a Air filter holding plate with air filter(s)  
b Interchangeable plate

- **Suspension bolts.** Use M10 suspension bolts for installation. Attach the hanger bracket to the suspension bolt. Fix it securely using a nut and washer from the upper and lower sides of the hanger bracket.
- **Ceiling opening size.** Make sure the ceiling opening is within the following limits:

## 5 Installation




Model	A (mm)	B (mm)
35~50	700	738
60~71	1000	1038
100~140	1400	1438

- a1 Nut (field supply)
- a2 Double nut (field supply)
- b1 Washer (accessories)
- c1 Hanger bracket (attached to the unit)
- a Indoor unit
- b Pipe
- c Hanger bracket pitch (suspension)
- d Suspension bolt spacing

### INFORMATION


- The fan speed of the indoor unit is preset to ensure the standard external static pressure.
- To set a higher or lower external static pressure, reset the initial setting with user interface.

#### Installation example:



#### Install the unit temporarily.

- 5 Attach the hanger bracket to the suspension bolt.
  - 6 Fix it securely.
- **Level.** Make sure the unit is level at all four corners using a level or a water-filled vinyl tube.



- 7 Tighten the upper nut.


### NOTICE

Do NOT install the unit tilted. **Possible consequence:** If the unit is tilted against the direction of the condensate flow (the drain piping side is raised), the float switch might malfunction and cause water to drip.

### 5.1.3 Guidelines when installing the ducting

The ducting is to be field supplied.

- **Air inlet side.** Attach the duct and intake-side flange (field supply). For connecting the flange, use 7 accessory screws.



- a Connection screw (accessory)
- b Flange (field supply)
- c Main unit
- d Insulation (field supply)
- e Aluminium tape (field supply)

- **Filter.** Be sure to attach an air filter inside the air passage on the intake side. Use an air filter with dust collecting efficiency  $\geq 50\%$  (gravimetric method). The included filter is not used when the intake duct is attached.
- **Air outlet side.** Connect the duct according to the inside dimension of the outlet-side flange.
- **Air leaks.** Wind aluminium tape around the intake side flange and duct connection. Make sure there are no air leaks at any other connection.
- **Insulation.** Insulate the duct to prevent condensation from forming. Use glass wool or polyethylene foam 25 mm thick.


### 5.1.4 Guidelines when installing the drain piping

Make sure condensation water can be evacuated properly. This involves:

- General guidelines
- Connecting the drain piping to the indoor unit
- Checking for water leaks


#### General guidelines

- **Drain pump.** For this "high lift type", the drainage sounds will be reduced when the drain pump is installed in a higher location. Recommended height is 300 mm.
- **Pipe length.** Keep drain piping as short as possible.
- **Pipe size.** Keep the pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter).
- **Slope.** Make sure the drain piping slopes down (at least 1/100) to prevent air from being trapped in the piping. Use hanging bars as shown.




- **Condensation.** Take measures against condensation. Insulate the complete drain piping in the building.

- **Rising piping.** If necessary to make the slope possible, you can install rising piping.
  - Drain hose inclination: 0~75 mm to avoid stress on the piping and to avoid air bubbles.
  - Rising piping: ≤300 mm from the unit, ≤625 mm perpendicular to the unit.



- a Metal clamp (accessory)
- b Drain hose (accessory)
- c Rising drain piping (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter) (field supply)
- d Hanging bars (field supply)

- **Combining drain pipes.** You can combine drain pipes. Make sure to use drain pipes and T-joints with the correct gauge for the operating capacity of the units.




a T-joint

## To connect the drain piping to the indoor unit

### NOTICE

Incorrect connection of the drain hose might cause leaks, and damage the installation space and surroundings.

- 1 Push the drain hose as far as possible over the drain pipe connection.
- 2 Tighten the metal clamp until the screw head is less than 4 mm from the metal clamp part.
- 3 Check for water leaks (see To check for water leaks).
- 4 Install the insulation piece (drain pipe).
- 5 Wind the large sealing pad (= insulation) around the metal clamp and drain hose, and fix it with cable ties.
- 6 Connect the drain piping to the drain hose.




- a Drain pipe connection (attached to the unit)
- b Drain hose (accessory)
- c Metal clamp (accessory)
- d Large sealing pad (accessory)
- e Insulation piece (drain pipe) (accessory)
- f Drain piping (field supply)

### NOTICE

- Do NOT remove the drain pipe plug. Water might leak out.
- Use the drain outlet only to discharge the water if the drain pump is not used or before maintenance.
- Insert and remove the drain plug gently. Excessive force may deform the drain socket of the drain pan.


### Pull out the plug.

- Do NOT wiggle the plug up and down.



### Push in the plug.

- Set the plug and push it in using a Phillips screwdriver.



- a Drain plug
- b Phillips screwdriver


## To check for water leaks

The procedure differs depending on whether electrical wiring is already finished. When electrical wiring is not finished yet, you need to temporarily connect the user interface and power supply to the unit.

### When electrical wiring is not finished yet


- 1 Temporarily connect electrical wiring.
- 2 Remove the switch box cover (a).
- 3 Connect the single-phase power supply (50 Hz, 230 V) to connections No. 1 and No. 2 on the terminal block for power supply (d) and earth (c).
- 4 Reattach the switch box cover (a).

## 5 Installation



- a Switch box cover
- b Transmission wiring port
- c Power supply wiring port
- d Wiring diagram
- e Switch box
- f Plastic clamp
- g User interface wiring
- h Terminal board for unit transmission wiring
- i Power supply wiring
- j Power supply terminal board
- k Transmission wiring between units

- 5 Turn ON the power.
- 6 Start cooling operation (see To perform a test run).
- 7 Gradually put approximately 1 l of water through the air discharge outlet, and check for leaks.



- a Water inlet
- b Portable pump
- c Water inlet cover
- d Bucket (adding water through water inlet)
- e Drain outlet for maintenance
- f Refrigerant pipes

- 8 Turn OFF the power.
- 9 Disconnect the electrical wiring.
- 10 Remove the control box cover.
- 11 Disconnect the power supply and earth.
- 12 Reattach the control box cover.

### When electrical wiring is finished already

- 1 Start cooling operation (see To perform a test run).
- 2 Gradually pour approximately 1 l of water through the air discharge outlet, and check for leaks (see When electrical wiring is not finished yet).

## 5.2 Connecting the refrigerant piping



**DANGER: RISK OF BURNING**

### 5.2.1 To connect the refrigerant piping to the indoor unit




#### WARNING: FLAMMABLE MATERIAL

The R32 refrigerant (if applicable) in this unit is mildly flammable.<sup>(a)</sup>

(a) Refer to the outdoor unit specifications for the type of refrigerant to be used.

- **Pipe length.** Keep refrigerant piping as short as possible.
- **Flare connections.** Connect refrigerant piping to the unit using flare connections.
- **Insulation.** Insulate the refrigerant piping on the indoor unit as follows:



- A Gas piping
- B Liquid piping

- a Insulation material (field supply)
- b Cable tie (accessory)
- c Insulation pieces: Large (gas pipe), small (liquid pipe) (accessories)
- d Flare nut (attached to the unit)
- e Refrigerant pipe connection (attached to the unit)
- f Unit
- g Sealing pads: Medium 1 (gas pipe), medium 2 (liquid pipe) (accessories)

- 1 Turn up the seams of the insulation pieces.
- 2 Attach to the base of the unit.
- 3 Tighten the cable ties on the insulation pieces.
- 4 Wrap the sealing pad from the base of the unit to the top of the flare nut.



#### NOTICE

Make sure to insulate all refrigerant piping. Any exposed piping might cause condensation.

## 5.3 Connecting the electrical wiring



#### DANGER: RISK OF ELECTROCUTION



#### WARNING

ALWAYS use multicore cable for power supply cables.



#### WARNING

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

### 5.3.1 Guidelines when connecting the electrical wiring

#### Tightening torques

Wiring	Screw size	Tightening torque (N•m)
Interconnection cable (indoor↔outdoor)	M4	1.18~1.44
User interface cable	M3.5	0.79~0.97

- If single-core wires are used, be sure to curl the end of the lead. Improper work may cause heat or fire.
- The earth wire between the pull relief and the terminal must be longer than the other wires.

### 5.3.2 Specifications of standard wiring components

Component		FBA			
		35+50	60+71	100	125+140
Power supply cable	MCA <sup>(a)</sup>	1.4 A	1.3 A	3.5 A	3.9 A
	Voltage	220~240 V			
	Phase	1~			
	Frequency	50/60 Hz			
	Wire sizes	Must comply with applicable legislation			
Interconnection cable		Minimum cable section of 2.5 mm <sup>2</sup> and applicable for 220~240 V			
User interface cable		Vinyl cord with 0.75 to 1.25 mm <sup>2</sup> sheath or cables (2 core wires) Maximum 500 m			
Recommended field fuse		16 A			
Earth leakage circuit breaker		Must comply with applicable legislation			

(a) MCA=Minimum circuit ampacity. Stated values are maximum values (see electrical data of combination with indoor units for exact values).

### 5.3.3 To connect the electrical wiring on the indoor unit

#### NOTICE

- Follow the wiring diagram (delivered with the unit, located on the switch box cover).
- Make sure the electrical wiring does NOT obstruct proper reattachment of the service cover.

It is important to keep the power supply and the transmission wiring separated from each other. In order to avoid any electrical interference the distance between both wiring should always be at least 50 mm.

#### NOTICE

Be sure to keep the power line and transmission line apart from each other. Transmission wiring and power supply wiring may cross, but may not run parallel.

- 1 Remove the service cover.
- 2 **User interface cable:** Route the cable through the frame, connect the cable to the terminal block, and fix the cable with a cable tie.
- 3 **Interconnection cable** (indoor↔outdoor): Route the cable through the frame, connect the cable to the terminal block (make sure the numbers match with the numbers on the outdoor unit, and connect the earth wire), and fix the cable with a cable tie.
- 4 Divide the small sealing (accessory) and wrap it around the cables to prevent water from entering the unit. Seal all gaps to prevent small animals from entering the system.




#### WARNING


Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.

- 5 Reattach the service cover.


- When using 1 user interface with 1 indoor unit.



- When using 2 user interface<sup>1</sup>



- When using group control<sup>1</sup>



- a Power supply  
b Main switch  
c Fuse  
d User interface

<sup>(1)</sup> Dashed line represents separate power supply.

## 6 Configuration

- **Master unit:** Be sure to connect the wiring when combining with a simultaneously operating multi-type in group control.
- Use separate power only in case of following combination:

1×FBA35A + RXS35L or RXM35M
2×FBA60A + RR100/125B or RQ100/125B
2×FBA71A + RR100/125B or RQ100/125B
4×FBA50A + RZQ200C
3×FBA60A + RZQ200C
3×FBA71A + RZQ200C
2×FBA100A + RZQ200C
4×FBA60A + RZQ200C
2×FBA125A + RZQ200C

- **EN/IEC 61000-3-12** provided that the short-circuit power  $S_{sc}$  is greater than or equal to the minimum  $S_{sc}$  value at the interface point between the user's supply and the public system.
  - EN/IEC 61000-3-12 = European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current >16 A and ≤75 A per phase.
  - It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power  $S_{sc}$  greater than or equal to the minimum  $S_{sc}$  value.
- Ensure that equipment is connected only to a supply with a short-circuit power  $S_{sc}$  greater than or equal to  $S_{sc}$  in table below.

Combination	FBA35A	FBA50A	FBA60A	FBA71A
RZAG71M	2 (—)	—	—	1 (—)
RZQG71L				
RZAG100M	3 (2.31)	2 (1.30)	—	—
RZQG100L				
RZAG125M	4 (3.33)	3 (2.32)	2 (2.05)	—
RZQG125L				
RZAG140M	4 (3.33)	3 (2.32)	—	2 (2.05)
RZQG140L				
RZASG71M	2 (1.10)	—	—	1 (1.22)
RZQSG71L				
RZASG100M	2 (1.65)	2 (—)	—	—
RZQSG100L				
RZASG125M	4 (3.33)	3 (2.32)	2 (2.05)	—
RZQSG125L				
RZASG140M	4 (3.33)	3 (2.32)	—	2 (2.05)
RZQSG140L				

Combination	FBA100A	FBA125A	FBA140A
RZAG71M	—	—	—
RZQG71L			
RZAG100M	1 (0.73)	—	—
RZQG100L			

RZAG125M	—	1 (0.74)	—
RZQG125L			
RZAG140M	—	—	1 (0.74)
RZQG140L			
RZASG71M	—	—	—
RZQSG71L			
RZASG100M	1 (—)	—	—
RZQSG100L			
RZASG125M	—	1 (0.74)	—
RZQSG125L			
RZASG140M	—	—	1 (0.74)
RZQSG140L			



### INFORMATION

In case of group control it is not necessary to address the indoor unit. The address is automatically set when the power is activated.

## 6 Configuration

### 6.1 Field settings

Make the following field settings so that they correspond with the actual installation setup and with the needs of the user:

- External static pressure setting using:
  - Airflow automatic adjustment setting
  - User interface
- Time to clean air filter

#### To set airflow automatic adjustment

- When the air conditioning unit is running in fan operation mode:

- 1 Stop the air conditioning unit.
- 2 Set second code number to 03.

Setting content:	Then <sup>2</sup>		
	M	C1	C2
Airflow adjustment is OFF	11(21)	7	01
Press ON/OFF to return to normal operating mode.			03
<b>Possible consequence:</b> The operation lamp will light up and the unit will start the fan operation for airflow automatic adjustment.			
Operation stops after 1 to 8 minutes.			02
<b>Possible consequence:</b> Setting is finished and the operation lamp will be off.			

If there is no change after airflow adjustment, perform the setting again.

#### User interface

Check the indoor unit setting: the second code number of mode 11(21) must be set to 01.

<sup>(2)</sup> Field settings are defined as follows:

- **M:** Mode number – **First number:** for group of units – **Number between brackets:** for individual unit
- **C1:** First code number
- **C2:** Second code number
- **■:** Default

Change the second code number according to the external static pressure of the duct to be connected as in table below.

M	C1	C2	External static pressure			
			FBA			
			35	50	60	71
13(23)	6	01	30	30	30	30
		02	—	—	—	—
		03	30	30	30	30
		04	40	40	40	40
		05	50	50	50	50
		06	60	60	60	60
		07	70	70	70	70
		08	80	80	80	80
		09	90	90	90	90
		10	100	100	100	100
		11	110	110	110	110
		12	120	120	120	120
		13	130	130	130	130
		14	140	140	140	140
		15	150	150	150	150

M	C1	C2	External static pressure		
			FBA		
			100	125	140
13(23)	6	01	40	50	50
		02	—	—	—
		03	—	—	—
		04	40	—	—
		05	50	50	50
		06	60	60	60
		07	70	70	70
		08	80	80	80
		09	90	90	90
		10	100	100	100
		11	110	110	110
		12	120	120	120
		13	130	130	130
		14	140	140	140
		15	150	150	150

#### Time to clean air filter

This setting must correspond with the air contamination in the room. It determines the interval at which the **TIME TO CLEAN AIR FILTER** notification is displayed on the user interface. When using a wireless user interface, you must also set the address (see the installation manual of the user interface).

If you want an interval of... (air contamination)	Then <sup>2</sup>		
	M	C1	C2
±2500 h (light)	10(20)	0	01
±1250 h (heavy)			02
No notification		3	02

<sup>(2)</sup> Field settings are defined as follows:

- **M**: Mode number – **First number**: for group of units – **Number between brackets**: for individual unit
- **C1**: First code number
- **C2**: Second code number
- **■**: Default

- **2 user interfaces**: When using 2 user interfaces one must be set to "MAIN" and the other to "SUB".

## 7 Commissioning



### NOTICE

NEVER operate the unit without thermistors and/or pressure sensors/switches. Burning of the compressor might result.

### 7.1 Checklist before commissioning

Do NOT operate the system before the following checks are OK:

<input type="checkbox"/>	You read the complete installation instructions, as described in the <b>installer reference guide</b> .
<input type="checkbox"/>	The <b>indoor units</b> are properly mounted.
<input type="checkbox"/>	In case a wireless user interface is used: The <b>indoor unit decoration panel</b> with infrared receiver is installed.
<input type="checkbox"/>	The <b>outdoor unit</b> is properly mounted.
<input type="checkbox"/>	There are <b>NO missing phases</b> or <b>reversed phases</b> .
<input type="checkbox"/>	The system is properly <b>earthed</b> and the earth terminals are tightened.
<input type="checkbox"/>	The <b>fuses</b> or locally installed protection devices are installed according to this document, and have not been bypassed.
<input type="checkbox"/>	The <b>power supply voltage</b> matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are <b>NO loose connections</b> or damaged electrical components in the switch box.
<input type="checkbox"/>	The <b>insulation resistance</b> of the compressor is OK.
<input type="checkbox"/>	There are <b>NO damaged components</b> or <b>squeezed pipes</b> on the inside of the indoor and outdoor units.
<input type="checkbox"/>	There are <b>NO refrigerant leaks</b> .
<input type="checkbox"/>	The correct pipe size is installed and the <b>pipes</b> are properly insulated.
<input type="checkbox"/>	The <b>stop valves</b> (gas and liquid) on the outdoor unit are fully open.

### 7.2 To perform a test run

This task is only applicable when using the BRC1E52 or BRC1E53 user interface. When using any other user interface, see the installation manual or service manual of the user interface.



### NOTICE

Do not interrupt the test run.




### INFORMATION





**Backlight.** To perform an ON/OFF action on the user interface, the backlight does not need to be lit. For any other action, it needs to be lit first. The backlight is lit for ±30 seconds when you press a button.

## 8 Disposal

### 1 Perform introductory steps.


#	Action
1	Open the liquid stop valve (A) and gas stop valve (B) by removing the stem cap and turning counterclockwise with a hex wrench until it stops. 
2	Close the service cover to prevent electric shocks.
3	Turn ON power for at least 6 hours before starting operation to protect the compressor.
4	On the user interface, set the unit to cooling operation mode.

### 2 Start the test run

#	Action	Result
1	Go to the home menu. 	
2	Press at least 4 seconds. 	The Service Settings menu is displayed.
3	Select Test Operation. 	
4	Press. 	Test Operation is displayed on the home menu. 
5	Press within 10 seconds. 	Test run starts.

### 3 Check operation for 3 minutes.

### 4 Stop the test run.

#	Action	Result
1	Press at least 4 seconds. 	The Service Settings menu is displayed.
2	Select Test Operation. 	
3	Press. 	The unit returns to normal operation, and the home menu is displayed.

## 7.3 Error codes when performing a test run

If the installation of the outdoor unit has NOT been done correctly, the following error codes may be displayed on the user interface:

Error code	Possible cause
Nothing displayed (the currently set temperature is not displayed)	<ul style="list-style-type: none"> <li>The wiring is disconnected or there is a wiring error (between power supply and outdoor unit, between outdoor unit and indoor units, between indoor unit and user interface).</li> <li>The fuse on the outdoor or indoor unit PCB has blown.</li> </ul>
E3, E4 or L8	<ul style="list-style-type: none"> <li>The stop valves are closed.</li> <li>The air inlet or air outlet is blocked.</li> </ul>
E7	There is a missing phase in case of three-phase power supply units. <b>Note:</b> Operation will be impossible. Turn OFF the power, recheck the wiring, and switch two of the three electrical wires.
L4	The air inlet or air outlet is blocked.
U0	The stop valves are closed.
U2	<ul style="list-style-type: none"> <li>There is a voltage imbalance.</li> <li>There is a missing phase in case of three-phase power supply units. <b>Note:</b> Operation will be impossible. Turn OFF the power, recheck the wiring, and switch two of the three electrical wires.</li> </ul>
U4 or UF	The inter-unit branch wiring is not correct.
UA	The outdoor and indoor unit are incompatible.

## 8 Disposal




### NOTICE



Do not try to dismantle the system yourself: the dismantling of the system, treatment of the refrigerant, oil and other parts must comply with applicable legislation. Units must be treated at a specialised treatment facility for reuse, recycling and recovery.



## 9 Technical data

- A **subset** of the latest technical data is available on the regional Daikin website (publicly accessible).
- The **full set** of latest technical data is available on the Daikin extranet (authentication required).

## 9.1 Wiring diagram

Unified Wiring Diagram Legend					
For applied parts and numbering refer to the wiring diagram sticker supplied on the unit. Part numbering is realized by Arabic numbers in ascending order for each part and is represented in the overview below by symbol <sup>***</sup> in the part code.					
	:	CIRCUIT BREAKER		:	PROTECTIVE EARTH
	:	CONNECTION		:	PROTECTIVE EARTH (SCREW)
	:	CONNECTOR		:	RECTIFIER
	:	EARTH		:	RELAY CONNECTOR
	:	FIELD WIRING		:	SHORT CIRCUIT CONNECTOR
	:	FUSE		:	TERMINAL
	:	INDOOR UNIT		:	TERMINAL STRIP
	:	OUTDOOR UNIT		:	WIRE CLAMP
BLK : BLACK	GRN : GREEN	PNK : PINK	WHT : WHITE		
BLU : BLUE	GRY : GREY	PRP,PPL : PURPLE	YLW : YELLOW		
BRN : BROWN	ORG : ORANGE	RED : RED			
A*P	:	PRINTED CIRCUIT BOARD	PS	:	SWITCHING POWER SUPPLY
BS*	:	PUSH BUTTON ON / OFF, OPERATION SWITCH	PTC*	:	THERMISTOR PTC
BZ, H*O	:	BUZZER	Q*	:	INSULATED GATE BIPOLAR TRANSISTOR (IGBT)
C*	:	CAPACITOR	Q*DI	:	EARTH LEAK CIRCUIT BREAKER
AC*, ON*, E*, HA*, HE, HL*, HN*, HR*, MR*_A, MR*_B, S*, U, V, W, X*A	:	CONNECTION, CONNECTOR	Q*L	:	OVERLOAD PROTECTOR
D*, V*D	:	DIODE	Q*M	:	THERMO SWITCH
DB*	:	DIODE BRIDGE	R*	:	RESISTOR
DS*	:	DIP SWITCH	R*T	:	THERMISTOR
E*H	:	HEATER	RC	:	RECEIVER
F*U, FU* (FOR CHARACTERISTICS REFER TO PCB INSIDE YOUR UNIT)	:	FUSE	S*C	:	LIMIT SWITCH
FG*	:	CONNECTOR (FRAME GROUND)	S*L	:	FLOAT SWITCH
H*	:	HARNESS	S*NPH	:	PRESSURE SENSOR (HIGH)
H*P, LED*, V*L	:	PILOT LAMP, LIGHT EMITTING DIODE	S*NPL	:	PRESSURE SENSOR (LOW)
HAP	:	LIGHT EMITTING DIODE (SERVICE MONITOR GREEN)	S*PH, HPS*	:	PRESSURE SWITCH (HIGH)
HIGH VOLTAGE	:	HIGH VOLTAGE	S*PL	:	PRESSURE SWITCH (LOW)
IES	:	INTELLIGENT EYE SENSOR	S*T	:	THERMOSTAT
IPM*	:	INTELLIGENT POWER MODULE	S*W, SW*	:	OPERATION SWITCH
K*R, KCR, KFR, KHuR	:	MAGNETIC RELAY	SA*	:	SURGE ARRESTOR
L	:	LIVE	SR*, WLU	:	SIGNAL RECEIVER
L*	:	COIL	SS*	:	SELECTOR SWITCH
L*R	:	REACTOR	SHEET METAL	:	TERMINAL STRIP FIXED PLATE
M*	:	STEPPER MOTOR	T*R	:	TRANSFORMER
M*C	:	COMPRESSOR MOTOR	TC, TRC	:	TRANSMITTER
M*F	:	FAN MOTOR	V*, R*V	:	VARISTOR
M*P	:	DRAIN PUMP MOTOR	V*R	:	DIODE BRIDGE
M*S	:	SWING MOTOR	WRC	:	WIRELESS REMOTE CONTROLLER
MR*, MRCW*, MRM*, MRN*	:	MAGNETIC RELAY	X*	:	TERMINAL
N	:	NEUTRAL	X*M	:	TERMINAL STRIP (BLOCK)
n = *	:	NUMBER OF PASSES THROUGH FERRITE CORE	Y*E	:	ELECTRONIC EXPANSION VALVE COIL
PAM	:	PULSE-AMPLITUDE MODULATION	Y*R, Y*S	:	REVERSING SOLENOID VALVE COIL
PCB*	:	PRINTED CIRCUIT BOARD	Z*C	:	FERRITE CORE
PM*	:	POWER MODULE	ZF, Z*F	:	NOISE FILTER





ERC



**DAIKIN INDUSTRIES CZECH REPUBLIC s.r.o.**

U Nové Hospody 1/1155, 301 00 Plzeň Skvrňany, Czech Republic

**DAIKIN EUROPE N.V.**

Zandvoordestraat 300, B-8400 Oostende, Belgium

Copyright 2017 Daikin

4P456962-1C 2017.04