

Service Manual

SA R32 Sky-Air RZAG-L

Indoor unit

FCAHG71/100/125/140FVEB

Outdoor unit

RZAG71/100/125/140L7V1B



The present publication is drawn up by way of information only and does not constitute an offer binding upon Daikin Europe N.V.. Daikin Europe N.V. has compiled the content of this publication to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein. Specifications are subject to change without prior notice. Daikin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this publication. All content is copyrighted by Daikin Europe N.V..

| | |
|--|---------------|
| Part 1. Introduction | 7 |
| 1.1. Version log | 7 |
| 1.2. Safety precautions | 8 |
| 1.2.1. Meaning of symbols | 8 |
| 1.2.2. Warnings | 8 |
| 1.2.3. Cautions | 10 |
| 1.2.4. Information | 10 |
| 1.3. General operation | 11 |
| 1.4. How to use | 12 |
| 1.4.1. Interactive information flow | 12 |
| 1.4.2. Parts of the book | 13 |
| 1.4.2.1. The introduction chapter | 13 |
| 1.4.2.2. The troubleshooting chapter | 13 |
| 1.4.2.3. The repair chapter | 13 |
| 1.4.2.4. The maintenance chapter | 13 |
| 1.4.2.5. Appendices | 13 |
| 1.4.3. Contact information | 13 |
| Part 2. Troubleshooting | 15 |
| 2.1. Error codes check | 15 |
| 2.1.1. Error codes via remote controller | 15 |
| 2.1.1.1. Error codes via wired remote controller BRC1E | 15 |
| 2.1.1.2. Error codes via wireless remote controller BRC7 | 17 |
| 2.1.2. Error codes via outdoor unit PCB | 19 |
| 2.1.2.1. How to retrieve error codes | 19 |
| 2.1.2.2. How to reset error codes | 21 |
| 2.1.2.3. History of error codes and warnings | 22 |
| 2.1.2.4. Content of retry | 22 |
| 2.2. Error based troubleshooting | 23 |
| 2.2.1. Indoor unit | 24 |
| 2.2.1.1. "A1-01" – Indoor unit PCB abnormality | 24 |
| 2.2.1.2. "A3-00" – Drain water level system abnormality | 24 |
| 2.2.1.3. "A6-00" – Indoor unit fan motor abnormality | 24 |
| 2.2.1.4. "AJ-00" – Capacity setting abnormality | 25 |
| 2.2.1.5. "C1-00" – Transmission error (indoor & adapter PCB) | 25 |
| 2.2.1.6. "C4-00" – Heat exchanger thermistor abnormality | 26 |
| 2.2.1.7. "C5-00" – Intermediate heat exchanger thermistor abnormality | 26 |
| 2.2.1.8. "C9-00" – Suction air thermistor abnormality | 27 |
| 2.2.1.9. "CC-00" – Humidity sensor system abnormality | 27 |
| 2.2.1.10. "CJ-00" – Remote controller thermistor abnormality | 27 |
| 2.2.2. Outdoor unit | 28 |
| 2.2.2.1. "E1-00" – Outdoor unit PCB abnormality | 28 |
| 2.2.2.2. "E3-00" – Discharge pressure abnormality | 28 |
| 2.2.2.3. "E4-00" – Suction pressure abnormality | 29 |
| 2.2.2.4. "E5-00" – Compressor motor lock or overheated | 29 |
| 2.2.2.5. "E7-00" – Fan motor abnormality | 30 |
| 2.2.2.6. "E9-00" – Electronic expansion valve abnormality | 31 |
| 2.2.2.7. "F3-00" – Discharge pipe temperature abnormality | 31 |
| 2.2.2.8. "H3-00" – High pressure switch abnormality | 32 |
| 2.2.2.9. "H4-00" – Low pressure switch abnormality | 33 |
| 2.2.2.10. "H9-00" – Outdoor air temperature thermistor abnormality | 33 |
| 2.2.2.11. "J3-00" – Discharge pipe thermistor abnormality | 33 |
| 2.2.2.12. "J5-00" – Suction pipe thermistor abnormality | 34 |
| 2.2.2.13. "J6-00" – Outdoor heat exchanger thermistor abnormality | 34 |
| 2.2.2.14. "J7-00" – Intermediate heat exchanger thermistor abnormality | 34 |
| 2.2.2.15. "J8-00" – Liquid pipe thermistor abnormality | 35 |
| 2.2.2.16. "L1-00" – Outdoor main PCB abnormality | 35 |
| 2.2.2.17. "L5-00" – Output overcurrent detection | 36 |

| | |
|--|----|
| 2.2.2.18. "L8-00" – Electronic thermal overload | 37 |
| 2.2.2.19. "L9-00" – Stall prevention time lag | 37 |
| 2.2.2.20. "LC-00" – Transmission system abnormality | 38 |
| 2.2.2.21. "P1-00" – Open phase or power supply voltage imbalance | 38 |
| 2.2.2.22. "P4-00" – Radiating fin temperature sensor abnormality | 38 |
| 2.2.2.23. "PJ-00" – Capacity setting abnormality | 39 |
| 2.2.3. System | 40 |
| 2.2.3.1. "U0-00" – Refrigerant shortage | 40 |
| 2.2.3.2. "U1-00" – Reverse phase or open phase | 40 |
| 2.2.3.3. "U2-00" – Power supply abnormality or instantaneous power failure | 41 |
| 2.2.3.4. "U4-00" – Transmission abnormality between indoor unit and outdoor unit | 42 |
| 2.2.3.5. "UA-00" – Improper combination of indoor unit and outdoor unit | 42 |
| 2.2.3.6. "UF-00" – Wiring and piping mismatch | 43 |
| 2.2.4. Others | 43 |
| 2.3. Symptom based troubleshooting | 44 |
| 2.3.1. Indoor unit | 44 |
| 2.3.2. Outdoor unit | 44 |
| 2.3.3. System | 44 |
| 2.3.4. Others | 44 |
| 2.4. Component checklist | 45 |
| 2.4.1. Indoor unit | 46 |
| 2.4.1.1. Fan motor | 46 |
| 2.4.2. Outdoor unit | 47 |
| 2.4.2.1. 4-way valve | 47 |
| 2.4.2.2. Compressor | 49 |
| 2.4.2.3. Electronic expansion valve | 50 |
| 2.4.2.4. Fan motor | 52 |
| 2.4.2.5. High pressure switch | 53 |
| 2.4.2.6. Low pressure switch | 54 |
| 2.4.2.7. Main PCB | 55 |
| 2.4.2.8. Refrigerant thermistors | 57 |
| 2.4.3. System | 59 |
| 2.4.4. Others | 59 |
| 2.5. Other capacity range | 59 |

Part 3. Repair61

| | |
|--|----|
| 3.1. Refrigerant repair procedures | 61 |
| 3.1.1. Refrigerant piping handling | 61 |
| 3.1.2. Recovery procedure | 61 |
| 3.1.2.1. Outdoor unit casing | 61 |
| 3.1.3. Refrigerant pump down | 63 |
| 3.1.3.1. Small outdoor unit | 63 |
| 3.1.3.2. Large outdoor unit | 64 |
| 3.1.4. Piping repair procedures | 64 |
| 3.2. Service tools | 65 |
| 3.3. Unit specific repair procedures | 66 |
| 3.3.1. Indoor unit | 66 |
| 3.3.2. Outdoor unit | 67 |
| 3.3.2.1. Basic removal | 67 |
| 3.3.2.2. Replacing thermistor | 71 |
| 3.3.2.3. Replacing 4-way valve body | 73 |
| 3.3.2.4. Replacing 4-way valve coil | 75 |
| 3.3.2.5. Replacing accumulator assembly | 75 |
| 3.3.2.6. Replacing compressor | 76 |
| 3.3.2.7. Replacing DC fan motor assembly | 79 |
| 3.3.2.8. Replacing electrical noise filter | 80 |
| 3.3.2.9. Replacing expansion valve body | 81 |
| 3.3.2.10. Replacing expansion valve motor | 82 |
| 3.3.2.11. Replacing solenoid valve | 84 |
| 3.3.2.12. Replacing solenoid valve coil | 85 |

| | |
|--|----|
| 3.3.2.13. Replacing high pressure switches | 86 |
| 3.3.2.14. Replacing inverter PCB | 87 |
| 3.3.2.15. Replacing low pressure switch | 88 |
| 3.3.2.16. Replacing main PCB | 89 |
| 3.3.2.17. Replacing propeller fan blade assembly | 93 |

Part 4. Maintenance 95

| | |
|---|----|
| 4.1. Indoor unit | 95 |
| 4.1.1. General maintenance indoor unit | 95 |
| 4.2. Outdoor unit | 96 |
| 4.2.1. General maintenance outdoor unit | 96 |

Part 5. Appendix 97

| | |
|---|-----|
| 5.1. Field setting | 99 |
| 5.1.1. Indoor unit | 99 |
| 5.1.1.1. Retrieve field settings BRC1E | 99 |
| 5.1.1.2. Retrieve field settings BRC7 | 101 |
| 5.1.1.3. Sky-Air R32 indoor field settings | 102 |
| 5.1.2. Outdoor unit | 103 |
| 5.1.2.1. Retrieve field settings OU mode 2 | 103 |
| 5.1.2.2. Sky-Air R32 outdoor field settings through outdoor | 105 |
| 5.1.3. Remote controller | 106 |
| 5.2. Detailed information setting mode | 107 |
| 5.2.1. Indoor unit | 107 |
| 5.2.2. Outdoor unit | 107 |
| 5.2.3. Remote controller | 108 |
| 5.2.3.1. Quiet (Low Noise) Operation | 108 |
| 5.2.3.2. I-Demand Function | 109 |
| 5.2.3.3. Setting for Low Humidity Application | 109 |
| 5.2.3.4. Defrost Operation | 112 |
| 5.3. Wiring diagram | 114 |
| 5.3.1. Indoor unit | 114 |
| 5.3.2. Outdoor unit | 115 |
| 5.3.3. Field wiring | 116 |
| 5.4. Piping diagram | 117 |
| 5.4.1. Indoor unit | 117 |
| 5.4.2. Outdoor unit | 117 |
| 5.5. Component overview of unit | 118 |
| 5.5.1. Indoor unit | 118 |
| 5.5.2. Outdoor unit | 119 |
| 5.6. Product specific information | 121 |
| 5.6.1. Error codes | 121 |
| 5.6.1.1. "E9-00" - Electronic expansion valve abnormality | 121 |
| 5.6.1.2. "F3-00" - Discharge pipe temperature abnormality | 121 |
| 5.6.2. Component checklist | 121 |
| 5.6.2.1. How to activate inverter test | 121 |
| 5.6.2.2. Component checklist | 121 |
| 5.7. Switch box | 122 |
| 5.7.1. Indoor unit | 122 |
| 5.7.2. Outdoor unit | 122 |
| 5.8. Field information report | 122 |

| | |
|--|-----|
| Figure 3-1: 1 service port at the stop valves | 62 |
| Figure 3-2: 3 service ports at the stop valves | 63 |
| Figure 3-3: Removing the top plate assembly | 67 |
| Figure 3-4: Removing the front plate | 68 |
| Figure 3-5: Removing the front plate assembly | 68 |
| Figure 3-6: Removing the cover | 69 |
| Figure 3-7: Removing the piping cover | 69 |
| Figure 3-8: Removing the right side plate | 70 |
| Figure 3-9: Thermistor location | 71 |
| Figure 3-10: Replacing a thermistor | 72 |
| Figure 3-11: Removing 4-way valve body | 73 |
| Figure 3-12: Removing 4-way valve body | 75 |
| Figure 3-13: Removing stop valve mounting plate | 76 |
| Figure 3-14: Removing compressor | 77 |
| Figure 3-15: Removing the DC fan motor assembly | 79 |
| Figure 3-16: Removing the electrical noise filter | 80 |
| Figure 3-17: Removing expansion valve | 81 |
| Figure 3-18: Removing expansion valve motor | 82 |
| Figure 3-19: Removing expansion valve motor | 83 |
| Figure 3-20: Removing solenoid valve | 84 |
| Figure 3-21: Removing solenoid valve coil | 85 |
| Figure 3-22: Removing high pressure switches | 86 |
| Figure 3-23: Removing low pressure switch | 88 |
| Figure 3-24: Removing the main PCB assembly | 90 |
| Figure 3-25: Stripping the main PCB assembly (front) | 91 |
| Figure 3-26: Stripping the main PCB assembly (rear) | 92 |
| Figure 3-27: Removing the propeller fan blade assembly | 93 |
| Figure 5-1: Wiring diagram - indoor unit | 114 |
| Figure 5-2: Wiring diagram - outdoor unit 71 | 115 |
| Figure 5-3: Wiring diagram - outdoor unit 100-140 | 116 |
| Figure 5-4: Piping diagram - indoor unit | 117 |
| Figure 5-5: Piping diagram - outdoor unit | 117 |
| Figure 5-6: Components overview - indoor unit | 118 |
| Figure 5-7: Components overview - outdoor unit 71 | 119 |
| Figure 5-8: Components overview - outdoor unit 100-140 | 120 |

Part 1. Introduction

This part contains the following chapters:

| | |
|-------------------------|----|
| Version log | 7 |
| Safety precautions..... | 8 |
| General operation..... | 11 |
| How to use | 12 |

1.1. Version log

| Version code | Description | Date |
|--------------|---|------------|
| ESIE16-03A | Document release | 19/07/2016 |
| ESIE16-03B | Update chapter 2.1.2.: correction of setting items in monitor mode for malfunction/content of retry Update chapter 3.3.2.2.: addition of 3D view of RZAG71 Update chapter 5.6.2.: component checklist added | 22/08/2016 |

1.2. Safety precautions

The precautions described in this document cover very important topics, follow them carefully.

All activities described in the service manual must be performed by an authorized person.

If you are not sure how to install, operate or service the unit, contact your dealer.









In accordance with the applicable legislation, it might be necessary to provide a logbook with the product containing at least: information on maintenance, repair work, results of tests, stand-by periods, ...

Also, at least, following information must be provided at an accessible place at the product:


- Instructions for shutting down the system in case of an emergency
- Name and address of fire department, police and hospital
- Name, address and day and night telephone numbers for obtaining service













In Europe, EN378 provides the necessary guidance for this logbook.

1.2.1. Meaning of symbols

| | |
|---|--|
|  | WARNING Indicates a situation that could result in death or serious injury. |
|  | WARNING: RISK OF ELECTROCUTION Indicates a situation that could result in electrocution. |
|  | WARNING: RISK OF BURNING Indicates a situation that could result in burning because of extreme hot or cold temperatures. |
|  | WARNING: RISK OF EXPLOSION Indicates a situation that could result in explosion. |
|  | WARNING: RISK OF POISONING Indicates a situation that could result in poisoning. |
|  | WARNING: RISK OF FIRE Indicates a situation that could result in fire. |
|  | CAUTION Indicates a situation that could result in equipment or property damage. |
|  | INFORMATION Indicates useful tips or additional information. |

1.2.2. Warnings

| | |
|---|---|
|  | WARNING Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Only use accessories, optional equipment and spare parts made or approved by Daikin. |
|---|---|

| | |
|---|---|
|  | <p>WARNING</p> <p>Make sure installation, testing and applied materials comply with applicable legislation (on top of the instructions described in the Daikin documentation).</p> |
|  | <p>WARNING</p> <p>Make sure the work site environment is clean and safe to work in. Beware of spilled fluids, like water, oil or other substances. Protect bystanders from injury and property from possible damage cause by service works.</p> |
|  | <p>WARNING</p> <p>Wear adequate personal protective equipment (protective gloves, safety glasses,...) when installing, maintaining or servicing the system.</p> |
|  | <p>WARNING</p> <p>Tear apart and throw away plastic packaging bags so that nobody, especially children, can play with them. Possible risk: suffocation.</p> |
|  | <p>WARNING</p> <p>Do NOT touch the air inlet or aluminium fins of the unit.</p> |
|  | <p>WARNING</p> <ul style="list-style-type: none"> Do NOT place any objects or equipment on top of the unit. Do NOT sit, climb or stand on the unit. |
|  | <p>WARNING</p> <p>During tests, NEVER pressurize the product with a pressure higher than the maximum allowable pressure (as indicated on the nameplate of the unit).</p> |
|  | <p>WARNING</p> <ul style="list-style-type: none"> Never mix different refrigerants or allow air to enter the refrigerant system. Never charge recovered refrigerant from another unit. Use recovered refrigerant only on the same unit where it was recovered from, or have it recycled at a certified facility. |
|  | <p>WARNING: RISK OF FIRE</p> <ul style="list-style-type: none"> When reconnecting a connector to the PCB, do not apply force or damage the connector or the connector pins on the PCB. |
|  | <p>WARNING: RISK OF BURNING</p> <ul style="list-style-type: none"> Do NOT touch the refrigerant piping, water piping or internal parts during and immediately after operation. It could be too hot or too cold. Give it time to return to normal temperature. If you must touch it, wear protective gloves. Do NOT touch any accidental leaking refrigerant. |
|  | <p>WARNING</p> <p>Always recover the refrigerants. Do NOT release them directly into the environment. Use a recovery pump to evacuate the installation.</p> <p>Take sufficient precautions in case of refrigerant leakage. If refrigerant gas leaks, ventilate the area immediately.</p> <p>Possible risks:</p> <ul style="list-style-type: none"> Excessive refrigerant concentrations in a closed room can lead to oxygen deficiency. Toxic gas may be produced if refrigerant gas comes into contact with fire. <p>Where applicable, pump down the system and close the service valve, before leaving the site if leak was not repaired, to avoid further leaking of the refrigerant.</p> |
|  | <p>WARNING: RISK OF ELECTROCUTION</p> <ul style="list-style-type: none"> Turn OFF all power supply before removing the switch box cover, connecting electrical wiring or touching electrical parts. Where applicable, stop the equipment's operation first and allow (refrigerant) pressure to equalize, before turning OFF the power. Disconnect the power supply for more than 1 minute, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage must be less than 50 V DC before you can touch electrical components. For the location of the terminals, refer to "Wiring diagram" on page 114. Do NOT touch electrical components with wet hands. Do NOT leave the unit unattended when the service cover is removed. Protect electric components from getting wet while the service cover is opened. |

**WARNING**

- Only use copper wires.
- All field wiring must be performed in accordance with the wiring diagram and installation manual supplied with the product.
- If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires may cause an electrical shock, excessive heat generation or fire.
- Secure all terminal connections and provide proper routing for cables, both inside and outside the switchbox.
- NEVER squeeze bundled cables and make sure they do not come in contact with the piping and sharp edges.
- Make sure no external pressure is applied to the terminal connections.
- Make sure to check the earth wiring. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Improper earth wiring may cause electrical shock.
- Make sure to use a dedicated power circuit. NEVER use a power supply shared by another appliance.
- Make sure to check the required fuses and/or circuit breakers before starting works.

**WARNING**

- After finishing the electrical work, confirm that each electrical component and terminal inside the electrical components box is connected securely.
- Make sure all covers are closed before starting the unit again.

1.2.3. Cautions**CAUTION**

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.

**CAUTION**

- Make sure water quality complies with EU directive 98/83 EC.
- Check the system for leaks after each repair/modification of the water side.
- Check drainage system(s) after repairs.
- Be careful when tilting units as water may leak.

1.2.4. Information**INFORMATION**


Make sure refrigerant piping installation complies with applicable legislation. In Europe, EN378 is the applicable standard.

**INFORMATION**

Make sure the field piping and connections are not subjected to stress.

1.3. General operation

- The Sky-Air is typically used for cooling or heating in commercial applications. Some units also have settings to perform technical cooling. The medium which is used to transfer the heat from inside to outside or vice versa, is refrigerant. In case of the RZAG-L, the refrigerant which is used, is R32.
- In case of heating, the compressor builds up pressure and hence the temperature of the refrigerant is increased. The hot refrigerant is blown into the room by a fan which blows over a heat exchanger. Colder refrigerant flows back to the outdoor unit, where temperature is further decreased by expansion through an expansion valve. After the expansion valve, the refrigerant is capable of taking up heat again. This is enabled by a fan that sucks outdoor air over a heat exchanger. This refrigerant is then transported to the compressor where temperature is further built up again and the cycle starts again. For cooling, it's just the other way round.




1.4. How to use

1.4.1. Interactive information flow

This Daikin product Service Manual is intended for professional use only. The actions described hereafter, are only to be performed by qualified and certified persons, taking into account the safety precautions mentioned in this manual and the local regulations as well.

By following the diagram below, the reader can find the relevant information related to his/her task. The digital (pdf) version of this book allows direct page access through all active links. When Adobe Acrobat Reader is used, the <Alt> + <Back Arrow> keys or the arrow in the top right-hand corner of this page can be used to return to the previously viewed page.



1.4.2. Parts of the book

This Daikin product Service Manual is intended for professional use only. The actions described hereafter, are only to be performed by qualified and certified persons, taking into account the safety precautions mentioned in this manual and the local regulations as well.

As can be observed from the Table of Contents, this manual is split up into several chapters:

1.4.2.1. The introduction chapter

The chapter "Introduction" on page 7 includes the safety precautions, this topic and the general operation description of the product(s) this manual refers to.

1.4.2.2. The troubleshooting chapter

The chapter "Troubleshooting" on page 15 not only deals with the methods to recognize and resolve occurring error codes; it also describes the methods how to solve a problem that does not immediately trigger an error code. Such problems are referred to as 'symptom based'. Both the error code based and symptom based troubleshooting tables, indicate possible causes, the necessary checks and in case required, how to repair. The possible causes have been sorted to probability of occurrence and speed of execution.

1.4.2.3. The repair chapter

The chapter "Repair" on page 61 handles the removal and replacement of the major components in the product and discusses cleaning methods as well if applicable, such as for filters. Where applicable, refrigerant handling precautions are mentioned for certain actions; please consider these carefully for your own safety.

1.4.2.4. The maintenance chapter

The chapter "Maintenance" on page 95 of this manual describes the maintenance intervals and procedures to be performed on the product. Remember that a well maintained product, is a more reliable and efficient product.

1.4.2.5. Appendices

Finally, the service manual provides in chapter "Appendix" on page 97 valuable reference data such as piping/wiring diagrams, field settings overview and a checklist to be filled in when you need to escalate an issue to your dealer.

1.4.3. Contact information

This manual has been made with much care and effort. Use it in your daily jobs, as it has been made for you.

Despite our efforts, there is always a chance some clerical or other mistake has been made during the creation of this manual. We kindly ask you to send the found mistakes, or remarks for improvement, to the no-reply email address servicemanual@daikineurope.com.

Part 2. Troubleshooting

This part contains the following chapters:

| | |
|-------------------------------------|----|
| Error codes check | 15 |
| Error based troubleshooting | 23 |
| Symptom based troubleshooting | 44 |
| Component checklist | 45 |
| Other capacity range | 59 |


2.1. Error codes check

2.1.1. Error codes via remote controller

2.1.1.1. Error codes via wired remote controller BRC1E

2.1.1.1.1 How to retrieve error codes

The following message will be displayed on the screen when a malfunction or a warning occurs during operation.














| | Operation Status | Display | |
|--------------------|-------------------------------------|---|--|
| Abnormal shut-down | The system stops operating. | The operation lamp (green) starts to blink. The message "Error: Press Menu button" will appear and blink at the bottom of the screen. | |
| Warning | The system continues its operation. | The operation lamp (green) remains on. The message "Warning: Press Menu button" will appear and blink at the bottom of the screen. | |

If an error or warning is present, it will be displayed on the user interface screen: for more information about troubleshooting, refer to "Error based troubleshooting" on page 23.

2.1.1.1.2 How to reset error codes

In "Error based troubleshooting" on page 23 you find a description of how to reset the specific error or warning.

2.1.1.1.3 History of error codes

| | | | | |
|-----|---|-----|---|---|
| | | | <Basic screen> | |
| 8-1 | Press and hold the Cancel button for 4 seconds or longer in the Basic screen. The Service Settings menu is displayed. | 8-1 |   |  Press and hold the Cancel button for 4 seconds or longer while the backlight is lit. |
| | | | <Service Settings> | |
| 8-2 | Select <i>Error History</i> and press the Menu/Enter button. The Error History menu is displayed | 8-2 |   |  Press the Menu/Enter button. |
| 8-3 | Select <i>RC Error History</i> and press the Menu/Enter button. The error codes and unit No. can be confirmed in the RC Error History screen. | 8-3 |   |  Press the Menu/Enter button. |
| 8-4 | In the RC Error History screen the last 10 items are displayed in order. | 8-4 |  | 1. Latest record 2. Unit no. |
| 8-5 | Press the Cancel button in the RC Error History screen 3 times. The Basic screen returns. | 8-5 |  1 2 | |

**INFORMATION**

The indoor unit error history of each indoor unit can be independently consulted. The last 5 items are displayed in order of appearance.

2.1.1.2. Error codes via wireless remote controller BRC7


2.1.1.2.1 How to retrieve error codes

If the unit stops due to an error, the operation indicating LED on the indoor unit flashes.

The error code can be determined through the wireless remote controller by following the procedure described below.


If an error or warning is present, it will be displayed on the screen: for more information about troubleshooting, refer to "Error based troubleshooting" on page 23.

| | |
|---|--|
| 1 | <p>Press the INSPECTION/TEST button to select "inspection". The equipment enters the inspection mode. The "Unit" indication is displayed and the Unit No. display shows flashing "0" indication.</p> |
| 2 | <p>Set the Unit No. Press the UP or DOWN button and change the Unit No. display until the buzzer (*1) is generated from the indoor unit. *1 Number of beeps 3 short beeps: Conduct all of the following operations. 1 short beep: Conduct steps 3 and 4. Continue the operation in step 4 until a buzzer remains ON. The continuous buzzer indicates that the error code is confirmed. Continuous beep: No abnormality.</p> |
| 3 | <p>Press the MODE selector button. The left "0" (upper digit) indication of the error code flashes.</p> |
| 4 | <p>Error code upper digit diagnosis Press the UP or DOWN button and change the error code upper digit until the error code matching buzzer (*2) is generated. • The upper digit of the code changes as shown below when the UP and DOWN buttons are pressed.</p> <div data-bbox="336 1160 975 1249" style="text-align: center;"> <p>⇨ "UP" button ⇩ "DOWN" button</p> </div> <p>*2 Number of beeps Continuous beep: Both upper and lower digits matched. (Error code confirmed) 2 short beeps: Upper digit matched. 1 short beep: Lower digit matched.</p> |
| 5 | <p>Press the MODE selector button. The right "0" (lower digit) indication of the error code flashes.</p> |
| 6 | <p>Error code lower digit diagnosis Press the UP or DOWN button and change the error code lower digit until the continuous error code matching buzzer (*2) is generated. • The lower digit of the code changes as shown below when the UP and DOWN buttons are pressed.</p> <div data-bbox="336 1675 975 1765" style="text-align: center;"> <p>⇨ "UP" button ⇩ "DOWN" button</p> </div> |



Normal status

Enters inspection mode from normal status when the INSPECTION/ TEST button is pressed.



2.1.1.2.2 How to reset error codes

In "Error based troubleshooting" on page 23 you find a description of how to reset the specific error or warning.

2.1.2. Error codes via outdoor unit PCB

2.1.2.1. How to retrieve error codes

There are 2 ways to retrieve error codes through the outdoor unit:

1. Troubleshooting by LED on the outdoor main PCB

The following diagnosis can be conducted by turning on the power switch and checking the LED indication on the PCB of the outdoor unit.

☀ : LED on / ● : LED off / ⚡ : LED blinks / — : Not used for diagnosis

| LED detection | | Description |
|---------------|-------|--|
| HAP | H1P | |
| (Green) | (Red) | |
| ☀ | ● | Normal |
| ☀ | — | Faulty outdoor unit PCB (Information 1) |
| ● | — | Power supply abnormality, or faulty outdoor unit PCB (Information 2) |
| ⚡ | ☀ | Activation of protection device (Information 3) |



INFORMATION

1. Turn off the power switch, and turn it on again after 5 seconds or more. Check the error condition, and diagnose the problem.
2. Turn off the power switch. After 5 seconds or more, disconnect the connection wire (2). Then turn on the power switch. If the HAP on the outdoor unit PCB flashes after about 10 seconds, the PCB A1P is faulty.
3. Also check for open phase.




INFORMATION

The error detection monitor continues to indicate the previously generated error until the power switch is turned off. Be sure to turn off the power switch after inspection.


2. Troubleshooting by LED on the outdoor service PCB

Take the following steps to check the error or warning (malfunction):



! Pushing the MODE (BS1) button will bring the system to the "Setting mode 1".

(*) Using the MODE button, the modes can be changed as follows.



(**)

| | HAP | H1P | H2P | H3P | H4P | H5P | H6P | H7P |
|---------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|
| LED-status: | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ |
| | | | | | | | | |
| Binary counting: value: | | 64 | 32 | 16 | 8 | 4 | 2 | 1 |
| | | | | | | | | |
| Setting item: 14= latest error= | | ☀ | ● | ● | ☀ | ☀ | ☀ | ● |
| 15= previous error= | | ☀ | ● | ● | ☀ | ☀ | ☀ | ☀ |
| 16= 2 before= | | ☀ | ● | ☀ | ● | ● | ● | ● |

☀: ON ●: OFF ☀: BLINK

| Malfunction code | Contents of retry or malfunction | Return 1 | | | | | | | Return 2 | | | | | | | Return 3 | | | | | | | | | | |
|------------------|--|---|------|------|------|------|------|------|----------|------|------|------|------|------|------|----------|------|------|------|------|------|------|------|------|------|---|
| | | HA P | H1 P | H2 P | H3 P | H4 P | H5 P | H6 P | H7 P | HA P | H1 P | H2 P | H3 P | H4 P | H5 P | H6 P | H7 P | HA P | H1 P | H2 P | H3 P | H4 P | H5 P | H6 P | H7 P | |
| C4 | Indoor heat exchanger thermistor | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ● | ☀ | ☀ | ☀ | ● | ● | ☀ | ● | ● | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| E1 | Faulty outdoor PC board | ☀ | ☀ | ● | ☀ | ● | ● | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| E3 | Abnormal high pressure | | | | | | | | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| E4 | Abnormal low pressure | | | | | | | | ☀ | ☀ | ☀ | ● | ● | ☀ | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| E5 | Compressor motor lock | | | | | | | | ☀ | ☀ | ☀ | ● | ● | ☀ | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| E7 | Abnormal outdoor fan motor | DC motor 1 lock | | | | | | | ☀ | ☀ | ☀ | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | |
| | | DC motor 2 lock | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ☀ | ● |
| | | Abnormal inverter transmission | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ☀ |
| E9 | Abnormal electronic expansion valve | Disconnected electronic expansion valve connector | | | | | | | ☀ | ☀ | ☀ | ● | ☀ | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | |
| | | Malfunction due to wet conditions | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ☀ |
| F3 | Abnormal discharge pipe temperature | Abnormal discharge pipe temperature | | ☀ | ☀ | ● | ☀ | ● | ☀ | ● | ☀ | ☀ | ☀ | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | |
| | | Disconnected discharge pipe thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ☀ |
| H3 | Abnormal high pressure switch | ☀ | ☀ | ● | ☀ | ● | ☀ | ● | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| H9 | Abnormal outdoor air thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| J1 | Abnormal pressure sensor | ☀ | ☀ | ● | ☀ | ● | ☀ | ☀ | ● | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| J3 | Abnormal discharge pipe thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| J5 | Abnormal suction pipe thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| J6 | Abnormal heat exchanger distributor pipe thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| J7 | Abnormal intermediate heat exchanger thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| J8 | Abnormal liquid pipe thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| L1 | PC board failure | ☀ | ☀ | ● | ☀ | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| L4 | Elevated radiation fin temperature | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| L5 | Compressor instantaneous overcurrent | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| L8 | Compressor overload | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| L9 | Compressor lock | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| LC | Abnormal transmission (between the control and the inverter) | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| P1 | Unbalanced power supply voltage | ☀ | ☀ | ● | ☀ | ● | ☀ | ● | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● | |
| P4 | Abnormal radiation fin thermistor | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| PJ | Faulty capacity setting | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| U0 | Abnormal gas shortage | Gas shortage warning | | ☀ | ☀ | ● | ☀ | ● | ☀ | ● | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ | |
| | | Abnormal gas shortage | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ☀ |
| U2 | Abnormal power supply voltage | Inverter undervoltage and overvoltage | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ☀ |
| | | SP-PAM overvoltage | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ☀ |
| U4 | Abnormal transmission (between indoor and outdoor units) | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| UA | Faulty field setting switch | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |
| UF | Improper piping and improper communication wiring | | | | | | | | | | | | | | | | | ☀ | ☀ | ☀ | ☀ | ☀ | ● | ● | ● | ● |

For more information about troubleshooting, refer to "Error based troubleshooting" on page 23.

2.1.2.2. How to reset error codes

In "Error based troubleshooting" on page 23 you find a description on how to reset the specific error or warning.

2.1.2.3. History of error codes and warnings

As described in above procedure, the latest error or warning codes can also be consulted in Monitor mode:

Setting item 5= latest error

Setting item 6= previous error

Setting item 7= 2 before

For the procedure and the meaning of the different displays, refer to "How to retrieve error codes" above.

2.1.2.4. Content of retry

Through the outdoor PCB, the content of retry can be determined.


Here, you can find the errors which are being created before they are being displayed on the user interface.

As described in below procedure, the content of retry can again be consulted in Monitor mode:

Setting item 2= latest retry

Setting item 3= 1 cycle before

Setting item 4= 2 cycles before



* Pressing the MODE (BS1) button will bring the system to the "Setting mode 1".

2.2. Error based troubleshooting

Overview of error codes:

| | |
|---|----|
| Indoor unit | 24 |
| “A1-01” – Indoor unit PCB abnormality | 24 |
| “A3-00” – Drain water level system abnormality | 24 |
| “A6-00” – Indoor unit fan motor abnormality | 24 |
| “AJ-00” – Capacity setting abnormality | 25 |
| “C1-00” – Transmission error (indoor & adapter PCB) | 25 |
| “C4-00” – Heat exchanger thermistor abnormality | 26 |
| “C5-00” – Intermediate heat exchanger thermistor abnormality | 26 |
| “C9-00” – Suction air thermistor abnormality | 27 |
| “CC-00” – Humidity sensor system abnormality | 27 |
| “CJ-00” – Remote controller thermistor abnormality | 27 |
| Outdoor unit | 28 |
| “E1-00” – Outdoor unit PCB abnormality | 28 |
| “E3-00” – Discharge pressure abnormality | 28 |
| “E4-00” – Suction pressure abnormality | 29 |
| “E5-00” – Compressor motor lock or overheated | 29 |
| “E7-00” – Fan motor abnormality | 30 |
| “E9-00” – Electronic expansion valve abnormality | 31 |
| “F3-00” – Discharge pipe temperature abnormality | 31 |
| “H3-00” – High pressure switch abnormality | 32 |
| “H4-00” – Low pressure switch abnormality | 33 |
| “H9-00” – Outdoor air temperature thermistor abnormality | 33 |
| “J3-00” – Discharge pipe thermistor abnormality | 33 |
| “J5-00” – Suction pipe thermistor abnormality | 34 |
| “J6-00” – Outdoor heat exchanger thermistor abnormality | 34 |
| “J7-00” – Intermediate heat exchanger thermistor abnormality | 34 |
| “J8-00” – Liquid pipe thermistor abnormality | 35 |
| “L1-00” – Outdoor main PCB abnormality | 35 |
| “L5-00” – Output overcurrent detection | 36 |
| “L8-00” – Electronic thermal overload | 37 |
| “L9-00” – Stall prevention time lag | 37 |
| “LC-00” – Transmission system abnormality | 38 |
| “P1-00” – Open phase or power supply voltage imbalance | 38 |
| “P4-00” – Radiating fin temperature sensor abnormality | 38 |
| “PJ-00” – Capacity setting abnormality | 39 |
| System | 40 |
| “U0-00” – Refrigerant shortage | 40 |
| “U1-00” – Reverse phase or open phase | 40 |
| “U2-00” – Power supply abnormality or instantaneous power failure | 41 |
| “U4-00” – Transmission abnormality between indoor unit and outdoor unit | 42 |
| “UA-00” – Improper combination of indoor unit and outdoor unit | 42 |
| “UF-00” – Wiring and piping mismatch | 43 |
| Others | 43 |

2.2.1. Indoor unit

2.2.1.1. "A1-01" – Indoor unit PCB abnormality

| Trigger | Effect | Reset |
|--|---------------------------|-------------------------------|
| EEPROM data is not received correctly. | Unit will stop operating. | Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|--|--|--|
| Indoor Unit - Electrical components | | |
| Faulty indoor PCB. | Check if error still occurs after turning off power and turning it back on again. Check if the indoor PCB receives power. Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check the wiring to indoor PCB. | Adjust power to the indoor PCB. Replace indoor PCB when HAP LED is not blinking in regular intervals. Install correct spare part or update indoor PCB. Adjust wiring to indoor PCB when required. |

2.2.1.2. "A3-00" – Drain water level system abnormality

| Trigger | Effect | Reset |
|---|---------------------------|------------------|
| Drain water level reaches its upper limit and float switch turns OFF. | Unit will stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|---|--|--|
| Defective drain pump. | Check drain pump. | Replace drain pump when required. |
| Improper drain piping work or clogging. | Check if drain piping is executed correctly. Check if drain piping is clogged. | Correct or clean drain piping when required. |
| Defective flow switch. | Check flow switch. | Replace flow switch when required. |
| (for optional drain pump kit) Defective short circuit connector X15A. | Check if connector is firmly connected. Check the continuity of the short circuit connector. | Connect the short circuit connector. Replace the short circuit connector when required. Replace the indoor PCB when required. |
| Faulty indoor PCB. | Check if error still occurs after turning off power and turning it back on again. Check if the indoor PCB receives power. Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check the wiring to indoor PCB. | Adjust power to the indoor PCB. Replace indoor PCB when HAP LED is not blinking in regular intervals. Install correct spare part or update indoor PCB. Adjust wiring to indoor PCB when required. |

2.2.1.3. "A6-00" – Indoor unit fan motor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|-------------------------------|
| The rotation speed of the fan motor is not detected while the output voltage to the fan is at its maximum. | Unit will stop operating. | Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|--------------------------|---|---|
| Faulty indoor PCB. | <p>Check if error still occurs after turning off power and turning it back on again.</p> <p>Check if the indoor PCB receives power.</p> <p>Check if the HAP LED is blinking in regular intervals.</p> <p>Check if the correct spare part is installed.</p> <p>Check the wiring to indoor PCB.</p> | <p>Adjust power to the indoor PCB.</p> <p>Replace indoor PCB when HAP LED is not blinking in regular intervals.</p> <p>Install correct spare part or update indoor PCB.</p> <p>Adjust wiring to indoor PCB when required.</p> |
| Faulty indoor fan motor. | <p>Check the fan motor (see "Fan motor" on page 46).</p> <p>Check fan motor connections and wiring.</p> | <p>Replace fan motor when required.</p> <p>Adjust wiring when required.</p> |
| Indoor fan motor locked. | <p>Switch of the power.</p> <p>Turn fan manually.</p> | <p>Replace fan motor when the fan does not turn smoothly.</p> |

2.2.1.4. "AJ-00" – Capacity setting abnormality

| Trigger | Effect | Reset |
|--|---------------------------|-------------------------------|
| The capacity setting adaptor is not connected or not recognised by the indoor PCB. | Unit will stop operating. | Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|--|---|---|
| Faulty indoor PCB. | <p>Check if error still occurs after turning off power and turning it back on again.</p> <p>Check if the indoor PCB receives power.</p> <p>Check if the HAP LED is blinking in regular intervals.</p> <p>Check if the correct spare part is installed.</p> <p>Check the wiring to indoor PCB.</p> | <p>Adjust power to the indoor PCB.</p> <p>Replace indoor PCB when HAP LED is not blinking in regular intervals.</p> <p>Install correct spare part or update indoor PCB.</p> <p>Adjust wiring to indoor PCB when required.</p> |
| Faulty capacity adapter on indoor PCB (in case of spare part PCB). | <p>Check if the correct adapter is installed.</p> <p>Check if the correct spare part is installed.</p> | <p>Adjust capacity adapter when required.</p> |

2.2.1.5. "C1-00" – Transmission error (indoor & adapter PCB)

| Trigger | Effect | Reset |
|--|---------------------------|-------------------------------|
| When normal transmission between indoor unit PCB & adaptor PCB is not conducted for a certain duration (15 seconds or more). | Unit will stop operating. | Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|---------------------|---|------------------------------|
| Faulty adaptor PCB. | <p>Check if the adaptor PCB is installed.</p> <p>Check if the connector X8A on the adaptor PCB is not circuited.</p> <p>Check the wire harness.</p> | <p>Adjust when required.</p> |

| Possible cause | Check | Corrective action |
|--|---|---|
| Faulty indoor PCB. | <p>Check if error still occurs after turning off power and turning it back on again.</p> <p>Check if the indoor PCB receives power.</p> <p>Check if the HAP LED is blinking in regular intervals.</p> <p>Check if the correct spare part is installed.</p> <p>Check the wiring to indoor PCB.</p> | <p>Adjust power to the indoor PCB.</p> <p>Replace indoor PCB when HAP LED is not blinking in regular intervals.</p> <p>Install correct spare part or update indoor PCB.</p> <p>Adjust wiring to indoor PCB when required.</p> |
| External factory (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while). | Check for source which could cause electrical interference. | Avoid electrical interference. |
| Internal wiring is not OK. | Check if wiring between PCB's is correct (refer to wiring diagram). | Correct wiring. |

2.2.1.6. "C4-00" – Heat exchanger thermistor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|--|
| Resistance value is out of range. T measured < -43.6°C or > 90°C. | Unit will stop operating. | Automatic reset when resistance is within range. |

| Possible cause | Check | Corrective action |
|-----------------------------------|---|---|
| Faulty Heat Exchanger thermistor. | Check heat exchanger thermistor (see "Refrigerant thermistors" on page 57). | Replace heat exchanger thermistor when required. |
| Faulty indoor PCB. | <p>Check if error still occurs after turning off power and turning it back on again.</p> <p>Check if the indoor PCB receives power.</p> <p>Check if the HAP LED is blinking in regular intervals.</p> <p>Check if the correct spare part is installed.</p> <p>Check the wiring to indoor PCB.</p> | <p>Adjust power to the indoor PCB.</p> <p>Replace indoor PCB when HAP LED is not blinking in regular intervals.</p> <p>Install correct spare part or update indoor PCB.</p> <p>Adjust wiring to indoor PCB when required.</p> |

2.2.1.7. "C5-00" – Intermediate heat exchanger thermistor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|--|
| Resistance value is out of range. T measured < -43.6°C or > 90°C. | Unit will stop operating. | Automatic reset when resistance is within range. |

| Possible cause | Check | Corrective action |
|--|---|---|
| Faulty Intermediate Heat Exchanger thermistor. | Check intermediate heat exchanger thermistor (see "Refrigerant thermistors" on page 57). | Replace intermediate heat exchanger thermistor when required. |
| Faulty indoor PCB. | <p>Check if error still occurs after turning off power and turning it back on again.</p> <p>Check if the indoor PCB receives power.</p> <p>Check if the HAP LED is blinking in regular intervals.</p> <p>Check if the correct spare part is installed.</p> <p>Check the wiring to indoor PCB.</p> | <p>Adjust power to the indoor PCB.</p> <p>Replace indoor PCB when HAP LED is not blinking in regular intervals.</p> <p>Install correct spare part or update indoor PCB.</p> <p>Adjust wiring to indoor PCB when required.</p> |

2.2.1.8. “C9-00” – Suction air thermistor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|--|
| Resistance value is out of range. T measured < -43.6°C or > 90°C. | Unit will stop operating. | Automatic reset when resistance is within range. |

| Possible cause | Check | Corrective action |
|--------------------------------|--|--|
| Faulty suction air thermistor. | Check suction air thermistor (see " Refrigerant thermistors " on page 57). | Replace suction air thermistor when required. |
| Faulty indoor PCB. | Check if error still occurs after turning off power and turning it back on again. Check if the indoor PCB receives power. Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check the wiring to indoor PCB. | Adjust power to the indoor PCB. Replace indoor PCB when HAP LED is not blinking in regular intervals. Install correct spare part or update indoor PCB. Adjust wiring to indoor PCB when required. |

2.2.1.9. “CC-00” – Humidity sensor system abnormality

| Trigger | Effect | Reset |
|--|-------------------------------|----------------------------------|
| The humidity sensor is disconnected or short circuit when the unit is running. | Unit will not stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|--|---|--|
| Faulty humidity sensor. | Check good connection to indoor PCB. | Replace the humidity sensor when required. |
| External factory (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while). | Check for source which could cause electrical interference. | Avoid electrical interference. |

2.2.1.10. “CJ-00” – Remote controller thermistor abnormality

| Trigger | Effect | Reset |
|---|-------------------------------|------------------|
| Disconnected or short circuit remote controller thermistor. | Unit will not stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|--|---|--|
| Indoor Unit - Electrical components | | |
| Faulty remote controller thermistor. | Erase the error record from the remote controller. | Push the ON/OFF button on the remote controller for 5 seconds in the check mode. Replace the remote controller. |
| External factory (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while). | Check for source which could cause electrical interference. | Avoid electrical interference. |

2.2.2. Outdoor unit

2.2.2.1. "E1-00" – Outdoor unit PCB abnormality

| Trigger | Effect | Reset |
|---|---------------------------|---|
| Outdoor main PCB detects that EEPROM is abnormal. | Unit will stop operating. | Manual reset via user interface. Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see " Main PCB " on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see " Replacing main PCB " on page 89). |
| Faulty capacity adapter on outdoor main PCB installed. | Check if the correct capacity adapter is used. | Replace capacity adapter when required. |
| External factor (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while). | Check for source which could cause electrical interference. | |
| Faulty outdoor fan motor. | Check the fan motor (see " Fan motor " on page 52). Check fan motor connections and wiring. | Replace fan motor when required (see " Replacing DC fan motor assembly " on page 79). Adjust wiring when required. |
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |

2.2.2.2. "E3-00" – Discharge pressure abnormality

| Trigger | Effect | Reset |
|---|---------------------------|----------------------------------|
| High pressure switch opens due to measure pressure > 41.7 bar. | Unit will stop operating. | Manual reset via user interface. |
| High pressure control (measure pressure > 38 bar) occurs 16 times within 300 minutes. | | |

| Possible cause | Check | Corrective action |
|---|--|--|
| Faulty high pressure switch. | Check high pressure switch (see " High pressure switch " on page 53). | Replace high pressure switch (see " Replacing high pressure switches " on page 86). |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see " Replacing main PCB " on page 89). |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |
| Refrigerant overcharge. | Check for refrigerant overcharge. Refer to the nameplate for the correct charge. | Charge the correct refrigerant amount when required. |
| Humidity in refrigerant (ice formation in expansion valve). | Check for humidity in the refrigerant. | In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant. |

| Possible cause | Check | Corrective action |
|----------------------------------|---|--|
| Non condensables in refrigerant. | Check for non condensables in refrigerant. | In case of suspicion of non condensables, recover, vacuum and recharge with virgin refrigerant. |
| Refrigerant is contaminated. | Check for non condensables in refrigerant. | In case of suspicion of non condensables. Recover, vacuum and recharge refrigerant. |
| Stop valve is closed. | Check if stop valve is open. | Open stop valve when required. |
| Faulty outdoor fan motor. | Check the fan motor (see "Fan motor" on page 52). Check fan motor connections and wiring. | Replace fan motor when required (see "Replacing DC fan motor assembly" on page 79). Adjust wiring when required. |

2.2.2.3. "E4-00" – Suction pressure abnormality

| Trigger | Effect | Reset |
|---|---------------------------|----------------------------------|
| When refrigerant pressure is below 1,2 bar for 5 minutes. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Bad contact through pressure sensor cable. | Check if pressure sensor connector is properly connected to the outdoor PCB board. | Connect or replace sensor cable when required. |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |
| Stop valve is closed. | Check if stop valve is open. | Open stop valve when required. |
| Abnormal drop of low pressure, caused by inadequate refrigerant, abnormal refrigerant piping system or faulty electronic expansion valve. | Check for possible blockage. (Blockages can be checked by measuring the refrigerant/pipe temperature. Sudden drop in temperature could indicate a blockage (remark: this is not valid for the expansion valve.)) | Replace the blocked part. |

2.2.2.4. "E5-00" – Compressor motor lock or overheated

| Trigger | Effect | Reset |
|----------------------------------|---------------------------|--|
| Compressor overload is detected. | Unit will stop operating. | Automatic reset if the unit runs for 60 seconds without error. |

| Possible cause | Check | Corrective action |
|-----------------------------------|---|--|
| Faulty discharge pipe thermistor. | Check discharge pipe thermistor (see "Refrigerant thermistors" on page 57). | Replace discharge pipe thermistor when required. |
| Faulty outdoor fan motor. | Check the fan motor (see "Fan motor" on page 52). Check fan motor connections and wiring. | Replace fan motor when required (see "Replacing DC fan motor assembly" on page 79). Adjust wiring when required. |
| Faulty overload protection. | Check the overload protection. Check the overload protection connections and wiring. | Replace the overload protection when required. Adjust wiring when required. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty expansion valve. | Check the expansion valve (see "Electronic expansion valve" on page 50). | Replace the expansion valve body (see "Replacing expansion valve body" on page 81) or motor (see "Replacing expansion valve motor" on page 82) when required. |
| Faulty 4-way valve. | Check the 4-way valve (see "4-way valve" on page 47). | Replace the 4-way valve coil (see "Replacing 4-way valve coil" on page 75) or body (see "Replacing 4-way valve body" on page 73) when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty power module = faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. | Restore the power to the outdoor inverter PCB. Replace the outdoor inverter PCB when required (see "Replacing main PCB" on page 89). |
| Refrigerant shortage. | Check for refrigerant shortage. Refer to the nameplate for the correct charge. | Charge the correct refrigerant amount when required. |
| Humidity in refrigerant (ice formation in expansion valve). | Check for humidity in the refrigerant. | In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant. |
| Non condensables in refrigerant. | Check for non condensables in refrigerant. | In case of suspicion of non condensables, recover, vacuum and recharge with virgin refrigerant. |
| Stop valve is closed. | Check stop valve. | Open stop valve when required. |

2.2.2.5. "E7-00" – Fan motor abnormality

| Trigger | Effect | Reset |
|--|-------------------------------|---|
| Fan does not start in about 15~30 seconds = fan motor lock. It can occur that E7-00 error is triggered even when the fan motor is running caused by a NG hall signal. | Unit will not stop operating. | Automatic reset after a continuous run. Refer to "'E7-00" – Fan motor abnormality" on page 30. |
| | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|------------------------------|--|---|
| Faulty outdoor fan motor. | Check the fan motor (see "Fan motor" on page 52). Check fan motor connections and wiring. | Replace fan motor when required (see "Replacing DC fan motor assembly" on page 79). Adjust wiring when required. |
| Faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. | Restore the power to the outdoor inverter PCB. Replace the outdoor inverter PCB when required (see "Replacing main PCB" on page 89). |
| Blown fuse. | Check the fuse on the outdoor unit PCB's. | Replace fuse when required. |

2.2.2.6. "E9-00" – Electronic expansion valve abnormality

| Trigger | Effect | Reset |
|---|---------------------------|---|
| 1. No continuity of expansion valve. 2. Minimum expansion valve opening and suction superheat < A K and discharge superheat < B K (refer to "Product specific information" on page 121 for values of A and B). | Unit will stop operating. | Manual reset via user interface. Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|--|--|---|
| Wet operation. | Check for wet operation. (Wet operation can be detected by checking the suction superheat. If the suction superheat is 0°C then liquid refrigerant is returned to the compressor.) | In case wet operation was detected, confirm the cause: <ul style="list-style-type: none"> Refrigerant overcharge. Faulty expansion valve. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty thermistor. | Check thermistor (see "Refrigerant thermistors" on page 57). | Replace thermistor when required. |
| Faulty or disturbance of the power supply (imbalance >10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |
| Faulty expansion valve. | Check the expansion valve (see "Electronic expansion valve" on page 50). | Replace the expansion valve body or motor (see "Replacing expansion valve body" on page 81) when required. |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |
| External factory (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while). | Check for source which could cause electrical interference. | Avoid electrical interference. |

2.2.2.7. "F3-00" – Discharge pipe temperature abnormality

| Trigger | Effect | Reset |
|--|-------------------------------|---|
| Discharge temperature is too high: <ul style="list-style-type: none"> If the discharge temperature detected is above A°C, 10 times within 200 min. If within 200 min the discharge temperature detected is 10 times above B°C for 15 min. Refer to "Product specific information" on page 121 for values of A and B. | Unit will not stop operating. | Automatic reset when temperature drops below C°C. Refer to "Product specific information" on page 121 for values of C. |
| | Unit will stop operating. | Manual reset via remote controller. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Refrigerant shortage. | Check for refrigerant shortage. Refer to the nameplate for the correct charge. | Charge the correct refrigerant amount when required. |
| Humidity in refrigerant (ice formation in expansion valve). | Check for humidity in the refrigerant. | In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant. |

| Possible cause | Check | Corrective action |
|--|---|---|
| Non condensables in refrigerant. | Check for non condensables in refrigerant. | In case of suspicion of non condensables, recover, vacuum and recharge with virgin refrigerant. |
| Stop valve is closed. | Check if stop valve is open. | Open stop valve when required. |
| Faulty 4-way valve. | Check the 4-way valve (see "4-way valve" on page 47). | Replace the 4-way valve coil (see "Replacing 4-way valve coil" on page 75) or body (see "Replacing 4-way valve body" on page 73) when required. |
| Faulty expansion valve. | Check the expansion valve (see "Electronic expansion valve" on page 50). | Replace the expansion valve body (see "Replacing expansion valve body" on page 81) or motor (see "Replacing expansion valve motor" on page 82) when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty discharge thermistor. | Check discharge thermistor (see "Refrigerant thermistors" on page 57). | Replace discharge thermistor when required. |
| Faulty heat exchanger thermistor. | Check heat exchanger thermistor (see "Refrigerant thermistors" on page 57). | Replace heat exchanger thermistor when required. |
| Faulty outdoor temperature thermistor. | Check outdoor temperature thermistor (see "Refrigerant thermistors" on page 57). | Replace outdoor temperature thermistor when required. |

2.2.2.8. "H3-00" – High pressure switch abnormality

| Trigger | Effect | Reset |
|---|---------------------------|----------------------------------|
| High pressure switch is activated when compressor is off. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Stop valve is closed. | Check if stop valve is open. | Open stop valve when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the alive led is blinking in regular intervals. Check if the correct spare part is installed. | Adjust the power to the outdoor inverter PCB. Replace outdoor inverter PCB (see "Replacing main PCB" on page 89). |
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |
| Faulty high pressure switch. | Check high pressure switch (see "High pressure switch" on page 53). | Replace the high pressure switch (see "Replacing high pressure switches" on page 86). |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |

2.2.2.9. "H4-00" – Low pressure switch abnormality

| Trigger | Effect | Reset |
|---|---------------------------|------------------|
| When there is no continuity in the low pressure switch during compressor start. | Unit will stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|-------------------------------|--|--|
| Refrigerant shortage. | Check for refrigerant shortage. Refer to the nameplate for the correct charge. | Charge the correct refrigerant amount when required. |
| Stop valve is closed. | Check if stop valve is open. | Open stop valve when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty expansion valve. | Check the expansion valve (see "Electronic expansion valve" on page 50). | Replace the expansion valve body (see "Replacing expansion valve body" on page 81) or motor (see "Replacing expansion valve motor" on page 82) when required. |
| Faulty low pressure switch. | Check low pressure switch (see "Low pressure switch" on page 54). | Replace low pressure switch (see "Replacing low pressure switch" on page 88). |

2.2.2.10. "H9-00" – Outdoor air temperature thermistor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|----------------------------------|
| Thermistor input voltage is > 4.96 V or < 0.04 V when power is on. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|--|--|---|
| Faulty outdoor air temperature thermistor. | Check outdoor temperature thermistor (see "Refrigerant thermistors" on page 57). | Replace outdoor temperature thermistor when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

2.2.2.11. "J3-00" – Discharge pipe thermistor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|----------------------------------|
| Thermistor input voltage is > 4.96 V or < 0.04 V when power is on. | Unit will stop operating. | Manual reset via user interface. |
| Discharge pipe temperature is lower than the heat exchanger temperature. | | |

| Possible cause | Check | Corrective action |
|-----------------------------------|---|--|
| Faulty discharge pipe thermistor. | Check discharge pipe thermistor (see "Refrigerant thermistors" on page 57). | Replace discharge pipe thermistor when required. |

| Possible cause | Check | Corrective action |
|-------------------------------|---|--|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

2.2.2.12. "J5-00" – Suction pipe thermistor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|------------------|
| Suction pipe thermistor R3T detects an abnormal value (open or short circuit). | Unit will stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty suction pipe thermistor R3T. | Check suction pipe thermistor R3T (see "Refrigerant thermistors" on page 57). | Replace suction pipe thermistor R3T when required. |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |

2.2.2.13. "J6-00" – Outdoor heat exchanger thermistor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|----------------------------------|
| Thermistor input voltage is > 4.96 V or < 0.04 V when power is on. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|-----------------------------------|---|--|
| Faulty heat exchanger thermistor. | Check heat exchanger thermistor (see "Refrigerant thermistors" on page 57). | Replace heat exchanger thermistor when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

2.2.2.14. "J7-00" – Intermediate heat exchanger thermistor abnormality

| Trigger | Effect | Reset |
|---|---------------------------|------------------|
| Intermediate heat exchanger thermistor R5T detects an abnormal value (open or short circuit). | Unit will stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|--|--|--|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty intermediate heat exchanger thermistor R5T. | Check intermediate heat exchanger thermistor (see "Refrigerant thermistors" on page 57). | Replace intermediate heat exchanger thermistor R5T when required. |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |

2.2.2.15. "J8-00" – Liquid pipe thermistor abnormality

| Trigger | Effect | Reset |
|---|---------------------------|------------------|
| Liquid pipe thermistor R6T detects an abnormal value (open or short circuit). | Unit will stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|---|--|--|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty liquid pipe thermistor R6T. | Check liquid pipe thermistor R6T (see "Refrigerant thermistors" on page 57). | Replace liquid pipe thermistor R6T when required. |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |

2.2.2.16. "L1-00" – Outdoor main PCB abnormality

| Trigger | Effect | Reset |
|--|---------------------------|---|
| Outdoor main PCB detects current/voltage errors. | Unit will stop operating. | Manual reset via user interface. Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|-------------------------------|--|--|
| Blown fuse. | Check fuse on outdoor main PCB. | Replace fuse if blown. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the alive led is blinking in regular intervals. Check if the correct spare part is installed. | Adjust the power to the outdoor inverter PCB. Replace outdoor inverter PCB (see "Replacing main PCB" on page 89). |

| Possible cause | Check | Corrective action |
|---|---|--|
| Faulty compressor. | <p>Check compressor (see "Compressor" on page 49).</p> <p>Check connections and wiring of the compressor.</p> <p>Check expansion valve (liquid back issue) (see "Electronic expansion valve" on page 50).</p> <p>Check the refrigerant charge. Refer to the nameplate for correct charge.</p> | <p>Replace compressor when required (see "Replacing compressor" on page 76).</p> <p>Investigate reason of breakdown.</p> <p>Replace expansion valve when required (see "Replacing expansion valve body" on page 81).</p> <p>Fix possible leak.</p> |
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |
| Faulty outdoor fan motor. | <p>Check the fan motor (see "Fan motor" on page 52).</p> <p>Check fan motor connections and wiring.</p> | <p>Replace fan motor when required (see "Replacing DC fan motor assembly" on page 79).</p> <p>Adjust wiring when required.</p> |
| Faulty capacity adapter on outdoor PCB. | <p>Check if the correct adapter is installed.</p> <p>Check if the correct spare part is installed.</p> | Adjust capacity adapter when required. |
| External factory (e.g. electrical noise). (cause when error is reset after power reset, and error happens again after a while). | Check for source which could cause electrical interference. | Avoid electrical interference. |

2.2.2.17. "L5-00" – Output overcurrent detection

| Trigger | Effect | Reset |
|---|---------------------------|----------------------------------|
| Outdoor inverter PCB detects overcurrent to power transistor. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|---|---|--|
| Refrigerant circuit is clogged. | Check for possible blockage. | Replace blocked part when required. |
| Humidity in refrigerant (ice formation in expansion valve). | Check for humidity in the refrigerant. | In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant. |
| Non condensables in refrigerant. | Check for non condensables in refrigerant. | In case of suspicion of non condensables, recover, vacuum and recharge with virgin refrigerant. |
| Faulty outdoor inverter PCB. | <p>Check outdoor inverter PCB.</p> <p>Check if the alive led is blinking in regular intervals.</p> <p>Check if the correct spare part is installed.</p> | <p>Adjust the power to the outdoor inverter PCB.</p> <p>Replace outdoor inverter PCB (see "Replacing main PCB" on page 89).</p> |
| Faulty compressor. | <p>Check compressor (see "Compressor" on page 49).</p> <p>Check connections and wiring of the compressor.</p> <p>Check expansion valve (liquid back issue) (see "Electronic expansion valve" on page 50).</p> <p>Check the refrigerant charge. Refer to the nameplate for correct charge.</p> | <p>Replace compressor when required (see "Replacing compressor" on page 76).</p> <p>Replace expansion valve when required (see "Replacing expansion valve body" on page 81).</p> <p>Fix possible leak.</p> |
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |

2.2.2.18. "L8-00" – Electronic thermal overload

| Trigger | Effect | Reset |
|--|---------------------------|----------------------------------|
| When compressor overload (except during start-up) is detected. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|---------------------------------|--|---|
| Refrigerant circuit is clogged. | Check for possible blockage. | Replace blocked part when required. |
| Refrigerant overcharge. | Check for refrigerant overcharge. Refer to the nameplate for the correct charge. | Charge the correct refrigerant amount when required. |
| Refrigerant is contaminated. | | Replace refrigerant. |
| Faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the alive led is blinking in regular intervals. Check if the correct spare part is installed. | Adjust the power to the outdoor inverter PCB. Replace outdoor inverter PCB (see "Replacing main PCB" on page 89). |
| Faulty compressor | Check compressor (see "Compressor" on page 49). Check connections and wiring of the compressor. Check expansion valve (liquid back issue) (see "Electronic expansion valve" on page 50). Check the refrigerant charge. Refer to the nameplate for correct charge. | Replace compressor when required (see "Replacing compressor" on page 76). Investigate reason of breakdown. Replace expansion valve when required (see "Replacing expansion valve body" on page 81). Fix possible leak. |

2.2.2.19. "L9-00" – Stall prevention time lag

| Trigger | Effect | Reset |
|---|---------------------------|----------------------------------|
| Outdoor inverter PCB detects compressor overload at start up. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|--|--|---|
| Refrigerant circuit is clogged. | Check for possible blockage. | Replace blocked part when required. |
| Refrigerant condition is not OK (HP-LP > 0,2 MPa at start-up). | Check refrigerant condition. | |
| Faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the alive led is blinking in regular intervals. Check if the correct spare part is installed. | Adjust the power to the outdoor inverter PCB. Replace outdoor inverter PCB (see "Replacing main PCB" on page 89). |
| Faulty compressor. | Check compressor (see "Compressor" on page 49). Check connections and wiring of the compressor. Check expansion valve (liquid back issue) (see "Electronic expansion valve" on page 50). Check the refrigerant charge. Refer to the nameplate for correct charge. | Replace compressor when required (see "Replacing compressor" on page 76). Investigate reason of breakdown. Replace expansion valve when required (see "Replacing expansion valve body" on page 81). Fix possible leak. |

2.2.2.20. "LC-00" – Transmission system abnormality

| Trigger | Effect | Reset |
|--|---------------------------|------------------|
| No transmission between outdoor main PCB and outdoor inverter PCB. | Unit will stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Internal wiring is not OK. | Check if wiring between PCB's. (refer to wiring diagram). | Correct wiring. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the alive led is blinking in regular intervals. Check if the correct spare part is installed. | Adjust the power to the outdoor inverter PCB. Replace outdoor inverter PCB (see "Replacing main PCB" on page 89). |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |
| External factory (e.g. electrical noise). (cause when error is reset after power reset, and error happens again after a while). | Check for source which could cause electrical interference. | Avoid electrical interference. |

2.2.2.21. "P1-00" – Open phase or power supply voltage imbalance

| Trigger | Effect | Reset |
|--|---------------------------|--|
| Outdoor inverter PCB detects incorrect power supply. | Unit will stop operating. | Manual reset via user interface. Automatic reset. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty outdoor inverter PCB. | Check outdoor inverter PCB. Check if the alive led is blinking in regular intervals. Check if the correct spare part is installed. | Adjust the power to the outdoor inverter PCB. Replace outdoor inverter PCB (see "Replacing main PCB" on page 89). |
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |

2.2.2.22. "P4-00" – Radiating fin temperature sensor abnormality

| Trigger | Effect | Reset |
|--|---------------------------|----------------------------------|
| Radiating fin thermistor input voltage is < 0.04 V or > 4.96 V when power is on. | Unit will stop operating. | Manual reset via user interface. |

| Possible cause | Check | Corrective action |
|---|---|--|
| Faulty radiating fin thermistor. | Check radiating fin thermistor (see "Refrigerant thermistors" on page 57). | Replace radiating fin thermistor when required. |
| Faulty outdoor unit PCB in which radiating fin thermistor is connected. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

2.2.2.23. "PJ-00" – Capacity setting abnormality

| Trigger | Effect | Reset |
|--|---------------------------|---|
| Outdoor main PCB detects a defective capacity in EEPROM. | Unit will stop operating. | Manual reset via user interface. Power supply reset. |

| Possible cause | Check | Corrective action |
|--|--|---|
| Position of PCB dip switches are not OK. | Check if dip switches are set to default (OFF) position. | |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |

2.2.3. System

2.2.3.1. "U0-00" – Refrigerant shortage

| Trigger | Effect | Reset |
|--------------------------------|---------------------------|--|
| Refrigerant shortage detected. | Unit will stop operating. | Automatic reset (see "Error codes" on page 121). |
| | | Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty air thermistor. | Check air thermistor (see "Refrigerant thermistors" on page 57). | Replace air thermistor when required. |
| Faulty discharge thermistor. | Check discharge thermistor (see "Refrigerant thermistors" on page 57). | Replace discharge thermistor when required. |
| Faulty outdoor heat exchanger thermistor. | Check outdoor heat exchanger thermistor (see "Refrigerant thermistors" on page 57). | Replace outdoor heat exchanger thermistor when required. |
| Stop valve is closed. | Check stop valve. | Open stop valve when required. |
| Refrigerant shortage. | Check for refrigerant shortage. Refer to the nameplate for the correct charge. | Charge the correct refrigerant amount when required. |
| Humidity in refrigerant (ice formation in expansion valve). | Check for humidity in the refrigerant. | In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant. |
| Non condensables in refrigerant. | Check for non condensables in refrigerant. | In case of suspicion of non condensables, recover, vacuum and recharge with virgin refrigerant. |
| Faulty compressor. | Check compressor (see "Compressor" on page 49). Check connections and wiring of the compressor. Check expansion valve (liquid back issue) (see "Electronic expansion valve" on page 50). Check the refrigerant charge. Refer to the nameplate for the correct charge. | Replace compressor when required (see "Replacing compressor" on page 76). Investigate reason of breakdown. Replace expansion valve when required (see "Replacing expansion valve body" on page 81). Fix possible leak. |
| Faulty expansion valve. | Check the expansion valve (see "Electronic expansion valve" on page 50). | Replace the expansion valve body (see "Replacing expansion valve body" on page 81) or motor (see "Replacing expansion valve motor" on page 82) when required. |

2.2.3.2. "U1-00" – Reverse phase or open phase

| Trigger | Effect | Reset |
|--|---------------------------|--|
| Outdoor main PCB detects incorrect power supply. | Unit will stop operating. | Manual reset via user interface. Automatic reset. |

| Possible cause | Check | Corrective action |
|-------------------------------|--|--|
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals. Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Adjust the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

| Possible cause | Check | Corrective action |
|---|---|---|
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |
| Faulty capacity adapter on outdoor PCB. | Check if the correct adapter is installed. Check if the correct spare part is installed. | Adjust capacity adapter when required. |

2.2.3.3. "U2-00" – Power supply abnormality or instantaneous power failure

| Trigger | Effect | Reset |
|--|---------------------------|---|
| There is no zero-cross detected in approximately 10 seconds (indoor unit PCB). | Unit will stop operating. | Power reset via outdoor unit. |
| Abnormal voltage drop (< 150-180 V) is detected by the DC voltage detection circuit. | Unit will stop operating. | Automatic restart after compressor stand-by of 3 minutes. |
| Abnormal voltage rise is detected by the over-voltage detection circuit. | Unit will stop operating. | Automatic restart after compressor stand-by of 3 minutes. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |
| Defective DC voltage detection circuit. | Check PCB with DC voltage detection circuit. | Replace PCB when required. |
| Defective over-voltage detection circuit. | Check PCB with over-voltage detection circuit. | Replace PCB when required. |
| Defective PAM control part. | Check PAM control part. | Replace PAM control part when required. |
| Faulty compressor. | Check compressor (see "Compressor" on page 49). Check connections and wiring of the compressor. Check expansion valve (liquid back issue) (see "Electronic expansion valve" on page 50). Check the refrigerant charge. Refer to the nameplate for correct charge. | Replace compressor when required (see "Replacing compressor" on page 76). Investigate reason of breakdown. Replace expansion valve when required (see "Replacing expansion valve body" on page 81). Fix possible leak. |
| Faulty outdoor fan motor. | Check the fan motor (see "Fan motor" on page 52). Check fan motor connections and wiring. | Replace fan motor when required (see "Replacing DC fan motor assembly" on page 79). Adjust wiring when required. |
| Momentary drop of voltage. | - | Wait until compressor restarts. |
| Momentary power failure. | - | Wait until compressor restarts. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty indoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the indoor main PCB receives power. | Restore the power to the indoor main PCB. Replace indoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

2.2.3.4. "U4-00" – Transmission abnormality between indoor unit and outdoor unit

| Trigger | Effect | Reset |
|--|---------------------------|-------------------------------|
| Data sent from outdoor unit cannot be received normally, content of the send data is abnormal. | Unit will stop operating. | Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|---|--|---|
| Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit. | Check if the power supply is conform with regulations. No fluctuations in frequency. | Adjust power supply when required. Power reset via outdoor unit. |
| Wiring abnormality between indoor unit and outdoor unit. | Check wiring between indoor unit and outdoor unit. | Adjust wiring between indoor unit and outdoor unit when required. Replace wiring between indoor unit and outdoor unit when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty outdoor fan motor. | Check the fan motor (see "Fan motor" on page 52). Check fan motor connections and wiring. | Replace fan motor when required (see "Replacing DC fan motor assembly" on page 79). Adjust wiring when required. |
| Faulty indoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the indoor main PCB receives power. | Restore the power to the indoor main PCB. Replace indoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

2.2.3.5. "UA-00" – Improper combination of indoor unit and outdoor unit

| Trigger | Effect | Reset |
|---|---------------------------|-------------------------------|
| Signal transmission between indoor unit and outdoor unit abnormality. | Unit will stop operating. | Power reset via outdoor unit. |

| Possible cause | Check | Corrective action |
|--|--|---|
| Improper combination of indoor unit and outdoor unit. | Check combination. | Adjust installation when required. |
| Wiring abnormality between indoor unit and outdoor unit. | Check wiring between indoor unit and outdoor unit. | Adjust wiring between indoor unit and outdoor unit when required. Replace wiring between indoor unit and outdoor unit when required. |
| Faulty outdoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the outdoor main PCB receives power. | Restore the power to the outdoor main PCB. Replace outdoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |
| Faulty indoor unit main PCB. | Check if the HAP LED is blinking in regular intervals (see "Main PCB" on page 55). Check if the correct spare part is installed. Check if the indoor main PCB receives power. | Restore the power to the indoor main PCB. Replace indoor main PCB when HAP LED is not blinking in regular intervals (see "Replacing main PCB" on page 89). |

2.2.3.6. “UF-00” – Wiring and piping mismatch

| Trigger | Effect | Reset |
|--|---------------------------|------------------|
| When the interunit wiring between indoor and outdoor unit is incorrect. Piping abnormality. | Unit will stop operating. | Automatic reset. |

| Possible cause | Check | Corrective action |
|--|---|--|
| Faulty wiring between indoor and outdoor unit. | Check wiring between indoor and outdoor unit (see " Wiring diagram " on page 114). | Correct wiring. |
| Refrigerant shortage (incorrect charge/leakage). | Check for refrigerant shortage. Perform a leak test. | If required, repair the leak and charge the correct amount of refrigerant. |
| Refrigerant circuit is clogged. | Check for possible blockage (Blockages can be checked by measuring the refrigerant/pipe temperature. Sudden drop in temperature could indicate a blockage. (Remark: This is not valid for the expansion valve.)). | |

2.2.4. Others

Not applicable.

2.3. Symptom based troubleshooting

2.3.1. Indoor unit

Not available yet.

2.3.2. Outdoor unit

Not available yet.

2.3.3. System

Not available yet.

2.3.4. Others

Not available yet.

2.4. Component checklist

Overview of component checklists:

| | |
|---------------------------------|----|
| Indoor unit | 46 |
| Fan motor | 46 |
| Outdoor unit..... | 47 |
| 4-way valve | 47 |
| Compressor..... | 49 |
| Electronic expansion valve..... | 50 |
| Fan motor | 52 |
| High pressure switch | 53 |
| Low pressure switch..... | 54 |
| Main PCB | 55 |
| Refrigerant thermistors..... | 57 |
| System | 59 |
| Others | 59 |

2.4.1. Indoor unit

2.4.1.1. Fan motor

| Technical specification | | Description | |
|---|--------------------------------|---|----------------------------|
| The motor has a single connector for DC power and the rotation counter feed back from the integrated pulse generator (4 pulses/revolution). | | The fan motor runs on a fixed speed to supply the required air flow rate. | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Indoor unit" on page 117. | See "Indoor unit" on page 114. | Not applicable. | Not applicable. |
| Check procedure | | | |
| Mechanical check | | | |

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove casing when required.
4. Check the state of the rotor, replace the rotor if damaged, deformed, cracked or broken.
5. Check the motor shaft bearing friction, only perform electrical check if motor runs with low shaft bearing friction. Replace fan motor if friction is abnormal.

Electrical check

General

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove casing when required.
4. Check fuse on indoor PCB, replace if blown.



WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

5. Check if fan motor connector is plugged into PCB.
6. Power the Daikin unit.
7. Check power supply, the measured voltage must be 198 - 240 VAC, if not replace indoor PCB.

2.4.2. Outdoor unit

2.4.2.1. 4-way valve

| Technical specification | | Description | |
|---------------------------------|---------------------------------|---|---------------------------------|
| - | | The 4-way valve directs the super heated refrigerant discharged from the compressor to the indoor heat exchanger in case of heating operation or to the outdoor heat exchanger in case of defrosting and cooling operation. | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |
| Mechanical check | | | |

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required.
4. Loosen the screw and remove the coil from the 4-way valve (refer to "Replacing 4-way valve coil" on page 75).



WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

5. Unplug 4-way valve connector from applicable PCB.
6. Switch on the Daikin unit via the user interface, start cooling/defrost operation.
If the temperature after the heat exchanger drops, proceed with next step.
If the temperature after the heat exchanger rises, the 4-way valve is stuck in heating position, replace the 4-way valve body (refer to "Replacing 4-way valve body" on page 73).
If the temperature after the heat exchanger does not rise, check the refrigerant pressure by connecting a manifold to one of the service ports.
 - If no pressure is measured, perform a pressure test and fix any leaks.
 - If pressure is measured, the 4-way valve is stuck in the middle, confirm by determining the position of the 4-way valve as described below and replace the 4-way valve (refer to "Replacing 4-way valve body" on page 73).



CAUTION - RISK OF LIQUID ENTERING THE COMPRESSOR

To prevent damage to the compressor the step below must only be done once.

7. While listening to the 4-way valve, place a round permanent magnet on the core of the solenoid valve. If you do not hear the 4-way valve switching, it must be replaced (refer to "Replacing 4-way valve body" on page 73).

Electrical check

1. Switch off Daikin unit via the user interface.
2. Switch off Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required.
4. Switch on the Daikin unit, start heating operation.

**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

5. Measure the voltage on 4-way valve connector: pin 1-3. If the measured voltage does not range 220-240 VAC during switching / 15 VAC after switching, unplug 4-way valve connector from PCB and measure the voltage directly on the PCB: pin 1-3 of 4-way valve connection.
 - If the voltage, measured directly on the PCB does not range 220-240 VAC during switching / 15 VAC after switching, replace main PCB.
 - If the voltage, measured directly on the PCB does range 220-240 VAC during switching / 15 VAC after switching, replace the 4-way valve coil (refer to ["Replacing 4-way valve coil" on page 75](#)).

**WARNING: RISK OF FIRE**


When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

6. Unplug 4-way valve connector from PCB and measure the resistance of the 4-way valve coil. If the measured resistance does not range 1000 - 2000 Ω , replace the 4-way valve coil (refer to ["Replacing 4-way valve coil" on page 75](#)).
7. Switch on the Daikin unit, start cooling/defrost operation.

If the temperature after the plate type heat exchanger rises, the control of the 4-way valve is wrong. Replace main PCB.

Determine the position of the 4-way valve

1. Switch off Daikin unit via the user interface.
2. Switch off Daikin unit with the field supplied circuit breaker.
3. Slide a magnet over the front and the rear of the 4-way valve body and sense the attraction of the magnet to determine the valve position.
4. If the magnet is attracted in positions A,A' or B,B', the 4-way valve is OK; if the magnet is attracted in positions C,C' the 4-way valve must be replaced (refer to ["Replacing 4-way valve body" on page 73](#)).



2.4.2.2. Compressor

| Technical specification | | Description | |
|--|---------------------------------|---|---------------------------------|
| Type: inverter driven, swing double swing. | | The compressor compresses the refrigerant in the refrigerant circuit. | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |
| Preliminary check | | | |

1. Check if the Daikin unit is connected to earth.
2. Check if the stop valve is open.

Mechanical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Open the compressor insulation.
5. Check if the condition of the compressor dampers and piping is correct.

Electrical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required.
4. Open the compressor insulation.
5. Switch on the Daikin unit and measure the U, V, W inverter voltages. All voltages must be identical, if not, replace the inverter PCB.
6. Switch off the Daikin unit via the user interface.
7. Switch off the Daikin unit with the field supplied circuit breaker.



INFORMATION

Note the position of the cables on the compressor wire terminals to allow identical wiring during reinstallation.

8. Disconnect the Faston connectors U, V and W from the compressor, take picture.
9. Measure the compressor motor windings U-V, V-W and U-W (refer to "Product specific information" on page 121).
10. Megger the compressor using 500 or 1000 VDC, the insulation must be higher than 3 MΩ.
11. Replace the compressor if the windings and/or insulation measurements fail (refer to "Replacing compressor" on page 76).
12. Run the compressor and measure the current in each phase; the current for each phase should be identical (refer to "Product specific information" on page 121). In that case it can be decided to preventively replace the compressor (refer to "Replacing compressor" on page 76).



2.4.2.3. Electronic expansion valve

| Technical specification | | Description | |
|--|---------------------------------|---|---------------------------------|
| The electronic expansion valve has a hermetically sealed body with a slide-on stepping motor drive coil (480 pulses from fully closed to fully open position). | | The electronic expansion valve is used: <ul style="list-style-type: none"> To control the flow of refrigerant. Depending on location, the trigger point is sub-cool or superheat. To stop the flow of refrigerant completely when closing (= 0 pulses). | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |
| Mechanical check | | | |

- Switch off the Daikin unit via the user interface.
- Switch off the Daikin unit with the field supplied circuit breaker.
- Switch on the Daikin unit and listen to the expansion valve assembly, if the expansion valve body does not create a latching sound, continue with the electrical check.
- Switch off the Daikin unit via the user interface.
- Switch off the Daikin unit with the field supplied circuit breaker.
- Remove plate work when required (refer to "Basic removal" on page 67).
- Remove the expansion valve coil from the expansion valve body.
- Slide the magnet (tool part N° 9950038) over the expansion valve body and gently rotate the magnet to manually operate the expansion valve body clockwise (closing) and counterclockwise (opening).
- If it is not possible to open the expansion valve body with the magnet, the expansion valve body is blocked and the expansion valve body must be replaced (refer to "Replacing expansion valve body" on page 81).

Electrical check

- Switch off the Daikin unit via the user interface.
- Switch off the Daikin unit with the field supplied circuit breaker.
- Remove plate work when required (refer to "Basic removal" on page 67).
- Check if the electrical connector of the expansion valve coil was correctly connected to the PCB, if not, connect the electrical connector.
- Disconnect the electrical connector of the expansion valve coil and check the continuity between below pins using a multi meter. It should be \pm the same value.
 - Connector pin 1-6: connected
 - Connector pin 2-6: connected
 - Connector pin 3-6: connected
 - Connector pin 4-6: connected



6. If one or more of the windings have no continuity, replace the expansion valve coil.

2.4.2.4. Fan motor

| Technical specification | | Description | |
|---|---------------------------------|---|---------------------------------|
| The motor has a single connector for DC power and the rotation counter feed back from the integrated pulse generator (4 pulses/revolution). | | The fan motor runs on a fixed speed to supply the required air flow rate. | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |
| Mechanical check | | | |

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "[Basic removal](#)" on page 67).
4. Check the state of the propeller, replace the propeller if damaged, deformed, cracked or broken (refer to "[Replacing propeller fan blade assembly](#)" on page 93).
5. Check the motor shaft bearing friction, only perform electrical check if motor runs with low shaft bearing friction. Replace fan motor if friction is abnormal (refer to "[Replacing DC fan motor assembly](#)" on page 79).

Electrical check

General

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "[Basic removal](#)" on page 67).
4. Check fuse on PCB, replace if blown.

**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

5. Check if fan motor connector is plugged into PCB.
6. Power the Daikin unit.
7. Check power supply, the measured voltage must be 198 - 240 VAC, if not replace main PCB (refer to "[Replacing main PCB](#)" on page 89).

2.4.2.5. High pressure switch

| Technical specification | | Description | |
|---|---|--|---|
| The high pressure switch has a normally closed contact. If the pressure exceeds 41.7 (+0 / -1) bar the contact will open; if the pressure drops below 32 (±2) bar the contact will close. | | The high pressure switch is a safety component that stops the compressor if overpressure is detected in the refrigerant circuit. | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |
| Electrical check | | | |

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to ["Basic removal" on page 67](#)).
4. Disconnect the high pressure switch connector from applicable PCB.
5. Recover the refrigerant.
6. Pressurize the refrigerant circuit at 41.7 bar with nitrogen.
7. Measure the switch contacts between high pressure switch connector: pins 1-2; the switch must be open.
8. Replace the high pressure switch if the contact is not open (refer to ["Replacing high pressure switches" on page 86](#)).
9. Lower the refrigerant circuit pressure to 30 bar.
10. Measure the switch contacts between high pressure switch connector: pins 1-2; the switch must be closed.
11. Replace the high pressure switch if the contact is not closed (refer to ["Replacing high pressure switches" on page 86](#)).

2.4.2.6. Low pressure switch

| Technical specification | | Description | |
|---|---------------------------------|---|---------------------------------|
| The low pressure switch has a normally closed contact. If the pressure drops below -0,31 ($\pm 0,2$) bar, the contact will open. When the pressure rises above 0,51 ($\pm 0,3$) bar the contact will close again. | | The low pressure switch is a safety component that stops the compressor if under-pressure is detected in the refrigerant circuit. | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |
| Electrical check | | | |

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Disconnect the low pressure switch connector from applicable PCB.
5. Recover the refrigerant.
6. Connect vacuum pump to gas service port and vacuum to -0,5 bar.
7. Measure the switch contacts between low pressure switch connector: pins 1-2; the switch must be open.
8. Replace the low pressure switch if the contact is not open (refer to "Replacing high pressure switches" on page 86).
9. Increase the refrigerant circuit pressure to 1 bar.
10. Measure the switch contacts between low pressure switch connector: pins 1-2; the switch must be closed.
11. Replace the low pressure switch if the contact is not closed (refer to "Replacing high pressure switches" on page 86).

2.4.2.7. Main PCB

| Technical specification | | Description | |
|---------------------------------|---------------------------------|---------------------------------|---------------------------------|
| | | | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |
| Mechanical check | | | |

Not applicable.

Electrical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Switch on the Daikin unit with the field supplied circuit breaker.
5. Switch on the Daikin unit via the user interface.
6. Check if the HAP LED is blinking in regular intervals (1/0,5 sec), if not blinking, replace the main PCB board (refer to "Replacing main PCB" on page 89).
7. Measure the supply voltage to the main PCB board: there should be ± 220 V between brown and blue cable. If not correct voltage, replace the electrical noise filter PCB (refer to "Replacing electrical noise filter" on page 80).
8. Switch off the Daikin unit via the user interface.
9. Switch off the Daikin unit with the field supplied circuit breaker.
10. Remove plate work when required.
11. Open the compressor insulation.
12. Remove the terminal cover of compressor wiring.



WARNING: RISK OF ELECTROCUTION

The smoothing capacitor must discharge below 10 VDC before removing the compressor wiring.


13. Measure the voltage on S70: pin 7-4 and wait until it drops below 10 VDC.



INFORMATION

Note the position of the cables on the compressor wire terminals to allow identical wiring during reinstallation.

14. Disconnect the compressor wires and connect the compressor wires to the Inverter Analyzer (SPP number 1368521).



15. Power the Daikin unit.



WARNING

Electrical shock hazard. Do not touch live wires.

16. Activate the inverter test (refer to ["Component checklist" on page 121](#)).

17. Check that all LED's on the Inverter Analyzer are lit; if not, replace the inverter board (refer to ["Replacing inverter PCB" on page 87](#)).

18. Switch off the Daikin unit with the field supplied circuit breaker.

19. Wait a few minutes and confirm that the LED's on the Inverter Analyzer are off.

20. Disconnect the Inverter Analyzer from the U V W wiring.



CAUTION

When wiring the compressor, observe UV W as indicated on the compressor.

21. Reconnect the U V W leads to the compressor.

2.4.2.8. Refrigerant thermistors

| Technical specification | | Description | |
|---|---------------------------------|--|---------------------------------|
| A single type of thermistor is used; the resistance vs. temperature characteristics is shown in below table "Thermistor resistance / temperature characteristics (type 1)". | | The thermistors are used to measure the temperature at multiple locations inside the Daikin unit. The measured temperatures are processed by the main board. | |
| Location | | | |
| Piping diagram | Wiring diagram | Switch box | Component overview of unit |
| See "Outdoor unit" on page 117. | See "Outdoor unit" on page 115. | See "Outdoor unit" on page 122. | See "Outdoor unit" on page 119. |
| Check procedure | | | |

Mechanical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Locate the thermistor and check if thermal contact with the piping or ambient is ensured.

Electrical check



INFORMATION

If a thermistor check fails, replace the thermistor.

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required.
4. From the table in the appendix ("Component checklist" on page 121), select the thermistor that must be checked.
5. Measure the temperature of the thermistor using a contact thermometer.



WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

6. Unplug the connector from the appropriate PCB and measure the resistance between the pins listed in the table in the appendix ("Component checklist" on page 121).
 - Compare the measured resistance with the range determined by the lower and higher temperature.
7. If the measured resistance does not match the listed value, the thermistor must be replaced.



INFORMATION

All thermistors have a tolerance of 5%.

E.g. R3T air thermistor - main PCB - connector S90: pin 1-2 type 1:

- Measured temperature with contact thermometer: 23.1°C.
- Unplug the sensor and measure the resistance between S90: 1-2: 21.86 kΩ.
- The resistance values are defined by below table "Thermistor resistance / temperature characteristics (type 1)":
 - Resistance at 23°C: 21.85 kΩ.
 - Resistance at 24°C: 20.90 kΩ.

- The measured value 21.86 kΩ is inside the range, thermistor R3T passes the check.

**INFORMATION**

The user interface allows to monitor most thermistors.

If the measured resistance of the thermistor matches the temperature measured with the contact thermometer but the temperature for the corresponding thermistor is not correct on the user interface display, replace applicable PCB.

Table 2-1: Thermistor resistance / temperature characteristics (type 1)

| T °C | kΩ | T °C | kΩ | T °C | kΩ | T °C | kΩ | T °C | kΩ |
|------|--------|------|-------|------|-------|------|-------|------|------|
| -20 | 197.81 | 0 | 65.84 | 20 | 25.01 | 40 | 10.63 | 60 | 4.87 |
| -19 | 186.53 | 1 | 62.54 | 21 | 23.91 | 41 | 10.21 | 61 | 4.70 |
| -18 | 175.97 | 2 | 59.43 | 22 | 22.85 | 42 | 9.81 | 62 | 4.54 |
| -17 | 166.07 | 3 | 56.49 | 23 | 21.85 | 43 | 9.42 | 63 | 4.38 |
| -16 | 156.80 | 4 | 53.71 | 24 | 20.90 | 44 | 9.06 | 64 | 4.23 |
| -15 | 148.10 | 5 | 51.09 | 25 | 20.00 | 45 | 8.71 | 65 | 4.08 |
| -14 | 139.94 | 6 | 48.61 | 26 | 19.14 | 46 | 8.37 | 66 | 3.94 |
| -13 | 132.28 | 7 | 46.26 | 27 | 18.32 | 47 | 8.05 | 67 | 3.81 |
| -12 | 125.09 | 8 | 44.05 | 28 | 17.54 | 48 | 7.75 | 68 | 3.68 |
| -11 | 118.34 | 9 | 41.95 | 29 | 16.80 | 49 | 7.46 | 69 | 3.56 |
| -10 | 111.99 | 10 | 39.96 | 30 | 16.10 | 50 | 7.18 | 70 | 3.44 |
| -9 | 106.03 | 11 | 38.08 | 31 | 15.43 | 51 | 6.91 | 71 | 3.32 |
| -8 | 100.41 | 12 | 36.30 | 32 | 14.79 | 52 | 6.65 | 72 | 3.21 |
| -7 | 95.14 | 13 | 34.62 | 33 | 14.18 | 53 | 6.41 | 73 | 3.11 |
| -6 | 90.17 | 14 | 33.02 | 34 | 13.59 | 54 | 6.65 | 74 | 3.01 |
| -5 | 85.49 | 15 | 31.50 | 35 | 13.04 | 55 | 6.41 | 75 | 2.91 |
| -4 | 81.08 | 16 | 30.06 | 36 | 12.51 | 56 | 6.18 | 76 | 2.82 |
| -3 | 76.93 | 17 | 28.70 | 37 | 12.01 | 57 | 5.95 | 77 | 2.72 |
| -2 | 73.01 | 18 | 27.41 | 38 | 11.52 | 58 | 5.74 | 78 | 2.64 |
| -1 | 69.32 | 19 | 26.18 | 39 | 11.06 | 59 | 5.14 | 79 | 2.55 |
| | | | | | | | | 80 | 2.47 |

Table 2-2: Thermistor resistance / temperature characteristics (type 2)

| T °C | kΩ | T °C | kΩ | T °C | kΩ | T °C | kΩ | T °C | kΩ |
|------|--------|------|-------|------|-------|------|-------|------|------|
| -20 | 192.08 | 0 | 64.17 | 20 | 24.45 | 40 | 10.41 | 60 | 4.87 |
| -19 | 181.16 | 1 | 60.96 | 21 | 23.37 | 41 | 10.00 | 61 | 4.70 |
| -18 | 170.94 | 2 | 57.94 | 22 | 22.35 | 42 | 9.61 | 62 | 4.54 |
| -17 | 161.36 | 3 | 55.08 | 23 | 21.37 | 43 | 9.24 | 63 | 4.38 |
| -16 | 152.38 | 4 | 52.38 | 24 | 20.45 | 44 | 8.88 | 64 | 4.23 |
| -15 | 143.96 | 5 | 49.83 | 25 | 19.56 | 45 | 8.54 | 65 | 4.08 |
| -14 | 136.05 | 6 | 47.42 | 26 | 18.73 | 46 | 8.21 | 66 | 3.94 |
| -13 | 128.63 | 7 | 45.14 | 27 | 17.93 | 47 | 7.90 | 67 | 3.81 |
| -12 | 121.66 | 8 | 42.98 | 28 | 17.17 | 48 | 7.60 | 68 | 3.68 |
| -11 | 115.12 | 9 | 40.94 | 29 | 16.45 | 49 | 7.31 | 69 | 3.56 |
| -10 | 108.96 | 10 | 39.01 | 30 | 15.76 | 50 | 7.04 | 70 | 3.44 |
| -9 | 103.18 | 11 | 37.18 | 31 | 15.10 | 51 | 6.78 | 71 | 3.32 |
| -8 | 97.73 | 12 | 35.45 | 32 | 14.48 | 52 | 6.53 | 72 | 3.21 |
| -7 | 92.61 | 13 | 33.81 | 33 | 13.88 | 53 | 6.53 | 73 | 3.11 |
| -6 | 87.79 | 14 | 32.25 | 34 | 13.31 | 54 | 6.53 | 74 | 3.01 |
| -5 | 83.25 | 15 | 30.77 | 35 | 12.77 | 55 | 6.29 | 75 | 2.91 |
| -4 | 78.97 | 16 | 29.37 | 36 | 12.25 | 56 | 6.06 | 76 | 2.82 |
| -3 | 74.94 | 17 | 28.05 | 37 | 11.76 | 57 | 5.84 | 77 | 2.72 |
| -2 | 71.14 | 18 | 26.78 | 38 | 11.29 | 58 | 5.43 | 78 | 2.64 |
| -1 | 67.56 | 19 | 25.59 | 39 | 10.84 | 59 | 5.05 | 79 | 2.55 |
| | | | | | | | | 80 | 2.47 |

2.4.3. System

Not applicable.

2.4.4. Others

Not applicable.

2.5. Other capacity range

Not applicable.

Part 3. Repair

This part contains the following chapters:

| | |
|---------------------------------------|----|
| Refrigerant repair procedures | 61 |
| Service tools | 65 |
| Unit specific repair procedures | 66 |

3.1. Refrigerant repair procedures

Overview:

| | |
|-----------------------------------|----|
| Refrigerant piping handling | 61 |
| Recovery procedure | 61 |
| Refrigerant pump down | 63 |
| Piping repair procedures | 64 |


3.1.1. Refrigerant piping handling

- Make sure the applied pressure is never higher than the unit design pressure as indicated on the nameplate (PS).
- Work according the F-gas regulation and/or local regulations.
- Make sure the correct amount according the F-gas regulation label on the unit (factory + additional where required) of refrigerant is charged after repair.
- Make sure to use the appropriate equipment and tools according to the refrigerant and unit type.
- Charge non-azeotropic refrigerant (e.g. R-410A) always in a liquid state.
- R32 can be charged in gas phase.
- Make sure to use a digital scale (no charging cylinder).
- Execute correct vacuum drying procedure after repair work:
 - -0,1 MPa / -760 mmHg / -750 Torr / -1 bar for at least 1 hour.
 - Connect the unit according the available service ports, refer to "[Recovery procedure](#)" on page 61.
 - Use related field setting where necessary to open expansion valve/solenoid valve.

3.1.2. Recovery procedure

3.1.2.1. Outdoor unit casing

1. Switch off the Daikin unit via the user interface.
2. Manually open the expansion valve (located on the outdoor unit).
3. Connect the vacuum pump, manifold, recovery unit and refrigerant bottle to the service port as shown below.
For the location of the service ports, refer to "[Outdoor unit](#)" on page 117.

In case of 1 service port at the stop valves**Figure 3-1: 1 service port at the stop valves****INFORMATION**

See instruction of the recovery pump supplier how to recover the refrigerant.


In case of 2 service ports at the stop valves

Connect both stop valve service ports to the manifold.

In case of 3 service ports at the stop valves

Connect 1 hose to the suction stop valve service port and 1 hose to the service port between the expansion valve and outdoor H/E.

Figure 3-2: 3 service ports at the stop valves



INFORMATION

See instruction of the recovery pump supplier how to recover the refrigerant.

3.1.3. Refrigerant pump down

This unit is equipped with an automatic pump down operation which will collect all refrigerant from the field piping and indoor unit in the outdoor unit. To protect the environment, make sure to perform the following pump down operation when relocating the unit.



WARNING: RISK OF EXPLOSION

- When the refrigeration circuit has a leak, do not execute pump down with the compressor.
- Use recovery system into separate cylinder.
- Warning, explosive hazard exists when executing pump down.
- Pump down with compressor can lead to self-combustion due to air entering during pump down.



INFORMATION

Some outdoor units are equipped with a low pressure switch to protect the compressor by switching it off. Never short-circuit the low pressure switch during pump down operation!

3.1.3.1. Small outdoor unit

1. Remove the valve lid from liquid stop valve and gas stop valve.
2. Carry out forced cooling operation.

**CAUTION**

Refer to Installer Reference Guide for 'Forced cooling operation' procedure.

3. After 5-10 min (after only 1-2 min in case of very low Ta < -10°C), close the liquid stop valve with a hexagonal wrench.
4. Check on manifold if vacuum is reached, close gas stop valve and forced cooling operation.

3.1.3.2. Large outdoor unit

1. Stop all demands for the Daikin unit.
2. Switch OFF / ON the power supply of the outdoor unit.
3. Carry out forced cooling operation.

**CAUTION**

Refer to Installer Reference Guide for 'Forced cooling operation' procedure.

4. The compressor and outdoor fan will start automatically.
5. Request heating via remote controller to prevent HE freeze-up.
6.
 - a. Check on manifold if vacuum is reached, close gas stop valve and forced cooling operation.
 - b. Once operation stops (after 3 to 5 minutes), close the liquid and the gas stop valve.
7. Pump down is now finished. U4 may be displayed on the remote controller, this is not a malfunction.
8. (After "pump down/forced defrost" is finished or stopped, keep the circulation pump running for at least 5 minutes.)
9. Switch OFF the power supply of the outdoor unit.

**NOTE**

- Make sure to re-open both stop valves before restart operation of the unit.
- After a finished or stopped pump down, the unit will perform a test run at first operation (same as during commissioning).


3.1.4. Piping repair procedures

- Make sure to cover open pipe ends during repair work so no dust or moisture can enter.
- Make sure to re-apply insulation removed during repair.
- Pipe expansion / flare making:
 - Remove any burrs on the cut surface and use correct tool such as reamer or scraper (note that excessive deburring can thin the pipe walls and cause cracking of the pipe).
 - Make sure the flare has the correct size (use a flare gauge).
 - Make sure no particles remain in the piping.
 - Apply just a drop of refrigerant oil on the inner surface of the flare.
 - Make sure the flare connection is tightened with the correct torque (torque values refer to installation manual).
- Brazing:
 - Use correct brazing tool.
 - Use a phosphor copper filler metal (silver composition of 0 to 2%). Do not use flux material.
 - Flush the piping before brazing with nitrogen to avoid oxidation of the inside of the copper tubes (nitrogen purity ≥ 99,99%).

3.2. Service tools

For an overview of the applicable service tools, please check the Daikin Business Portal: <http://www.mydaikin.eu>

Go to the tab “After-sales support” on the left side and then select “Technical support”.



You will then find a button “Service tools” which gives you an overview on which service tool to use for which product. Also additional information on the service tool (instruction, latest software) can be found there.

3.3. Unit specific repair procedures

Overview:

| | |
|---|----|
| Indoor unit..... | 66 |
| Outdoor unit..... | 67 |
| Basic removal..... | 67 |
| Replacing thermistor..... | 71 |
| Replacing 4-way valve body..... | 73 |
| Replacing 4-way valve coil..... | 75 |
| Replacing accumulator assembly..... | 75 |
| Replacing compressor..... | 76 |
| Replacing DC fan motor assembly..... | 79 |
| Replacing electrical noise filter..... | 80 |
| Replacing expansion valve body..... | 81 |
| Replacing expansion valve motor..... | 82 |
| Replacing solenoid valve..... | 84 |
| Replacing solenoid valve coil..... | 85 |
| Replacing high pressure switches..... | 86 |
| Replacing inverter PCB..... | 87 |
| Replacing low pressure switch..... | 88 |
| Replacing main PCB..... | 89 |
| Replacing propeller fan blade assembly..... | 93 |

3.3.1. Indoor unit


Not applicable.

3.3.2. Outdoor unit

3.3.2.1. Basic removal


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Loosen and remove the 9 screws (1) that fix the top plate assembly (2).
4. Lift the top plate assembly (2) and remove it from the Daikin unit.

Figure 3-3: Removing the top plate assembly



5. Loosen and remove the screw (1) that fixes the front plate (2).
6. Lift the front plate (2) and remove it from the unit.

Figure 3-4: Removing the front plate




7. Loosen and remove the 11 screws (1) that fix the front plate assembly (3).
8. Loosen and remove the screw (2) that fixes the front plate assembly (3).

**CAUTION**

The screw (2) has a different length.

9. Lift the front plate assembly (3) and remove it from the unit.


Figure 3-5: Removing the front plate assembly



10. Loosen and remove the screw (1) that fixes the cover (2).

11. Remove the cover (1) from the unit.


Figure 3-6: Removing the cover



12. Loosen and remove the screw (1) that fixes the piping cover (2).

13. Remove the piping cover (2) from the unit.

Figure 3-7: Removing the piping cover



14. Loosen the thermistor fixing plate (2).

15. Slightly twist the right side of the thermistor fixing plate (2), and gently pull the left side of the thermistor fixing plate (2) until it unlatches.

16. Slide the thermistor fixing plate (2) until it detaches from the right side plate (4).

17. Turn over the thermistor fixing plate (2) and unlatch the thermistor cover.

18. Remove thermistor R1T (1) from the thermistor fixing plate (2).


19. Remove the thermistor fixing plate (2).

20. Guide the thermistor R1T (1) into the unit.

21. Loosen and remove the 5 screws (3) that fix the right side plate (4).

22. Remove the right side plate (4) from the unit.

Figure 3-8: Removing the right side plate




3.3.2.2. Replacing thermistor

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).


| Thermistor | Processed on PCB | Connector / colour |
|---|------------------|--------------------|
| R1T (air) | Main | X11A |
| R2T (discharge) | Main | X12A / yellow |
| R3T (suction) | Main | X12A / green |
| R4T (heat exchanger) | Main | X12A / red |
| R5T (heat exchanger middle) | Main | X12A / white |
| R6T (liquid) | Main | X13A: / blue |
| R7T, R8T (Positive Temperature Coefficient) | - | - |

Figure 3-9: Thermistor location



4. Cut the tie wraps (1) that fix the insulation (3) and the thermistor wire (2).
5. Cut the insulation (3) and remove it.
6. Pull the clip (5) that fixes the thermistor (6).
7. Remove the thermistor (6) from the thermistor holder (4).

Figure 3-10: Replacing a thermistor



Installation

1. Proceed in reverse order.

3.3.2.3. Replacing 4-way valve body

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Recover the refrigerant (refer to "Refrigerant repair procedures" on page 61).
5. Remove the main PCB (refer to "Replacing main PCB" on page 89).
6. Connect a nitrogen hose to the outdoor suction service port.
7. Attach a hose with core-depressor to allow the release of the nitrogen.
8. Cut the 4-way valve pipes (1).
9. Remove the 4-way valve (2).




CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

10. Supply nitrogen to the piping circuit.
11. Using an oxygen acetylene torch, heat a solder connection of the 4-way valve (2).
12. When the solder material is liquid, pull the 4-way valve pipe (1).
13. Repeat steps 11 and 12 for the 3 remaining 4-way valve pipes (1).
14. Cut the nitrogen supply when the piping has cooled down.

Figure 3-11: Removing 4-way valve body



Installation



CAUTION

Overheating the 4-way valve will damage or destroy it.



INFORMATION

Install the putty on the 4-way valve.
Replace all tie wraps that were cut during removal.

1. Wrap a wet rag around the 4-way valve (2).
2. Proceed in reverse order.

3.3.2.4. Replacing 4-way valve coil

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Cut the tie wraps that fix the 4-way valve coil wire.




WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

5. Unplug the 4-way valve connector from the main PCB.
6. Loosen and remove the screw (1) that fixes the 4-way valve coil (2).
7. Remove the 4-way valve coil (2) from the 4-way valve.

Figure 3-12: Removing 4-way valve body



1. Screw

2. 4-way valve coil

Installation



INFORMATION

Replace all tie wraps that were cut during removal.

1. Proceed in reverse order.

3.3.2.5. Replacing accumulator assembly

Not applicable.

3.3.2.6. Replacing compressor

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Recover the refrigerant (refer to "Refrigerant repair procedures" on page 61).
5. Remove the compressor jacket.
6. Remove the lower propeller fan (refer to "Replacing propeller fan blade assembly" on page 93).
7. Connect a nitrogen hose to the outdoor suction service port.
8. Attach a hose with core-depressor to allow the release of the nitrogen.
9. Cut the 2 tie wraps that fix the power and communication wires to the stop valve mounting plate.
10. Loosen and remove the 4 screws (1) that fix the stop valves.




CAUTION

The 2 screws that are removed in the next step must be re-installed in the same location upon reassembly.

11. Loosen and remove the 2 screws (2) that fix the stop valve mounting plate (3).
12. Lift and remove the stop valve mounting plate (3).

Figure 3-13: Removing stop valve mounting plate




1. Screw
2. Screw

3. Stop valve mounting plate





13. Cut the tie wrap that fixes the R2T thermistor wiring and put the R2T thermistor (2) aside.
14. Put aside the DC fan motor wiring.
15. Remove the terminal cover and unplug the compressor wiring (3).
16. Remove the rubber grommet (6) from the compressor.
17. Cut the compressor pipes (1) below the soldered joint.

18. Loosen and remove the 3 bolts (5) that fix the compressor (7).
19. Remove the compressor (7).
20. Remove the dampers (4) from the compressor (7).
21. Supply nitrogen to the piping circuit.
22. Heat the 2 compressor pipes (1) using an oxygen acetylene torch.
23. When the solder is liquid, remove the 2 compressor pipes (1).
24. Cut the nitrogen supply when the piping has cooled down.

Figure 3-14: Removing compressor



Installation

| | |
|---|---|
|  | CAUTION The oil in the compressor is hygroscopic. Remove the caps from the compressor piping as late as possible. |
|  | INFORMATION Before installing a new compressor, determine the cause of the compressor failure and take all required corrective actions. |
|  | INFORMATION If the dampers are worn, replace the dampers. The bushings inside the dampers are recuperated for use with the new dampers. |
|  | INFORMATION Install the compressor sound insulation in the same location. |


1. Check damper status, replace when worn.
2. First install the 3 (new) dampers on the new compressor.
3. When installing the new compressor, remove the caps from the compression pipe and the suction pipe as late as possible.
4. When soldering the compressor pipes, cover the compressor pipes with a wet cloth to prevent overheating the compressor (and the oil in the compression pipe).
5. Proceed in reverse order.

3.3.2.7. Replacing DC fan motor assembly

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the propeller fan (refer to "[Replacing propeller fan blade assembly](#)" on page 93).
4. Disconnect the fan connector (1 or 2).
5. Cut the tie wraps (3)
6. Remove the fan motor cable (4) from the cable clamp (5).
7. Guide the fan motor cable (4) through the opening between the partition plate (6) and the stop valve mounting plate (7).
8. Loosen and remove the 4 screws (9) that fix the fan motor (8).
9. Remove the fan motor (8) from the unit.

Figure 3-15: Removing the DC fan motor assembly



Installation

1. Proceed in reverse order.



CAUTION

Plug in the fan connector before installing the plate work (this allows to trace the DC fan motor wiring).
Do not swap DC fan motor connections (main PCB: upper connector = M2F = lower fan, lower connector = M1F = upper fan).

3.3.2.8. Replacing electrical noise filter

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main PCB Assy (refer to "Replacing main PCB" on page 89).




WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

4. Unplug the connectors (2, 4, 5).
5. Remove the wiring from the screw terminals (1, 3).
6. Unplug the ground wires (6).
7. Unlock the 9 standoffs (8) that fix the electrical noise filter PCB.
8. Remove the electrical noise filter PCB (7) from the main PCB assembly.

Figure 3-16: Removing the electrical noise filter



1. Screw terminal
2. Connector
3. Screw terminal
4. Connector

5. Connector
6. Ground wire
7. Electrical noise filter PCB
8. Standoff

Installation



INFORMATION

Replace all tie wraps that were cut during removal.

1. Proceed in reverse order.

3.3.2.9. Replacing expansion valve body

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Recover the refrigerant (refer to "Refrigerant repair procedures" on page 61).
5. Remove the expansion valve motor (refer to "Replacing expansion valve motor" on page 82).
6. Connect a nitrogen hose to the outdoor suction service port.
7. Attach a hose with core-depressor to allow the release of the nitrogen.
8. Cut the 2 expansion valve pipes (1).
9. Remove the expansion valve (2).




CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

10. Supply nitrogen to the piping circuit.
11. Using an oxygen acetylene torch, heat the 2 expansion valve pipes (1).
12. When the solder material is liquid, pull the 2 expansion valve pipes (1).
13. Cut the nitrogen supply when the piping has cooled down.

Figure 3-17: Removing expansion valve



1. Expansion valve pipe

2. Expansion valve

Installation

1. Wrap a wet rag around the expansion valve Y1E (3).



WARNING

Overheating the expansion valve Y1E will damage or destroy it.

2. Proceed in reverse order.

3.3.2.10. Replacing expansion valve motor

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to ["Basic removal" on page 67](#)).
4. Turn the expansion valve Y1E motor (1) 1/8th turn counter clockwise to unlock it.
5. Remove the expansion valve Y1E motor (1) from the expansion valve Y1E (2).
6. Cut all tie wraps that fix the expansion valve motor wiring.




WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

7. Unplug the expansion valve motor connector from the Main PCB.

Figure 3-18: Removing expansion valve motor



Installation




INFORMATION

Replace all tie wraps that were cut during removal.

1. Proceed in reverse order.
2. When installing the expansion valve motor (1), lock it on the expansion valve (2).

Figure 3-19: Removing expansion valve motor



3.3.2.11. Replacing solenoid valve

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Recover the refrigerant (refer to "Refrigerant repair procedures" on page 61).
5. Connect a nitrogen hose to the outdoor suction service port.
6. Attach a hose with core-depressor to allow the release of the nitrogen.
7. Remove the solenoid valve coil (refer to "Replacing solenoid valve coil" on page 85).
8. Connect a nitrogen hose to the outdoor suction service port.
9. Attach a hose with core-depressor to allow the release of the nitrogen.
10. Cut the 2 solenoid valve pipes (1).
11. Remove the solenoid valve (2).




CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

12. Supply nitrogen to the piping circuit.
13. Using an oxygen acetylene torch, heat the 2 solenoid valve pipes (1).
14. When the solder material is liquid, pull the 2 solenoid valve pipes (1).
15. Cut the nitrogen supply when the piping has cooled down.

Figure 3-20: Removing solenoid valve



1. Solenoid valve pipe

2. Solenoid valve

Installation

1. Wrap a wet rag around the solenoid valve.



WARNING

Overheating the solenoid valve will damage or destroy it.

2. Proceed in reverse order.

3.3.2.12. Replacing solenoid valve coil

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Recover the refrigerant (refer to "Refrigerant repair procedures" on page 61).
5. Connect a nitrogen hose to the outdoor suction service port.
6. Attach a hose with core-depressor to allow the release of the nitrogen.
7. Loosen and remove the screw (1) that fixes the solenoid valve coil (2) to the solenoid valve (3).
8. Remove the solenoid valve coil (2) from the solenoid valve (3).
9. Cut tie wraps that fix the solenoid valve coil (2) wiring.




WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

10. Unplug the solenoid valve coil connector from the Main PCB.

Figure 3-21: Removing solenoid valve coil



1. Screw

2. Solenoid valve coil

3. Solenoid valve

Installation



INFORMATION

Replace all tie wraps that were cut during removal.

1. Proceed in reverse order.

3.3.2.13. Replacing high pressure switches

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Recover the refrigerant (refer to "Refrigerant repair procedures" on page 61).
5. Connect a nitrogen hose to the outdoor suction service port.
6. Attach a hose with core-depressor to allow the release of the nitrogen.
7. Unplug the high pressure switch connector (3).
8. Cut the tie wrap (4).
9. Cut the high pressure switch S1PH pipe (5).
10. Remove the high pressure switch (1 or 2).




CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

11. Supply nitrogen to the piping circuit.
12. Heat the pressure switch pipe (5) using an oxygen acetylene torch.
13. When the solder is liquid, pull the pressure sensor pipe (5).
14. Cut the nitrogen supply when the piping has cooled down.

Figure 3-22: Removing high pressure switches



1. Resettable high pressure switch
2. High pressure switch
3. High pressure switch connector

4. Tie wrap
5. High pressure switch pipe

Installation



CAUTION

Overheating the high pressure sensor will damage or destroy it.

1. Wrap a wet rag around the pressure sensor.
2. Proceed in reverse order.

3.3.2.14. Replacing inverter PCB

The inverter is integrated in the main PCB, see ["Replacing main PCB" on page 89](#).

3.3.2.15. Replacing low pressure switch

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to "Basic removal" on page 67).
4. Recover the refrigerant (refer to "Refrigerant repair procedures" on page 61).
5. Connect a nitrogen hose to the outdoor suction service port.
6. Attach a hose with core-depressor to allow the release of the nitrogen.
7. Unplug the low pressure switch connector on the main PCB.
8. Cut the tie wrap that fixes the low pressure switch wiring.
9. Cut the low pressure switch pipe (1).
10. Remove the low pressure switch (2).




CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

11. Supply nitrogen to the piping circuit.
12. Heat the low pressure switch pipe (1) using an oxygen acetylene torch.
13. When the solder is liquid, pull the low pressure switch pipe (1).
14. Cut the nitrogen supply when the piping has cooled down.

Figure 3-23: Removing low pressure switch



1. Low pressure switch pipe
2. Low pressure switch

3. R2T sensor holder (R2T removed)

Installation



CAUTION

Overheating the low pressure switch will damage or destroy it.

1. Wrap a wet rag around the low pressure switch.
2. Proceed in reverse order.

3.3.2.16. Replacing main PCB

Removal

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to ["Basic removal" on page 67](#)).
4. Flip over the protection sheet (1).
5. Remove the power and remote control wiring from the terminal block (2).
6. Cut the 5 tie wraps (3).



WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

7. Unplug all connectors (4) from the main PCB (5).
8. Remove the 4-way valve coil (6) from the 4-way valve (refer to ["Replacing 4-way valve coil" on page 75](#)).
9. Remove the wiring from the cable clamp (9).
10. Remove the 3 screws (8) that fix the heat sink with a ring spanner or a wrench/socket.



CAUTION

Due to the large size of the PCB it is sensitive to bending.
Only use a wrench/socket or a ring spanner to loosen or fasten the heat sink screws.
Do not use a screwdriver.

11. Remove the 4 screws (7) that fix the main PCB support to the Daikin unit.
12. Lift and turn the lid (10) to the left.



CAUTION

Do not remove the main PCB assembly yet, it is still attached by wiring.

13. Lift the main PCB (5) to release it from the unit.




CAUTION

Tilting the main PCB stresses the heat pipe, do not tilt more than 15°.

14. Slightly tilt (max. 15°) the main PCB (5) and disconnect 2 connectors at the rear of the main PCB panel.
15. Guide the wiring (11) through the slots.

Figure 3-24: Removing the main PCB assembly




16. Cut the tie wraps (1) that fix the protection sheet (2); remove the protection sheet (2).

17. Cut the tie wrap (3).

18. Loosen and remove the 2 screws (4) that fix the wiring.


19. Loosen and remove the 3 screws (5) that fix the wiring.
20. Loosen and remove the 2 screws (6) that fix the wiring.
21. Loosen and remove the 2 screws (7) that fix the wiring.
22. Disconnect the 3 connectors (8) from the terminal block.
23. Loosen and remove the 2 screws (9) that fix the terminal block.

Figure 3-25: Stripping the main PCB assembly (front)



24. Loosen and remove the 2 screws (1) that fix the wiring.
25. Cut the 2 tie wraps (2) that fix the wiring.
26. Unlock the 9 standoffs (3) that fix the electrical noise filter PCB.
27. Remove the wiring from the cable clamp (4).
28. Remove the electrical noise filter PCB (5).

Figure 3-26: Stripping the main PCB assembly (rear)




Installation

1. Proceed in reverse order.

3.3.2.17. Replacing propeller fan blade assembly

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Loosen and remove the 4 nuts (1) that fix the air discharge grill (2).
4. Press (A) the 2 latches to release the air discharge grill (2).
5. Tilt (B) the air discharge grill (2) and remove it from the Daikin unit.
6. Remove the nut (3) that fixes the propeller fan (4).
7. Pull the propeller fan blade assembly (2) from the fan motor (5).

Figure 3-27: Removing the propeller fan blade assembly



Part 4. Maintenance

This part contains the following chapters:

| | |
|-------------------|----|
| Indoor unit | 95 |
| Outdoor unit..... | 96 |

4.1. Indoor unit

4.1.1. General maintenance indoor unit

1. Optimal operation conditions

| | Cooling | Heating |
|--|---------|---------|
| Differential between suction temperature and discharge temperature | 8~18°C | 14~30° |
| DB | 27°C | 20°C |
| WB | 19°C | NA |

2. Correlation of air-conditioner's operation status, pressure and running current

| COOLING | Low pressure | High pressure | Running current |
|-----------------------------------|--------------|---------------|-----------------|
| Dirty air filter | Lower | Lower | Lower |
| Short circuit of air inlet/outlet | Lower | Lower | Lower |
| Air mixed in refrigerant | Higher | Higher | Higher |
| Water mixed in refrigerant | Lower* | Lower | Lower |
| Dirt mixed in refrigerant | Lower** | Lower | Lower |
| Refrigerant shortage (gas) | Lower | Lower | Lower |
| Unsatisfactory compression | Higher*** | Lower | Lower |

* Water in the refrigerant freezes inside the electronic expansion valve and is basically the same phenomenon as pump down.

** Dirt in the refrigerant clogs filters inside the piping and is basically the same phenomenon as pump down.

*** Pressure differential between high and low pressure becomes low.

4.2. Outdoor unit

4.2.1. General maintenance outdoor unit

1. Outdoor unit coil

- Straighten hair fins.
- Clear coil from dust, leaves, etc. with a fin-comb, or compressed air/N₂. Avoid bending or damaging of the Alu fins during the cleaning process.



CAUTION

Make sure not to bend the hair fins.

2. Correlation of air-conditioner's operation status, pressure and running current.

| COOLING | Low pressure | High pressure | Running current |
|-----------------------------------|--------------|---------------|-----------------|
| Dirty air filter | Higher | Higher | Higher |
| Short circuit of air inlet/outlet | Higher | Higher | Higher |
| Air mixed in refrigerant | Higher | Higher | Higher |
| Water mixed in refrigerant | Lower* | Lower | Lower |
| Dirt mixed in refrigerant | Lower** | Lower | Lower |
| Refrigerant shortage (gas) | Lower*** | Lower | Lower |

* Water in the refrigerant freezes inside the electronic expansion valve and is basically the same phenomenon as pump down.

** Dirt in the refrigerant clogs filters inside the piping and is basically the same phenomenon as pump down.

*** Pressure differential between high and low pressure becomes low.

Part 5. Appendix


This part contains the following chapters:

| | |
|---|-----|
| Field setting | 99 |
| Detailed information setting mode | 107 |
| Wiring diagram | 114 |
| Piping diagram | 117 |
| Component overview of unit | 118 |
| Product specific information | 121 |
| Switch box | 122 |
| Field information report | 122 |

5.1. Field setting

5.1.1. Indoor unit

5.1.1.1. Retrieve field settings BRC1E




1. Press and hold Cancel button for 4 seconds or more. Field setting menu is displayed.
2. Select *Field setting list* in the field setting menu, and press Menu/Enter button.
Field setting list screen is displayed.
3. Highlight the mode, and select desired "Mode No." by using ▲▼ (Up/Down) button.
4. In the case of setting per indoor unit during group control (When Mode No. such as 20, 21, 22, 23, 25 are selected), highlight the unit No. and select "Indoor unit No." to be set by using ▲▼ (Up/Down) button. (In the case of group total setting, this operation is not needed.)
In the case of individual setting per indoor unit, current settings are displayed. And, Second Code No. "-" means no function.
5. Highlight Second Code No. of the First Code No. to be changed, and select desired "Second Code No." by using ▲▼ (Up/Down) button. Multiple identical mode number settings are available.
In the case of group total setting, all of Second Code No. which may be set are displayed as "**".
** is changed to Second Code No. to be set. And, Second Code No. "-" means no function.

6. Press Menu/Enter button. Setting confirmation screen is displayed.
7. Select Yes and press Menu/Enter button. Setting details are determined and field setting list screen returns.
8. In the case of multiple setting changes, repeat "(3)" to "(7)".
9. After all setting changes are completed, press Cancel button twice.
10. Backlight goes out, and "Connection under check Please wait for a moment" is displayed for initialization. After the initialization, the basic screen returns.

**CAUTION**

- When an optional accessory is installed on the indoor unit, settings of the indoor unit may be changed. See the manual of the optional accessory.
- For field setting details of the outdoor unit, see installation manual attached to the outdoor unit.

5.1.1.2. Retrieve field settings BRC7



- | | | |
|-----------------------|--------------------|---------------------------|
| 1. Mode No. | 4. First code No. | 7. DOWN button |
| 2. Field setting mode | 5. Second code No. | 8. MODE button |
| 3. RESERVE button | 6. UP button | 9. INSPECTION/TEST button |

Setting

To set the field settings, you have to change:

- “Mode No.”
- “First code No.”
- “Second code No.”.

To change the field settings, proceed as follows:

1. Hold down the INSPECTION/TEST button for at least 4 s during normal mode to enter the “Field setting mode”.
2. Press the MODE button to select the desired “Mode No.”.
3. Press the UP button to select the “First code No.”.
4. Press the DOWN button to select the “Second code No.”
5. Press the RESERVE button to set the present settings.
6. Press the INSPECTION/TEST button to return to the “Normal mode”.

5.1.1.3. Sky-Air R32 indoor field settings

| Mode No. | First Code No. | Description of Setting | Second Code No. | | | | |
|----------|----------------|---|--|---|--|--|---------|
| | | | 01 | 02 | 03 | 04 | 05 |
| 10 (20) | 0 | Filter cleaning sign interval Long life filter | 2,500 hrs. (factory setting) | 1,250 hrs. | — | — | — |
| | 1 | Filter type | Long (factory setting) | Super long | — | — | — |
| | 2 | Remote controller thermistor | Enabled | Disabled (factory setting) | — | — | — |
| | 3 | Filter cleaning sign | Display (factory setting) | No display | — | — | — |
| | 7 (note 3) | Detection time for NOT presence | 30 min (factory setting) | 60 min | — | 0,,,0 | — |
| | 8 (note 4) | Compensation of suction air temperature in heating mode | COMPENSATE (Temperature [A+2] °C which an air conditioner controls when the temperature of a remote controller is A °C) (factory setting) | NO COMPENSATION (Temperature [A] °C which an air conditioner controls when the temperature of a remote controller is A °C) | — | — | — |
| 11 (21) | 2 | Fan OFF at Thermostat OFF | Normal (factory setting) | OFF | — | — | — |
| | 3 | Airflow rate setting during heating | Standard (factory setting) | Slightly up | Up | — | — |
| | 4 | Automatic operation mode control | Available (factory setting) | Prohibition | — | — | — |
| | 6 (note 5) | Sensitivity of presence sensor | High | Low | Standard (factory setting) | Sensor does not work | — |
| 11 (22) | 0 | Option (KRP1B*) output | Compressor (factory setting) | Option | Operation | Malfunction | — |
| | 7 (note 5) | Compensation of temperature around human body | Floor sensor does not work | Higher priority on the air temperature | Standard (factory setting) | Higher priority on the floor temperature | — |
| | 8 (note 5) | Compensation of floor temperature | -4°C | -2°C | ±0°C (factory setting) | +2°C | — |
| 12 (22) | 3 | Fan speed heating thermostat OFF | LL-speed (factory setting) | Set-speed | — | — | — |
| | 5 | Automatic restart after power failure reset | Disabled | Enabled (factory setting) | — | — | — |
| | 6 | Fan speed cooling thermostat OFF | LL-speed | Set-speed (factory setting) | — | — | — |
| 13 (23) | 0 | High air outlet velocity (for high ceiling applications) | Standard (factory setting) | Slightly up | Up | — | — |
| | 1 | Selection of airflow direction | 4-way flow (factory setting) | 3-way flow | — | — | — |
| | 2 | Flap moving in the swing mode | All 4 flaps synchronized | — | Two opposite flaps synchronized (factory setting) | — | — |
| | 4 | Airflow range setting | Upper | Normal (factory setting) | Lower | — | — |
| 14 (24) | 2 | The largest time interval for Dust Collection Sign Display for "self cleaning decoration panel" | About 1250 hrs (dusty place) | About 2500 hrs (factory setting) | About 5000 hrs (less dusty place) | — | — |
| | 4 | Display or non-display of green lamp on the selfcleaning decoration panel | Display both: - airconditioning operation, - filter auto cleaning | Non display: - airconditioning operation, Display: - filter auto cleaning (factory setting) | Display: - airconditioning operation, Non display: - filter auto cleaning | — | — |
| | 8 | Auto control operation for Filter Auto Cleaning | Auto control operation | Not auto control operation (factory setting) | — | — | — |
| | 9 | Filter cleaning time for "selfcleaning decoration panel" | Normal place in terms of dust (Normal office) (factory setting) | In case of dusty place | — | — | — |
| 15 (25) | 5 | Individual setting of ventilation | Normal (factory setting) | Individual operation | — | — | — |
| 1b (2b) | 14 | Wind block (note 6) enable / disable setting | Enable (factory setting) | — | — | — | Disable |



INFORMATION


- Settings are made simultaneously for the entire group, however, if you select the mode No. inside parentheses, you can also set by each individual unit. Setting changes however cannot be checked except in the individual mode for those in parentheses. (Even if the setting are made for the entire group, the display always indicates "01".)
- "88" may be displayed to indicate the remote controller is resetting when returning to the normal mode.
- This function does not work when "SET BACK Function" is set by remote controller.
- This is the case when the remote sensor (optional kit) is used.
- This is the case when the sensor option (optional kit) is used.
- Wind block: one of 4 flaps can be set a block position (block position = closed position). Wind can not be blocked 100% but mostly blocked without additional parts.

5.1.2. Outdoor unit

5.1.2.1. Retrieve field settings OU mode 2

5.1.2.1.1 Location of DIP Switch and BS Button

Various settings are available by using the DIP switches and the BS buttons on the PCB.



| | Display | | Function or Operating Procedure | |
|--------------|---------|-----------|---|--|
| | Symbol | Name | | |
| Display Lamp | H1P | MODE | During "Setting mode 1", the lamp is OFF (●). During "Monitor mode", the lamp blinks (◐). | |
| | H2P | TEST | During test operation in "Setting mode 1", the lamp is ON (○). During "Monitor mode", the lamp is OFF (●). | |
| | H3P | HWL | When an error occurs during "Setting mode 1", the lamp turns ON (○). | |
| | H4P | L.N.O.P | During "Setting mode 1", low noise level is displayed. | |
| | H5P | | | |
| | H6P | DEMAND | During "Setting mode 1", demand level is displayed. | |
| | H7P | | | |
| BS Button | BS1 | MODE | Used to change "Setting mode". | |
| | BS2 | SET | Used to change "Setting item" and "Setting condition". | |
| | BS3 | RETURN | Used to decide "Setting item" and "Setting condition". | |
| | BS4 | PUMP DOWN | Used for pump down operation, forced oil return operation and forced defrost operation. | |
| Dip Switch | DS1-1 | ON | EMERGENCY | Switch from "OFF" to "ON" for emergency operation (forced operation). |
| | | OFF(*1) | | |
| | DS1-2 | COOL | | Maintain "HEAT" in case of heating in emergency operation, and switch to "COOL" in case of cooling in emergency operation. |
| | | HEAT(*1) | | |

*1. Factory settings: "OFF" and "HEAT"



INFORMATION

BS button (Pump down / Forced defrosting)

Pressing the BS button forcibly operates the air conditioner in the cooling mode.

- To conduct a pump-down operation (sending refrigerant to outdoor unit), press the BS button to forcibly operate the equipment in the cooling mode, then operate the unit for about 1 minute to stabilize the system. After stabilizing system, close the liquid pipe stop valve on the outdoor unit, and after the pressure decreases and the low pressure sensor activates, close the gas pipe stop valve.
- Forced defrost
To activate the defrost operation during the heating operation, press the BS button. This will activate the forced defrost operation (cooling operation).
When the defrost cancel conditions are met, the equipment automatically switches off the defrost operation.

5.1.2.1.2 Field Setting for Outdoor Unit

Setting by BS Buttons

With "Setting mode 1", "Setting mode 2" and "Monitor mode", various settings and data can be checked.

1. Setting mode 1

The initial status (normal operation) is "Setting mode 1". This mode indicates operating status - "TEST (test operation)", "HWL (error)", "L.N.O.P (night time quiet operation)" or "DEMAND (demand operation)".


2. Setting mode 2

Each operating status can be modified.

3. Monitor mode

This mode indicates "oil return operation", "outdoor unit class", "contents of retry", "contents of error", "causes of stepping-down operation", etc.

Using the MODE button, the modes can be changed as follows.




Setting Mode 1

In this mode, the following conditions can be checked:


- Current operating condition (normal/test operation/line inspection and normal/error)
- Night time quiet operation condition (normal/low noise level 1, 2, and)
- Demand operating condition (normal/30% demand/40% demand/50% demand)

These conditions above can be checked by performing the following steps:



Setting Mode 2

In this mode, settings for the following items can be made.



* If you become unsure of how to proceed, push the **MODE (BS1)** button and return to setting mode 1.

5.1.2.2. Sky-Air R32 outdoor field settings through outdoor

●: OFF ○: ON

| No. | Display of setting items | | | | | | | | Display of setting conditions | | | | | | | |
|-----|---|-------------|-----|-----|-----|-----|-----|-----|--------------------------------------|-------------|-----|-----|-----|-----|-----|-----|
| | Setting items | LED display | | | | | | | Setting condition | LED Display | | | | | | |
| | | H1P | H2P | H3P | H4P | H5P | H6P | H7P | | H1P | H2P | H3P | H4P | H5P | H6P | H7P |
| 3 | Demand 2 operation | ○ | ● | ● | ● | ● | ○ | ○ | 30% Demand | ○ | ● | ● | ● | ○ | ● | ● |
| | | | | | | | | | 40% Demand (factory set) | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 50% Demand | ○ | ● | ● | ● | ● | ● | ○ |
| 11 | TeS Lower limit value | ○ | ● | ● | ○ | ● | ○ | ○ | 0°C | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 2°C (factory set) | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 4°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 6°C | ○ | ● | ● | ● | ○ | ● | ● |
| 28 | Refrigerant recovery mode | ○ | ● | ○ | ○ | ○ | ● | ● | OFF (factory setting) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | ON | ○ | ● | ● | ● | ● | ○ | ● |
| 33 | TeS Lower limit value | ○ | ○ | ● | ● | ● | ● | ○ | 0°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 6°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 9°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 11°C | ○ | ● | ● | ● | ○ | ● | ● |
| | | | | | | | | | 13°C | ○ | ● | ● | ● | ○ | ● | ○ |
| | | | | | | | | | 15°C | ○ | ● | ● | ● | ○ | ○ | ● |
| | | | | | | | | | 17°C | ○ | ● | ● | ● | ○ | ○ | ○ |
| | | | | | | | | | Weather depending control in cooling | ○ | ● | ● | ○ | ● | ● | ● |
| 34 | TcS Upper limit value | ○ | ○ | ● | ● | ● | ○ | ● | 60°C | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 50°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 47°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 45°C | ○ | ● | ● | ● | ○ | ● | ● |
| | | | | | | | | | 43°C | ○ | ● | ● | ● | ○ | ● | ○ |
| | | | | | | | | | Weather depending control in heating | ○ | ● | ● | ● | ○ | ○ | ● |
| 54 | Weather depending control TeS Lower limit value A | ○ | ○ | ○ | ● | ○ | ○ | ● | 9°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 11°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 13°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 15°C | ○ | ● | ● | ● | ○ | ● | ● |
| 57 | Weather depending control TeS Lower limit value B | ○ | ○ | ○ | ○ | ● | ● | ○ | 2°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 4°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 6°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 8°C | ○ | ● | ● | ● | ○ | ● | ● |
| 58 | Weather depending control TeS Lower limit value C | ○ | ○ | ○ | ○ | ● | ○ | ● | 14°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 17°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 20°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 23°C | ○ | ● | ● | ● | ○ | ● | ● |
| 59 | Weather depending control TeS Lower limit value D | ○ | ○ | ○ | ○ | ● | ○ | ○ | 23°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 27°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 31°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 35°C | ○ | ● | ● | ● | ○ | ● | ● |
| 60 | Weather depending control TcS Upper limit value E | ○ | ○ | ○ | ○ | ○ | ● | ● | 47°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 48°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 49°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 50°C | ○ | ● | ● | ● | ○ | ● | ● |
| 61 | Weather depending control TcS Upper limit value F | ○ | ○ | ○ | ○ | ○ | ● | ○ | 43°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 44°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 45°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 46°C | ○ | ● | ● | ● | ○ | ● | ● |
| 62 | Weather depending control TcS Upper limit value G | ○ | ○ | ○ | ○ | ○ | ○ | ● | 2°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 5°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 8°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 11°C | ○ | ● | ● | ● | ○ | ● | ● |
| 63 | Weather depending control TcS Upper limit value H | ○ | ○ | ○ | ○ | ○ | ○ | ○ | 15°C (factory set) | ○ | ● | ● | ● | ● | ● | ○ |
| | | | | | | | | | 18°C | ○ | ● | ● | ● | ● | ○ | ● |
| | | | | | | | | | 21°C | ○ | ● | ● | ● | ● | ○ | ○ |
| | | | | | | | | | 24°C | ○ | ● | ● | ● | ○ | ● | ● |

The figures in the columns under "No." represent the number of times to push the SET (BS2) button.

5.1.3. Remote controller

| Mode No. | First Code No. | Description | Second Code No. | | | | | Details |
|----------|----------------|---|----------------------------|--------------------------------|--|--|---------------|--|
| | | | 01 | 02 | 03 | 04 | 05 | |
| 16 (26) | 0 | Night time low noise operation | Disabled (Factory setting) | Automatic low noise activation | Capacity preceding setting (when using KRP58 option) | Automatic low noise + capacity preceding | — | Refer to "Quiet (Low Noise) Operation" on page 108. |
| | 1 | Automatic low noise start and stop time | — | — | 22h00 ~ 06h00 | 22h00 ~ 08h00 (Factory) | 20h00 ~ 08h00 | Refer to "Quiet (Low Noise) Operation" on page 108. |
| | 2 | EDP room setting | Disabled (Factory setting) | — | EDP room setting | EDP room setting + no freeze up | — | Refer to "Setting for Low Humidity Application" on page 109. |
| | 3 | Defrost starting setting | Standard (Factory setting) | Defrost slow starting setting | Defrost quick starting setting | — | — | Refer to "Defrost Operation" on page 112. |
| | 7 | Slow start for EDP applications | Normal start | Slow start | — | — | — | |

5.2. Detailed information setting mode

5.2.1. Indoor unit

Not applicable.

5.2.2. Outdoor unit

Setting of Demand 2 operation

With this setting, compressor operation can be controlled to reduce power consumption. (60% - 80% demand is available when a demand adapter (optional accessory) is used.)

| Setting item | Setting condition | Description |
|--------------------|------------------------------|---|
| Demand 2 operation | 30% demand | Operates with 30% of rated power consumption. |
| | 40% demand (factory setting) | Operates with 40% of rated power consumption. |
| | 50% demand | Operates with 50% of rated power consumption. |

[Work procedure]

●: OFF ○: BLINK ○: ON

| Operating procedure | H1P | H2P | H3P | H4P | H5P | H6P | H7P |
|---|--------------------------------|-----|-----|-----|-----|-----|-----|
| Push and hold the MODE (BS1) button of "Setting mode 1" for 5 seconds or more and set to "Setting mode 2". | ○ | ● | ● | ● | ● | ● | ● |
| Push the SET (BS2) button three times to set the LED display as shown in the table on the right. | ○ | ● | ● | ● | ● | ○ | ○ |
| Push the RETURN (BS3) button once. (Present settings are displayed.) | ○ | ● | ● | ● | ● | ○ | ● |
| Push the SET (BS2) button to set the LED display as shown in the table on the right. | 30% of rated power consumption | ○ | ● | ● | ● | ○ | ● |
| | 40% of rated power consumption | ○ | ● | ● | ● | ○ | ● |
| | 50% of rated power consumption | ○ | ● | ● | ● | ● | ○ |
| Push the RETURN (BS3) button once to make a decision. | 30% of rated power consumption | ○ | ● | ● | ● | ○ | ● |
| | 40% of rated power consumption | ○ | ● | ● | ● | ○ | ● |
| | 50% of rated power consumption | ○ | ● | ● | ● | ● | ○ |
| Push the RETURN (BS3) button once again for execution (The LED display is in the initial status of "Setting mode 2".) | ○ | ● | ● | ● | ● | ● | ● |
| Push the MODE (BS1) button once to return to Setting mode 1 (normal operation). | ● | ● | ● | ● | ● | ● | ● |

Setting of Refrigerant Recovery Mode

When a refrigerant recovery unit is connected onsite to recover refrigerant, fully open the expansion valve of the outdoor unit to help the recovery.

1. Stop operation.
2. Turn ON refrigerant recovery mode by performing the following steps.

●: OFF ○: BLINK ○: ON

| Operating procedure | H1P | H2P | H3P | H4P | H5P | H6P | H7P |
|---|-----|-----|-----|-----|-----|-----|-----|
| Press the MODE (BS1) button of "Setting mode 1" for 5 seconds or more and set to "Setting mode 2". | ○ | ● | ● | ● | ● | ● | ● |
| Press the SET (BS2) button 28 times to set the LED display as shown in the table on the right. (*1) | ○ | ● | ○ | ○ | ○ | ● | ● |
| Press the RETURN (BS3) button once. (Present settings are displayed.) | ○ | ● | ● | ● | ● | ● | ○ |
| Press the SET (BS2) button once to set the LED display as shown in the table on the right. | ○ | ● | ● | ● | ● | ○ | ● |
| Press the RETURN (BS3) button once to make a decision. | ○ | ● | ● | ● | ● | ○ | ● |
| When the RETURN (BS3) button is pressed once again, the electronic expansion valve opens fully. | ○ | ● | ● | ● | ● | ● | ● |

3. Connect a refrigerant recovery unit to perform refrigerant recovery.
4. Upon completion of refrigerant recovery, turn OFF refrigerant recovery mode by taking the following steps or turning OFF the power of outdoor unit.

| Operating procedure | H1P | H2P | H3P | H4P | H5P | H6P | H7P |
|---|-----|-----|-----|-----|-----|-----|-----|
| Press the SET (BS2) button 28 times to set the LED display as shown in the table on the right. (*1) | ○ | ● | ○ | ○ | ○ | ● | ● |
| Press the RETURN (BS3) button once. (Present settings are displayed.) | ○ | ● | ● | ● | ● | ○ | ● |
| Press the SET (BS2) button once to set the LED display as shown in the table on the right. | ○ | ● | ● | ● | ● | ● | ○ |
| Press the RETURN (BS3) button once to make a decision. | ○ | ● | ● | ● | ● | ● | ○ |
| When the RETURN (BS3) button is pressed once again, the electronic expansion valve fully opens. | ○ | ● | ● | ● | ● | ● | ● |



INFORMATION

*1: If you become unsure how many times you have pushed the button, push the MODE (BS1) button once to return to "Setting mode 1" and start the operating procedure all over again.

5.2.3. Remote controller

5.2.3.1. Quiet (Low Noise) Operation

Lower the operation sound of the outdoor unit.

Silent Operation can be activated by:

1. Automatic control (by field setting from remote controller)
2. External activation (from optional PCB KRP58M)

Quiet (Low Noise) Operation by Automatic Control

Silent operation can be set by field setting from the wired remote controller:

| Description | Mode No. | First Code No. | Second Code No. | | | | |
|-----------------------------|----------|----------------|-----------------|----------------------|---------------|-------------------------------|---------------|
| | | | 01 | 02 | 03 | 04 | 05 |
| Silent Operation | 16(26) | 0 | OFF | Low noise activation | — | Low noise + capacity priority | — |
| Low noise start & stop time | | 1 | — | — | 22h00 ~ 06h00 | 22h00 ~ 08h00 | 20h00 ~ 08h00 |


When setting mode 16(26)-0-02, quiet (low noise) operation will be carried out by presuming the current time in accordance with the outside temperature.

Automatic mode will start when the outdoor temperature is = average max of last 10 days -5°C and will be conducted for 10 hours.

The maximum outdoor temperature is supposed to occur at 14:00h.


As the time judgement is made in accordance with the outdoor temperature, the above mentioned timing is an estimation only.

When setting mode 16(26)-0-04, the low noise operation will be stopped when the heating or cooling load increases. In that case, the operation will return to normal operation. The unit will return to low-noise operation when the heating or cooling load decreases again.



External Activation from Optional PCB

Quiet (low noise) operation can also be activated from the optional PCB.



Quiet (low noise) operation will start when the contact on LNOP-COM is closed and will remain active as long as the contact is closed. No field setting on the outdoor unit or by remote controller is required.

Quiet (low noise) operation will be ended when the contact is re-opened.

Use of the KRP58M enables the use of an external time clock.

Same as with the automatic control, priority for capacity can be set. Priority for capacity will be activated by changing field setting 26-0-03 in combination with the closed contact on KRP58M.

| Description | Mode No. | First Code No. | Second Code No. | | | |
|-----------------------------|----------|----------------|-----------------|----|---------------------------|----|
| | | | 01 | 02 | 03 | 04 |
| Quiet (low noise) operation | 16(26) | 0 | Factory setting | — | Capacity priority setting | — |

The Quiet (low noise) operation will be overruled in the following conditions:

- Pump down residual operation
- Startup control
- Defrost operation
- Oil recovery


| Model | RZQG71 | RZQG100 | RZQG125 | RZQG140 |
|-----------------|--------|---------|---------|---------|
| Sound reduction | 6 dBA | 5 dBA | 6 dBA | 7 dBA |

5.2.3.2. I-Demand Function

Set a limitation towards the power consumption from the system (e.g. budget control, limit power consumption during peak moments, ...).

3 different demand setting can be selected by using terminal X801M:

- Demand 1 → Close contact between COM and contact 1
- Demand 2 → Close contact between COM and contact 2
- Demand 3 → Close contact between COM and contact 3



Demand 1

Power consumption limitation in function of setting on DS1.

| DS1 Setting | | ON OFF | Maximum Power Consumption |
|-------------|-----|-----------|---------------------------|
| 1 | 2 | | |
| OFF | OFF | | 60% |
| ON | OFF | | 70% |
| OFF | ON | | 80% |
| ON | ON | | 100% |

Demand 2


Power consumption limitation set to 40%.

Demand 3

Forced thermostat OFF.

5.2.3.3. Setting for Low Humidity Application

Can be set when using the RZAG-L units for year round cooling in low humidity applications such as computer rooms (EDP rooms), technical rooms, etc...to increase the capacity of the unit.





CAUTION

When using the "LH settings" outside the "Low Humidity Area" there is an increased risk of ice accumulation on the indoor coil or water blowing out from the indoor unit.


| | | Factory setting | Low humidity application setting | Low humidity application + freeze up operation prevention |
|----------------------------|-------|--|--|---|
| Field Setting | | 16(26)-2-01 | 16(26)-2-03 | 16(26)-2-04 |
| Compressor control | | <ul style="list-style-type: none"> The compressor frequency is controlled in function of the target evaporating temperature. The target evaporating temperature is controlled in function of the cooling load. | | |
| | | Minimum target Te = 2°C See graph 1 | Minimum target Te = 0°C See graph 2 | Initial minimum target Te = 2°C, but can be changed in function of actual Te, to avoid freeze up activation: <ul style="list-style-type: none"> Te ≤ -1°C for 20 minutes accumulated => Change target Te ≥ 5°C Te ≤ -1°C for 30 minutes accumulated => Change target Te ≥ 8°C See graph 3 |
| Freeze protection function | Start | Te ≤ -1°C for 40 minutes accumulated OR Te ≤ A°C for 1 minute continuous (Indoor decision) | Te ≤ -1°C for 40 minutes accumulated OR Te ≤ -3°C for 1 minute continuous (Outdoor decision) | Te ≤ -1°C for 40 minutes accumulated OR Te ≤ A°C for 1 minute continuous (Outdoor decision) |
| | End | Te > 7°C for 10 minutes continuously. (Indoor decision) | Te > 7°C for 3 minutes continuously OR Te > 4°C for 20 minutes continuously (Outdoor decision) | Te > 7°C for 3 minutes continuously OR Te > 4°C for 20 minutes continuously (Outdoor decision) |

Parameters

| | FCQG | FHQG |
|---|------|------|
| A | -5°C | -3°C |


Graph 1

Target evaporating temperature control in case of factory setting 16(26)-2-01:




Graph 2

Target evaporating temperature control when “low humidity application” is selected. Field setting 16(26)-2-03:



Graph 3

Target evaporating temperature control when “low humidity application + freeze up operation prevention” is selected. Field setting 16(26)-2-04:



In order to increase continuous operation of the unit in low latent heat applications and avoid the rise of temperature after thermostat OFF, the thermostat control will be changed when using field settings 16(26)-2-03 & 16(26)-2-04.

Thermostat ON

- $\Delta Trs \geq 0.5^\circ\text{C}$ (No change from standard setting)

Thermostat OFF

- $\Delta Trs \leq -2.0^\circ\text{C}$ for 5 minutes continuously.
- $\Delta Trs \leq 4.5^\circ\text{C}$

Capacity

When “low humidity application” is selected. Field setting 16(26)-2-03:

| Outdoor Temp. (°C-DB) | Indoor Temp. (°C-WB) | | | | | | | |
|--------------------------------|----------------------|------|------|------|------|------|------|------|
| | 11 | 14 | 16 | 18 | 19 | 20 | 22 | 24 |
| Capacity (% of standard point) | | | | | | | | |
| -15 | 0.62 | 0.76 | 0.86 | 0.95 | 1.00 | 1.02 | 1.07 | 1.11 |
| -10 | 0.62 | 0.76 | 0.86 | 0.95 | 1.00 | 1.02 | 1.07 | 1.11 |
| -5 | 0.62 | 0.81 | 0.91 | 1.01 | 1.06 | 1.16 | 1.21 | 1.26 |
| 0 | 0.62 | 0.81 | 0.91 | 1.01 | 1.06 | 1.16 | 1.21 | 1.26 |

| Outdoor Temp. (°C-DB) | Indoor Temp. (°C-WB) | | | | | | | |
|-----------------------|--------------------------------|------|------|------|------|------|------|------|
| | 11 | 14 | 16 | 18 | 19 | 20 | 22 | 24 |
| | Capacity (% of standard point) | | | | | | | |
| 5 | 0.62 | 0.81 | 0.91 | 1.01 | 1.06 | 1.16 | 1.21 | 1.26 |
| 10 | 0.62 | 0.81 | 0.91 | 1.01 | 1.06 | 1.16 | 1.21 | 1.26 |
| 15 | 0.62 | 0.81 | 0.91 | 1.01 | 1.12 | 1.14 | 1.19 | 1.24 |
| 20 | 0.62 | 0.81 | 0.91 | 1.07 | 1.10 | 1.12 | 1.16 | 1.21 |
| 25 | 0.62 | 0.81 | 0.91 | 1.05 | 1.07 | 1.09 | 1.13 | 1.18 |
| 30 | 0.61 | 0.81 | 0.91 | 1.01 | 1.04 | 1.06 | 1.10 | 1.14 |
| 35 | 0.61 | 0.81 | 0.94 | 0.98 | 1.00 | 1.02 | 1.06 | 1.11 |
| 40 | 0.61 | 0.81 | 0.90 | 0.94 | 0.96 | 0.98 | 1.02 | 1.06 |

When "low humidity application + freeze up operation prevention" is selected. Field setting 16(26)-2-04:

| Outdoor Temp. (°C-DB) | Indoor Temp. (°C-WB) | | | | | | | |
|-----------------------|--------------------------------|------|------|------|------|------|------|------|
| | 11 | 14 | 16 | 18 | 19 | 20 | 22 | 24 |
| | Capacity (% of standard point) | | | | | | | |
| -15 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.26 |
| -10 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.26 |
| -5 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.26 |
| 0 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.26 |
| 5 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.26 |
| 10 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.26 |
| 15 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.24 |
| 20 | 0.51 | 0.68 | 0.78 | 0.95 | 1.01 | 1.06 | 1.16 | 1.21 |
| 25 | 0.51 | 0.68 | 0.78 | 0.95 | 1.00 | 1.06 | 1.13 | 1.18 |
| 30 | 0.51 | 0.68 | 0.78 | 0.95 | 1.00 | 1.05 | 1.10 | 1.14 |
| 35 | 0.51 | 0.68 | 0.78 | 0.95 | 1.00 | 1.02 | 1.06 | 1.11 |
| 40 | 0.51 | 0.67 | 0.78 | 0.94 | 0.96 | 0.98 | 1.02 | 1.06 |



INFORMATION

- Operation range on indoor side expanded from minimum 12°CWB to 11°CWB when using LH setting.
- Do not use a setpoint below 20°C to avoid operation out of the indoor operation range (11°CWB).
- Be sure to set the indoor fan to high speed.

5.2.3.4. Defrost Operation


When in heating mode, a defrost operation will be conducted in order to avoid ice formation on the outdoor unit heat exchanger.

Starting conditions

Defrost will start when the following conditions have been realized:

- & [
 - Integrated compressor running time is 25 minutes or more since the completion of the previous defrost operation.
 OR [
 - Defrost upper limit time A is met.
 - Outdoor unit heat exchanger temperature is within the defrost request area.

Defrost conditions




Defrost upper limit A

Depending on the defrost start setting (field setting mode of the indoor unit remote controller), frost upper limit time A becomes as shown in the table below.

| | When quick defrost starting is set | Factory setting | When slow defrost starting is set |
|--------------------------------|------------------------------------|-----------------|-----------------------------------|
| Outdoor air temperature > -5°C | 40 minutes | 2 hours | 6 hours |
| Outdoor air temperature ≤ -5°C | 40 minutes | 6 hours | 8 hours |

Defrost Control



Defrost Ending Conditions

Defrosting ends when the following conditions have been realized. Note that defrosting can be operated for 10 minutes at longest.

Hp: High pressure

Tb: Heat exchanger distributor pipe temperature


Tm: Intermediate heat exchanger temperature

- OR (
 - & (
 - Defrost Time > 10 sec.
 - Hp > 2.45 MPa
 - & (
 - Defrost Time > 1 min.
 - Tb > 10°C
 - Tm > 12°C
 - & (
 - Defrost Time > 9 min.
 - Tb > 8°C
 - Tm > 10°C

5.3. Wiring diagram

5.3.1. Indoor unit

Figure 5-1: Wiring diagram - indoor unit



Notes

1. In case using central remote controller, connect it to the unit in accordance with the attached installation manual.
2. In case of main/sub changeover. See the installation manual attached to remote controller.
3. Shows only in case of protected pipes. Use H07RN in case of no protection.
4. When connecting the input wires from outside, forced off or on/off control operation can be selected by the remote controller. See installation manual for more details.
5. Connect power of adapter for wiring to terminal block (X2M) of indoor unit directly.
6. X35A, X39A, X70A are connected when the optional accessories are being used. In case an auto cleaning panel is used, see the wiring diagram.

Legend

| | |
|------------|--|
| A1P | Main PCB |
| A2P | Adapter PCB |
| A3P, A4P | * Sensor kit PCB |
| A5P, A6P | Receiver/display PCB |
| A7P | * Adapter for wiring |
| BS01 (A6P) | Push button (ON/Off) |
| C105 (A1P) | Capacitor |
| DS1 (A1P) | DIP switch |
| F1U (A7P) | Fuse B, 5 A 250 V |
| F2U (A7P) | Fuse B, 5 A 250 V |
| HAP (A1P) | Running LED (service monitor-green) |
| H1P (A6P) | LED (On-red) |
| H2P (A6P) | LED (timer-green) |
| H3P (A6P) | LED (filtersign-red) |
| H4P (A6P) | LED (defrost-orange) |
| H5P (A6P) | LED (element cleaning-red) |
| H6P (A6P) | LED (ventilation cleaning-green) |
| KCR (A7P) | Magnetic relay |
| KFR (A7P) | Magnetic relay |
| KHuR (A7P) | Magnetic relay (Hu) |
| K2R | Magnetic relay |
| M1F | Fan motor (indoor) |
| M1P | Motor (drain pump) |
| M*S | Motor (swing flap) |
| PS (A1P) | Power supply |
| R1T | Thermistor (air) |
| R2T | Thermistor (liquid piping) |
| R3T | Thermistor (coil) |
| RC (A1P) | Signal receiver circuit |
| SS1 (A5P) | Selector switch (emergency) |
| SS2 (A5P) | Selector switch (wireless address set) |
| S1L | Float switch |
| TC (A1P) | Signal transmission circuit |

| | |
|------------|--|
| V1R (A1P) | Diode module |
| X1A (A7P) | Connector (power supply for option PCB) |
| X2A (A7P) | PCB connector (sensor kit) |
| X24A (A1P) | PCB connector (wireless remote controller) |
| X33A (A1P) | PCB connector (adapter for wiring) |
| X35A (A1P) | PCB connector (auto clean panel) |
| X39A (A1P) | PCB connector (auto clean panel) |
| X70A (A1P) | PCB connector (auto clean panel) |
| X*A | PCB connector |
| X*M | Terminal strip |
| X*Y | Connector |
| Z*C | Noise filter (ferrite core) |
| Z*F | Noise filter |
| | * Optional |
| | # Field supply |

Symbols


| | |
|-------------|---|
| X1M | Main terminal |
| ----- | Earth wiring |
| 15 | Wire number 15 |
| ----- | Field wire |
| --- --- --- | Field cable |
| → **/12.2 | Connection ** continues on page 12 column 2 |
| ① | Several wiring possibilities |
| [] | Option |
| [] | Not mounted in switch box |
| [] | Wiring depending on model |
| [] | PCB |

Colours

| | |
|------|-------|
| BLK: | Black |
| WHT: | White |
| RED: | Red |

5.3.2. Outdoor unit

Figure 5-2: Wiring diagram - outdoor unit 71

**Legend**

| | |
|------------|--|
| A1P | Printed circuit board (main) |
| A2P | Printed circuit board |
| BS1-BS4 | Push button switch |
| C1-C3 | Capacitor |
| DS1 | DIP switch |
| E1H | Bottom plate heater (option) |
| F1U, F2U | Fuse |
| F6U | Fuse (T 3.15 A / 250 V) |
| F7U, F8U | Fuse (F 1.0 A / 250 V) |
| H1P-H7P | Light-emitting diode (service monitor is orange) |
| HAP | Light-emitting diode (service monitor is green) |
| K1R | Magnetic relay (Y1S) |
| K2R | Magnetic relay (Y2S) |
| K2R, K10R | Magnetic relay |
| K11M | Magnetic contactor |
| K13R-K15R | Magnetic relay |
| L1R | Reactor |
| M1C | Motor (compressor) |
| M1F | Motor (fan) |
| PS | Switching power supply |
| Q1DI | Earth leakage circuit breaker (30 mA) |
| R2, R5, R6 | Resistor |
| R1T | Thermistor (air) |
| R2T | Thermistor (discharge) |
| R3T | Thermistor (suction) |
| R4T | Thermistor (heat exchanger inlet) |
| R5T | Thermistor (heat exchanger middle) |
| R6T | Thermistor (liquid) |
| R7T, R8T | Thermistor (Positive Temperature Coefficient) |
| RC | Signal receiver circuit |
| S1PH-A | Automatic high pressure switch |
| S1PH-M | Manual high pressure switch |
| S1PL | Low pressure switch |

| | |
|----------|--|
| TC | Signal transmission circuit |
| V1D-V3D | Diode |
| V1R | IGBT power module |
| V2R | Diode module |
| V1T, V2T | Insulated Gate Bipolar Transistor (IGBT) |
| X1M | Terminal strip |
| Y1E | Electronic expansion valve |
| Y3E | Electronic expansion valve |
| Y1S | Solenoid valve (4-way valve) |
| Y2S | Solenoid valve |
| Z1C-Z6C | Noise filter (ferrite core) |
| Z1F-Z3F | Noise filter |


Symbols

| | |
|---------|------------------|
| L | Live |
| N | Neutral |
| — — — — | Field wiring |
| □□□□ | Terminal strip |
| ○ | Terminal |
| ⊗ | Connector |
| —●— | Connection |
| ⊕ | Protective earth |
| ⊕ | Noiseless earth |
| ⋯ | Option |

Colours

| | |
|------|--------|
| BLK: | Black |
| BLU: | Blue |
| BRN: | Brown |
| GRN: | Green |
| PPL: | Purple |
| RED: | Red |
| WHT: | White |
| YLW: | Yellow |

Figure 5-3: Wiring diagram - outdoor unit 100-140



2D099153-1

Legend

| | |
|-----------|--|
| A1P | Printed circuit board (main) |
| A2P | Printed circuit board |
| BS1-BS4 | Push button switch |
| C1-C3 | Capacitor |
| DS1 | DIP switch |
| E1H | Bottom plate heater (option) |
| F1U-F4U | Fuse |
| F6U | Fuse (T 5.0 A / 250 V) |
| F7U, F8U | Fuse (F 1.0 A / 250 V) |
| H1P-H7P | Light-emitting diode (service monitor is orange) |
| HAP | Light-emitting diode (service monitor is green) |
| K1R | Magnetic relay (Y1S) |
| K2R | Magnetic relay (Y2S) |
| K10R | Magnetic relay |
| K11M | Magnetic contactor |
| K13R-K15R | Magnetic relay |
| K4R | Magnetic relay E1H (option) |
| L1R-L3R | Reactor |
| M1C | Motor (compressor) |
| M1F | Motor (fan) (upper) |
| M2F | Motor (fan) (lower) |
| PS | Switching power supply |
| 01DI | Earth leakage circuit breaker (30 mA) |
| R1-R5 | Resistor |
| R1T | Thermistor (air) |
| R2T | Thermistor (discharge) |
| R3T | Thermistor (suction) |
| R4T | Thermistor (heat exchanger inlet) |
| R5T | Thermistor (heat exchanger middle) |
| R6T | Thermistor (liquid) |
| R7T | Thermistor (fin) |
| RC | Signal receiver circuit |
| S1PH-A | Automatic high pressure switch |
| S1PH-M | Manual high pressure switch |

| | |
|----------|--|
| S1PL | Low pressure switch |
| TC | Signal transmission circuit |
| V1D-V4D | Diode |
| V1R | IGBT power module |
| V2R | Diode module |
| V1T, V3T | Insulated Gate Bipolar Transistor (IGBT) |
| X1M | Terminal strip |
| Y1E | Electronic expansion valve |
| Y3E | Electronic expansion valve |
| Y1S | Solenoid valve (4-way valve) |
| Y2S | Solenoid valve |
| Z1C-Z6C | Noise filter (ferrite core) |
| Z1F-Z6F | Noise filter |

Symbols

| | |
|------|------------------|
| L | Live |
| N | Neutral |
| --- | Field wiring |
| □□□□ | Terminal strip |
| ○ | Terminal |
| □ | Connector |
| ● | Connection |
| ⊕ | Protective earth |
| ⊖ | Noiseless earth |
| ⋯ | Option |

Colours

| | |
|------|--------|
| BLK: | Black |
| BLU: | Blue |
| BRN: | Brown |
| GRN: | Green |
| PPL: | Purple |
| RED: | Red |
| WHT: | White |
| YLW: | Yellow |


5.3.3. Field wiring

Not applicable.

5.4. Piping diagram


5.4.1. Indoor unit

Figure 5-4: Piping diagram - indoor unit



5.4.2. Outdoor unit


Figure 5-5: Piping diagram - outdoor unit



5.5. Component overview of unit

5.5.1. Indoor unit

Figure 5-6: Components overview - indoor unit




- a. Switch box
- b. Gas pipe connection
- c. Liquid pipe connection

- d. Drain pipe connection (VP25)
- e. Drain pump
- f. Float switch

- g. Fan motor
- h. Heat exchanger
- i. Hanger bracket

5.5.2. Outdoor unit


Figure 5-7: Components overview - outdoor unit 71



- a. Heat exchanger
- b. Internal service port
- c. Switch box cooling
- d. Check valve
- e. Liquid receiver
- f. Stop valve with service port (liquid)
- g. Stop valve with service port (gas)
- h. Cable tie mountings (to fix the field wiring with cable ties to ensure stress relief)
- i. Compressor accumulator

- A1P Printed circuit board (main)
- M1C Motor (compressor)
- M1F Motor (fan)
- S1PH-A Automatic high pressure switch
- S1PH-M Manual high pressure switch
- S1PL Low pressure switch
- X1M Terminal (communication and power supply)
- Y1E Electronic expansion valve
- Y3E Electronic expansion valve
- Y1S Solenoid valve (4-way valve)
- Y2S Solenoid valve

Figure 5-8: Components overview - outdoor unit 100-140



- a. Heat exchanger
- b. Internal service port
- c. Switch box cooling
- d. Check valve
- e. Liquid receiver
- f. Stop valve with service port (liquid)
- g. Stop valve with service port (gas)
- h. Cable tie mountings (to fix the field wiring with cable ties to ensure stress relief)
- i. Compressor accumulator

- A1P Printed circuit board (main)
- M1C Motor (compressor)
- M1F Motor (upper fan)
- M2F Motor (lower fan)
- S1PH-A Automatic high pressure switch
- S1PH-M Manual high pressure switch
- S1PL Low pressure switch
- X1M Terminal (communication and power supply)
- Y1E Electronic expansion valve
- Y3E Electronic expansion valve
- Y1S Solenoid valve (4-way valve)
- Y2S Solenoid valve

5.6. Product specific information

5.6.1. Error codes

5.6.1.1. "E9-00" - Electronic expansion valve abnormality

Trigger conditions

- A = 4 K
- B = 10 K

5.6.1.2. "F3-00" - Discharge pipe temperature abnormality

| Compressor | A (°C) | B (°C) | C (°C) |
|------------|--------|--------|--------|
| 2YC71 | 120 | 110 | / |
| 2YC100 | 120 | 110 | / |

5.6.2. Component checklist

5.6.2.1. How to activate inverter test

Not available yet.

5.6.2.2. Component checklist

| Component | Component name | Connector on 71-class | Connector on 100/140-class | PCB | Specific |
|--------------|------------------------------------|-----------------------|----------------------------|-----|----------|
| Outdoor unit | | | | | |
| M1C | Motor (compressor) | X502A | X502A | A1P | |
| M1F | Motor (upper fan) | X106A | X106A | A1P | |
| M2F | Motor (lower fan) | | X107A | A1P | |
| S1PH-A | Automatic high pressure switch | X32A | X32A | A1P | |
| S1PH-M | Manual high pressure switch | X32A | X32A | A1P | |
| S1PL | Low pressure switch | X31A | X31A | A1P | |
| Y1E | Electronic expansion valve | X21A | X21A | A1P | |
| Y3E | Electronic expansion valve | X22A | X22A | A1P | |
| Y1S | Solenoid valve (4-way valve) | X25A | X25A | A1P | |
| Y2S | Solenoid valve | X26A | X26A | A1P | |
| R1T | Thermistor (air) | X11A | X11A | A1P | Type 1 |
| R2T | Thermistor (discharge) | X12A | X12A | A1P | Type 2 |
| R3T | Thermistor (suction) | X12A | X12A | A1P | Type 1 |
| R4T | Thermistor (heat exchanger inlet) | X12A | X12A | A1P | Type 1 |
| R5T | Thermistor (heat exchanger middle) | X12A | X12A | A1P | Type 1 |
| R6T | Thermistor (liquid) | X13A | X13A | A1P | Type 1 |

5.7. Switch box

5.7.1. Indoor unit

Not applicable.

5.7.2. Outdoor unit

Not applicable.

5.8. Field information report

See next page.

In case a problem occurred on the unit which could not be resolved by using the content of this service manual or in case you have a problem which could be resolved but of which the manufacturer should be notified, we advise you to contact your distributor.

To facilitate the investigation, additional information is required. Please fill out the following form before contacting your distributor.



FIELD INFORMATION REPORT

| Key person info | |
|---------------------------------------|-----------------|
| Name: | Company name: |
| Your contact details Phone number: | E-mail address: |
| Site address: | |
| Your reference: | Date of visit: |

| Claim info | |
|--|---------------|
| Title: | |
| Problem description: | |
| Error code: | Trouble date: |
| Problem frequency: | |
| Investigation steps done: | |
| Insert picture of the trouble. | |
| Current situation (solved, not solved, ...): | |
| Countermeasures taken: | |
| Comments and proposals: | |
| Part available for return (if applicable): | |

Application info

Application (house, apartment, office, ...):

New project or refurbishment:

Heat emitters (radiators / under floor heating / fan coils / ...):

Hydraulic layout (simple schematic):

Unit / Installation info

Model name:

Serial number:

Installation / commissioning date:

Software version hydro PCB A1P:

Software version hydro PCB A5P:

Software version user interface:

Software version outdoor PCB:

Minimum water volume:

Maximum water volume:

Brine composition and mixture:

Brine freeze up temperature:

Space heating control (leaving water temperature, room thermostat, ext. room thermostat):

Space heating setpoint:

Domestic hot water control (reheat only, schedule only, reheat + schedule):

Domestic hot water setpoint:

Provide pictures of the field settings overview (viewable on the user interface).