

DAIKIN




INSTALLATION MANUAL


Split System air conditioners

FHYCP71B8V1
FHYCP100B8V1
FHYCP125B8V1


FCQ35B8V1
FCQ50B8V1
FCQ60B8V1
FCQ71B8V3B
FCQ100B8V3B
FCQ125B8V3B




1




2




3





4




5




6




7




8




9




10




12




11




13




14




15




16




17



18



19



20

CE - DECLARATION-OF-COMFORMITY
 CE - KONFORMITÄTSEKKLARACIJA
 CE - DECLARATION-DE-CONFORMITE
 CE - KONFORMITEITS/VERKLARING

CE - DECLARACION-DE-CONFORMIDAD
 CE - DICHIAZIONE-DI-CONFORMITA
 CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ

CE - DECLARACÃO-DE-CONFORMIDADE
 CE - ЗАРЯБЛЕННЕ-О-СОТВЕТСТВИИ
 CE - OPEYДЛЕНСЯЕКЛЕРИНГ
 CE - FÖRSÄKRAN-OM-ÖVERENSÄMMEELSE

CE - ERKLÄRUNG-DES-CONFORMITÄT
 CE - ИЛМОИТУС-ЙХЕННИИКИАИСУUDESTA
 CE - DEKLARACJA-ZGODNOSC
 CE - DECLARAȚIE-DE-CONFORMITATE

CE - IZJAVA O USKLADAVOSTI
 CE - MEGFELELŐSÉG-NYILATKOZAT
 CE - DEKLARACIJA-ZGODNOSTI
 CE - DECLARAȚIE-DE-CONFORMITATE

CE - IZJAVA O SKLADAVOSTI
 CE - VASTAVUSDEKLARACIJA
 CE - ATILIKITES-DEKLARACIJA
 CE - VYHLÁSENIE-ZHODY
 CE - UYUMLULUK-BİLDİRİSİ

CE - ATILIKITES-DEKLARACIJA
 CE - VASTAVUSDEKLARACIJA
 CE - VYHLÁSENIE-ZHODY
 CE - UYUMLULUK-BİLDİRİSİ

Daikin Europe N.V.

- 01 declares under its sole responsibility that the air conditioning models to which this declar ation relates:
- 02 erklärt auf seine alleinige Verantwortung daß die Modelle der Klimaanlage für die diese Erklärung bestimmt ist:
- 03 déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration ont:
- 04 verklaart hierbij op eigen exclusieve verantwoordelijkheid dat de airconditioning units waarop deze verklaring betrekking heeft:
- 05 declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración:
- 06 dichiara sotto sua responsabilità che i condizionatori modello a cui è riferita questa dichiarazione:
- 07 δηλώνει με αποκλειστική της ευθύνη ότι τα ποτέλα των κλιματιστικών αεροκλιματιστών που ονομάζονται στην παρούσα δήλωση:
- 08 declara sob sua exclusiva responsabilidade que os modelos de ar condicionado a que esta declaração se refere:
- 09 заявляет исключительно под свое ответственность, что модели кондиционеров воздуха, к которым относится настоящее заявление:

FHYCP71B8V1, FHYCP100B8V1, FHYCP125B8V1,
 FCQ35B8V1, FCQ50B8V1, FCQ60B8V1,
 FCQ71B8V3B, FCQ100B8V3B, FCQ125B8V3B

- 01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:
- 02 befinden folgenden Normen) oder einem anderen Normdokument oder Dokumenten entsprechend, unter der Voraussetzung, daß sie gemäß unseren Anweisungen eingesetzt werden:
- 03 sont conformes à la(s) norme(s) ou autre(s) document(s) normatif(s), pour autant qu'ils soient utilisés conformément à nos instructions:
- 04 conform de volgende norm(en) of één of meer andere technische document(en) zijn, op voorwaarde dat ze worden gebruikt overeenkomstig onze instructies:
- 05 están en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras instrucciones:
- 06 sono conformi all(i) seguente(i) standard(i) o altro(i) documento(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni:
- 07 эти модели соответствуют следующим стандартам и/или другим техническим документам, при условии их использования согласно нашим инструкциям:
- 08 conform de volgende norm(en) of één of meer andere technische document(en) zijn, op voorwaarde dat ze worden gebruikt overeenkomstig onze instructies:
- 09 находятся в соответствии с следующими стандартами и/или другими техническими документами, при условии их использования согласно нашим инструкциям:
- 10 under følgende standard(er) eller andre tekniske dokument(er), forudsat at disse anvendes i henhold til vores instruktioner:
- 11 respectivelie utstilling är utförd i överensstämmelse med och följer följande standard(er) eller andra normgivande dokument, under förutsättning att användning sker i överensstämmelse med våra instruktioner:
- 12 respectivelie uslyer er i overensstemmelse med følgende standard(er) eller andre normgivende dokument(er), under forudsætning at disse bruges i henhold til våre instruksjoner:
- 13 vastavaat seuraavien standardien ja muiden ohjeistettujen dokumenttien vaatimuksissa edellyttäen, että niitä käytetään ohjeidemme mukaisesti:
- 14 за предпоставки, że jsou vzhledy v souladu s našimi pokyny, odpovídají následujícím normám nebo normativním dokumentům:
- 15 u skladu sa sledjećim standardom(i)ma ili drugim normativnim dokumentom(i)ma), uz uvjet da se oni koriste u skladu s našim uputama:
- 16 conform de următoarele standarde și alte documente tehnice, în condiția să fie utilizate în conformitate cu instrucțiunile noastre:
- 17 zgodnie z następującymi normami i innymi dokumentami technicznymi, pod warunkiem że używane są zgodnie z naszymi instrukcjami:
- 18 conform de următoarele standarde și alte documente tehnice, în condiția să fie utilizate în conformitate cu instrucțiunile noastre:
- 19 onder følgende standard(er) eller andre tekniske dokument(er), forudsat at disse anvendes i henhold til vores instruktioner:
- 20 under følgende standard(er) eller andre tekniske dokument(er), forudsat at disse anvendes i henhold til vores instruktioner:
- 21 conform de următoarele standarde și alte documente tehnice, în condiția să fie utilizate în conformitate cu instrucțiunile noastre:
- 22 conform de următoarele standarde și alte documente tehnice, în condiția să fie utilizate în conformitate cu instrucțiunile noastre:
- 23 conform de următoarele standarde și alte documente tehnice, în condiția să fie utilizate în conformitate cu instrucțiunile noastre:
- 24 conform de următoarele standarde și alte documente tehnice, în condiția să fie utilizate în conformitate cu instrucțiunile noastre:
- 25 conform de următoarele standarde și alte documente tehnice, în condiția să fie utilizate în conformitate cu instrucțiunile noastre:

- 01 Note * as set out in the Technical Construction File DAIKIN.TCF.016-DAIKIN.TCF.021 and judged positive) by KEIMA according to the Certificate 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 02 Hinweis * wie in der Technischen Konstruktionsakte DAIKIN.TCF.016-DAIKIN.TCF.021 ausgeführt und von KEIMA positiv ausgeschrieben
- 03 Remarque * gemäß Zertifikat 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 04 Remark * tel que stipulé dans le Fichier de Construction Technique DAIKIN.TCF.016-DAIKIN.TCF.021 et jugé positivement par KEIMA conformément au Certificat 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 05 Remark * zoals vermeld in het Technisch Constructiebesluit DAIKIN.TCF.016-DAIKIN.TCF.021 en in orde bevonden door KEIMA overeenkomstig Certificaat 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565
- 06 Nota * tal como se expone en el Archivo de Construcción Técnica DAIKIN.TCF.016-DAIKIN.TCF.021 y juzgado positivamente por KEIMA según el Certificado 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 07 Nota * delimitat nel File Tecnico di Costruzione DAIKIN.TCF.016-DAIKIN.TCF.021 e giudicato positivamente da KEIMA secondo il Certificato 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565
- 08 Nota * όπως προορίζεται στο Αρχείο Τεχνικής Κonstrukτικής DAIKIN.TCF.016-DAIKIN.TCF.021 και κρίνεται θετικά από το KEIMA σύμφωνα με το Πρωτόκολλο 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 09 Nota * tal como estabelecido no Ficheiro Técnico de Construção DAIKIN.TCF.016-DAIKIN.TCF.021 e com o parecer positivo de KEIMA de acordo com o Certificado 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 10 Bemerk * som antori den Tekniske Konstruktionsfil DAIKIN.TCF.016-DAIKIN.TCF.021 og positivt vurderet af KEIMA i henhold til Certifikat 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 11 Information * KEMA villet også tillægge at Certifikat 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 12 Merk * KEMA villet också tillägga att Certifikat 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 13 Huom * KEMA illoje lisäksi lisätäksää Asiakirjassa DAIKIN.TCF.016-DAIKIN.TCF.021 tai mikä KEIMA on hyväksynyt Sertifikaatin 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565 mukaisesti.
- 14 Pozornia * jak bylo uvelereno v souboru technické konstrukce DAIKIN.TCF.016-DAIKIN.TCF.021 a pozitivně zjišeno KEIMA v souladu s ovedením 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 15 Napomena * kako je izloženo u Datojici o tehničkoj konstrukciji DAIKIN.TCF.016-DAIKIN.TCF.021 pozitivno ocjenjeno od strane KEIMA prema Certifikatu 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565
- 16 Megjegyzés * a(z) DAIKIN.TCF.016-DAIKIN.TCF.021 műszaki konstrukciós dokumentációjában, a(z) KEMA igazolta a megjelölt a(z) 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565 tanúsítvány szerinti.
- 17 Uwaga * zgodnie z archiwem dokumentacji konstrukcyjnej DAIKIN.TCF.016-DAIKIN.TCF.021, pozytywną opinią KEIMA i Świadectwem 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.

Jiro Tomita
 Director Quality Assurance
 Ostend, 2nd of November 2005



3PW25005-5

- 10 erklärt unter eigenem Namen, daß Klimaenergie-Modelle, zu dem Datum der Deklaration vordatumiert:
- 11 ыявляе пад сваёй адповедальнасцю, што даты адкрыцця гэтых мадэляў кліматычных энергіяў адпавядае тым, што ўказана ў гэтым заяўленні:
- 12 erklärt er följande, att luftkonditioneringsmodellerna som berörs av denna deklaration innehar att:
- 13 ilmoittaa yksinomaan omalla vastuullaan, että tämän ilmoituksen tarkoituksena on ilmoittaa ilmastointilaitteiden matit:
- 14 prohlásuje ve své plné odpovědnosti, že modely klimatizace, k nimž se toto prohlášení vztahuje:
- 15 izjavljue pod skupnoo vlastno odgovornostjo, da su modeli klima uređaja na koje se ova izjava odnosi:
- 16 teljes felelősséggel kijelentem, hogy a klímaberendezés modellek, melyekre e nyilatkozat vonatkozik:
- 17 deklarije na własną odpowiedzialność, że modele klimatyzatorów, których dotyczy niniejsza deklaracja:
- 18 deklará pe proprie răspundere că aparatele de aer condiționat la care se referă această declarație:

- 19 ыявляе пад сваёй адповедальнасцю, што даты адкрыцця гэтых мадэляў кліматычных энергіяў адпавядае тым, што ўказана ў гэтым заяўленні:
- 20 kinnitab oma täieliku vastutuse, et käesoleva deklaratsiooni alla kuuluvad kliimaseadmete mudelid:
- 21 deklaara na swoj odpowiedzialnosci, że modely klimatycznych instalacji, za które se odnosi taż deklaracja:
- 22 vyškla savo atsakomybę šekibia, kad oro kondicionavimo prietaisų modeliai, kuriems yra taikoma ši deklaracija:
- 23 ыявляе пад сваёй адповедальнасцю, што даты адкрыцця гэтых мадэляў кліматычных энергіяў адпавядае тым, што ўказана ў гэтым заяўленні:
- 24 vyhlásuje na vlastní zodpovednosť, že tieto klimatizačné modely, na ktoré sa vzťahuje toto vyhlásenie:
- 25 lamamen kendi sorumluluğunda olmak üzere bu bildirim için oluştüğü klima modellerinin sağduđakı gibi olduğunu beyan eder:

- 16 megjelölnek az alábbi szabvány(ok)nak vagy egyéb irányadó dokumentum(ok)nak, ha azokat előírás szerint használták:
- 17 megfelelnek az alábbi szabvány(ok)nak vagy egyéb irányadó dokumentum(ok)nak, ha azokat előírás szerint használták:
- 18 sunt în conformitate cu următoarele (normative) standarde (sau altele) documente (normative), cu condiția ca acestea să fie utilizate în conformitate cu instrucțiunile noastre:
- 19 skladni z naslednjimi standardi in drugimi normativi, pod pogojem, da se uporabijo v skladu z našimi navodili:
- 20 on vastavaus järgmistele standarditele või teiste normatiivse dokumente, kui need kasutatakse vastavalt meie juhenditele:
- 21 съответстват на следните стандарти или други нормативни документи, при условие, че се използват съгласно нашите инструкции:
- 22 allinka zemia nurobytus standartus ir (arba) kitus norminius dokumentus su sąlyga, kad yra naudojami pagal mūsų nurodymus:
- 23 tad, ja laiboti atbilstošs raščioja normatyvum, abia serijoseim standartien su citim normatiivem dokumentim:
- 24 su vzhod s naslednjimi (normativni) dokumentom(i)mi), za predpostavki, že se poživajajo v skladu s našimi navodili:
- 25 őrün, lálmalárm az gőre kulánlmasa kőszulva asgáduki standartiar ve nom beiflen begetele utumuldu:

- 01 Directives, as amended.
- 02 Direktiven, gemäß Änderung.
- 03 Directives, telles que modifiées.
- 04 Richtlijnen, zoals gewijzigd.
- 05 Directivas, según lo emmendado.
- 06 Directive, come da modifica.
- 07 Ohjuid, muut, sicut vromononjeli.
- 08 Direktivas, conforme alteração em.
- 09 Direktive, cu amendamentele respective.
- 10 Direktive, med senere ændringer.
- 11 Direkti, med foretagne ændringer.
- 12 Direktive, s tevarne izmenjena.
- 13 Direktive, sã laasã nã kũn ne ovat muutetuna.
- 14 v platném znení.
- 15 Smernice, kako je izmjeneno.
- 16 irányelvi (ek) és módosítások rendelkezései.
- 17 z poboljšanjim popravkami.
- 18 Direktivelor, cu amendamentele respective.

- 18 Nota * conform celor stabilite în Dosarul tehnic de construcție DAIKIN.TCF.016-DAIKIN.TCF.021 și apreciate pozitiv de KEIMA în conformitate cu Certificat 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 19 Opomba * KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 20 Märkus * nagu on määratud tehnilises konstruktsioonis DAIKIN.TCF.016-DAIKIN.TCF.021 ja heaks kiidetud KEIMA järgi vastavalt sertifikaatile 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 21 Zabeleška * kako je zabeleženo v Krta za tehnička konstrukcija DAIKIN.TCF.016-DAIKIN.TCF.021 i opešeno potvrdjeno ot KEIMA certifikatu 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 22 Pasaba * regu on määratud tehnilises konstruktsioonis DAIKIN.TCF.016-DAIKIN.TCF.021 ja heaks kiidetud KEIMA järgi vastavalt sertifikaatile 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 23 Pozornos * kako je zabeleženo u Krta za tehnička konstrukcija DAIKIN.TCF.016-DAIKIN.TCF.021 i opešeno potvrdjeno ot KEIMA certifikatu 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 24 Pozornia * ako je stanoveno v Souboru tehničke konstrukce DAIKIN.TCF.016-DAIKIN.TCF.021 a laide pozitivne KEIMA podľa Certifikatu 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565.
- 25 Not * DAIKIN.TCF.016-DAIKIN.TCF.021 Technik Yapı Dosyasında belirtilmiş gibi ve 81728-KRO.EMC98-4341 + 2024351-QUA.EMC02-4565 sertifikasına göre KEIMA tarafından olumlu olarak değerlendirilmiştir.



CONTENTS

	<u>Page</u>
Before installation	1
Selecting installation site	2
Preparations before installation	2
Installation procedures for fresh air intake duct connection.....	3
Indoor unit installation.....	3
Refrigerant piping work.....	4
Drain piping work.....	4
Electric wiring work.....	5
Wiring example and how to set the remote controller.....	5
Wiring example.....	6
Field setting	7
Installation of the decoration panel.....	8
Test operation	8
Wiring diagram	9



READ THESE INSTRUCTIONS CAREFULLY BEFORE INSTALLATION. KEEP THIS MANUAL IN A HANDY PLACE FOR FUTURE REFERENCE.

IMPROPER INSTALLATION OR ATTACHMENT OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORT-CIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.

IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DAIKIN DEALER FOR ADVICE AND INFORMATION.

BEFORE INSTALLATION









- Leave the unit inside its packaging until you reach the installation site. Where unpacking is unavoidable, use a sling of soft material or protective plates together with a rope when lifting, this to avoid damage or scratches to the unit.
- Refer to the installation manual of the outdoor unit for items not described in this manual.
- Caution concerning refrigerant series R-407C:
 - The connectable outdoor units must be designed exclusively for R-407C.
 - If outdoor units for R22, R-410A are connected, the system will not work properly.
- Caution concerning refrigerant series R-410A:
 - The connectable outdoor units must be designed exclusively for R-410A.
 - If outdoor units for R22, R-407C are connected, the system will not work properly.

Precautions

- Do not install or operate the unit in rooms mentioned below.
 - Places with mineral oil, or filled with oil vapour or spray like in kitchens. (Plastic parts may deteriorate.)
 - Where corrosive gas like sulphurous gas exists. (Copper tubing and brazed spots may corrode.)
 - Where volatile flammable gas like thinner or gasoline is used.
 - Where machines generating electromagnetic waves exist. (Control system may malfunction.)
 - Where the air contains high levels of salt such as air near the ocean and where voltage fluctuates a lot (e.g. in factories). Also in vehicles or vessels.
- When selecting the installation site, use the supplied paper pattern for installation.
- Do not install accessories on the casing directly. Drilling holes in the casing may damage electrical wires and consequently cause fire.

Accessories

Check if the following accessories are included with your unit.

 Clamp 1 pc.	Also used as packing material  Paper pattern for installation 1 pc.	 Drain hose 1 pc.
 Screws M5 For paper pattern for installation 4 pcs.	 Washer for hanging bracket 8 pcs.	 Sealing 2 pcs.
Insulation for fitting 1 each		Other: installation and operation manual
 for gas pipe	 for liquid pipe	

Optional accessories

- There are two types of remote controllers: wired and wireless. Select a remote controller according to customers request and install in an appropriate place. Refer to catalogues and technical literature for selecting a suitable remote controller.
- A decoration panel is also required for this indoor unit.

For the following items, take special care during construction and check after installation is finished

Tick ✓ when checked	
<input type="checkbox"/>	Is the indoor unit fixed firmly? The unit may drop, vibrate or make noise.
<input type="checkbox"/>	Is the gas leak test finished? It may result in insufficient cooling.
<input type="checkbox"/>	Is the unit fully insulated? Condensate water may drip.
<input type="checkbox"/>	Does drainage flow smoothly? Condensate water may drip.
<input type="checkbox"/>	Does the power supply voltage correspond to that shown on the name plate? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Are wiring and piping correct? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Is the unit safely grounded? Dangerous at electric leakage.
<input type="checkbox"/>	Is the wiring size according to specifications? The unit may malfunction or components may burn out.
<input type="checkbox"/>	Is nothing blocking the air outlet or inlet of either the indoor or outdoor units? It may result in insufficient cooling.
<input type="checkbox"/>	Are refrigerant piping length and additional refrigerant charge noted down? The refrigerant charge in the system might not be clear.

Notes to the installer

- Read this manual carefully to ensure correct installation. Be sure to instruct the customer how to properly operate the system and show him/her the enclosed operation manual.
- Explain to the customer what system is installed on the site. Be sure to fill out the appropriate installation specifications in the chapter "What to do before operation" of the outdoor unit operation manual.

SELECTING INSTALLATION SITE

When the conditions in the ceiling are exceeding 30°C and a relative humidity of 80%, or when fresh air is inducted into the ceiling, an additional insulation is required (minimum 10 mm thickness, polyethylene foam).

For this unit you can select different air flow directions. It is necessary to purchase an optional blocking pad kit to discharge the air in 2 or 3 directions.

- 1 Select an installation site where the following conditions are fulfilled and that meets your customer's approval.
 - Where optimum air distribution can be ensured.
 - Where nothing blocks air passage.
 - Where condensate water can be properly drained.
 - Where the false ceiling is not noticeably on an incline.
 - Where sufficient clearance for maintenance and service can be ensured.
 - Where piping between indoor and outdoor units is possible within the allowable limit. (Refer to the installation manual of the outdoor unit.)
 - Keep indoor unit, outdoor unit, power supply wiring and transmission wiring at least 1 meter away from televisions and radios. This is to prevent image interference and noise in those electrical appliances. (Noise may be generated depending on the conditions under which the electric wave is generated, even if 1 meter is kept.)

2 Ceiling height

This indoor unit may be installed on ceilings up to 3.5 m in height (for 80~125 units: 4.2 m). However, it becomes necessary to make field settings using the remote controller when installing the unit at a height over 2.7 m (for 80~125 units: 3.2 m). To avoid accidental touching, it is recommended to install the unit higher than 2.5 m. Refer to "Field setting" on page 7 and to the decoration panel installation manual.

3 Air flow directions

Select the air flow directions best suited to the room and point of installation. (For air discharge in 2 or 3 directions, it is necessary to make field settings by means of the remote controller and to close the air outlet(s). Refer to the installation manual of the optional blocking pad kit and to "Field setting" on page 7. (See figure 1) (↑: air flow direction)

- 1 Air discharge in 4 directions
- 2 Air discharge in 3 directions
- 3 Air discharge in 2 directions

4 Use suspension bolts for installation. Check whether the ceiling is strong enough to support the weight of the indoor unit. If there is a risk, reinforce the ceiling before installing the unit.

(The installation pitch is marked on the paper pattern for installation. Refer to it to check for points requiring reinforcing.) Space required for installation see figure 2 (↑: air flow direction)

- 1 Air discharge
- 2 Air inlet

NOTE Leave 200 mm or more space where marked with *, on sides where the air outlet is closed.

Model	H
35~71	≥240
100+125	≥298

PREPARATIONS BEFORE INSTALLATION

1 Relation of ceiling opening to unit and suspension bolt position. (See figure 3)

- 1 Refrigerant piping
- 2 Suspension bolt (x4)
- 3 Hanger bracket
- 4 False ceiling
- 5 Suspension bolt pitch
- 6 Indoor unit
- 7 Ceiling opening
- 8 Decoration panel

■ Installation is possible when opening dimensions are as follows. When installing the unit within the frame for fixing ceiling materials. (See figure 4)

- 1 Dimensions inside frame
- 2 Opening dimension inside the frame for ceiling
- 3 Frame
- 4 Ceiling material
- 5 Ceiling opening dimension
- 6 Ceiling-panel overlapping dimension

NOTE

Installation is possible with a ceiling dimension of 910 mm (marked with*). However, to achieve a ceiling-panel overlapping dimension of 20 mm, the spacing between the ceiling and the unit should be 35 mm or less. If the spacing between ceiling and the unit is over 35 mm, attach ceiling material to the part or recover the ceiling.

2 Make the ceiling opening needed for installation where applicable. (For existing ceilings.)

- Refer to the paper pattern for installation for the ceiling opening dimensions.
- Create the ceiling opening required for installation. From the side of the opening to the casing outlet, implement the refrigerant and drain piping and wiring for remote controller (unnecessary for wireless type). Refer to each piping or wiring section.
- After making an opening in the ceiling, it may be necessary to reinforce ceiling beams to keep the ceiling level and to prevent it from vibrating. Consult the builder for details.

3 Install the suspension bolts. (Use either a W3/8 or M10 size bolt.)

Use anchors for existing ceilings, and a sunken insert, sunken anchors or other field supplied parts for new ceilings to reinforce the ceiling in order to bear the weight of the unit. Adjust clearance from the ceiling before proceeding further.

Installation example (See figure 5)

- 1 Ceiling slab
- 2 Anchor
- 3 Long nut or turn-buckle
- 4 Suspension bolt
- 5 False ceiling

NOTE

- All the above parts are field supplied.
- For other installation than standard installation, contact your Daikin dealer for details.

INSTALLATION PROCEDURES FOR FRESH AIR INTAKE DUCT CONNECTION

1 Preparing the connection hole. (See figure 10)

- Cut off the knockout hole on the side plate with a nipper.
- Cut the insulation of the hole portion with a cutter.

- 1 Piping
- 2 Drain pipe
- 3 Side plate
- 4 Inner insulation
- 5 Slit

2 Placing the insulation. (See figure 11)

- Put the insulation tightly around the hole of the unit as shown. The ends of the side plate and the inner insulation must be completely adhered without leaving any clearance along the circumference of the hole. Make sure the inner surface of insulation tightly contacts the inner insulation edge and the side plate.

- 1 Insulation (field supply)
- 2 Side plate
- 3 Inner insulation

INDOOR UNIT INSTALLATION

When installing optional accessories (except for the decoration panel), read also the installation manual of the optional accessories. Depending on the field conditions, it may be easier to install optional accessories before the indoor unit is installed. However, for existing ceilings, install fresh air inlet component kit and branch duct before installing the unit.

1 Install the indoor unit temporarily.

- Attach the hanger bracket to the suspension bolt. Be sure to fix it securely by using a nut and washer from the upper and lower sides of the hanger bracket.

- Securing the hanger bracket (See figure 6)

- 1 Nut (field supply)
- 2 Washer (supplied with the unit)
- 3 Hanger bracket
- 4 Tighten (double nut)

2 Fix the paper pattern for installation. (For new ceilings only.)

- The paper pattern for installation corresponds with the measurements of the ceiling opening. Consult the builder for details.

- The centre of the ceiling opening is indicated on the paper pattern for installation. The centre of the unit is indicated on the unit casing and on the paper pattern for installation.

- After removing the packaging material from the paper pattern for installation, attach the paper pattern for installation to the unit with the attached screws as shown in figure 7.

- 1 Height adjustment of the unit
- 2 Ceiling material
- 3 Paper pattern for installation
- 4 Installation of paper pattern for installation (supplied with the unit)
- 5 Centre of the ceiling opening
- 6 Centre of the unit
- 7 Screws (supplied with the unit)

- Adjust the height of the unit until it matches the indication in figure 7.

3 Adjust the unit to the right position for installation.

(See "Preparations before installation" on page 2.)

4 Check if the unit is horizontally levelled.

- Do not install the unit tilted. The indoor unit is equipped with a built-in drain pump and float switch. (If the unit is tilted against condensate flow, the float switch may malfunction and cause water to drip.)

- Check if the unit is levelled at all four corners with a water level or a water-filled vinyl tube as shown in figure 14.

- 1 Water level
- 2 Vinyl tube

5 Remove the paper pattern for installation. (For new ceilings only.)

REFRIGERANT PIPING WORK


For refrigerant piping of outdoor unit, refer to the installation manual supplied with the outdoor unit.

Before rigging tubes, check which type of refrigerant is used.

! All field piping must be provided by a licensed refrigeration technician and must comply with the relevant local and national codes.

- Use a pipe cutter and flare suitable for the used refrigerant.
- If R-407C or R-410A refrigerant is used, apply ether or ester oil around the flare portions before connecting.
- To prevent dust, moisture or other foreign matter from infiltrating the tube, either pinch the end, or cover it with tape.
- The outdoor unit is charged with refrigerant.
- Be sure to use both a spanner and torque wrench together when connecting or disconnecting pipes to/from the unit.

- 1 Torque wrench
- 2 Spanner
- 3 Piping union
- 4 Flare nut




- Do not mix anything other than the specified refrigerant, such as air, etc. inside the refrigerant circuit.
- Refer to Table 1 for the dimensions of flare nut spaces and the appropriate tightening torque. (Overtightening may damage the flare and cause leaks.)

Table 1

Pipe gauge	Tightening torque	Flare dimension A (mm)		Flare shape
		R-407C	R-410A	
Ø6.4	14.2~17.2 N·m (144~176 kgf·cm)	8.3~8.7	8.7~9.1	
Ø9.5	32.7~39.9 N·m (333~407 kgf·cm)	12.0~12.4	12.8~13.2	
Ø12.7	49.5~60.3 N·m (504~616 kgf·cm)	15.4~15.8	16.2~16.6	
Ø15.9	61.8~75.4 N·m (630~770 kgf·cm)	18.6~19.0	19.3~19.7	
Ø19.1	97.2~118.6 N·m (990~1210 kgf·cm)	22.9~23.3	—	


When connecting the flare nut, coat the flare both inside and outside with refrigerating ether or ester oil and initially tighten by hand 3 or 4 turns before tightening firmly.

Coat here with ether oil or ester oil



- Check the pipe connector for gas leaks, then insulate it as shown in the figure below.


- 1 Liquid pipe
- 2 Gas pipe
- 3 Insulation for fitting of liquid line (supplied with the unit)
- 4 Insulation for fitting of gas line (supplied with the unit)
- 5 Clamps (use 2 clamps per insulation)



- If the refrigerant gas leaks during the work, ventilate the area. A toxic gas is emitted by the refrigerant gas being exposed to a fire.
- Finally make sure there is no refrigerant gas leak. A toxic gas may be released by the refrigerant gas leaking indoor and being exposed to flames from an area heater, cooking stove, etc.

DRAIN PIPING WORK

Rig the drain piping as shown in the figure and take measures against condensation. Improperly rigged piping could lead to leaks and eventually wet furniture and belongings.




- 1 Hanging bar

- 1 Install the drain pipes.

- Keep piping as short as possible and slope it downwards so that air may not remain trapped inside the pipe.
- Keep pipe size equal to or greater than that of the connecting pipe (vinyl pipe of 25 mm nominal diameter and 32 mm outer diameter).
- Insert the supplied drain hose into the drain socket, up to the white tape.
- Tighten the clamp until the screw head is less than 4mm from the hose.

- 1 Clamp metal (supplied with the unit)
- 2 Drain hose (supplied with the unit)
- 3 White tape (field supply)



- Insulate the drain piping inside the building.
- If the drain hose cannot be sufficiently set on a slope, fit the hose with drain raising piping (field supply).

HOW TO PERFORM PIPING (See figure 8)

- 1 Ceiling slab
- 2 Hanger bracket
- 3 Adjustable range
- 4 Drain raising pipe
- 5 Drain hose (supplied with the unit)
- 6 Clamp metal (supplied with the unit)

- Connect the drain hose to the drain raising pipes, and insulate them.
- Connect the drain hose to the drain outlet on the indoor unit, and tighten it with the clamp.

PRECAUTIONS

- Install the drain raising pipes at a height of less than 550 mm.
- Install the drain raising pipes at a right angle to the indoor unit and no more than 300 mm from the unit.

NOTE



The incline of attached drain hose should be 75 mm or less so that the drain socket does not have to withstand additional force.

To ensure a downward slope of 1:100, install hanging bars every 1 to 1.5 m.

When unifying multiple drain pipes, install the pipes as shown in figure 9. Select converging drain pipes whose gauge is suitable for the operating capacity of the unit.

- 1 T-joint converging drain pipes

2 After the piping work is finished, check if drainage flows smoothly.

- Open the water inlet lid, add approximately 2 l of water gradually and check the drainage flow.

Method of adding water (See figure 13)

- 1 Portable pump
- 2 Drain pipe
- 3 Service cover
- 4 Inspection opening
- 5 Service drain outlet (with rubber plug) (Use this outlet to drain water from the drain pan)
- 6 Plastic watering can (tube should be about 100 mm long) (Adding water through air discharge outlet)
- 7 Bucket (Adding water from inspection opening)

When electric wiring work is finished


Check drainage flow during COOL running, explained in "Test operation" on page 8.

When electric wiring work is not finished

For FHYCP only

- Remove the control box lid and change the emergency switch above the PC board assembly of the indoor unit from "Normal" to "Emergency". Connect the single-phase power supply (50 Hz, 230 V) to connections No. 1 and No. 3 on the power supply terminal board and confirm drain operation. Be sure to change the switch before turning on the power.
- Be aware that the fan will turn during the operation.
- After confirming drainage, turn off the power and be sure to change the emergency switch back to "Normal". (See figure 12)

Power supply terminal board (1)




Single phase power supply (2)

For FCQ only

- Remove the control box lid. Connect the single-phase power supply (50 Hz, 230 V) to connections No. 1 and No. 2 on the power supply terminal board and confirm drain operation.
- Be aware that the fan will turn during the operation.
- After confirming drainage, turn off the power. (See figure 12)

- 1 Switch box lid (1)
- 2 Power supply
- 3 Power supply terminal board
- 4 Rubber bush A
- 5 Clamp A
- 6 Switch box lid (2) with wiring diagram label
- 7 Transmission wiring
- 8 Terminal board for transmission wiring
- 9 Rubber bush B
- 10 Clamp B
- 11 Outside of the unit
- 12 Inside of the unit
- 13 Cable (power supply or transmission wiring)
- 14 Opening for the cable
- 15 Small sealing

Power supply terminal board (1)



Single phase power supply (2)

ELECTRIC WIRING WORK

General instructions

- All field supplied parts and materials and electric works must conform to local codes.
- Use copper wire only.
- Follow the 'Wiring diagram' attached to the unit body to wire the outdoor unit, indoor units and the remote controller. For details on hooking up the remote controller, refer to the "Installation manual of the remote controller".
- All wiring must be performed by an authorized electrician.
- A circuit breaker capable of shutting down power supply to the entire system must be installed.
- Note that the operation will restart automatically if the main power supply is turned off and then turned back on again.
- Refer to the installation manual attached to the outdoor unit for the size of power supply electric wire connected to the outdoor unit, the capacity of the circuit breaker and switch, and wiring instructions.

Electrical characteristics

NOTE For details, refer to "Electrical data".



Specifications for field wire

	Wire	Size (mm ²)	Length
Between indoor units	H05VV-U4G ^{(1),(2)}	2,5	—
Unit-Remote controller	Sheathed wire (2 wire) ⁽³⁾	0.75-1.25	Max. 500 m ⁽⁴⁾

- (1) Shows only in case of protected pipes. Use H07RN-F in case of no protection.
- (2) Run transmission wiring between the indoor and outdoor units through a conduit to protect against external forces, and feed the conduit through the wall together with refrigerant piping.
- (3) Use double insulation wire for remote controller (sheath thickness: ≥1 mm) or run wires through a wall or conduit so that the user cannot come in contact with them.
- (4) This length shall be the total extended length in the system of the group control.

WIRING EXAMPLE AND HOW TO SET THE REMOTE CONTROLLER

How to connect wiring (See figure 12)

- Power supply wiring
Remove the switch box lid (1) and connect the wires to the power supply terminal board inside. While doing this, pull the wires inside through the rubber bush A and clamp the wires along with other wires using clamp A, untightening the clip of clamp A by pressing. After the connection, tighten clamp A as before.
- Unit wiring and remote controller wiring
Remove the switch box lid (2) and pull the wires inside through the rubber bush B and connect to the terminal board for unit transmission wiring.

■ After connection

Attach the small sealing (supplied with the unit) around the cables to prevent infiltrating of water from the outside into the unit. If two or more cables are used, divide the small sealing into the required number of pieces and wrap them around all the cables.

- 1 Switch box lid (1)
- 2 Power supply
- 3 Power supply terminal board
- 4 Rubber bush A
- 5 Clamp A
- 6 Switch box lid (2) with wiring diagram label
- 7 Transmission wiring
- 8 Terminal board for transmission wiring
- 9 Rubber bush B
- 10 Clamp B
- 11 Outside of the unit
- 12 Inside of the unit
- 13 Cable (power supply or transmission wiring)
- 14 Opening for the cable
- 15 Small sealing

PRECAUTIONS

- 1 Observe the notes mentioned below when wiring to the power supply terminal board.
 - Do not connect wires of different gauge to the same power supply terminal. (Looseness in the connection may cause overheating.)
 - When connecting wires of the same gauge, connect them according to the figure.



Use the specified electric wire. Connect the wire securely to the terminal. Lock the wire down without applying excessive force to the terminal. (Tightening torque: 1.31 N·m ±10%).

- 2 Keep total current of crossover wiring between indoor units less than 12 A. Branch the line outside the terminal board of the unit in accordance with electrical equipment standards, when using two power wiring of a gauge greater than 2 mm² (Ø1.6).
The branch must be sheathed in order to provide an equal or greater degree of insulation as power supply wiring itself.
- 3 Do not connect wires of different gauge to the same grounding terminal. Looseness in the connection may deteriorate the protection.
- 4 Remote controller cords and wires connecting the units should be located at least 50 mm away from power supply wiring. Not following this guideline may result in malfunction due to electrical noise.
- 5 For the remote controller wiring, refer to the "Installation manual of the remote controller" supplied with the remote controller.

NOTE The customer has the ability to select the remote controller thermistor.

- 6 Never connect the power supply wiring to the terminal board for transmission wiring. This mistake could damage the entire system.
- 7 Use only specified wires and tightly connect wires to the terminals. Be careful that wires do not place external stress on the terminals. Keep wiring in neat order so that they do not obstruct other equipment such as popping open the service cover. Make sure the cover closes tight. Incomplete connections could result in overheating, and in the worst case, electric shock or fire.

WIRING EXAMPLE

For the wiring of outdoor units, refer to the installation manual attached to the outdoor units.

Confirm the system type:

- Pair type or multi system: 1 remote controller controls 1 indoor unit (standard system).
- Simultaneous operation system: 1 remote controller controls 2 indoor units (2 indoor units operate equally)
- Group control: 1 remote controller controls up to 16 indoor units (All indoor units operate according to the remote controller).
- 2 remote controller control: 2 remote controllers control 1 indoor unit.

Pair type or multi system (See figure 15)

Simultaneous operation system (See figure 16)

Group control (See figure 17)

2 remote controller control (See figure 18)

- 1 Main power supply
- 2 Main switch
- 3 Fuse
- 4 Outdoor unit
- 5 Indoor unit
- 6 Remote controller (optional accessories)
- 7 Indoor unit (Master)
- 8 Indoor unit (Slave)

NOTE It is not necessary to designate indoor unit address when using group control. The address is automatically set when the power is activated.

PRECAUTIONS

- 1 All transmission wiring except for the remote controller wiring is polarized and must match the terminal symbol.
- 2 In case of group control, perform the remote controller wiring to the master unit when connecting to the simultaneous operation system (wiring to the slave unit is unnecessary).
- 3 For group control remote controller, choose the remote controller that suits the indoor unit which has the most functions (as attached swing flap).
- 4 When controlling the simultaneous operation system with 2 remote controllers, connect it to the master unit (wiring to the slave unit is unnecessary).
- 5 Be sure to connect the wiring to the master unit when combining with a simultaneous operating multi-type in group control.
- 6 Do not ground the equipment on gas pipes, water pipes, lightning rods or crossground with telephones. Improper grounding could result in electric shock.

FIELD SETTING

Field setting must be made from the remote controller in accordance with the installation condition.

- Setting can be made by changing the "Mode number", "FIRST CODE No." and "SECOND CODE No.".
- For setting and operation, refer to "Field setting" in the installation manual of the remote controller.

Setting ceiling height

Select the SECOND CODE No. that corresponds to the ceiling height. (SECOND CODE No. is factory set to "01" for a ceiling height of 2.7 m or less.)

Ceiling height (m)		Mode n°	1st code n°	2nd code n°
units 35-71	units 100-125			
<2.7	<3.2	N	13 (23)	01
>2.7 or <3.0	<3.2 or <3.6	H	13 (23)	02
>3.0 or <3.5	<3.6 or 4.2	S	13 (23)	03

The figure of ceiling height is for air discharge in 4 directions.

Setting air discharge direction

For changing air discharge direction (2 or 3 directions), refer to the option handbook of the optional blocking pad kit. (SECOND CODE No. is factory set to "01" for air discharge in 4 directions.)

Setting when installing high performance filters

In case of installing high performance filters, refer to the option handbook of the high performance filters.

Setting air filter sign

Remote controllers are equipped with liquid crystal air filter signs to display the time to clean the air filter.

Change the SECOND CODE No. Depending on the amount of dirt or dust in the room. (SECOND CODE No. is factory set to "01" for air filter contamination-light)

Air Filter contamination

Setting	Display interval	Mode n°	1st code n°	2nd code n°
Light	±2500 hrs	10 (20)	0	01
Heavy	±1250 hrs	10 (20)	0	02

When using wireless remote controllers it is necessary to use address setting. Refer to the installation manual attached to the wireless remote controller for the setting instructions.

Setting indoor unit number of simultaneous operation system

When using in simultaneous operation system mode, change the SECOND CODE No. as shown in the table. (SECOND CODE No. is factory set to "01" for 1 connected unit.)

Setting	Mode No.	FIRST CODE No.	SECOND CODE No.
Pair system (1 unit)	11 (21)	0	01
Simultaneous operation system (2-unit)			02
Simultaneous operation system (3-unit)			03
Simultaneous operation system (4-unit)			04

When using in simultaneous operation system mode, refer to "Simultaneous operation system individual setting" on page 7 to set master and slave units separately.

When using wireless remote controllers

When using wireless remote controllers, wireless remote controller address setting is necessary. Refer to the installation manual attached to the wireless remote controller for setting instructions.

Simultaneous operation system individual setting

It is easier if the optional remote controller is used when setting the slave unit.

Perform the following procedures when setting the master and slave unit separately.

Procedure (See figure 19)

- 1 Change the SECOND CODE No. to "02", individual setting, so that the slave unit can be individually set. (SECOND CODE No. is factory set to "01", unified setting.)

Setting	Mode No.	FIRST CODE No.	SECOND CODE No.
Unified setting	11 (21)	1	01
Individual setting			02

- 2 Perform field setting for the master unit.
- 3 Turn off the main power supply switch after (2).
- 4 Detach remote controller from the master unit and connect it to the slave unit.
- 5 Turn on the main power supply switch again, and as in (1), change the Position No. to "02", individual setting.
- 6 Perform field setting for the slave unit.
- 7 Turn off the main power supply switch after (6).
- 8 Detach the remote controller from the slave unit after the setting, and reattach to the master unit. This is the end of the setting procedure.

You do not need to rewire the remote controller from the master unit if the optional remote controller for slave unit is used. (However, remove the wires attached to the remote controller terminal board of the master unit.)

Computerised control (forced off and on/off operation)

- 1 Wire specifications and how to perform wiring
 - Connect the input wire (option) to connector X40A on the indoor PCB.

Wire specifications (to extend the optional wire):

Wire specification	Sheathed vinyl cord or cable (2 wire)
Gauge	0.75-1.25 mm ²
Length	Max. 100 m
External terminal	Contact that can ensure the minimum applicable load of 15 V DC, 10 mA

(See figure 20)

- 1 Input A (Input "ON" = closed contact)
- 2 Actuation
 - The following table explains "forced off" and "on/off operations" in response to input A.

Forced off	on/off operation
Input "on" stops operation + disables control	input off → on: starts operation remote, control is still enabled
Input "off" enables control	input on → off: stops operation remote, control is still enabled

- 3 How to select forced off and on/off operation

Change the second code No. according to the table below. (Second code No. is factory set to "01" for forced off.)

Setting	Mode No.	FIRST CODE No.	SECOND CODE No.
Forced off	12 (22)	1	01
ON/OFF operation			02

INSTALLATION OF THE DECORATION PANEL

Refer to the installation manual attached to the decoration panel.
After installing the decoration panel, ensure that there is no space between the unit body and decoration panel. Otherwise air may leak through the gap and cause dew drop.

TEST OPERATION

Refer to "For the following items, take special care during construction and check after installation is finished" on page 2.

After finishing the construction of refrigerant piping, drain piping, and electric wiring, conduct test operation accordingly to protect the unit.

TEST OPERATION AFTER INSTALLING DECORATION PANEL

- 1 Open the gas side stop valve.
- 2 Open the liquid side stop valve.
- 3 Electrify crank case heater for 6 hours.
- 4 Set to cooling operation with the remote controller and start operation by pushing ON/OFF button.
- 5 Press Inspection/Test Operation button 4 times (2 times for wireless remote controller) and operate at Test Operation mode for 3 minutes.
- 6 Push air flow direction adjust button to make sure the unit is in operation.
- 7 Press Inspection/Test Operation button and operate normally.
- 8 Confirm function of unit according to the operation manual.

TEST OPERATION BEFORE INSTALLING DECORATION PANEL (See NOTE 3 on page 9)

- 1 Open the gas side stop valve.
- 2 Open the liquid side stop valve.
- 3 Electrify crank case heater for 6 hours.
- 4 Set to cooling operation with the wired remote controller and start operation by pushing ON/OFF button. "A7" appears on the display.
- 5 Press Inspection/Test Operation button on the remote controller and operate at Test Operation mode for 3 minutes.
- 6 Press Inspection/Test Operation button and operate normally.
- 7 Confirm function of unit according to the operation manual.
- 8 Turn off the main power supply after operation.

PRECAUTIONS

- 1 In case something is wrong with the unit and it does not operate, refer to the malfunction diagnosis label attached to the unit.
- 2 Refer to the installation manual attached to the outdoor unit in case of Individual Operation System type.
- 3 Conduct test operation after installing decoration panel if the wireless remote controller is used.

WIRING DIAGRAM

	: FIELD WIRING
	: TERMINAL
	: CONNECTOR
	: WIRE CLAMP
	: PROTECTIVE EARTH (SCREW)
33HFLOAT SWITCH
A1PPRINTED CIRCUIT BOARD
C1RCAPACITOR (FAN MOTOR)
CDCURRENT DETECT CIRCUIT
F1UFUSE (250 V/5 A) (only for FCQ35~60)
HAP,HBPLIGHT EMITTING DIODE (SERVICE MONITOR - GREEN)
M1AMOTOR (SWING FLAP)
M2FMOTOR (INDOOR FAN)
M3PMOTOR (DRAIN PUMP)
PCPHASE CONTROL CIRCUIT
Q1FTHERMO SWITCH (M2F EMBEDDED)
R1TTHERMISTOR (AIR)
R2TTHERMISTOR (LIQUID)
R3TTHERMISTOR (COIL) (only for FCQ35~60)
RCSIGNAL RECEIVER CIRCUIT
RyCMAGNETIC RELAY (OUTDOOR UNIT COMPRESSOR)
RyPMAGNETIC RELAY (DRAIN PUMP)
SS1SELECTOR SWITCH (EMERGENCY)
T1RTRANSFORMER (230 V, 22 V)
TCSIGNAL TRANSMISSION CIRCUIT
X1M,X2MTERMINAL STRIP

BLK	: BLACK
RED	: RED
WHT	: WHITE
YLW	: YELLOW

WIRED REMOTE CONTROLLER

SS1 SELECTOR SWITCH (MAIN/SUB)

RECEIVER/DISPLAY UNIT (ATTACHED TO WIRELESS REMOTE CONTROLLER)

A2P,A3P PRINTED CIRCUIT BOARD
BS ON/OFF BUTTON
H1P LIGHT EMITTING DIODE (ON - RED)
H2P LIGHT EMITTING DIODE (TIMER - GREEN)
H3P LIGHT EMITTING DIODE (FILTER SIGN - RED)
H4P LIGHT EMITTING DIODE (DEFROST - ORANGE)
SS1 SELECTOR SWITCH (MAIN/SUB)
SS2 SELECTOR SWITCH (WIRELESS ADDRESS SET)

ADAPTER FOR WIRING

RyC,RyF MAGNETIC RELAY

CONNECTOR FOR OPTIONAL PARTS

X30A CONNECTOR (INTERFACE ADAPTOR FOR SKY AIR SERIES) (only for FHYCP)
X33A CONNECTOR (ADAPTOR FOR WIRING)
X35A CONNECTOR (GROUP CONTROL ADAPTOR)
X40A CONNECTOR (REMOTE ON/OFF, FORCED OFF)
X60A,X61A CONNECTOR (INTERFACE ADAPTOR FOR SKY AIR SERIES) (only for FCQ)

RECEIVER/DISPLAY UNIT	:
IN CASE OF SIMULTANEOUS OPERATION SYSTEM	:
MASTER	:
SLAVE	:
REMOTE CONTROLLER	:
WIRED REMOTE CONTROLLER	:
ADAPTOR FOR WIRING	:
TERMINALS FOR OPERATION INDICATOR	:
FAN OPERATION	:
COMPRESSOR OPERATION	:
SWITCH BOX	:

NOTE



1. WHEN USING THE CENTRAL REMOTE CONTROLLER, SEE MANUAL FOR CONNECTION TO UNIT.
2. X24A IS CONNECTED WHEN THE WIRELESS REMOTE CONTROLLER KIT IS USED.
3. THE REMOTE CONTROLLER MODEL VARIES ACCORDING TO THE COMBINATION SYSTEM. SEE TECHNICAL MATERIALS AND CATALOGS, ETC. BEFORE CONNECTING.

