


DAIKIN

INVERTER




DAIKIN ROOM AIR CONDITIONER

Operation Manual

MODELS FLX50JV1B
FLX60JV1B

ENGLISH



CONTENTS

READ BEFORE OPERATION

- Safety Precautions 2
- Note for Multi System 4
- Names of Parts
 - Indoor unit, Opening the front grille 5
 - Remote controller 6
 - Outdoor unit 7
- Preparation Before Operation
 - Remote controller 8
 - Indoor unit 9

OPERATION

- AUTO • DRY • COOL • HEAT Operation 10
- Adjusting the Air Flow Direction
 - Adjusting the horizontal blade (flap) 11
 - Adjusting the vertical blade (louvre) 11
- POWERFUL Operation 12
- OUTDOOR UNIT SILENT Operation 12
- HOME LEAVE Operation 13
- Timer Operation
 - OFF TIMER operation 15
 - ON TIMER operation 15

CARE

- Care and Cleaning
 - Cleaning the air filters 16
 - Cleaning the indoor and outdoor units
and the remote controller 16
 - Replacing air purifying filters 16
 - Check 17
 - Before a long idle period 17

TROUBLE SHOOTING

- Trouble Shooting
 - These cases are not troubles 18
 - Check again 19
 - Call the service shop immediately 20
 - Fault diagnosis 21

Safety Precautions

- Read the following warnings and cautions carefully before operating the system and use it correctly.
- This manual classifies the precautions to the user into two categories on the right. Be sure to follow all as they are all important to ensure safety.
- After reading this manual, keep it in a place easily accessible to the user for future reference.

WARNING

Failure to follow a warning is very likely to result in such grave consequences as death or serious injury.

CAUTION

Failure to follow a caution may result in serious injury or property damage, and in certain conditions, may result in a grave consequence.

WARNING

- **Do not expose your body to the cool (heat) air for a long time, do not cool (heat) the room too much.**
It will affect your physical conditions and cause health problems.
- **Do not put a finger, a rod or other objects into the air outlet or inlet.**
As the fan is rotating at a high speed, it will cause injury.
- **Do not attempt to repair, relocate, modify or reinstall the air conditioner by yourself.**
Incorrect work will cause electric shocks, fire etc. For repairs and reinstallation, consult the shop where you bought the air conditioner.
- **If anything abnormal such as a burning smell occurs, stop the operation immediately and turn the breaker OFF.**
Continued abnormal operation will cause troubles, electric shocks, fire etc. If anything is abnormal, consult the shop where you bought the air conditioner.
- **If the air conditioner is not cooling or heating properly, the refrigerant may be leaking, so see the dealer where the unit was purchased. Check with a qualified repairman before attempting any repairs, which might accompany addition of refrigerant.**
The refrigerant used in the air conditioner is safe. Although leaks should not occur, if for some reason any refrigerant happens to leak into the room, make sure it does not come in contact with any flame, such as fan heaters, kerosene heaters, or gas ranges, as this may result noxious substances being generated.

CAUTION

- **Do not use the air conditioner for preservation purposes.**
Do not use it for preserving precision instruments, foods, plants, animals, works of fine arts etc. Performance or quality may deteriorate and animal or plant life may be shorter.
- **Do not operate the air conditioner with a wet hand.**
It may cause an electric shock.
- **Ventilate the room from time to time.**
Be careful especially when using a burning appliance in the same room. Insufficient ventilation may cause shortage of oxygen.
- **Before cleaning, be sure to stop the operation and turn the breaker OFF.**
As a fan is rotating at a high speed, cleaning during operation may cause injury.
- **After a long use, check the unit stand and fittings for damage.**
The unit may drop and cause injury if damage is left unrepaired.
- **Do not stand or sit on the outdoor unit. Do not place any object on the unit.**
The object or the person may fall down or drop, causing injury.

- **Do not place under the indoor or outdoor unit anything which must be kept away from moisture.**
Indoor unit : moisture in the air may condense and drip in certain conditions.
outdoor : during cooling operation, condensation may drip from the piping connections.
- **Do not wash the unit with water.**
It may cause an electric shock.
- **Do not place a burning appliance in places exposed to the air flow from the unit or under the indoor unit.**
It may cause incomplete combustion or deformation of the unit from heat.
- **Do not place a vessel containing water on the unit.**
Water may penetrate into the unit and degrade electrical insulations, resulting in an electric shock.
- **Do not expose plants or animals directly to the air flow.**
It may cause adverse effects on the plant or the animal.
- **Do not block air inlets nor outlets.**
Impaired air flow may result in insufficient performance or troubles.
- **Do not allow children to mount on the outdoor unit or avoid placing any object on it.**
Falling or tumbling may result in injury.

Installation

WARNING

- **Do not attempt to install the air conditioner by yourself.**
Consult the service shop or a qualified technician.
Incorrect work will result in water leakage, electric shocks or fire. For installation, consult the service shop where you bought the unit or a qualified technician.
- **The air conditioner must be earthed.**
Incomplete earthing may result in electric shocks. Do not connect the earth line to a gas pipe, water pipe, lightning rod, or a telephone earth line.

CAUTION

- **Depending on the environment, an earth leakage breaker must be installed.**
Lack of an earth leakage breaker may result in electric shocks.
- **Do not install the air conditioner in places where flammable gas may leak.**
If leaked gas should accumulate near the unit, fire may occur.
- **Arrange the drain hose to ensure smooth drainage.**
Incomplete drainage may cause wetting of the building, furniture etc.
- **Do not connect the air conditioner to a power supply different from the specification.**
It may cause trouble or fire.

Installation site

■ To install the air conditioner in the following types of environments, consult the shop.

- Places with an oily ambient or where steam or soot occurs.
- Salty environment such as coastal areas.
- Places where sulfide gas occurs such as hot springs.
- Places where snow may block the outdoor unit.

The drain from the outdoor unit must be discharged to a place of good drainage.

Consider nuisance to your neighbours from noises

■ For installation, choose a place as described below.

- A place solid enough to bear the weight of the unit which does not amplify the operation noise or vibration.
- A place from where the air discharged from the outdoor unit or the operation noise will not annoy your neighbours.

Electrical work

- For power supply, be sure to use a separate power circuit dedicated to the air conditioner.


System relocation

- Relocating the air conditioner requires specialized knowledge and skills. Please consult the shop where you bought the air conditioner if relocation is necessary for moving or remodeling.

Names of Parts

Indoor unit

The indoor unit can be installed either to the ceiling or to a wall. The descriptions contained in this manual show the case when installation is being carried out to the ceiling. (The methods of operation used are the same when installing to a wall.)



Opening the front grille

How to open the front grille : (See page 16 "Care and Cleaning")



CAUTION

Before opening the front grille, be sure to stop the operation and turn the breaker OFF.

Names of Parts

Remote controller

Open the cover.



Display

It displays the current settings. (In this illustration, each section is shown with all its displays ON for the purpose of explanation.)

POWERFUL button

(See page 12.)

MODE selector button

It selects the operation mode.



HOME LEAVE button

(See page 13.)

ON TIMER button

(See page 15.)

OFF TIMER button

(See page 15.)

TIME adjustment button

It changes the time setting.

Transmitter

It sends signals to the indoor unit.

TEMPERATURE adjustment button

It changes the temperature setting.

ON/OFF button

Press it once to start operation. To stop it, press it once again.

FAN setting button

It selects the air flow rate setting.

SWING button

(See page 11.)

OUTDOOR UNIT SILENT button


(See page 12.)

TIMER CANCEL button

It cancels the timer setting.


CLOCK button

(See page 9.)



Names of Parts

Outdoor unit




Appearance of the outdoor unit may differ from some models.


<RXD50/60J>

Preparation Before Operation

Remote controller

■ Setting the batteries



- 1 Press  with a finger and slide the front cover to take it off.
- 2 Set two alkaline dry batteries (LR03).
- 3 Set the front cover as before.
 - This will cause the figures on the display to flash. Set the clock at this point.


ATTENTION

About batteries

- Always replace two batteries at the same time. Replace them with new ones of an identical type.
- Do not use manganese dry batteries since their use may cause a malfunction.
- If you are not going to use the air conditioner for a long period, take out all the batteries.
- Batteries should last for about a year under normal conditions. When you find the displays unclear and signal communication often failing, replace them with new ones.
- Batteries may be exhausted even before the recommended date of consumption printed on them, if the air conditioner was manufactured many months ago.
- Never try to recharge the batteries.


■ Operating the remote controller

- To use the remote controller, aim the transmitter at the indoor unit. If there is anything to block signals between the unit and the remote controller, such as a curtain, the unit will not operate.
- Do not drop the remote controller. Do not get it wet.
- The maximum distance for communication is about 7 m.



■ To fix the remote controller holder on the wall

- 1 Choose a place from where the signals reach the unit.
- 2 Fix the holder to a wall, a pillar, etc. with the screws supplied with the holder.
- 3 Place the remote control in the remote control holder.



- To remove, pull it upwards.

ATTENTION

About the remote controller

- Never expose the remote controller to direct sunlight.
- Dust on the signal transmitter or receiver will reduce the sensitivity. Wipe off dust with soft cloth.
- Signal communication may be disabled if an electronic-starter-type fluorescent lamp (such as inverter-type lamps) is in the room. Consult the shop if that is the case.
- If the remote control signals happen to operate another appliance, move that appliance to somewhere else, or consult the shop.

Preparation Before Operation


Indoor unit

■ Setting the air purifying filters

- When opening the front grille, use a robust and stable stool and watch your steps carefully.


1 Open the front grille.

- Hold the grille by the tabs on the two sides and pull it until it stops.




2 Pull out the air filters.

- Push the tab at the center of each air filter, then pull it down.




3 Set the air purifying filters.

- Attach an air purifying filter to each air filter.



4 Set the air filters in their original positions and close the front grille.



- Push the grille at the 5 points indicated by ↑.
- Operation without air filters may result in troubles as dust will accumulate inside the indoor unit.

NOTE

Tips for saving energy

- Be careful not to cool the room too much. Keeping the temperature setting at a moderate level helps save energy.

Recommended temperature setting

For cooling: 26°C – 28°C
For heating: 20°C – 24°C

- Cover windows with a blind or a curtain. Blocking sunlight and air from outdoors increases the cooling effect.
- Clogged air filters cause inefficient operation and waste energy. Clean them once in about every two weeks.

■ Setting the clock

- #### 1 Press

0:00 is displayed.
AM 0:00 is displayed.
 blinks.

- #### 2 Press to set the clock to the present time.
- TEMP

3:30
PM 3:30

- Holding down (▲) or (▼) button rapidly increases or decreases the time display.

- #### 3 Press

3:30
PM 3:30 : blinks.

(Now the clock is set.)

■ Turn the breaker ON

- Turning ON the breaker opens the flap, then closes it again. (This is a normal procedure.)

Please note

- The air conditioner always consumes 15 – 35 watts of electricity even while it is not operating.
- If you are not going to use the air conditioner for a long period, for example in spring or autumn, turn the breaker OFF.
- Use the air conditioner in the following conditions.


Mode	Operating conditions	If operation is continued out of this range
COOL / DRY	<ul style="list-style-type: none"> • Outdoor temperature: -5 to 46 °C • Indoor temperature: 15 to 28 °C • Indoor humidity: 80% max. (*1) 	<ul style="list-style-type: none"> • A safety device may work to stop the operation. (In multi system, it may work to stop the operation of the outdoor unit only.) • Condensation may occur on the indoor unit and drip.
HEAT	<ul style="list-style-type: none"> • Outdoor temperature: -15 to 24 °C • Indoor temperature: 10 to 30 °C 	<ul style="list-style-type: none"> • A safety device may work to stop the operation.

(*1) Use in humidity 60 % or lower when using the unit at an outdoor temperature of 10°C or lower.


AUTO • DRY • COOL • HEAT Operation

The air conditioner operates with the settings of your choice.
From the next time on, the air conditioner will operate with the same settings.

1 Press **[MODE]** and select a mode.



- Each pressing of the button advances the mode setting in sequence.



2 Press **[ON/OFF]**.




Then OPERATION lamp lights up.

■ To stop:

Press **[ON/OFF]** once again.





Then OPERATION lamp goes off.

■ To change the temperature setting:

DRY mode	AUTO or HEAT or COOL mode
The temperature setting is not variable.	Press ▲ to raise the temperature and press ▼ to lower the temperature.
	Set to the temperature you like.
	

■ To change the air flow rate setting:

Press **[FAN]**.

DRY mode	AUTO or HEAT or COOL mode
The air flow rate setting is not variable.	Five levels of air flow rate setting from “  ” to “  ” plus “  ” are available.
	

- At smaller air flow rates, the cooling effect is also smaller.

■ To change the air flow direction:

(See page 11.)

NOTE

<Note on HEAT mode operation>

- Since this air conditioner heats the room by taking heat from outdoor air to indoors, the heating capacity becomes smaller in lower outdoor temperatures. If the heating effect is insufficient, it is recommended to use another heating appliance in combination with the air conditioner.
- The heat pump system heats the room by circulating hot air around all parts of the room. After the start of heating operation, it takes some time before the room gets warmer.
- In heating operation, frost may occur on the outdoor unit and lower the heating capacity. In that case, the system switches into defrosting operation to take away the frost.
- During defrosting operation, hot air does not flow out of indoor unit.

<Note on AUTO operation>


- In AUTO operation, the system selects a temperature setting and an appropriate mode (COOL or HEAT) based on the room temperature at the start of the operation.
- The system automatically reselects setting at a regular interval to bring the room temperature to user-setting level.
- If you do not like AUTO operation, you can select manually, you like the mode and setting.

Adjusting the Air Flow Direction

You can adjust the air flow direction to increase your comfort.

Adjusting the horizontal blade (flap)


Press .

- Every time the button is pressed, “” appears or disappears.



..... The flap automatically swings up and down.




..... To stop the flap at an angle you like, press .

No display

Notes on flap angles

- When [SWING] is selected, the flap swinging range depends on the operation mode. (See the figure.)



NOTE


- Unless [SWING] is selected, you should set the flap at a near- horizontal angle in COOL or DRY mode to obtain the best performance.
- In COOL or DRY mode, if the flap is fixed at a downward position, the flap automatically moves in about 60 minutes to prevent condensation on it.

ATTENTION

- Always use a remote controller to adjust the flap angle.
If you attempt to move it forcibly with hand when it is swinging, the mechanism may be broken.

Adjusting the vertical blade (louvre)

- When adjusting the louvre, use a robust and stable stool and watch your steps carefully.





Hold the knob and move the louvre.
(You will find a knob on the left side and the right side blades.)

POWERFUL Operation


POWERFUL operation quickly maximizes the cooling (heating) effect in any operation mode. You can get the maximum capacity with a touch of a button.

- Pressing the (POWERFUL) button during operation starts POWERFUL operation.
- POWERFUL operation ends in 20 minutes. Then the system automatically operates again with the settings which were used before POWERFUL operation.
- During you use “POWERFUL operation”, the other functions will not go on.

1 Press .



■ To cancel POWERFUL operation:

Press .

Notes on POWERFUL operation

● In COOL and HEAT mode

To maximize the cooling and heating effect, the capacity of outdoor unit must be increased and the air flow rate be fixed to the maximum setting.

The temperature and air flow settings are not variable.

● In DRY mode

The temperature setting is lowered by 3°C and the air flow rate is slightly increased.

OUTDOOR UNIT SILENT Operation


OUTDOOR UNIT SILENT operation lowers the noise-level of the outdoor unit by changing the frequency and fan rpm on the outdoor unit.

This function is convenient when sleeping, etc.

How to use OUTDOOR UNIT SILENT operation

- * This function is available in COOL, HEAT, and AUTO modes.

■ To use the “OUTDOOR UNIT SILENT operation”

Press .

■ To cancel the “OUTDOOR UNIT SILENT operation”

Press  again.

Note on OUTDOOR UNIT SILENT operation

- This function is available in COOL, HEAT, and AUTO modes.
(This is not available in DRY mode.)
- Using POWERFUL operation (P12) during OUTDOOR UNIT SILENT operation will disengage OUTDOOR UNIT SILENT operation.
- Turning the unit off either with the remote control or by flipping the switch on the unit during OUTDOOR UNIT SILENT operation will shut the unit off. The unit will continue in OUTDOOR UNIT SILENT operation when turned back on.


HOME LEAVE Operation

HOME LEAVE operation function is useful when you leave the house or the room.

How to use HOME LEAVE Operation

* This function is only available in COOL and HEAT modes.

■ To use the “HOME LEAVE Operation”

Press  while the air conditioner is operating.



(The HOME LEAVE lamp lights up.)

■ To cancel the “HOME LEAVE Operation”

Press  again.

(The HOME LEAVE lamp goes off.)

Before using HOME LEAVE Operation...


- When using HOME LEAVE Operation for the first time, set the temperature and air flow rate for HOME LEAVE Operation.


The initial settings are:


Heating ... Temperature 25°C Air flow rate AUTO

Cooling ... Temperature 25°C Air flow rate AUTO

■ How to set the temperature and air flow rate.

1 Press .

2 Adjust the set temperature with  as you like.

3 Adjust the air flow rate setting with  as you like.

* The temperature and air flow rate will be the same as the previous settings starting with the second use.

* If you want to change the settings from the previous use, repeat steps 1 through 3.

What's the HOME LEAVE Operation

● What is HOME LEAVE Operation?

Using HOME LEAVE Operation

During heating... It prevents the temperature in the room from dropping too far on cold winter days by using weak heating operation (*1). Disengaging HOME LEAVE Operation will return the room to the set temperature right away.


During cooling... It prevents the temperature in the room from rising too high on hot summer days by using weak cooling operation (*1). Disengaging HOME LEAVE Operation will return the room to the set temperature right away.

(*1)... You can change the set temperature and air flow rate as you wish. Refer to the “Before using home leave operation” section above on how to change the settings.

HOME LEAVE Operation

■ Useful at times like these!


1 Every day before you leave the house...



When you go out, push the "HOME LEAVE Operation" button, and the air conditioner will adjust capacity to reach the preset temperature for HOME LEAVE Operation.




When you return, you will be welcomed by a comfortably air conditioned room.




Push the "HOME LEAVE Operation" button again, and the air conditioner will adjust capacity to the set temperature for normal operation.


2 Before bed...



Set the unit to HOME LEAVE Operation before leaving the living room when going to bed.



The unit will maintain the temperature in the room at a comfortable level while you sleep.



When you enter the living room in the morning, the temperature will be just right. Disengaging HOME LEAVE Operation will return the temperature to that set for normal operation. Even the coldest winters will pose no problem!

NOTE

<Note on HOME LEAVE Operation>

- HOME LEAVE Operation is only available in COOL and HEAT modes. (Cannot be used in AUTO, DRY, and FAN modes.)
- HOME LEAVE Operation runs in accordance with the operation mode the unit was in before using HOME LEAVE Operation.
- HOME LEAVE Operation can be set within the ranges shown below.
Temperature: (During heating) 10°C to 30°C
(During cooling) 18°C to 32°C
Air flow rate: 5 steps from weak to strong, or automatic.
- Using POWERFUL operation (P12) during HOME LEAVE Operation will disengage HOME LEAVE Operation.
- Turning the unit off by flipping the switch on the unit during HOME LEAVE Operation will shut the unit off. The unit will continue in HOME LEAVE Operation when turned back on.
- Turning the unit off with the remote control during HOME LEAVE Operation will shut the unit off.
H/P: HOME LEAVE Operation will be disengaged when the unit is turned back on.


Timer Operation

Timer functions are useful for automatically switching the air conditioner on or off at night or in the morning. You can also use OFF TIMER and ON TIMER in combination.

OFF TIMER operation

- Check that the clock is correct. If not, set the clock to the present time. (See page 9.)


1 Press **OFF** while the air conditioner is operating.



2 Press **TEMP** until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by ten minutes. Holding down either button changes the setting rapidly.

3 Press **OFF** once again.



■ To cancel the timer:

Press **CANCEL**.

Then the TIMER lamp goes off.


Notes on OFF TIMER

- **NIGHT SET MODE**
When the OFF TIMER is set, the air conditioner automatically adjusts the temperature setting (0.5°C up in COOL) to prevent excessive cooling for your pleasant sleep.

ON TIMER operation

- Check that the clock is correct. If not, set the clock to the present time (See page 9).

1 Press **ON** while the air conditioner is not operating.



2 Press **TEMP** until the time setting reaches the point you like.

- Every pressing of either button increases or decreases the time setting by 10 minutes. Holding down either button changes the setting rapidly.

3 Press **ON** once again.



Then the TIMER lamp lights up.

Combining ON TIMER and OFF TIMER

- A sample setting for combining the two timers is shown below.

(Example)

Present time: 11:00 PM
(The unit operating)
OFF TIMER at 0:00 a.m. } Combined
ON TIMER at 7:00 a.m. }



Notes on ON,OFF TIMER

- When TIMER is set, the present time is not displayed.
- Once you set ON,OFF TIMER, the time setting is kept in the memory. (The memory is canceled when remote controller batteries are replaced.)
- When operating the unit via the ON/OFF Timer, the actual length of operation may vary from the time entered by the user. (Maximum approx. 10 minutes.)

ATTENTION

- In the following cases, set the timer again.
 - After a breaker has turned OFF.
 - After a power failure.
 - After replacing batteries in the remote controller.

Care and Cleaning

CAUTION


- Before cleaning, be sure to stop the operation and turn the breaker OFF.
- When opening the front grille, use a robust and stable stool and watch your steps carefully.

Cleaning the air filters

(It is recommended to clean them every two weeks.)


1 Open the front grille.

- Hold the grille by the tabs on the two sides and lift it until it stops.




2 Pull out the air filters.

- Push upwards the tab at the center of each air filter, then pull it down.



3 Take off the air purifying filters and clean them.

- Wash them with water, or clean them with a vacuum cleaner.
- If the dust does not come off easily, wash them with neutral detergent thinned with lukewarm water, then dry them up in the shade.



4 Set the air purifying filters and the air filters as they were and close the front grille.

- Insert claws of the filters into slots of the front panel.
- Push the grille at the 5 points. (See page 9 "Indoor unit".)

NOTE

- In a dusty environment, clean the air filters at least once in every two weeks.
- Operation with dusty air filters lowers the cooling capacity and wastes energy.

Cleaning the indoor and outdoor units and the remote controller


- Wipe them with dry soft cloth. For cleaning, do not use water hotter than 40°C, benzine, gasoline, thinner, nor other volatile oils, polishing compound, scrubbing brushes nor other hard stuff.

Replacing air purifying filters

(It is recommended to replace them every three months.)


- Air purifying filters need to be replaced regularly.

1 Open the front grille and pull out the air filters.




2 Take off the air purifying filters.

Air purifying filter frame




3 Detach the filter element and attach a new one.



- Hold the recessed parts of the frame and unhook the four claws.

4 Attach the air purifying filter.



5 Set the air filters as they were and close the front grille.

(Push the grille at the 5 point.)

NOTE

- To order air purifying filters, contact the service shop where you bought the air conditioner.
- Once the air purifying filter element gets dirty, it is not reusable but must be thrown away.
- Operation with dirty air purifying filters:
 - cannot clean the air.
 - results in poor cooling.
 - may cause odour.

Item	Part No.
Air purifying filter (with frame)	KAF918A41
Air purifying filter (without frame)	KAF918A42

Care and Cleaning

Check

Check that the base, stand and other fittings of the outdoor unit are not decayed or corroded.

Check that nothing blocks the air inlets and the outlets of the indoor unit and the outdoor unit.


Check that the earth wire is not disconnected or broken.


Check that the drain comes smoothly out of the drain hose during COOL or DRY operation.


- If no drain water is seen, water may be leaking from the indoor unit. Stop operation and consult the service shop if this is the case.

Before a long idle period

1 Operate the fan alone for several hours on a fine day to dry out the inside.

1 Press **MODE** and select “”.

2 Press  and set the temperature to 32°C

3 Press .

- Perform this operation when the room temperature is under 28°C.

2 Clean the air filters and set them again.

3 Take out batteries from the remote controller.

4 Turn OFF the breaker for the room air conditioner.

Trouble Shooting

● **These cases are not troubles.**

The following cases are not air conditioner troubles but have some reasons. You may just continue using it.

Case	Explanation
<p>Operation does not start soon.</p> <ul style="list-style-type: none"> ● When ON/OFF button was pressed soon after operation was stopped. ● When the mode was reselected. 	<ul style="list-style-type: none"> ● This is to protect the air conditioner. You should wait for about 3 minutes.
<p>Hot air does not flow out soon after the start of heating operation.</p>	<ul style="list-style-type: none"> ● The air conditioner is warming up. You should wait for 1 to 4 minutes. (The system is designed to start discharging air only after it has reached a certain temperature.)
<p>The heating operation stops suddenly and a flowing sound is heard.</p>	<ul style="list-style-type: none"> ● The system is taking away the frost on the outdoor unit. You should wait for about 3 to 8 minutes.
<p>The outdoor unit emits water or steam.</p>	<ul style="list-style-type: none"> ■ In HEAT mode <ul style="list-style-type: none"> ● The frost on the outdoor unit melts into water or steam when the air conditioner is in defrost operation. ■ In COOL or DRY mode <ul style="list-style-type: none"> ● Moisture in the air condenses into water on the cool surface of outdoor unit piping and drips.
<p>Mists come out of the indoor unit.</p>	<ul style="list-style-type: none"> ■ This happens when the air in the room is cooled into mist by the cold air flow during cooling operation.
<p>The indoor unit gives out odour.</p>	<ul style="list-style-type: none"> ■ This happens when smells of the room, furniture, or cigarettes are absorbed into the unit and discharged with the air flow. (If this happens, we recommend you to have the indoor unit washed by a technician. Consult the service shop where you bought the air conditioner.)
<p>The outdoor fan rotates while the air conditioner is not in operation.</p>	<ul style="list-style-type: none"> ■ After operation is stopped: <ul style="list-style-type: none"> ● The outdoor fan continues rotating for another 30 seconds for system protection. ■ While the air conditioner is not in operation: <ul style="list-style-type: none"> ● When the outdoor temperature is very high, the out door fan starts rotating for system protection.
<p>The operation stopped suddenly. (OPERATION lamp is on)</p>	<ul style="list-style-type: none"> ■ For system protection, the air conditioner may stop operating on a sudden large voltage fluctuation. It automatically resumes operation in about 3 minutes.

Trouble Shooting

● **Check again**

Please check again before calling a repair person.

Case	Check
<p>The air conditioner does not operate. (OPERATION lamp is off)</p>	<ul style="list-style-type: none"> ● Hasn't a breaker turned OFF or a fuse blown? ● Isn't it a power failure? ● Are batteries set in the remote controller? ● Is the timer setting correct?
<p>Cooling or Heating effect is poor.</p>	<ul style="list-style-type: none"> ● Are the air filters clean? ● Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? ● Is the temperature setting appropriate? ● Are the windows and doors closed? ● Are the air flow rate and the air direction set appropriately?
<p>Operation stops suddenly. (OPERATION lamp blinks.)</p>	<ul style="list-style-type: none"> ● Are the air filters clean? ● Is there anything to block the air inlet or the outlet of the indoor and the outdoor units? <p>Clean the air filters or take all obstacles away and turn the breaker OFF. Then turn it ON again and try operating the air conditioner with the remote controller. If the lamp still blinks, call the service shop where you bought the air conditioner.</p>
<p>An abnormal functioning happens during operation.</p>	<ul style="list-style-type: none"> ● The air conditioner may malfunction with lightening or radio waves. Turn the breaker OFF, turn it ON again and try operating the air conditioner with the remote controller.

Trouble Shooting

- Call the service shop immediately.

WARNING

- When an abnormality (such as a burning smell) occurs, stop operation and turn the breaker OFF.
Continued operation in an abnormal condition may result in troubles, electric shocks or fire.
Consult the service shop where you bought the air conditioner.
- Do not attempt to repair or modify the air conditioner by yourself.
Incorrect work may result in electric shocks or fire.
Consult the service shop where you bought the air conditioner.

If one of the following symptoms takes place, call the service shop immediately.

- The power cord is abnormally hot or damaged.
- An abnormal sound is heard during operation.
- The safety breaker, a fuse, or the earth leakage breaker cuts off the operation frequently.
- A switch or a button often fails to work properly.
- There is a burning smell.
- Water leaks from the indoor unit.

Turn the breaker OFF and call the service shop.

■ After a power failure

The air conditioner automatically resumes operation in about three minutes. You should just wait for a while.

■ Lightening

If lightening may strike the neighbouring area, stop operation and turn the breaker OFF for system protection.

Disposal requirements

Dismantling of the unit, treatment of the refrigerant, oil and eventual other parts, should be done in accordance with the relevant local and national regulations.

We recommend periodical maintenance

In certain operating conditions, the inside of the air conditioner may get foul after several seasons of use, resulting in poor performance. It is recommended to have periodical maintenance by a specialist aside from regular cleaning by the user. For specialist maintenance, contact the service shop where you bought the air conditioner.
The maintenance cost must be born by the user.

Trouble Shooting

● Fault diagnosis

FAULT DIAGNOSIS BY REMOTE CONTROLLER

IN THE EVENT OF AN ABNORMALITY, THE RELEVANT ABNORMALITY CODE APPEARS FLASHING IN THE REMOTE CONTROLLER'S TEMPERATURE DISPLAY.

	CODE	MEANING
SYSTEM	00	NORMAL
	U0	REFRIGERANT SHORTAGE
	U2	MAIN CIRCUIT OVERVOLTAGE OR LOWVOLTAGE
	U4	INCORRECT INTERUNIT WIRING (INTERUNIT)
INDOOR UNIT	A1	INDOOR PCB DEFECTIVENESS
	A5	STOPPED BY HIGH PRESSURE CONTROL OR FREEZE-UP PROTECTOR
	A6	FAN MOTOR FAULT
	C4 OR C5	FAULTY HEAT EXCHANGER SENSOR
	C9	FAULTY SUCTION AIR TEMPERATURE SENSOR
	E3	HIGH PRESSURE SWITCH ABNORMALITY
OUTDOOR UNIT	E5	OL OR TFU
	E6	FAULTY COMPRESSOR START
	E7	FAN MOTOR FAULT
	E8	INPUT OVERCURRENT

	CODE	MEANING
OUTDOOR UNIT	F3	STOPPED BY HIGH TEMPERATURE DISCHARGE PIPE CONTROL
	H3	HIGH PRESSURE SWITCH DEFECT
	H6	FAULTY POSITION DEFLECTION SENSOR
	H8	CT ABNORMALITY
	H9	FAULTY SUCTION AIR TEMPERATURE SENSOR
	J3	FAULTY DISCHARGE PIPE TEMPERATURE SENSOR
	J6	FAULTY HEAT EXCHANGER SENSOR
	L4	HIGH TEMPERATURE AT INVERTER CIRCUIT HEATSINK
	L5	OUTPUT OVERCURRENT
	P4	FAULTY INVERTER CIRCUIT HEATSINK TEMPERATURE SENSOR

FAULT DIAGNOSIS BY LED ON OUTDOOR UNIT PCB

GREEN MICROCOMPUTER NORMAL LED-A	RED MALFUNCTION DETECTION				DIAGNOSIS
	LED1	LED2	LED3	LED4	
●	●	●	●	●	NORMAL → CHECK INDOOR UNIT
●	✱	●	✱	✱	HIGH PRESSURE PROTECTOR WORKED, OR FREEZE-UP IN OPERATING UNIT OR STAND-BY UNIT
●	✱	●	✱	●	✱ INTERNAL THERMOSTAT WORKED OR HIGH DISCHARGE PIPE TEMPERATURE
●	●	✱	✱	●	FAULTY COMPRESSOR START
●	●	✱	●	✱	INPUT OVERCURRENT
●	✱	✱	●	●	THERMISTOR OR CT ABNORMALITY
●	✱	✱	●	✱	HIGH TEMPERATURE SWITCHBOX
●	●	●	●	✱	HIGH TEMPERATURE AT INVERTER CIRCUIT HEATSINK
●	●	●	✱	●	✱ OUTPUT OVERCURRENT
●	●	●	✱	✱	REFRIGERANT SHORTAGE
●	✱	●	●	✱	POWER FACTOR MODULE ABNORMALITY
✱	-	-	-	-	[NOTE 1]
●	-	-	-	-	POWER SUPPLY FAULT OR[NOTE 2]

GREEN	NORMALLY FLASHING
RED	NORMALLY OFF
✱	ON
●	FLASHING
●	OFF
-	IRRELEVANT

- NOTES**
- TURN THE POWER OFF AND THEN ON AGAIN. IF THE LED DISPLAY RECURS, THE OUTDOOR UNIT PCB IS FAULTY.
 - TURN THE POWER OFF AND THEN ON AGAIN. IF THE LED DISPLAY RECURS, TURN THE POWER OFF AND DISCONNECT LINE 2 OF INTER-UNIT WIRING FOR ALL UNITS, THEN TURN THE POWER ON AGAIN.
 <IF LED-A IS OFF;>
 THE OUTDOOR UNIT PCB IS FAULTY
 <IF LED-A IS FLASHING;>
 THE INDOOR UNIT PCB IS FAULTY. TURN THE POWER OFF, RECONNECT LINE 2 OF ALL INTER-UNIT WIRING AND CHECK THE DIAGNOSIS BY THE LEDS ON THE INDOOR UNIT PCB.
 - DIAGNOSES MARKED
 ✱ DO NOT APPLY TO SOME CASES. FOR DETAILS, REFER TO THE SERVICE GUIDE.

DAIKIN INDUSTRIES, LTD.

Head office:
Umeda Center Bldg., 4-12, Nakazaki-Nishi 2 chome,
Kita-ku, Osaka, 530-8323 Japan

Tokyo office:
Shinjuku Sumitomo Bldg., 6-1 Nishi-Shinjuku
2-chome, Shinjuku-ku, Tokyo, 163-0235 Japan

DAIKIN EUROPE NV

Zandvoordestraat 300, B-8400 Oostende, Belgium