



**DAIKIN**



# INSTALLATION MANUAL

**Split system air conditioner**





RZQ200C7Y1B  
RZQ250C7Y1B









	①	②	③	④
A+B+C+D	I)*	$c \geq 300 \text{ mm}$ $a \geq 10 \text{ mm}$ $b \geq 10 \text{ mm}$ $d \geq 500 \text{ mm}$		$c \geq 500 \text{ mm}$ $a \geq 10 \text{ mm}$ $b \geq 10 \text{ mm}$ $d \geq 500 \text{ mm}$
			$e \geq 20 \text{ mm}$ $f \geq 600 \text{ mm}$	$f \geq 900 \text{ mm}$
A+B	II)*	$c \geq 100 \text{ mm}$ $a \geq 50 \text{ mm}$ $b \geq 50 \text{ mm}$ $d \geq 500 \text{ mm}$		$c \geq 500 \text{ mm}$ $a \geq 50 \text{ mm}$ $b \geq 50 \text{ mm}$ $d \geq 500 \text{ mm}$
			$e \geq 100 \text{ mm}$ $f \geq 500 \text{ mm}$	$f \geq 600 \text{ mm}$
	III)	$a \geq 200 \text{ mm}$ $c \geq 300 \text{ mm}$ $e \geq 400 \text{ mm}$		

\*  $H > 1500 \text{ mm} \Rightarrow d \geq d + (h_2/2)$   
 $h > 500 \text{ mm} \Rightarrow c \geq c + (h_2/2)$





1







2






6



8



12



16

**CE - DECLARACION-DE-CONFORMIDAD**  
**CE - DICHIARAZIONE-DE-CONFORMITA**  
**CE - ΔΗΛΩΣΗ ΣΥΜΜΟΡΦΩΣΗΣ**

**Daikin Europe N.V.**

- 01 (GB) declares under its sole responsibility that the air conditioning models to which this declaration relates;
- 02 (E) erklärt auf seine alleinige Verantwortung daß die Modelle der Klimaanlage für die diese Erklärung bestimmt ist;
- 03 (D) déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration;
- 04 (NL) verklaart hierop op eigen exclusieve verantwoordelijkheid dat de airconditioning units waarop deze verklaring betrekking heeft;
- 05 (E) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración;
- 06 (IT) dichiara sotto la propria responsabilità che i condizionatori modelli a cui si riferisce questa dichiarazione;
- 07 (G) δηλώνει με αποκλειστική της ευθύνη ότι το προϊόν των κλιματιστικών αερίων που αναφέρεται η παρούσα δήλωση;
- 08 (E) declara sob sua exclusiva responsabilidade que os modelos de ar condicionado a que esta declaração se refere;

**RZQ200CY7Y1B \***, **RZQ250CY7Y1B \***,  
\* = . . . 1 . 2 . 3 . ... 9

- 01 are in conformity with the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
  - 02 (E) der/den folgenden Norm(en) oder einem anderen Normdokument oder Dokumenten entsprechend entsprechen unter der Voraussetzung, daß sie gemäß unserer Anweisungen eingesetzt werden;
  - 03 sono conformi ai/lux norme(s) o altre(s) documenti(s) normativi, purchè adottati quali sono utilizzati conformemente à noi istruzioni.
- EN60335-2-40,**

01 following the provisions of:

- 02 gemäß den Vorschriften der:
- 11 negli standard:
- 03 conformément aux stipulations des:
- 12 negli standard di riferimento:
- 04 overeenkomstig de bepalingen van:
- 13 de onderzochte normen:
- 05 segundo las prescripciones de:
- 14 de normelekki ystanovienija:
- 06 de acordo com o previsto em:
- 15 oveti standard:
- 07 в соответствии с положениями:
- 16 в соответствии с положениями:
- 08 in accordance with the provisions of:
- 17 in accordance with the provisions of:
- 09 in overeenstemming met de bepalingen van:
- 18 in overeenstemming met de bepalingen van:

- 01\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 02\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 03\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:

**Zertifikat**

- 01\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 02\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 03\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:

- 04\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 05\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 06\* as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:

**CE - DECLARACIÓN-DE-CONFORMIDAD**  
**CE - ЗАЯВЛЕНИЕ-О-СОБЛЮДЕНИИ**  
**CE - OPYJDELSESKERKLARING**  
**CE - FÖRSÄKRAN-OM-ÖVERENSSTÄMMELSE**

**CE - IZJAVA-O-USKLABAVENOSTI**  
**CE - MEGFELELŐSÉG-NYILATKOZAT**  
**CE - DEKLARACJA-ZGODNOSCI**  
**CE - DECLARATIE-DE-CONFORMITATE**

- 09 (NB) záručen, nespornostno pod svoje odgovornosti, da so modeli klimatisalnih zrakov, ki so opredeljeni v tej deklaraciji, skladni s predpisanimi standardi (s) ali drugimi normativnimi dokumenti (s), če so uporabljeni skladno s našimi navodili.
- 10 (D) erklærer under eneansvar, at klimaanlægsmødelne, som denne deklaration vedrører:
- 11 (S) deklarerer i egenansvar, att luftkonditioneringsmodellerna som berörs av denna deklaration innebär att:
- 12 (N) erklærer i fuldstændigt ansvar for at luftkonditioneringsmodeller som berøres af denne deklaration inderbærer at:
- 13 (NB) imolitat ykstronaam omalla vastuullaan, että tämän ilmoituksen tallentamattomia sisältöä koskevat tiedot ovat oikeat.
- 14 (G) prohlásuje ve své plné odpovědnosti, že modely klimatizace, k nimž se toto prohlášení vztahuje.
- 15 (E) δηλώνει υπό αποκλειστική μου ευθύνη ότι τα μοντέλα κλιματιστικών αερίων που αναφέρονται σε αυτή την δήλωση:
- 16 (E) teljes felelősségge tudatlatlan kijelentem, hogy a klímaberendezés modellek, melyekre e nyilatkozat vonatkozik:

**Machinery 2006/42/EC**  
**Machinery 2004/108/EC**  
**Pressure Equipment 97/23/EC**

- 17 (G) as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 18 (D) erklærer i egenansvar, at maskinens konstruktion og konstruktionens komponenter er i overensstemmelse med følgende standard(er) eller andre normerende dokument(er), under forudsætning af at disse bruges i henhold til disse instrukser.
- 19 (S) deklarerar i eigenansvar, att maskinens konstruktion och konstruktionens komponenter är i överensstämmelse med följande standard(er) eller andra normerande dokument(er), under förutsättning att användningen sker i överensstämmelse med våra instruktioner.
- 20 (N) erklærer i fuldstændigt ansvar for at maskinens konstruktion og konstruktionens komponenter er i overensstemmelse med følgende standard(er) eller andre normerende dokument(er), under forudsætning at anvendelsen sker i overensstemmelse med vores instruktioner.
- 21 (NB) deklaruje w pełnej odpowiedzialności, że konstrukcja i konstrukcyjne części maszyny są zgodne z następującymi standardami (s) lub innymi normatywnymi dokumentami (s), o ile są stosowane zgodnie z naszymi instrukcjami.
- 22 (G) δηλώνει με αποκλειστική μου ευθύνη ότι η δομή και οι κατασκευαστικές μερών της μηχανής συμμορφώνονται με τον/τα ακόλουθο/ους πρότυπο/ους, υπό την προϋπόθεση ότι χρησιμοποιούνται σύμφωνα με τις οδηγίες χρήσης.
- 23 (E) deklaruje w pełnej odpowiedzialności, że konstrukcja i konstrukcyjne części maszyny są zgodne z następującymi standardami (s) lub innymi normatywnymi dokumentami (s), o ile są stosowane zgodnie z naszymi instrukcjami.

**CE - IZJAVA-O-USKLABAVENOSTI**  
**CE - MEGFELELŐSÉG-NYILATKOZAT**  
**CE - DEKLARACJA-ZGODNOSCI**  
**CE - DECLARATIE-DE-CONFORMITATE**

- 09 (NB) záručen, nespornostno pod svoje odgovornosti, da so modeli klimatisalnih zrakov, ki so opredeljeni v tej deklaraciji, skladni s predpisanimi standardi (s) ali drugimi normativnimi dokumenti (s), če so uporabljeni skladno s našimi navodili.
- 10 (D) erklærer under eneansvar, at klimaanlægsmødelne, som denne deklaration vedrører:
- 11 (S) deklarerar i eigenansvar, att luftkonditioneringsmodellerna som berörs av denna deklaration innebär att:
- 12 (N) erklærer i fuldstændigt ansvar for at luftkonditioneringsmodeller som berøres af denne deklaration inderbærer at:
- 13 (NB) imolitat ykstronaam omalla vastuullaan, että tämän ilmoituksen tallentamattomia sisältöä koskevat tiedot ovat oikeat.
- 14 (G) prohlásuje ve své plné odpovědnosti, že modely klimatizace, k nimž se toto prohlášení vztahuje.
- 15 (E) δηλώνει υπό αποκλειστική μου ευθύνη ότι τα μοντέλα κλιματιστικών αερίων που αναφέρονται σε αυτή την δήλωση:
- 16 (E) teljes felelősségge tudatlatlan kijelentem, hogy a klímaberendezés modellek, melyekre e nyilatkozat vonatkozik:

**CE - IZJAVA-O-USKLABAVENOSTI**  
**CE - MEGFELELŐSÉG-NYILATKOZAT**  
**CE - DEKLARACJA-ZGODNOSCI**  
**CE - DECLARATIE-DE-CONFORMITATE**

- 17 (G) as set out in the following standards (s) or other normative document(s) provided that these are used in accordance with our instructions:
- 18 (D) erklærer i egenansvar, at maskinens konstruktion og konstruktionens komponenter er i overensstemmelse med følgende standard(er) eller andre normerende dokument(er), under forudsætning af at disse bruges i henhold til disse instrukser.
- 19 (S) deklarerar i eigenansvar, att maskinens konstruktion och konstruktionens komponenter är i överensstämmelse med följande standard(er) eller andra normerande dokument(er), under förutsättning att användningen sker i överensstämmelse med våra instruktioner.
- 20 (N) erklærer i fuldstændigt ansvar for at maskinens konstruktion og konstruktionens komponenter er i overensstemmelse med følgende standard(er) eller andre normerende dokument(er), under forudsætning at anvendelsen sker i overensstemmelse med vores instruktioner.
- 21 (NB) deklaruje w pełnej odpowiedzialności, że konstrukcja i konstrukcyjne części maszyny są zgodne z następującymi standardami (s) lub innymi normatywnymi dokumentami (s), o ile są stosowane zgodnie z naszymi instrukcjami.
- 22 (G) δηλώνει με αποκλειστική μου ευθύνη ότι η δομή και οι κατασκευαστικές μερών της μηχανής συμμορφώνονται με τον/τα ακόλουθο/ους πρότυπο/ους, υπό την προϋπόθεση ότι χρησιμοποιούνται σύμφωνα με τις οδηγίες χρήσης.
- 23 (E) deklaruje w pełnej odpowiedzialności, że konstrukcja i konstrukcyjne części maszyny są zgodne z następującymi standardami (s) lub innymi normatywnymi dokumentami (s), o ile są stosowane zgodnie z naszymi instrukcjami.

- 01 Directives, as amended.
  - 02 Direktiven, gemalt Änderung.
  - 03 Directives, telles que modifiées.
  - 04 Richtlijnen, zoals gewijzigd.
  - 05 Directivas, según se emendado.
  - 06 Direktiwe, come da modifica.
  - 07 Övertygg, omnik, styvut, förändrad.
  - 08 Directivas, conforme alteração.
  - 09 Директиви, со вклучени поправки.
- 01 Directive, as amended.  
11 Direktiv, med foretagne ændringer.  
12 Direktiv, с текуче изменения.  
13 Direktives, salaisina kuin ovat muuteltuna.  
14 в планетин зміни.  
15 Smjerница, kako je izmijenjeno.  
16 irányelv(ek) és módosítási rendelkezés(ek).  
17 z późniejszych poprawkami.  
18 Directive, ot amendamentele respective.

- 21 \*kerto osallisesti, että seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukainen laite on suunniteltu ja valmistettu näiden standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 22 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 23 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 24 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 25 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 26 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 27 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 28 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 29 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.
- 30 \*tämä laite on suunniteltu ja valmistettu seuraavien standardien (s) tai muiden normatiivisten asiakirjojen (s) mukaisesti.

<A>	DAIKIN.TCF.02.ID1/07-2007
<B>	KEMA
<C>	2024351-QUAEMC02-4565
<D>	Daikin.TCFP.001
<E>	AIB Vinçotte (NB00026)
<F>	DTI
<G>	.
<H>	II

- 19 \*\*\* Daikin Europe N.V. je pooblaščen za sestavo datoteke s tehnično pomočjo.
- 20 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 21 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 22 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 23 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 24 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 25 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 26 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 27 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 28 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 29 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 30 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.

- 19 \*\*\* Daikin Europe N.V. je pooblaščen za sestavo datoteke s tehnično pomočjo.
- 20 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 21 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 22 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 23 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 24 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 25 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 26 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 27 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 28 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 29 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.
- 30 \*\*\* Daikin Europe N.V. is authorized to compile the technical construction file.

- 01 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 02 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 03 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 04 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 05 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 06 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 07 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 08 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 09 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 10 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 11 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.
- 12 \*\*\* Daikin Europe N.V. is authorized to compile the Technical Construction File.



CONTENTS

	Page
1. Safety considerations.....	1
2. Introduction .....	2
2.1. Combination.....	2
2.2. Standard supplied accessories.....	2
2.3. Optional accessories .....	2
2.4. Technical and Electrical specifications.....	2
3. Main components .....	2
4. Selection of location.....	2
5. Inspecting and handling the unit .....	3
6. Unpacking and placing the unit.....	3
7. Refrigerant piping .....	4
7.1. Selection of piping material.....	4
7.2. Refrigerant pipe size.....	4
7.3. Selection of branch pipe .....	5
7.4. Allowable pipe length and height difference .....	5
7.5. Existing or pre-installed piping can be used .....	5
7.6. Precautions on refrigerant piping.....	5
7.7. Connecting the refrigerant piping.....	6
7.8. Leak test and vacuum drying.....	7
7.9. Pipe insulation .....	7
7.10. Checking of unit and installation conditions.....	8
7.11. Stop valve operation procedure.....	8
7.12. Additional refrigerant charge.....	8
8. Field wiring.....	11
8.1. Internal wiring – Parts table .....	11
8.2. Optional connectors.....	12
8.3. Power circuit and cable requirements.....	12
8.4. General cautions.....	12
8.5. Examples.....	13
9. Before operation .....	14
9.1. Service precautions .....	14
9.2. Checks before initial start-up .....	15
9.3. Field setting .....	15
9.4. Test operation .....	16
10. Service mode operation.....	17
11. Caution for refrigerant leaks.....	17
12. Disposal requirements .....	18



READ THIS MANUAL ATTENTIVELY BEFORE STARTING UP THE UNIT. DO NOT THROW IT AWAY. KEEP IT IN YOUR FILES FOR FUTURE REFERENCE.

IMPROPER INSTALLATION OR ATTACHMENT OF EQUIPMENT OR ACCESSORIES COULD RESULT IN ELECTRIC SHOCK, SHORT-CIRCUIT, LEAKS, FIRE OR OTHER DAMAGE TO THE EQUIPMENT. BE SURE ONLY TO USE ACCESSORIES MADE BY DAIKIN WHICH ARE SPECIFICALLY DESIGNED FOR USE WITH THE EQUIPMENT AND HAVE THEM INSTALLED BY A PROFESSIONAL.

DAIKIN EQUIPMENT IS DESIGNED FOR COMFORT APPLICATIONS. FOR USE IN OTHER APPLICATIONS, PLEASE CONTACT YOUR LOCAL DAIKIN DEALER.

IF UNSURE OF INSTALLATION PROCEDURES OR USE, ALWAYS CONTACT YOUR DEALER FOR ADVICE AND INFORMATION.

THIS AIR CONDITIONER COMES UNDER THE TERM "APPLIANCES NOT ACCESSIBLE TO THE GENERAL PUBLIC".

The English text is the original instruction. Other languages are translations of the original instructions.

1. SAFETY CONSIDERATIONS

The precautions listed here are divided into the following two types. Both cover very important topics, so be sure to follow them carefully.



**WARNING**

If the warning is not observed, it may cause serious casualties.

**CAUTION**

If the caution is not observed, it may cause injury or damage to the equipment.

Warning

- Ask your dealer or qualified personnel to carry out installation work. Do not install the machine by yourself. Improper installation may result in water leakage, electric shocks or fire.
- Perform installation work in accordance with this installation manual. Improper installation may lead to water leakage, electric shocks or fire.
- Be sure to use only the specified accessories and parts for installation work. Failure to use the specified parts may result in water leakage, electric shocks, fire, or the unit falling.
- When wiring between the indoor and outdoor units, and wiring the power supply, form the wires so that the frontside panel can be securely fastened. If the frontside panel is not in place, overheat of the terminals, electric shocks or a fire may be caused.
- If refrigerant gas leaks during installation work, ventilate the area immediately. Toxic gas may be produced if refrigerant gas comes into contact with fire.
- After completing the installation work, check to make sure that there is no leakage of refrigerant gas. Toxic gas may be produced if refrigerant gas leaks into the room and comes into contact with a source of fire, such as a fan heater, stove or cooker.
- Before touching electric terminal parts, turn off power switch.
- Live parts can be easily touched by accident. Do never leave the unit unattended during installation or servicing when the service panel is removed.
- When planning to relocate former installed units, you must first recover the refrigerant after the pumping-down operation. Refer to chapter "Precaution for pumping-down operation" on page 10.

Caution

- Install drain piping according to this installation manual to ensure good drainage, and insulate the pipe to prevent condensation. Improper drain piping may cause water leakage, and make the furnitures get wet.
- Install the indoor and outdoor units, power wire and connecting wire at least 1 meter away from televisions or radios to prevent image interference or noise. (Depending on the radio waves, a distance of 1 meter may not be sufficient to eliminate the noise.)
- Do not rinse the outdoor unit. This may cause electric shocks or fire.



### Precautions for R410A

- The refrigerant requires strict cautions for keeping the system clean, dry and tight.
  - Clean and dry  
Foreign materials (including mineral oils or moisture) should be prevented from getting mixed into the system.
  - Tight  
Read "7.6. Precautions on refrigerant piping" on page 5 carefully and follow these procedures correctly.
- Since R410A is a mixed refrigerant, the required additional refrigerant must be charged in its liquid state. (If the refrigerant is in state of gas, its composition changes and the system will not work properly).
- The connected indoor units must be indoor units designed exclusively for R410A.

Read "7. Refrigerant piping" on page 4 carefully and follow these procedures correctly.



Since design pressure is 4.0 MPa or 40 bar, pipes of larger wall thickness may be required. Refer to paragraph "7.1. Selection of piping material" on page 4.

## 2. INTRODUCTION

### 2.1. Combination

The indoor units can be installed in the following range.

- Always use appropriate indoor units compatible with R410A. To learn which models of indoor units are compatible with R410A, refer to the product catalogs.
- For installation of the indoor unit(s), refer to the installation manual delivered with the indoor unit(s).

### 2.2. Standard supplied accessories

	RZQ200	RZQ250	
Gas line piping (1)	1	1	
Gas line piping (2)	1	1	
Liquid line piping (1)	1	1	
Liquid line piping (2)	1	1	
Installation manual	1	1	
Additional refrigerant charge label	1	1	
Fluorinated greenhouse gases label	1	1	
Multilingual fluorinated greenhouse gases label	1	1	

Refer to figure 2.

- 1 Installation manual
- 2 Accessory pipes

### 2.3. Optional accessories

This outdoor unit requires the pipe branching kit (optional) when using a twin, triple or double twin application. Refer to catalogues for details.

### 2.4. Technical and Electrical specifications

Refer to the Engineering Data Book for the complete list of specifications.

## 3. MAIN COMPONENTS

For main components and function of the main components, refer to the Engineering Data Book.

## 4. SELECTION OF LOCATION

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.



This unit, both indoor and outdoor, is suitable for installation in a commercial and light industrial environment. If installed as a house-hold appliance it could cause electromagnetic interference.



- Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals.
- Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.

The inverter units should be installed in a location that meets the following requirements:

- 1 The foundation is strong enough to support the weight of the unit and the floor is flat to prevent vibration and noise generation. If not, the unit may fall over and cause injury.
- 2 The space around the unit is adequate for servicing and the minimum space for air inlet and air outlet is available. (Refer to figure 1 and choose one of the possibilities).

In case of an installation site where only the sides A+B have obstacles, the wall heights have no influence on any indicated service space dimensions.

**A B C D** Sides along the installation site with obstacles

➡ Suction side

- 3 Make sure to provide for adequate measures in order to prevent that the outdoor unit be used as a shelter by small animals. Small animals making contact with electrical parts can cause malfunctions, smoke or fire. Please instruct the customer to keep the area around the unit clean.
- 4 There is no danger of fire due to leakage of inflammable gas.
- 5 Ensure that water cannot cause any damage to the location in case it drips out the unit (e.g. in case of a blocked drain pipe).
- 6 The piping length between the outdoor unit and the indoor unit may not exceed the allowable piping length.
- 7 Select the location of the unit in such a way that neither the discharged air nor the sound generated by the unit disturb anyone.

- 8 Make sure that the air inlet and outlet of the unit are not positioned towards the main wind direction. Frontal wind will disturb the operation of the unit. If necessary, use a windscreen to block the wind.
- 9 Do not install or operate the unit on locations where air contains high levels of salt, like e.g. in the vicinity of oceans.
- 10 During installation, avoid the possibility that children can mount on the unit or place any object on the unit.  
Falling or tumble may result in injury.
- 11 The equipment is not intended for use in a potentially explosive atmosphere.



- The equipment described in this manual may cause electronic noise generated from radio-frequency energy. The equipment complies to specifications that are designed to provide reasonable protection against such interference. However, there is no guarantee that interference will not occur in a particular installation. It is therefore recommended to install the equipment and electric wires keeping proper distances away from stereo equipment, personal computers, etc... (See figure 3).

- 1 Personal computer or radio
- 2 Fuse
- 3 Earth leakage breaker
- 4 Remote controller
- 5 Indoor unit

In extreme circumstances you should keep distances of 3 m or more and use conduit tubes for power and transmission lines.

- In heavy snowfall areas, select an installation site where snow will not affect operation of the unit.
- The refrigerant R410A itself is nontoxic, nonflammable and is safe. If the refrigerant should leak however, its concentration may exceed the allowable limit depending on room size. Due to this it could be necessary to take measures against leakage.
- Do not install in the following locations.
  - Locations where acidic or alkaline vapour is present.
  - Locations where sulfurous acids and other corrosive gases may be present in the atmosphere. Copper piping and soldered joints may corrode, causing refrigerant to leak.
  - Locations where there is mist of mineral oil, oil spray or vapor for example a kitchen. Plastic parts may deteriorate, and cause them to fall out or water to leak.
  - Locations where the air contains high levels of salt such as that near the ocean.
  - Locations where flammable gases may leak, where thinner, gasoline, and other volatile substances are handled, or where carbon dust and other incendiary substances are found in the atmosphere. Leaked gas may accumulate around the unit, causing an explosion.
  - Locations where equipment that produces electromagnetic waves is found. The electromagnetic waves may cause the control system to malfunction, preventing normal operation.
  - Locations where voltage fluctuates a lot, such as that in factories.
  - In vehicles or vessels.
- During installation, take strong winds, typhoons or earthquakes into account. Improper installation may result in fall over of the unit.

## 5. INSPECTING AND HANDLING THE UNIT


At delivery, the package should be checked and any damage should be reported immediately to the carrier claims agent.

When handling the unit, take into account the following:

- 1 Fragile, handle the unit with care.
- Keep the unit upright in order to avoid compressor damage.
- 2 Choose in advance the path along which the unit is to be brought in.
- 3 Bring the unit as close as possible to its final installation position in its original package to prevent damage during transport. (See figure 4)
  - 1 Packaging material
  - 2 Opening (large)
  - 3 Belt sling
  - 4 Opening (small) (40x45)
  - 5 Protector
- 4 Lift the unit preferably with a crane and 2 belts of at least 8 m long. (See figure 4)

Always use protectors to prevent belt damage and pay attention to the position of the unit's centre of gravity.

**NOTE** Use a belt sling of  $\geq 20$  mm wide that adequately bears the weight of the unit.

- 5 If a forklift is to be used, preferably transport the unit with pallet first, then pass the forklift arms through the large rectangular openings on the bottom of the unit.
 
- 5.1 From the moment you use a forklift to move the unit to its final position, lift the unit under the pallet.
- 5.2 Once at final position, unpack the unit and pass the forklift arms through the large rectangular openings on the bottom of the unit.

**NOTE** Use filler cloth on the forklift arms to prevent damaging the unit. If the paint on the bottom frame peels off, the anti corrosion effect may decrease.

## 6. UNPACKING AND PLACING THE UNIT

- Remove the four screws fixing the unit to the pallet.
- Make sure the unit is installed level on a sufficiently strong base to prevent vibration and noise.
- Fasten the unit in place using four anchor bolts M12.
- Make sure the base under the unit is more than 765 mm.
- The unit must be installed on a solid longitudinal foundation (steelbeam frame or concrete) as indicated in figure 5.

Model	A	B
RZQ200+250	930	792

- Support the unit with a foundation of 66 mm width or more. (The support leg of the unit is 66 mm width).




Do not use stands to support the corners. (See figure 6)

- X Not allowed
- O Allowed



- Prepare a water drainage channel around the foundation to drain waste water from around the unit.
- If the unit is to be installed on a roof, check the strength of the roof and its drainage facilities first.
- If the unit is to be installed on a frame, install the waterproofing board within a distance of 150 mm under the unit in order to prevent infiltration of water coming from under the unit.
- When installed in a corrosive environment, use a nut with a resin clip plate (1) to protect the nut tightening part from rust.



## PRECAUTION

Block all gaps in the holes for passing out piping and wiring using sealing material (field supply). (Small animals may enter the machine.)

Example: passing piping out through the front. (See figure 10)

- 1 Plug the areas marked with " " (When the piping is routed from the front panel.)
- 2 Gas side piping
- 3 Liquid side piping

## 7. REFRIGERANT PIPING



Use R410A to add refrigerant.

All field piping must be installed by a licensed refrigeration technician and must comply with relevant local and national regulations.

### CAUTION TO BE TAKEN WHEN BRAZING REFRIGERANT PIPING

- Do not use flux when brazing copper-to-copper refrigerant piping. (Particularly for the HFC refrigerant piping) Therefore, use the phosphor copper brazing filler metal (BCuP) which does not require flux. Flux has extremely harmful influence on refrigerant piping systems. For instance, if the chlorine based flux is used, it will cause pipe corrosion or, in particular, if the flux contains fluorine, it will damage the refrigerant oil.
- Be sure to perform a nitrogen blow when brazing. (Brazing without performing nitrogen replacement or releasing nitrogen into the piping will create large quantities of oxidized film on the inside of the pipes, adversely affecting valves and compressors in the refrigerating system and preventing normal operation.)
- After completing the installation work, check that the refrigerant gas does not leak. Toxic gas may be produced if the refrigerant gas leaks into the room and when it comes in contact with a source of fire. If any leak would happen:
  - ventilate the area immediately.
  - do not directly touch the refrigerant that leaks. Frostbite may be caused.

### NOTE



Installation tools:

Make sure to use installation tools (gauge manifold charge hose, etc.) that are exclusively used for R410A installations to withstand the pressure and to prevent foreign materials (e.g. mineral oils such as SUNISO and moisture) from mixing into the system. (The screw specifications differ for R410A and R407C.)

Vacuum pump (use a 2-stage vacuum pump with a non-return valve):

- Make sure the pump oil does not flow oppositely into the system while the pump is not working.

## 7.1. Selection of piping material

- Construction material: phosphoric acid deoxidized seamless copper for refrigerant.
- Temper grade: use piping with temper grade in function of the pipe diameter as listed in table below.
- The pipe thickness of the refrigerant piping should comply with relevant local and national regulations. The minimal pipe thickness for R410A piping must be in accordance with the table below.

Pipe Ø	Temper grade of piping material	Minimal thickness t (mm)
9.5 / 12.7	O	0.80
15.9	O	1.00
22.2	1/2H	1.00

O=Annealed  
1/2H=Half hard

## 7.2. Refrigerant pipe size

Refer to figure 9 for twin system, to figure 12 for triple system and to figure 13 for double twin system.

- Main pipe (pipe between outdoor and first branch). The pipes should have the same size as the outdoor connections.

Model	Refrigerant pipe size <sup>(1)</sup>		
		Standard size	Size-up
RZQ200	Gas pipe	Ø22.2	Ø25.4
	Liquid pipe	Ø9.5	Ø12.7
RZQ250	Gas pipe	Ø22.2	Ø25.4
	Liquid pipe	Ø12.7	Ø15.9

(1) In case of twin, triple and double twin applications, the listed refrigerant pipe sizes relate to the main pipes only. (L1 = the pipes between the outdoor unit and the branch in figures 9, 12 and 13).

- Pipe between first branch and second branch (L2+L3) (only for double twin).

Liquid	Ø9.5
Gas	Ø15.9

- Pipe between last branch and indoor units (L2~L3 for twin, L2~L4 for triple and L4~L7 for double twin). These pipe sizes must have the same size as the connected indoor units pipe sizes. Branch: see marking "□" on figures 9, 12 and 13.

### NOTE



- For new installations, use the standard pipe sizes.
- When using existing pipes, size-up is allowed as mentioned in the table above. Size up is only allowed for pair combination (L1). Additional restrictions towards allowable pipe lengths, as mentioned in the table "Allowable pipe length" on page 5, must be taken into account. Not using the standard pipe size may result in capacity decrease. The installer must acknowledge this and judge this very carefully in function of the complete installation.



### 7.3. Selection of branch pipe

Twin	KHRQ22M20TA
Triple	KHRQ250H
Double twin	KHRQ22M20TA (3x)

### 7.4. Allowable pipe length and height difference

See the table below concerning lengths and heights. Refer to figures 8, 9, 12 and 13. Assume that the longest line in the figure corresponds with the actual longest pipe, and the highest unit in the figure corresponds with the actual highest unit.

Allowable pipe length			
<b>Minimum piping length</b>			
All			5 m <sup>(1)</sup>
<b>Maximum total one way piping length</b>			
Pair	L1	standard	100 m
		size-up of gas pipe	100 m
		size-up of liquid pipe	50 m
Twin	L1+L2	—	100 m
Triple	L1+L2	—	100 m
Double twin	L1+L2+L4	—	100 m
<b>Maximum branch piping length</b>			
Twin and triple	L2	—	20 m
Double twin	L2+L4	—	20 m
<b>Maximum difference between branch lengths</b>			
Twin	L2–L3	—	10 m
Triple	L2–L4	—	10 m
Double twin	L2–L3, L6–L7, (L2+L4)–(L3+L7)	—	10 m
<b>Maximum height between indoor and outdoor</b>			
All	H1	—	30 m
<b>Maximum height between indoors</b>			
Twin, triple and double twin	H2	—	0.5 m
<b>Chargeless length</b>			
All	L1+L2+L3+L4+L5 +L6+L7	standard	30 m
		size-up of gas pipe	30 m
		size-up of liquid pipe	10 m

(1) The minimum piping length must be 5 m. If installation is performed with less field piping, the system will be overcharged (abnormal HP, etc.). If the distance between indoor and outdoor unit is less than 5 m, please make sure that the piping length is  $\geq 5$  m by additional bending of the pipes.



If size-up of liquid pipes are used, the indoor unit must be installed on a lower location than the outdoor unit.



### 7.5. Existing or pre-installed piping can be used

- Piping must comply with the criteria below.
  - Pipe diameter must comply with the limitations as indicated in paragraph "7.2. Refrigerant pipe size" on page 4.
  - Piping length must be within limits of the allowable piping length as in paragraph "7.4. Allowable pipe length and height difference" on page 5.
  - Piping must be designed for R410A. See paragraph "7.1. Selection of piping material" on page 4.
- Only main piping can be reused without cleaning when:
  - Total 1-way piping length:  $< 50$  m.
  - No compressor breakdown has occurred in the history of the unit to be replaced.
  - A correct pump down operation can be executed:
    - Operate the unit continuously for 30 minutes in cooling mode.
    - Execute a pump down operation.
    - Remove the airconditioning units to be replaced.

- Check the contamination inside the existing piping. If you cannot meet all these requirements, the existing pipes must be cleaned or replaced after removing the air conditioning units to be replaced.

### 7.6. Precautions on refrigerant piping

- Do not allow anything other than the designated refrigerant to get mixed into the freezing cycle, such as air, etc. If any refrigerant gas leaks while working on the unit, ventilate the room thoroughly right away.
- In order to prevent dirt, liquid or dust from entering the piping, cure the piping with a pinch or taping.

Place	Installation period	Protection method
Outdoor side	More than a month	Pinch the pipe
	Less than a month	
Indoor side	Regardless of the period	Pinch or tape the pipe

Great caution is needed when passing copper tubes through walls.

- In case of simultaneous operating system
  - Upward and downward piping should be performed at the main piping line.
  - Use branch piping kit (optional) for branching refrigerant pipes.

Precautions to be taken. (For details, refer to the manual attached to branch piping kit.)

- Install the branch pipes horizontally (with a maximum inclination of  $15^\circ$ ) or vertically.
- Length of branch pipe to the indoor unit should be as short as possible.
- Try to keep lengths of both branch pipes to the indoor unit equal.

- When re-using existing refrigerant piping  
Pay attention to the following points when re-using existing refrigerant piping

- Perform a visual check on quality of residual oil in existing refrigerant piping.

This check is extremely important because using existing piping with deteriorated oil will cause compressor breakdown.

- Put some residual oil of the pipes you want to reuse on a piece of white paper or on the white surface of an oil checking reference card and compare that oil color with the circled color of the oil checking reference card.
- If oil color is identical to the circled color or darker, replace the piping, install new piping or clean the piping thoroughly.
- If oil color is lighter, the pipes can be reused without cleaning.

An oil checking reference card is indispensable for such evaluation and can be obtained at your dealer.

- In the following situations, the existing piping should not be re-used and new piping should be installed.
  - If the previously used model had problems with its compressor (this might cause oxidized coolant oil, scale residue and other adverse effects).
  - If the indoor or outdoor units were disconnected from the piping for a long period of time (water or dirt might have gotten into the piping).
  - If copper piping is corroded.
- Existing flares may not be re-used but new ones must be made in order to prevent leaks.
- Check welded connections for gas leaks, if the local piping has welded connections.
- Replace deteriorated insulation with new material.

## 7.7. Connecting the refrigerant piping

- 1 Installation of refrigerant branching kit. (See figure 14)  
For installation, refer to the installation manual delivered with the kit. Follow the conditions listed below:  
Mount the refnet joint so that it branches either horizontally (see view A) or vertically.

1 Horizontal surface

- 2 Removing the pinched piping



### Never remove the pinched piping by brazing.

Any gas or oil remaining inside the stop valve may blow off the pinched piping.

Failure to observe the instructions in procedure below properly may result in property damage or personal injury, which may be serious depending on the circumstances.



Use the following procedure to remove the pinched piping:

- 1 Remove the valve lid and make sure that the stop valves are fully closed.
- 2 Connect a charge hose to service ports of all stop valves.
- 3 Recover gas and oil from the pinched piping by using a recovery unit.



Do not vent gases into the atmosphere.

- 4 When all gas and oil is recovered from the pinched piping, disconnect the charge hose and close the service ports.
- 5 In case the pinched piping lower part looks like detail A in the illustration, follow instructions as per procedure steps 7+8.

In case the pinched piping lower part looks like detail B in the illustration, follow instructions as per procedure steps 6+7+8.

- 6 Cut off the lower part of the smaller pinched piping with an appropriate tool (e.g. a pipe cutter, a pair of nippers, ...) so that a cross-section is open, allowing remaining oil to drip out in case the recovery was not complete.  
Wait until all oil is dripped out.




- 7 Cut the pinched piping off with a pipe cutter just above the brazing point or just above the marking in case there is no brazing point.



Never remove the pinched piping by brazing.



- 8 Wait until all oil is dripped out in case the recovery was not complete, and only then proceed with connection of the field piping.



- 1 Service port
- 2 Stop valve
- 3 Point of pipe cutting just above brazing point or above marking

A Pinched piping

B Pinched piping




Precautions when connecting field piping.

- Perform brazing at the gas stop valve before brazing at the liquid stop valve.
- Add brazing material as shown in the figure.



- Be sure to use the supplied accessory pipes when carrying out piping work in the field.
- Be sure that the field installed piping does not touch other pipes, the bottom panel or side panel. Especially for the bottom and side connection, be sure to protect the piping with suitable insulation, to prevent it from coming into contact with the casing.

- 3 Installation of refrigerant piping is possible as front connection or side connection (when taken out from the bottom) as shown in the figure below.



- 1 Left-side connection
- 2 Front connection
- 3 Right-side connection

- Front connection:  
Remove the stop valve cover to connect. (See figure 7)
- Side (bottom) connection:  
Remove the knock holes on the bottom frame and route the piping under the bottom frame. (See figure 7)

A Front connection  
Remove the stop valve cover to connect.

B Bottom connection:  
Remove the knock holes on the bottom frame and route the piping under the bottom frame

- 1 Gas side stop valve
- 2 Liquid side stop valve
- 3 Service port for adding refrigerant
- 4 Gas side accessory pipe (1)
- 5 Gas side accessory pipe (2)
- 6 Liquid side accessory pipe (1)
- 7 Liquid side accessory pipe (2)
- 8 Brazing
- 9 Gas side piping (field supply)
- 10 Liquid side piping (field supply)
- 11 Punch the knockout holes (use a hammer)

### Precautions when knocking out knockout holes

- Be sure to avoid damaging the casing.
  - After knocking out the holes, we recommend you paint the edges and areas around the edges using the repair paint to prevent rusting.
  - When passing electrical wiring through the knock holes, wrap the wiring with protective tape to prevent damage.
- 4 Make sure to perform the piping installation within the range of the maximum allowable pipe length, allowable level difference and allowable length after branching as indicated in "7.4. Allowable pipe length and height difference" on page 5.

5 For installation of the refrigerant branching kit (Refnet), refer to the installation manual delivered with the kit.

## 6 Pipe connection

Be sure to perform a nitrogen blow when brazing. (Brazing without performing nitrogen replacement or releasing nitrogen into the piping will create large quantities of oxidized film on the inside of the pipes, adversely affecting valves and compressors in the refrigerating system and preventing normal operation.)

### NOTE



The pressure regulator for the nitrogen released when doing the brazing should be set to 0.02 MPa or less. (See figure 11)

- 1 Refrigerant piping
- 2 Location to be brazed
- 3 Nitrogen
- 4 Taping
- 5 Manual valve
- 6 Regulator



Do not use anti-oxidants when brazing the pipe joints. Residue can clog pipes and break equipment.

## Cautions for necessity of a trap

Since there is fear of the oil held inside the riser piping flowing back into the compressor when stopped and causing liquid compression phenomenon, or cases of deterioration of oil return, it will be necessary to provide a trap at an appropriate place in the riser gas piping.

- Trap installation spacing. (See figure 16)
  - A Outdoor unit
  - B Indoor unit
  - C Gas piping
  - D Liquid piping
  - E Oiltrap
  - H Install trap at each difference in height of 10 m.
- A trap is not necessary when the outdoor unit is installed in a higher position than the indoor unit.

## 7.8. Leak test and vacuum drying

The units were checked for leaks by the manufacturer. After connecting the field piping, perform the following inspections.

### 1 Preparations

Referring to figure 15, connect a nitrogen tank, a cooling tank, and a vacuum pump to the outdoor unit and perform the airtightness test and the vacuum drying. The stop valve and valves A and B in figure 15 should be open and closed as shown in the table below when performing the airtightness test and vacuum drying.

- 1 Pressure reducing valve
- 2 Nitrogen
- 3 Measuring instrument
- 4 Tank (siphon system)
- 5 Vacuum pump
- 6 Charge hose
- 7 Service port for adding refrigerant
- 8 Gas line stop valve
- 9 Liquid line stop valve
- 10 Outdoor unit
- 11 To indoor unit
- 12 Stop valve service port
- 13 Dotted lines represent on site piping
- 14 Valve B
- 15 Valve C
- 16 Valve A


State of the valves A and B and the stop valve	Valve A	Valve B	Valve C	Liquid side stop valve	Gas side stop valve
Performing the airtightness test and vacuum drying (Valve A must always be shut. Otherwise the refrigerant in the unit will pour out.)	Close	Open	Open	Close	Close

## 2 Airtightness test and vacuum drying

### NOTE



Make sure to perform airtightness test and vacuum drying using the service ports of the stop valves of the liquid side and of the gas side. (For the service port location, refer to the "Caution" label attached on the front panel of the outdoor unit.)



- See "7.11. Stop valve operation procedure" on page 8 for details on handling the stop valve.
- To prevent entry of any contamination and to prevent insufficient pressure resistance, always use the special tools dedicated for working with R410A refrigerant.

### ■ Airtightness test:

#### NOTE



Make sure to use nitrogen gas.

Pressurize the liquid and gas pipes to 4.0 MPa (40 bar) (do not pressurize more than 4.0 MPa (40 bar)). If the pressure does not drop within 24 hours, the system passes the test. If the pressure drops, check where the nitrogen leaks from.

- Vacuum drying: Use a vacuum pump which can evacuate to  $-100.7$  kPa (5 Torr,  $-755$  mm Hg)
  1. Evacuate the system from the liquid and gas pipes by using a vacuum pump for more than 2 hours and bring the system to  $-100.7$  kPa. After keeping the system under that condition for more than 1 hour, check if the vacuum gauge rises or not. If it rises, the system may either contain moisture inside or have leaks.
  2. Following should be executed if there is a possibility of moisture remaining inside the pipe (if piping work is carried out during the raining season or over a long period of time, rainwater may enter the pipe during work). After evacuating the system for 2 hours, pressurize the system to 0.05 MPa (vacuum break) with nitrogen gas and evacuate the system again using the vacuum pump for 1 hour to  $-100.7$  kPa (vacuum drying). If the system cannot be evacuated to  $-100.7$  kPa within 2 hours, repeat the operation of vacuum break and vacuum drying. Then, after leaving the system in vacuum for 1 hour, confirm that the vacuum gauge does not rise.

## 7.9. Pipe insulation

After finishing the leak test and vacuum drying, the piping must be insulated. Take into account the following points:

- Make sure to insulate the connection piping and refrigerant branch kits entirely.
- Be sure to insulate liquid and gas piping.
- Use heat resistant polyethylene foam which can withstand a temperature of  $70^{\circ}\text{C}$  for liquid side piping and polyethylene foam which can withstand a temperature of  $120^{\circ}\text{C}$  for gas side piping.
- If you think the temperature and the relative humidity around the cooling pipes might exceed  $30^{\circ}\text{C}$  and RH 80%, reinforce the insulation of the cooling pipes (at least 20 mm thick). Condensation might be formed on the surface of the insulation.

- If there is a possibility that condensation on the stop valve might drip down to the indoor side through gaps in the insulation and piping because the outdoor unit is located higher than the indoor unit this must be prevented by sealing up the connections. See [figure 20](#).

- 1 Liquid line stop valve
- 2 Gas line stop valve
- 3 Indoor -outdoor interconnection piping
- 4 Sealing up treatment
- 5 Heat insulator



Be sure to insulate local pipes, as touching them can cause burns.

## 7.10. Checking of unit and installation conditions

Be sure to check the following:

- 1 Make sure there is no faulty power wiring or loosening of a nut. See "8. Field wiring" on page 11.
- 2 Make sure there is no faulty transmission wiring or loosening of a nut. See "8. Field wiring" on page 11.
- 3 Make sure there is no faulty refrigerant piping. See "7. Refrigerant piping" on page 4.
- 4 Make sure piping size is correct. See "7.1. Selection of piping material" on page 4.
- 5 Make sure insulation work is done. See "7.9. Pipe insulation" on page 7.
- 6 Make sure insulation resistance of main power circuit is not deteriorated.

Using a megatester for 500 V, check that the insulation resistance of 2 MΩ or more is attained by applying a voltage of 500 V DC between power terminals and earth. Never use the megatester for the transmission wiring (between outdoor and indoor unit, outdoor and COOL/HEAT selector, etc.).

## 7.11. Stop valve operation procedure



Do not open the stop valve until the steps 1~6 of "7.10. Checking of unit and installation conditions" on page 8 are completed. If the stop valve is left open without turning on the power, it may cause refrigerant to buildup in the compressor, leading to insulation degradation.

### Introduction

Confirm the sizes of the stop valves connected to the system referring to the table below.

Model	Liquid line stop valve	Gas line stop valve
RZQ200	Ø9.5	Ø22.2
RZQ250	Ø9.5→12.7 (with reducer)	Ø22.2

### Opening stop valve

1. Remove the cap and turn the valve counterclockwise with the hexagon wrench.
2. Turn it until the shaft stops.  
Do not apply excessive force to the stop valve. Doing so may break the valve body, as the valve is not a backseat type. Always use the special tool.
3. Make sure to tighten the cap securely.

### Closing stop valve

1. Remove the cap and turn the valve clockwise with the hexagon wrench.
2. Securely tighten the valve until the shaft contacts the main body seal.
3. Make sure to tighten the cap securely.  
For the tightening torque, refer to the table below.

Tightening torque (N·m) (Turn clockwise to close)						
stop valve size	Shaft (valve body)		Cap (valve lid)	Service port	Flare nut	Gas line piping attached to unit
Ø9.5	5.4~6.6	Hexagonal wrench 4 mm	13.5~16.5	11.5~13.9	33~40	—
Ø12.7	8.1~9.9	Hexagonal wrench 6 mm	18~22		50~60	
Ø15.9	13.5~16.5	Hexagonal wrench 8 mm	23~27		62~75	
Ø22.2	27~33	Hexagonal wrench 10 mm	36~44		—	

(See figure 18)

- 1 Service port
- 2 Cap
- 3 Hexagon hole
- 4 Shaft
- 5 Seal

### CAUTION

- Always use a charge hose for service port connection.
- After tightening the cap, check that no refrigerant leaks are present.

## 7.12. Additional refrigerant charge

### Important information regarding the refrigerant used

This product contains fluorinated greenhouse gases covered by the Kyoto Protocol. Do not vent gases into the atmosphere.

Refrigerant type: R410A

GWP<sup>(1)</sup> value: 1975


<sup>(1)</sup> GWP = global warming potential

Please fill in with indelible ink,

- ① the factory refrigerant charge of the product,
- ② the additional refrigerant amount charged in the field and
- ①+② the total refrigerant charge

on the fluorinated greenhouse gases label supplied with the product.

The filled out label must be adhered on the inside of the product and in the proximity of the product charging port (e.g. on the inside of the service cover).



- 1 factory refrigerant charge of the product: see unit name plate
- 2 additional refrigerant amount charged in the field
- 3 total refrigerant charge
- 4 Contains fluorinated greenhouse gases covered by the Kyoto Protocol
- 5 outdoor unit
- 6 refrigerant cylinder and manifold for charging

### NOTE



National implementation of EU regulation on certain fluorinated greenhouse gases may require to provide the appropriate official national language on the unit. Therefore, an additional multilingual fluorinated greenhouse gases label is supplied with the unit.

Sticking instructions are illustrated on the backside of that label.

## Precaution for servicing



When performing service on the unit requiring the refrigerant system to be opened, refrigerant must be evacuated according to local regulations.

This unit requires additional charging of refrigerant according to the length of pipe connected at the site. Charge the refrigerant to the liquid pipe in its liquid state through the serviceport of the liquid stop valve. Since R410A is a mixed refrigerant, its composition changes if charged in a state of gas and normal system operation would no longer be assured.

On this model it is not necessary to charge additionally if the standard pipe size in pair combination is used and if the total piping length  $\leq 30$  m.

## Additional charging of refrigerant

Installations with total piping lengths  $\leq 30$  m do not require additional charging of refrigerant.


For total piping lengths over 30 m, calculate the required additional refrigerant in function of the calculated length and pipe diameters like explained in the following procedure.

- 1 Add up the total piping length.
  - In case the result is  $\leq 30$  m, your installation does not require any additional charge.
  - In case the result is over 30 m, proceed as explained from step 2 onwards.
- 2 Subtract 30 m from the calculated total piping length. Take note of this rest value and, starting from the outdoor unit, check the exact position in the refrigerant flow where you reach this rest value.
- 3 Determine the pipe diameter at that position in the refrigerant flow.
- 4 From that same position on, add up the remaining pipe lengths of that same pipe diameter downstream to the indoor unit(s).
- 5 Determine the required additional refrigerant charge in function of the calculated pipe length of that pipe diameter by multiplying that length by the appropriate calculation coefficient.  
Take note of the calculated weight.
- 6 Repeat step 5 for other pipe diameters in function of other pipe diameter pipe lengths downstream to the indoor units and add up all calculated weights.
- 7 The sum of all calculated weights is the total required additional refrigerant charge for your installation.  
The final result must be rounded to 100 g.
- 8 Calculation coefficients

$\varnothing$	Coefficient
12.7	0.09
9.5	0.05
6.4	0.03


- 9 See the examples below for a clear understanding.

### Example 1




Chargeless length = 30 m  
 Additional refrigerant charge =  $(80-30) \times 0.09 = 50 \times 0.09 = 4.5$  kg

### Example 2




Chargeless length = 30 m  
 Additional refrigerant charge  
 =  $((35+7+5)-30) \times 0.05 = 17 \times 0.05 = 0.85$  kg = 0.9 kg

### Example 3



Chargeless length = 30 m  
 $\varnothing 9.5 \quad (30-5) = 25$  m  
 $\varnothing 6.4 \quad 25-(7+17+10) = -9$  m  
 Additional refrigerant charge =  $9 \times 0.03 = 0.27$  kg = 0.3 kg

### Example 4



Chargeless length = 30 m  
 $\varnothing 12.7 \quad (30-25) = 5$  m  
 $\varnothing 9.5 \quad 5-(5+5) = -5$  m  
 $\varnothing 6.4 \quad 10+7+7+5 = 29$  m  
 Additional refrigerant charge =  $(5 \times 0.05) + (29 \times 0.03) = 1.12$  kg = 1.1 kg



In case of complete recharge of the refrigerant, please first execute vacuuming. Vacuuming must be executed using the both 2 service ports situated on the piping inside the airconditioning outdoor unit simultaneously. Make sure that both stop valves are open for vacuuming. Vacuuming can not be executed completely using the ports on the stop valves.

## Total charging weight of the refrigerant (after a leak, etc.)

The total charging amounts relate to the refrigerant piping length as in "Maximum total one way piping length" of the table in paragraph "7.4. Allowable pipe length and height difference" on page 5, the factory charging amount is mentioned on the nameplate label.

For the total charging amount refer to the additional refrigerant charge sticker mounted on the unit.

## Precaution for pumping-down operation

Take the following steps to perform the pumping-down operation.

Procedure	Precaution
1 Stop the unit from operating.	Use the remote controller.
2 Put a pressure gauge at the service port of the gas stop valve.	Use a pressure gauge reserved for R410A exclusively.
3 Close the stop valve on the liquid side securely and open the the gas side completely.	Insecure closing of the valve may result in burning of the compressor.
4 Start the fan operation with the remote controller.	Confirm that the stop valve: • on the liquid is closed • on the gas side is open.
5 Push the pumping-down button (BS5) on the PC board of the outdoor unit for more than 5 seconds.	The H2P LED will flash. Compressor and outdoor fan will start operation automatically. If step 5 is performed before step 4, then the indoor fan may automatically start running. Please pay attention to this.
6 Continue operation (automatic operation) for a maximum of 20 minutes.	—
7 The unit stops working. At this time, close the stop valve on the gas side.	—

This is the end of pumping-down operation. After pumping-down operation, the remote controller can show the following pattern:

- "LL"
- blank screen
- indoor fan operates for about 30 seconds

Even when ON button on the remote controller is pressed, it will not operate. Turn off the main power supply switch and turn it on again in need of operation.


Be sure to re-open stopvalves before re-starting the unit operation.

### To avoid compressor breakdown. Do not charge the refrigerant with more than the specified amount.

- This outdoor unit is factory charged with refrigerant and depending on pipe sizes and pipe lengths, some systems require additional charging of refrigerant. (Refer to "Additional refrigerant charge" on page 8).
- Make sure to use installation tools you exclusively use on R410A installations to withstand the pressure and to prevent foreign materials from mixing into the system.
- Charge the refrigerant to the liquid pipe in its liquid state. Since R410A is a mixed refrigerant, its composition changes if charged in a state of gas and normal system operation would no longer be assured.

- Before charging, check whether the refrigerant cylinder is equipped with a siphon tube or not.

Charge the liquid refrigerant with the cylinder in upright position.



Charge the liquid refrigerant with the cylinder in up-side-down position.

- Determine the weight of refrigerant to be charged additionally referring to the item "Additional refrigerant charge" in "Total charging weight of the refrigerant (after a leak, etc.)" on page 10 and fill in the amount in the "Additional refrigerant charge label" attached to the unit.

### Charging while the outdoor unit is at standstill


After the vacuum drying is finished, charge the additional refrigerant in its liquid state through the liquid stop valve service port taking into account following instructions:

- Check that gas and liquid stop valves are closed.
- Stop the compressor and charge the specified weight of refrigerant.



If the total refrigerant cannot be charged while the outdoor unit is at standstill, it is possible to charge the refrigerant by operating the outdoor unit using the refrigerant charge function (refer to "Setting mode 2" on page 17).

### Charging while the outdoor unit is operating

- 1 Charge refrigerant as much as possible when the power supply is switched off.
- 2 Turn the power supply on and charge only the amount of lacking refrigerant.
- 3 Completely open the gas line stop valve.  
See figure 15 and refer to "Airtightness test and vacuum drying" on page 7 for nomenclature of the parts in figure 15. Valve A must be left fully closed. Make sure the liquid stop valve is totally shut. If it is open, the refrigerant cannot be charged. Charge the additional refrigerant in its liquid state through the service port of the liquid line stop valve.
- 4 While the unit is at standstill and under setting mode 2 (refer to Checks before initial start-up, "Setting the mode 2" on page 15), set the required function A (additional refrigerant charging operation) to ON (ON). Then operation starts. The blinking H2P LED indicates test operation and the remote controller indicates  (test operation).
- 5 When the specified amount of refrigerant is charged, push the BS3 RETURN button. Then operation stops.
  - The operation automatically stops within 30 minutes.
  - If the refrigerant charge cannot be finished within 30 minutes, repeat step 2.
  - If the operation stops immediately after restart, there is a possibility that the system is overcharged. The refrigerant cannot be charged more than this amount.
- 6 After the refrigerant charge hose is removed, make sure to fully open the liquid stop valve. Otherwise the piping may burst due to blocked liquid.

## 8. FIELD WIRING









- All field wiring and components must be installed by a licensed electrician and must comply with relevant local and national regulations.
- The field wiring must be carried out in accordance with the wiring diagrams and the instructions given below.
- Be sure to use a dedicated power circuit. Never use a power supply shared by another appliance. This can lead to electrical shock or fire.
- Insufficient capacity of the power supply circuit or improper electrical construction may lead to electric shocks or fire.
- Do not operate until refrigerant piping work is completed.  
(If operated before completion of the piping work, the compressor may break down.)
- Never remove a thermistor, sensor, etc., when connecting power wiring and transmission wiring.  
(If operated without thermistor, sensor, etc., the compressor may break down.)
- The reversed phase protection detector of this product only works during the initialisation stage after a power reset.  
The reversed phase protection detector is designed to stop the product in case of an abnormality when the product is started up.  
When the reversed phase protection circuit forced the unit to stop, check if all phases are existing. If this is the case, shut off the power supply to the unit and replace two of three phases. Turn on power again and start the unit.
- Reversed phase detection is not performed while the product is operating.
- In case of possible reversal of phases after a momentary black out of power and the power goes on and off while the product is operating, install a reversed phase protection circuit on site. Such situation is not unimaginable when using generators. Running the product in reversed phase can break the compressor and other parts.
- Ground the air conditioner.  
Grounding resistance should be according to national regulations  
Do not connect the earth wire to gas or water pipes, lightning conductor or telephone earth wire.  
Incomplete grounding may cause electric shocks.
- Gas pipe.  
Ignition or explosion may occur if the gas leaks.
- Water pipe.  
Hard vinyl tubes are not effective grounds.
- Lightning conductor or telephone ground wire.  
Electric potential may rise abnormally if struck by a lightning bolt.
- Be sure to install an earth leakage breaker and fuse.  
Failure to install an earth leakage breaker may cause electric shocks and fire.



## 8.1. Internal wiring – Parts table

Refer to the wiring diagram sticker on the unit. The abbreviations used are listed below:

A1P~A6P .....	Printed circuit board (main, noise filter, inverter, fan, QA transmission) A5P (option) printed circuit board (for demand)
BS1~BS5 .....	Push button switch (mode, set, return, test, forced defrost)
C1,C63,C66 .....	Capacitor
DS1,DS2 .....	DIP switch
E1HC .....	Crankcase heater
F1U .....	Fuse (DC 650 V, 8 A)(A4P)
F1U,F2U .....	Fuse (250 V, 3.15 A, T)(A1P)
F400U .....	Fuse (250 V, 6.3 A, T)(A2P)
H1P~H7P .....	Light emitting diode (service monitor - orange) (H2P prepare test - blinking) (H2P malfunction detection - light up)
HAP .....	Pilot lamp (service monitor - green)
K1 .....	Magnetic relay
K2 .....	Magnetic contactor (M1C)
K3R~K7R .....	Magnetic relay (Y1S, Y2S, Y3S, E1HC)
L1,L2,L3 .....	Live
L1R .....	Reactor
M1C .....	Motor (compressor)
M1F .....	Motor (fan)
N .....	Neutral
PS .....	Switching power supply (A1P, A3P)
Q1RP .....	Phase reversal detect circuit
Q1DI .....	Earth leak breaker
R10 .....	Resistor (current sensor) (A4P)
R50,R59 .....	Resistor
R95 .....	Resistor (current limiting)
R1T .....	Thermistor (air) (A1P)
R1T .....	Thermistor (fin) (A3P)
R2T .....	Thermistor (suction)
R3T .....	Thermistor (discharge) (M1C)
R4T .....	Thermistor (coil-deicer)
R4T .....	Thermistor (heat exchange deicer)
R5T .....	Thermistor (sub cool outlet)
RC .....	Signal receiver circuit
S1NPH .....	Pressure sensor (high)
S1NPL .....	Pressure sensor (low)
S1PH .....	Pressure switch (high)
SD1 .....	Safety devices input
TC .....	Signal transmission circuit
V1R .....	Power module (A4P)
V1R,V2R .....	Power module (A3P)
X1A,X2A .....	Connector (Y1E,Y2E)
X1M .....	Terminal strip (power supply)
X2M .....	Terminal strip (QA transmission)
Y1E .....	Electronic expansion valve (main)
Y2E .....	Electronic expansion valve (subcool)
Y1S .....	Solenoid valve (hotgas bypass)
Y2S .....	Solenoid valve (gas purge of receiver)
Y3S .....	Solenoid valve (4-way valve)
Z1C~Z4C .....	Noise filter (ferrite core)
Z1F .....	Noise filter (with surge absorber)

	Field wiring
	Indication of parts outside switch box
	Terminal strip
	Connector
	Terminal
	Protective earth (screw)
BLK	Black
BLU	Blue
BRN	Brown
GRN	Green
GRY	Gray
ORG	Orange
PNK	Pink
RED	Red
WHT	White
YLW	Yellow

- NOTE**
- The wiring diagram only applies to the outdoor unit
  - When using the option adaptor, refer to the installation manual
  - Refer to the installation manual on how to use BS1~BS5 and DS1, DS2 switch
  - Do not operate the unit by short-circuiting protection device S1PH

## 8.2. Optional connectors

X36A,X66A.....Connector (adaptor power supply) (see note 4)

- NOTE**
- Use copper conductors only.
  - For connection wiring to the central remote controller, refer to the installation manual of the central remote controller.
  - Use insulated wire for the power cord.

## 8.3. Power circuit and cable requirements

A power circuit (see table below) must be provided for connection of the unit. This circuit must be protected with the required safety devices, i.e. a main switch, a slow blow fuse on each phase and an earth leakage breaker.

	Phase and frequency	Voltage	Recommended fuses	Transmission line section
RZQ200	3N~ 50 Hz	380~415 V	25 A	H05VV-U4G2.5
RZQ250	3N~ 50 Hz	380~415 V	25 A	H05VV-U4G2.5

When using residual current operated circuit breakers, be sure to use high-speed type circuit breakers of maximum 30 mA that can handle higher harmonics.

### Point for attention regarding quality of the public electric power supply

This equipment complies with EN/IEC 61000-3-12<sup>(1)</sup> provided that the short-circuit power  $S_{sc}$  is greater than or equal to 1025 kVA at the interface point between the user's supply and the public system.

It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power  $S_{sc}$  greater than or equal to 1025 kVA.

Above indicated value is the most stringent value. Refer to databooks for specific product-data.

Be sure to install a main switch for the complete system.

(1) European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current >16 A and ≤75 A per phase.

- NOTE**
- Select the power supply cable in accordance with relevant local and national regulations.
  - Wire size must comply with the applicable local and national code.
  - Specifications for local wiring power cord and branch wiring are in compliance with IEC60245.
  - WIRE TYPE H05VV(\*)  
\*Only in protected pipes (use H07RN-F when protected pipes are not used).

## 8.4. General cautions

- Make sure to connect the power source wire to the power source terminal block and to clamp it as shown in figure 21, chapter "Field line connection".
- As this unit is equipped with an inverter, installing a phase advancing capacitor not only will deteriorate power factor improvement effect, but also may cause capacitor abnormal heating accident due to high-frequency waves. Therefore, never install a phase advancing capacitor.
- Keep power imbalance within 2% of the supply rating.
  - Large imbalance will shorten the life of the smoothing capacitor.
  - As a protective measure, the product will stop operating and an error indication will be made, when power imbalance exceeds 4% of the supply rating.
- Only proceed with wiring work after switching off all power sources.
- Always ground wires. (In accordance with local regulations.)
- Do not connect the ground wire to gas pipes, sewage pipes, lightning rods, or telephone ground wires. This may cause electric shock.
  - Combustion gas pipes: can explode or catch fire if there is a gas leak.
  - Sewage pipes: no grounding effect is possible if hard plastic piping is used.
  - Telephone ground wires and lightning rods: dangerous when struck by lightning due to abnormal rise in electrical potential in the grounding.
- This unit uses an inverter, and therefore generates noise, which will have to be reduced to avoid interfering with other devices. The outer casing of the product may take on an electrical charge due to leaked electrical current, which will have to be discharged with the grounding.
- Be sure to install an earth leakage breaker. (One that can handle higher harmonics.)  
(This unit uses an inverter, which means that an earth leakage breaker capable of handling high harmonics needs to be used in order to prevent malfunctioning of the earth leakage breaker itself.)
- Earth leakage breakers which are especially designed for protecting ground-faults must be used in conjunction with main switch and fuse for use with wiring.
- This unit has a reverse phase protection circuit. (If it operates, only operate the unit after correcting the wiring.)
- Power supply wires must be attached securely.
- If the power supply would have a missing N-phase or a mistaken N-phase, equipment will break down.
- Make sure that all wiring is secured, the specified wires are used, and no external forces act on the terminal connection or wires.  
Improper connections or installation may result in fire.
- When wiring the power supply and connecting the remote controller wiring and transmission wiring, position the wires so that the control box lid can be securely fastened.  
Improper positioning of the control box lid may result in electric shocks, fire, or the overheating of the terminals.



## 8.5. Examples

### System example (See figure 22)

- 1 Field power supply
- 2 Main switch
- 3 Earth leakage breaker
- 4 Fuse
- 5 Remote controller
- Power supply wiring (sheathed cable)
- Wiring between units (sheathed cable)



### Field line connection

L1, L2, L3, N-phase of the power cord should be clamped to the plastic bracket using field supplied clamp material.

The green and yellow striped wrapped wires should be used for grounding. (See figure 21)

- 1 Power supply (380~415 V, 3N~ 50 Hz)
- 2 Fuse
- 3 Earth leakage breaker
- 4 Grounding wire
- 5 Power supply terminal block
- 6 Connect each power wire  
RED to L1, WHT to L2, BLK to L3 and BLU to N
- 7 Ground wire (GRN/YLW)
- 8 Clamp the power wire to the plastic bracket using a field supplied clamp to prevent external force being applied to the terminal.
- 9 Clamp (field supply)

See figure 24

- 1 Power supply wiring
- 2 Wiring between units
- 3 Clamp to the electric box with field supplied clamps.
- 4 When routing out the power/ground wires from the right side:
- 5  When routing the remote control cord and inter-unit wiring, secure clearance of 50 mm or more from the power wiring. Ensure that the power wiring does not contact any heated sections (  ).
- 6 Clamp to the back of the column support with field supplied clamps.
- 7 When routing out the inter-unit wirings from the opening for piping:
- 8 When routing out the power/ground wires from the front:
- 9 When routing out the ground wires from the left side:
- 10 Grounding wire
- 11 When wiring, pay attention not to detach the acoustic insulators from the compressor.




### Precautions when installing power wiring

Use round pressure terminals for connections to the power terminal block.

When none are available, follow the instructions below.

- Do not connect wiring of different thicknesses to the power terminal block. (Slack in the power wiring may cause abnormal heat.)
- When connecting wiring which is the same thickness, do as shown in the figure below.




- For wiring, use the designated power wire and connect firmly, then secure to prevent outside pressure being exerted on the terminal board.
- Use an appropriate screwdriver for tightening the terminal screws. A screwdriver with a small head will strip the head and make proper tightening impossible.
- Over-tightening the terminal screws may break them.
- Make sure that all wiring is secure, using the specified wires and ensuring that external forces do not act on the terminal connections or wires. Incomplete connection or fixing may cause a fire.
- See the table below for tightening torque for the terminal screws.

Tightening torque (N·m)	
M8 (Power terminal block) (X4M)	5.5~7.3
M8 (Ground)	
M3 (Optional wiring terminal block) (X1M, X3M)	0.8~0.97
M4 (Inter-unit wiring terminal block) (X2M)	1.4~1.6



### Recommendations when connecting the ground

When pulling the ground wire out, wire it so that it comes through the cut out section of the cup washer. (An improper ground connection may prevent a good ground from being achieved.)



### Fixing field line connection (See figure 23)


- 1 Wiring between the units (Indoor - outdoor)
- 2 Fix to the indicated plastic brackets using field supplied clamping material.
- 3 Plastic bracket

## Picking power line and transmission line

- Be sure to let the power line and the transmission line pass through a conduit hole.
  - Pick the power line from the upper hole on the left side plate, from the front position of the main unit (through the conduit hole of the wiring mounting plate) or from a knock out hole to be made in the unit's bottom plate. (See figure 19)
- A Electric wiring diagram. Printed on the back of the electric box lid.
- 1 Cut off the shaded zones before use.
  - 2 Through cover
  - 3 Power supply wiring (When wiring is routed out through the lateral panel.)
  - 4 Set apart
  - 5 Power supply wiring (When wiring is routed through the front panel)
  - 6 Transmission wire

### Precautions when knocking out knockout holes

- To punch a knockout hole, hit on it with a hammer.
- After knocking out the holes, we recommend you paint the edges and areas around the edges using the repair paint to prevent rusting.
- When passing electrical wiring through the knockout holes, remove any burrs from the knockout holes and wrap the wiring with protective tape to prevent damage.



- 1 Knockout hole
- 2 Burr
- 3 If there are any possibilities that small animals enter the system through the knockout holes, plug the holes with packing materials (to be prepared on-site).



- Use a power wire pipe for the power wiring.
- Outside the unit, make sure the weak low voltage electric wiring (i.e. for the remote control, between units, etc.) and the high voltage electric wiring do not pass near each other, keeping them at least 50 mm apart. Proximity may cause electrical interference, malfunctions, and breakage.
- Be sure to connect the power wiring to the power wiring terminal block and secure it as described under "Field line connection" on page 13.
- Inter-unit wiring should be secured as described in "Field line connection" in chapter "8.5. Examples" on page 13.
  - Secure the wiring with the accessory clamps so that it does not touch the piping.
  - Make sure the wiring and the electric box lid do not stick up above the structure, and close the cover firmly.

Never connect 400 V to the terminal block of the interconnecting wiring. Doing so will break the entire system.

- After installing the interconnecting wires inside the unit, wrap them along with the on-site refrigerant pipes using finishing tape, as shown in figure 17.

- 1 Liquid pipe
- 2 Gas pipe
- 3 Interconnecting wiring
- 4 Insulator
- 5 Finishing tape

- See the paragraph "Fixing field line connection" on page 13.



- Check that wiring lines do not make contact with refrigerant piping.
- Firmly close the lid and arrange the electrical wires so as to prevent the lid or other parts from coming loose.
- When you don't use a wire conduit, be sure to protect the wires with vinyl tubes etc, to prevent the edge of the knock-out hole from cutting the wires.

## 9. BEFORE OPERATION

### 9.1. Service precautions




#### WARNING: ELECTRIC SHOCK



#### Caution when performing service to inverter equipment

- Do not touch live parts for 10 minutes after the power supply is turned off because of high voltage risk.
- Additionally, measure the points as shown in the figure with a tester and confirm that the voltage of the capacitor in the main circuit is not higher than 50 V DC.



Then pull out the connector (X1A,X2A on A3P). Please pay attention not to come in contact with live parts.

- After the service is finished, re-connect the connector (X1A,X2A on A3P). Otherwise malfunction may occur.

#### Caution when obtaining access to terminals

- Before obtaining access to terminals in the switch box, all supply circuits must be disconnected.
- Be careful when taking off the cover. Touching live parts may cause electric shock.
- After servicing is finished, re-attach the cover. Otherwise malfunction may occur due to intrusion of water or other foreign materials.

#### NOTE



#### Play it safe!

For protection of the PCB, touch the switch box casing by hand in order to eliminate static electricity from your body before performing service.

## 9.2. Checks before initial start-up

### NOTE



Note that during the first running period of the unit, required power input may be higher than stated on the nameplate of the unit. This phenomenon originates from the compressor that needs elapse of a 50 hours run in period before reaching smooth operation and stable power consumption.



- Make sure that the circuit breaker on the power supply panel of the installation is switched off.
- Attach the power wire securely.
- Introducing power with a missing N-phase or with a mistaken N-phase will break the equipment.

After the installation, check the following before switching on the circuit breaker:

- 1 The position of the switches that require an initial setting  
Make sure that switches are set according to your application needs before turning the power supply on.
- 2 Power supply wiring and transmission wiring  
Use a designated power supply and transmission wiring and make sure that it has been carried out according to the instructions described in this manual, according to the wiring diagrams and according to local and national regulations.
- 3 Pipe sizes and pipe insulation  
Make sure that correct pipe sizes are installed and that the insulation work is properly executed.
- 4 Additional refrigerant charge  
The amount of refrigerant to be added to the unit should be written on the included "Added Refrigerant" plate and attached to the rear side of the front cover.
- 5 Insulation test of the main power circuit  
Using a megatester for 500 V, check that the insulation resistance of 2 MΩ or more is attained by applying a voltage of 500 V DC between power terminals and earth. Never use the megatester for the transmission wiring.
- 6 Installation date  
For reference, keep record of the installation date on the sticker on the rear of the upper front panel.


## 9.3. Field setting

If required, carry out field settings according to the following instructions. Refer to the service manual for more details.

### Opening the switch box and handling the switches

When carrying out field settings, remove the inspection cover (1).


Operate the switches with an insulated stick (such as a ball-point pen) to avoid touching of live parts.



Make sure to re-attach the inspection cover (1) into the switch box cover (2) after the job is finished.

## Location of the DIP switches, LEDs and buttons

- 1 LEDs H1P~H7P
- 2 Push button switches BS1~BS5
- 3 Dip switch 1 (DS1: 1~4)
- 4 Dip switch 2 (DS2: 1~4)




### Led state

Throughout the manual the state of the LEDs is indicated as follows:

- OFF
- ☀ ON
- ⚡ blinking


### Setting the DIP switches



What to set with DIP switches DS1 and DS2	
DS1-3	LOW NOISE OPERATION LEVEL SETTING (L.N.O.P) (OFF = not installed = factory setting)
DS1-4	HIGH STATIC PRESSURE SETTING
DS2-1	AUTOMATIC LOW NOISE OPERATION AT NIGHT TIME
DS2-2	POWER CONSUMPTION LIMITATION SETTING (DEMAND)
DS1-1 DS1-2 DS2-3 DS2-4	NOT APPLICABLE DO NOT CHANGE THE FACTORY SETTING.

### Setting the push button switch (BS1~5)

Function of the push button switch which is located on the outdoor unit PCB (A1P):



- BS1 MODE** For changing the set mode
- BS2 SET** For field setting
- BS3 RETURN** For field setting
- BS4 TEST** For test operation
- BS5 FORCED DEF** For forced defrost or pump down

### Setting the mode 2

The set mode can be changed by pressing the **BS1 MODE** button for 5 seconds. The setting mode will change to setting mode 2 and the H1P LED will be ON ☀.

### NOTE




If you get confused in the middle of the setting process, push the **BS1 MODE** button once. Then it returns to setting mode 2 (H1P LED is ON ☀).

### Exiting mode 2

When all settings are finished and the operation did start according to the setting, push the **BS1 MODE** button once to exit the mode 2.

## 9.4. Test operation


**NOTE**  After turning on the power supply, the unit cannot be started until the H2P initialisation LED goes off (maximum 12 minutes).

- Check the stop valves  
Make sure to open the gas and liquid line stop valves.
- For details on test operation, refer to the indoor unit installation manual.

### Pre-run checks

Items to check	
Electrical wiring Inter-unit wiring Ground wire	<ul style="list-style-type: none"> <li>■ Is the wiring as mentioned on the wiring diagram? Make sure no wiring has been forgotten and that there are no missing phases or reverse phases.</li> <li>■ Is the unit properly grounded?</li> <li>■ Are any of the wiring attachment screws loose?</li> <li>■ Is the insulation resistance at least 2 MΩ? - Use a 500 V mega-tester when measuring insulation. - Do not use a mega-tester for circuits which are not 230 V.</li> </ul>
Refrigerant piping	<ul style="list-style-type: none"> <li>■ Is the size of the piping appropriate?</li> <li>■ Is the insulation material for the piping attached securely? Are both the liquid and gas pipes insulated?</li> <li>■ Are the shut-off valves for both the liquid side and the gas side open?</li> </ul>
Extra refrigerant	<ul style="list-style-type: none"> <li>■ Did you write down the extra refrigerant and the refrigerant piping length?</li> </ul>

- 1 Make sure the liquid and gas shut-off valves are open.



#### Opening direction

- A Liquid side
- B Gas side

Remove the cap and turn counterclockwise with a hex wrench until it stops

Be sure to close the frontside panel before operation, as not doing so can cause electric shock.


- The refrigerant pressure may not rise, even if the shut-off valve is opened after an air purge is performed using a vacuum pump.  
This is because the indoor unit refrigerant piping is closed off with electric valves inside. This will not create any problems during operation.


- 2 To protect the compressor, make sure to turn on the power supply 6 hours before starting operation.

### Test operation from remote controller

- 1 Be sure to set it to cooling and press the operation switch.
- 2 Press the inspection/test-run switch on the remote control to put the machine into test-run mode.

### Test operation from outdoor PCB BS4 test button

- 3 Make sure to set the remote controller to fan mode, press the **BS1 MODE** button first and then press the operation switch.
- 4 Press the **BS4 TEST** button for 5 seconds (or longer when the unit is at standstill). The test operation starts when the H2P LED blinks and the remote controller indicates  (test operation).
- 5 Make sure the compressor is not starting and stopping during the test-run by listening. If it is starting and stopping, immediately stop the machine using the remote control, and check the refrigerant level, etc. There may be some sort of malfunction.







**NOTE**  When you want to terminate the test operation, press the **BS3 RETURN** button. The unit will keep running for 30 seconds and then stops. During test operation it is impossible to stop the unit with the remote controller.


The test operation will automatically switch to cooling mode for 3 minutes. The test operation will stop for 3 minutes and then switch to heating when heating mode was selected (only during first installation).

After the test operation (maximum 30 minutes), the unit automatically stops. Check the operation results by the outdoor unit LED indication.

### Defect judgement

**Judgement can be done by HAP, H1P on the PCB (A1P) if the power supply is turned on.**

HAP (green)	H1P (orange)	Content
		Normal
	—	Outdoor PCB is defect (see NOTE 1)
	—	Power supply abnormality or PCB is defect (see NOTE 2)
		Protection equipment is active (see NOTE 3)

- NOTE** 
- 1 Turn the power off for more than 5 seconds. Switch the power back on. If this was realized, confirm your judgement.
  - 2 Turn the power off for more than 5 seconds. Disconnect the indoor-outdoor connection wire 3. Switch the power back on for more than 10 seconds.  
If the outdoor PCB HAP LED is blinking the indoor PCB is not working correct.
  - 3 Indication of a possible negative phase.  
The abnormality detection continuously indicates the past abnormal history until power supply is shut off.



- After the test operation is finished, check the indoor units via the remote controller.
- The LED indication changes during this operation, but that is not abnormal.
- Please attach the front plate of the outdoor unit in order to prevent incorrect judgement during operation.

The H1P LED is on.

**Setting procedure**

- 1 Push the **BS2 SET** button according to the required function (A~E). The LED indication that matches the required function is shown below in the field marked  :

**Possible functions**

- A additional refrigerant charging operation.
- B refrigerant recovery operation/vacuuming operation.
- C low noise operation level setting (**L.N.O.P**) ( external).
- D automatic low noise operation setting at nighttime.
- E power consumption limitation setting (**DEMAND**) (external).

	H1P	H2P	H3P	H4P	H5P	H6P	H7P
A	☀	●	●	●	●	●	●
B	☀	●	●	●	●	●	☀
C	☀	●	●	●	●	☀	●
D	☀	●	●	●	●	☀	☀
E	☀	●	●	●	☀	☀	☀

- 2 When the **BS3 RETURN** button is pushed, the current setting is defined.
- 3 Push the **BS2 SET** button according to the required setting possibility as shown below in the field marked  .
- 3.1 Possible settings for function A and B are **ON** (ON) or **OFF** (OFF).

	H1P	H2P	H3P	H4P	H5P	H6P	H7P
ON	☀	●	●	●	●	☀	●
OFF <sup>(1)</sup>	☀	●	●	●	●	●	☀

(1) This setting = factory setting

- 3.2 Possible settings for function C, D and E
  - For function C (**L.N.O.P**) only: the noise of level 3 < level 2 < level 1 (▲1).
  - For function D only: automatic low noise at nighttime level 3 < level 2 < level 1 (▲1).
  - For function E (**DEMAND**) only: the power consumption of level 1 < level 2 < level 3 (▲3).

	H1P	H2P	H3P	H4P	H5P	H6P	H7P
▲1	☀	●	●	●	●	●	☀
▲2 <sup>(1)</sup>	☀	●	●	●	●	☀	●
▲3	☀	●	●	●	☀	●	●

(1) This setting = factory setting

- 4 Push the **BS3 RETURN** button and the setting is defined.
- 5 When the **BS3 RETURN** button is pushed again, the operation starts according to the setting.

Refer to the service manual for more details and for other settings.

## 10. SERVICE MODE OPERATION

### Vacuuming method

At the first installation, this vacuuming is not required. It is required only for repair purposes.

- 1 When the unit is at standstill and under the setting mode 2, set the required function B (refrigerant recovery operation/vacuuming operation) to **ON** (ON).
  - After this is set, do not reset the setting mode 2 until the vacuuming is finished.
  - The H1P LED is ON and the remote controller indicates (test operation) and the operation will be prohibited.
- 2 Evacuate the system with a vacuum pump.
- 3 Press the **BS1 MODE** button and reset the setting mode 2.

### Refrigerant recovery operation method

by a refrigerant reclaimer

- 1 When the unit is at standstill and under the setting mode 2, set the required function B (refrigerant recovery operation/vacuuming operation) to **ON** (ON).
  - The indoor unit and the outdoor unit expansion valves will fully open and some solenoid valves will be turned on.
  - The H1P LED is ON and the remote controller indicates (test operation) and the operation will be prohibited.
- 2 Cut off the power supply to the indoor units that have separate power supply and the outdoor unit with the circuit breaker. After the power supply to one side is cut off, cut off the power supply to the other side within 10 minutes. Otherwise, the communication between the indoor and outdoor unit may become abnormal and the expansion valves will be completely closed again.
- 3 Recover the refrigerant by a refrigerant reclaimer. For details, see the operation manual delivered with the refrigerant reclaimer.

## 11. CAUTION FOR REFRIGERANT LEAKS

(Points to note in connection with refrigerant leaks.)



When a unit is installed in a small room, it is necessary to take measures so that the leaked refrigerant amount does not exceed the limit even if it leaks. As for the measures to prevent the leak from not exceeding the limit, please consult with your distributor.

If the leaked amount exceeds the limit, it may cause an oxygen deficiency accident.

### Introduction

**The installer and system specialist shall secure safety against leakage according to local regulations or standards. The following standards may be applicable if local regulations are not available.**

The air conditioning systems, uses R410A as refrigerant. R410A itself is an entirely safe non-toxic, non-combustible refrigerant. Nevertheless care must be taken to ensure that air conditioning facilities are installed in a room which is sufficiently large. This assures that the maximum concentration level of refrigerant gas is not exceeded, in the unlikely event of major leak in the system and this in accordance to the local applicable regulations and standards.


## Maximum concentration level

The maximum charge of refrigerant and the calculation of the maximum concentration of refrigerant is directly related to the humanly occupied space in to which it could leak.

The unit of measurement of the concentration is  $\text{kg/m}^3$  (the weight in kg of the refrigerant gas in  $1 \text{ m}^3$  volume of the occupied space).

Compliance to the local applicable regulations and standards for the maximum allowable concentration level is required.

According to the appropriate European Standard, the maximum allowed concentration level of refrigerant to a humanly space for R410A is limited to  $0.44 \text{ kg/m}^3$ .



- 1 direction of the refrigerant flow
- 2 room where refrigerant leak has occurred (outflow of all the refrigerant from the system)

**Pay special attention to places, such as a basements, etc. where refrigerant can stay, since refrigerant is heavier than air.**

## Procedure for checking maximum concentration

Check the maximum concentration level in accordance with steps 1 to 4 below and take whatever action is necessary to comply.

- 1 Calculate the amount of refrigerant (kg) charged to each system separately.


amount of refrigerant in a single unit system (amount of refrigerant with which the system is charged before leaving the factory)	+	additional charging amount (amount of refrigerant added locally in accordance with the length or diameter of the refrigerant piping)	=	total amount of refrigerant (kg) in the system
---	---	--	---	--

**NOTE** Where a single refrigerant facility is divided into 2 entirely independent refrigerant systems, use the amount of refrigerant with which each separate system is charged.


- 2 Calculate the smallest room volume ( $\text{m}^3$ )

In a case such as the following, calculate the volume of (A), (B) as a single room or as the smallest room.

- A. Where there are no smaller room divisions



- B. Where there is a room division but there is an opening between the rooms sufficiently large to permit a free flow of air back and forth.



- 1 opening between rooms
- 2 partition

(Where there is an opening without a door or where there are openings above and below the door which are each equivalent in size to 0.15% or more of the floor area.)

- 3 Calculating the refrigerant density using the results of the calculations in steps 1 and 2 above.

$$\frac{\text{total volume of refrigerant in the refrigerant system}}{\text{size (m}^3\text{) of smallest room in which there is an indoor unit installed}} \leq \text{maximum concentration level (kg/m}^3\text{)}$$

If the result of the above calculation exceeds the maximum concentration level then make similar calculations for the second then third smallest room and so until the result falls short of the maximum concentration.

- 4 Dealing with the situations where the result exceeds the maximum concentration level.

Where the installation of a facility results in a concentration in excess of the maximum concentration level then it will be necessary to revise the system.

- 5 Please consult your supplier.

## 12. DISPOSAL REQUIREMENTS

Dismantling of the unit, treatment of the refrigerant, of oil and of other parts must be done in accordance with relevant local and national legislation.





\*4PW34720-1 G 0000000\*

Copyright 2006 Daikin

**DAIKIN EUROPE N.V.**

Zandvoordestraat 300, B-8400 Oostende, Belgium

4PW34720-1G – 07.2010