


**DAIKIN**

# Installation manual

## Split system air conditioners



**RZQG71L9V1B  
RZQG100L9V1B  
RZQG125L9V1B  
RZQG140L9V1B**

**RZQG71L8Y1B  
RZQG100L8Y1B  
RZQG125L8Y1B  
RZQG140L7Y1B**

**RZQSG100L9V1B  
RZQSG125L9V1B  
RZQSG140L9V1B**

**RZQSG100L8Y1B  
RZQSG125L8Y1B  
RZQSG140L7Y1B**

CE-DECLARATION OF CONFORMITY  
CE-KONFORMITÄTSERKLÄRUNG  
CE-DECLARAZIONE DI CONFORMITÀ  
CE-ΔΗΛΩΣΗ ΣΥΜΠΟΥΔΙΣΗ  
CE-KONFORMITÄTSPRÄKLÄRUNG

CE-DECLARACION DE CONFORMIDAD  
CE-DICHARAZIONE DI CONFORMITÀ  
CE-ΔΗΛΩΣΗ ΣΥΜΠΟΥΔΙΣΗ  
CE-FÖRSÄKRAN OM ÖVERENSÄMMELSE

CE-ERKLÄRUNG OM SÄMNSÄR  
CE-ILMOITUS YHDENMUKAISUUDESTA  
CE-PROHLÁSENÍ SHODY  
CE-DECLARAȚIE DE CONFORMITATE

CE-IZJAVA O SKLADNOSTI  
CE-MEGFELELŐSÉGNYILATKOZÁS  
CE-DEKLARACJA ZGODNOSCI  
CE-DECLARAȚIE DE CONFORMITATE

CE-IZJAVA O SKLADNOSTI  
CE-VASTAVISDEKLARATSIOON  
CE-ДЕКЛАРАЦІЯ З АСОБІТЦЬВІВІ  
CE-УГЛУБЛЕНІ БЕВІЯНИ

CE-ATTIKTES/DEKLARACJA  
CE-ATBI STĪBAS/DEKLĀRĀCIJA  
CE-УПЛАСЕНЕ ЗЛОДЫ  
CE-УГУБЛЕНІ БЕВІЯНИ

## Daikin Europe N.V.

01 (en) declares under its sole responsibility that the air conditioning models to which this declaration relates:  
02 (d) erklärt auf seine alleinige Verantwortung die Modelle der Klimaanlage für die diese Erklärung bezieht.  
03 (fr) déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration.  
04 (de) verkündet hiermit auf eigenem ausschließlichem Verantwortungsbereich die dem air conditioning units waarop deze verklaring betrekking heeft.  
05 (it) dichiara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración.  
06 (es) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración.  
07 (en) δηλώνει με αποκλειστική ευθύνη ότι τα μοντέλα των ΑΚΜ που αναφέρονται στο παρόν έγγραφο.  
08 (de) déclare sob sa exclusiva responsabilitate que os modely de ar conditionatob a que esta declaracão se referē.

RZQG71L9V1B\*, RZQG100L9V1B\*, RZQG125L9V1B\*, RZQG140L9V1B\*,  
RZQSG100L9V1B\*, RZQSG125L9V1B\*, RZQSG140L9V1B\*,  
RZQG71L8Y1B\*, RZQG100L8Y1B\*, RZQG125L8Y1B\*, RZQG140L7Y1B\*,  
RZQSG100L8Y1B\*, RZQSG125L8Y1B\*, RZQSG140L7Y1B\*,

\* = , 1, 2, 3, ..., 9

01 are in conformity with the following standard(s) or other normative document(s), provided that these are used in accordance with our instructions:  
02 (de) den folgenden Norm(en) oder einem anderen Normdokument oder -dokumenten entspricht/entsprechen, unter der Voraussetzung, daß sie konform mit unseren Anweisungen eingesetzt werden:  
03 sont conformes à la(ux) norme(s) ou autre(s) document(s) normatifs, pour autant qu'ils soient utilisés conformément à nos instructions.  
04 conforme de volgende norm(en) of één of meer andere bindende documenten zijn, op voorwaarde dat ze worden gebruikt overeenkomstig onze instructies.  
05 están en conformidad con la(s) siguiente(s) norma(s) u otro(s) documento(s) normativo(s), siempre que sean utilizados de acuerdo con nuestras instrucciones.  
06 sono conformi alla(i) seguente(i) standard(i) o altro(i) documento(i) a carattere normativo, a patto che vengano usati in conformità alle nostre istruzioni.  
07 είναι σύμφωνοι με το(α) ακόλουθο(α) πρότυπο(α) ή(α) άλλο(α) έγγραφο(α) κανονισμού, υπό την προϋπόθεση ότι χρησιμοποιούνται σύμφωνα με τις οδηγίες μας.  
10 Under the provisions of:  
11 enligt villkoren i:  
12 gli/het/hettili bestemmelserne i:  
13 noudatteen määräyksissä:  
14 za dotčené ustanovení předpisů:  
15 prema odredbama:  
16 követi az/azt:  
17 zgodnie z postanowieniami Dyrektywy:  
18 in omgjevende bepalingen:  
19 ob upoštevanju določb:  
20 vestavalt määradele:  
21 erregulering emnevene:  
22 liikentis määrustatule pabekamit:  
23 le egiort prasaba, les notiektes:  
24 orđavajuća ustavena:  
25 bunam kęglarnauygun datak:08 Note\* according to the Certificate <->  
09 Hinweis\* wie in der beigefügtenur von <-> positiv  
07 Zrijelac\* u skladu s ovim certifikatom <->  
06 Nota\* de acordo com o certificado <->  
05 Remarque\* les conditions de validité positives en <-> et non positives <->  
04 Bemerk\* zoals vermeld in <-> en positieve bevestiging door <-> overeenkomstig Certificaat <->  
03 Nota\* como se establece en <-> y es valorado positivamente por <-> de acuerdo con el Certificado <->  
02 Nota\* de acordo com o certificado <->  
01 Nota\* as set out in the Certificate <->

## EN60335-2-40,

01 Note\* according to the Certificate <->  
02 Hinweis\* wie in der beigefügtenur von <-> positiv  
07 Zrijelac\* u skladu s ovim certifikatom <->  
06 Nota\* de acordo com o certificado <->  
05 Remarque\* les conditions de validité positives en <-> et non positives <->  
04 Bemerk\* zoals vermeld in <-> en positieve bevestiging door <-> overeenkomstig Certificaat <->  
03 Nota\* como se establece en <-> y es valorado positivamente por <-> de acuerdo con el Certificado <->  
02 Nota\* de acordo com o certificado <->  
01 Nota\* as set out in the Certificate <->

CE-DECLARACION DE CONFORMIDAD  
CE-ЗАВЯЖЕНІЕ О СООБІТЦЬВІВІ  
CE-ÖVERENSÄMMELSEERKLÄRUNG  
CE-FÖRSÄKRAN OM ÖVERENSÄMMELSE

CE-ERKLÄRUNG OM SÄMNSÄR  
CE-ILMOITUS YHDENMUKAISUUDESTA  
CE-PROHLÁSENÍ SHODY  
CE-DECLARAȚIE DE CONFORMITATE

CE-IZJAVA O SKLADNOSTI  
CE-MEGFELELŐSÉGNYILATKOZÁS  
CE-DEKLARACJA ZGODNOSCI  
CE-DECLARAȚIE DE CONFORMITATE

CE-IZJAVA O SKLADNOSTI  
CE-VASTAVISDEKLARATSIOON  
CE-ДЕКЛАРАЦІЯ З АСОБІТЦЬВІВІ  
CE-УГУБЛЕНІ БЕВІЯНИ

CE-ATTIKTES/DEKLARACJA  
CE-ATBI STĪBAS/DEKLĀRĀCIJA  
CE-УПЛАСЕНЕ ЗЛОДЫ  
CE-УГУБЛЕНІ БЕВІЯНИ

09 (en) заявляет, исключительно под свою ответственность, что модели кондиционеров воздуха, к которым относится настоящее заявление:  
10 (de) erklärt unter eigener Verantwortung, ausschließlich unter eigener Verantwortung, dass die Modelle der Klimaanlage für die diese Erklärung bezieht.  
11 (fr) déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration.  
12 (de) verkündet hiermit auf eigenem ausschließlichem Verantwortungsbereich die dem air conditioning units waarop deze verklaring betrekking heeft.  
13 (it) dichiara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración.  
14 (es) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración.  
15 (en) δηλώνει με αποκλειστική ευθύνη ότι τα μοντέλα των ΑΚΜ που αναφέρονται στο παρόν έγγραφο.  
16 (de) déclare sob sa exclusiva responsabilitate que os modely de ar conditionatob a que esta declaracão se referē.

17 (en) declares under its sole responsibility that the air conditioning models to which this declaration relates:  
18 (d) erklärt auf seine alleinige Verantwortung die Modelle der Klimaanlage für die diese Erklärung bezieht.  
19 (fr) déclare sous sa seule responsabilité que les appareils d'air conditionné visés par la présente déclaration.  
20 (de) verkündet hiermit auf eigenem ausschließlichem Verantwortungsbereich die dem air conditioning units waarop deze verklaring betrekking heeft.  
21 (it) dichiara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración.  
22 (es) declara bajo su única responsabilidad que los modelos de aire acondicionado a los cuales hace referencia la declaración.  
23 (en) δηλώνει με αποκλειστική ευθύνη ότι τα μοντέλα των ΑΚΜ που αναφέρονται στο παρόν έγγραφο.  
24 (de) déclare sob sa exclusiva responsabilitate que os modely de ar conditionatob a que esta declaracão se referē.

08 estão em conformidade com a(s) seguinte(s) norma(s) ou outro(s) documento(s) normativo(s), desde que estes sejam utilizados de acordo com as nossas instruções:  
09 conformerontur stándardum, stándardam ili drugim normativnym dokumentam, pri ustáovanih ispol'zovanii sotslúgno-shumim instruktsiyam.  
10 overholder følgende standard(er) eller andre/andre tekniske dokument(er), forudsat at disse anvendes i henhold til vores instrukser.  
11 respektive utslutning, är utförd i överensstämmelse med och följer följande standard(er) eller andra normgivande dokument, under förutsättning att användning sker i överensstämmelse med våra instruktioner.  
12 respektive uslysty er i överensstemmelse med følgende standard(er) eller andre normgivende dokument(er), under forudsættelse at de disse bruges i henhold til vores instrukser.  
13 vestavlat suuraaven standardien ja muiden ohjeisten dokumentien vaatimuksa edellyttäen, että niitä käytetään ohjeiden mukaisesti.  
14 za deklaraciu, žaisiu vyžūdzāmy šīs deklarācijas mērķiem, jābūt ieviestai šādiem normatīvo dokumentiem.  
15 uskladu sa sliędžim stándardam (am) ili drugim normativnim dokumentam (am), uz viędže tie sa on konkrēti v sliędži s mēšim uzliędžim.  
16 megjelölnek az alábbi szabvány(ok)nak vagy egyéb irányadó dokumentum(ok)nak, ha azokat előírás szerint használják.  
17 spēkheid vinnogi nāsępējotchi normi (n)nykh dokumentu(n)u normatīva(n)u, pod vārunķiem žē uzvāne sa gžotchi v rāsnyhi instruktsiyam.  
18 surti in conformitate cu următorii (urmltoroare) standarde (e) sau al(e) document(e) normative (e), cu condiția ca acestea să fie utilizate în conformitate cu instrucțiunile noastre.  
19 sklađni z resleđim stándardim ili drugim normativim, pod pogodbem, da se uporabljajo v skladu z našim navodil.  
20 on vastavusse jęrgimisi le stándardile (ga) või leale normatīvisse dokumentidega, kui need kasutatakse vastavalt meie juhendile.  
21 osonevnet na sredine stándardim ili drugim normativnim dokumentim, pri ustáovane, že se korupavet osonevnet našim instruktsiyam.  
22 alimka žemau nuročiam stándartus ir (ata) kitiis normatīvis dokumentus su slięga, kad vna naudājamā pagalmīstus (n)uocojmūs.  
23 tad ja letai atbilstāš, izāzāģa nodriģimam, atbilst nodriģimam, atbilst nodriģimam un oģim normatīvo dokumentam.  
24 slię žhdos sa sliędžim (n)ny normatīvo (am) alebo (n)ny (n)normatīvo(n)u dokumentom (am)ny, za predpokladu, že sa použijú v sliędže s našimi instruktsiyami.  
25 urunuri, talimlarimiza gęre kullanimas kosulujula oęstęđilje oęstęđilje stándardlar ve norm beliflen beędelele uyumludur.

11 Direktiv, med senere ændringer.  
12 Direktiv, med foretagne ændringer.  
13 Direktiv, med foretagne ændringer.  
14 Richtlijnen, zoals goederkeerd.  
15 Richtlijnen, zoals goederkeerd.  
16 Richtlijnen, zoals goederkeerd.  
17 Richtlijnen, zoals goederkeerd.  
18 Richtlijnen, zoals goederkeerd.  
19 Richtlijnen, zoals goederkeerd.  
20 Richtlijnen, zoals goederkeerd.  
21 Richtlijnen, zoals goederkeerd.  
22 Richtlijnen, zoals goederkeerd.  
23 Richtlijnen, zoals goederkeerd.  
24 Richtlijnen, zoals goederkeerd.  
25 Richtlijnen, zoals goederkeerd.

<->	DAIKIN.TCF.02.1G27/09-2014
<->	DEKRA (NB0344)
<->	2024351-QUA/EMC02-4565

13\* Daikin Europe N.V. este autorizată să completeze Dosarul tehnic de construcție.  
14\* Společnost Daikin Europe N.V. má oprávnění ke kompletní souboru technické konstrukce.  
15\* Daikin Europe N.V. is geautoriseerd tot het complete dossier van de technische constructie.  
16\* A Daikin Europe N.V. jogosult a műszaki konstrukciós dokumentáció összesállítására.  
17\* Daikin Europe N.V. má povolenie do zberania a opracovania dokumentácie konštrukčnej.  
18\* Daikin Europe N.V. este autorizat să completeze Dosarul tehnic de construcție.

DAIKIN EUROPE N.V.  
Zandvoordestraat 300, B-8400 Oostende, Belgium

DAIKIN EUROPE N.V.  
Jean-Pierre Beuselincq  
Director  
Ostend, 3rd of November, 2014.

## Table of contents

<b>1</b>	<b>About the documentation</b>	<b>3</b>
1.1	About this document.....	3
<b>2</b>	<b>About the box</b>	<b>3</b>
2.1	Outdoor unit.....	3
2.1.1	To remove the accessories from the outdoor unit.....	3
<b>3</b>	<b>Installation</b>	<b>4</b>
3.1	Mounting the outdoor unit.....	4
3.1.1	To provide the installation structure.....	4
3.1.2	To install the outdoor unit.....	4
3.1.3	To provide drainage.....	4
3.1.4	To prevent the outdoor unit from falling over.....	5
3.2	Connecting the refrigerant piping.....	5
3.2.1	To connect the refrigerant piping to the outdoor unit ..	5
3.2.2	To determine if oil traps are required.....	6
3.3	Checking the refrigerant piping.....	6
3.3.1	Checking refrigerant piping: Setup.....	6
3.3.2	To check for leaks.....	6
3.3.3	To perform vacuum drying.....	6
3.4	Charging refrigerant.....	7
3.4.1	Definitions: L1~L7, H1, H2.....	7
3.4.2	To determine the additional refrigerant amount.....	7
3.4.3	To determine the complete recharge amount.....	8
3.4.4	Charging refrigerant: Setup.....	8
3.4.5	To charge refrigerant.....	8
3.4.6	To fix the fluorinated greenhouse gases label.....	8
3.5	Connecting the electrical wiring.....	8
3.5.1	About electrical compliance.....	8
3.5.2	Specifications of standard wiring components.....	9
3.5.3	To connect the electrical wiring on the outdoor unit....	9
3.6	Finishing the outdoor unit installation.....	10
3.6.1	To finish the outdoor unit installation.....	10
3.6.2	To check the insulation resistance of the compressor.....	10
<b>4</b>	<b>Commissioning</b>	<b>10</b>
4.1	Checklist before test run.....	10
4.2	To perform a test run.....	11
4.3	Error codes when performing a test run.....	11
<b>5</b>	<b>Technical data</b>	<b>12</b>
5.1	Wiring diagram.....	12
5.1.1	Wiring diagram: Outdoor unit.....	12

## 1 About the documentation

### 1.1 About this document

#### Target audience

Authorised installers



#### INFORMATION

This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.

#### Documentation set

This document is part of a documentation set. The complete set consists of:


Document	Contains...	Format
General safety precautions	Safety instructions that you must read before installing	Paper (in the box of the outdoor unit)
Outdoor unit installation manual	Installation instructions	
Installer reference guide	Preparation of the installation, technical specifications, reference data,...	Digital files on <a href="http://www.daikineurope.com/support-and-manuals/product-information/">http://www.daikineurope.com/support-and-manuals/product-information/</a> .

Latest revisions of the supplied documentation may be available on the regional Daikin website or via your dealer.

## 2 About the box

### 2.1 Outdoor unit

#### 2.1.1 To remove the accessories from the outdoor unit



- a General safety precautions
- b Outdoor unit installation manual
- c Cable tie
- d Fluorinated greenhouse gases label
- e Energy label


## 3 Installation

### 3 Installation

#### 3.1 Mounting the outdoor unit

##### 3.1.1 To provide the installation structure

Prepare 4 sets of anchor bolts, nuts and washers (field supply) as follows:




a Make sure not to cover the drain holes.



#### INFORMATION

The recommended height of the upper protruding part of the bolts is 20 mm.




#### NOTICE

Fix the outdoor unit to the foundation bolts using nuts with resin washers (a). If the coating on the fastening area is stripped off, the nuts rust easily.



##### 3.1.2 To install the outdoor unit



##### 3.1.3 To provide drainage

Make sure that condensation water can be evacuated properly.




#### INFORMATION

If necessary, you can use a drain plug kit (field supply) to prevent drain water from dripping.




#### NOTICE

If drain holes of the outdoor unit are covered by a mounting base or by floor surface, raise the unit to provide a free space of more than 150 mm under the outdoor unit.



#### Drain holes (dimensions in mm)




- A Discharge side
- B Distance between anchor points
- C Bottom frame
- D Drain holes
- E Knockout hole for snow

#### Snow

In regions with snowfall, snow might build up and freeze between the heat exchanger and the external plate. This might decrease the operating efficiency. To prevent this:


- 1 Drill (a, 4x) and remove the knockout hole (b).




- 2 Remove the burrs, and paint the edges and areas around the edges using repair paint to prevent rusting.

## 3.1.4 To prevent the outdoor unit from falling over

Connect cables (field supply) as shown:




## 3.2 Connecting the refrigerant piping




### 3.2.1 To connect the refrigerant piping to the outdoor unit


- Do the following:
  - Remove the service cover (a) with screw (b).
  - Remove the piping intake plate (c) with screw (d).




- Choose a piping route (a, b, c or d).




- If you have chosen the downwards piping route:
  - Drill (a, 4x) and remove the knockout hole (b).
  - Cut out the slits (c) with a metal saw.



- Do the following:
  - Connect the liquid pipe (a) to the liquid stop valve.
  - Connect the gas pipe (b) to the gas stop valve.



- Do the following:
  - Insulate the liquid piping (a) and the gas piping (b).
  - Wind heat insulation around the curves, and then cover it with vinyl tape (c).
  - Make sure the field piping does not touch any compressor components (d).
  - Seal the insulation ends (sealant etc.) (e).




- If the outdoor unit is installed above the indoor unit, cover the stop valves (f, see above) with sealing material to prevent condensed water on the stop valves from moving to the indoor unit.



#### NOTICE

Any exposed piping might cause condensation.

- Reattach the service cover and the piping intake plate.
- Seal all gaps (example: a) to prevent snow and small animals from entering the system.



#### WARNING

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.




#### NOTICE

Make sure to open the stop valves after installing the refrigerant piping and performing vacuum drying. Running the system with the stop valves closed may break the compressor.

## 3 Installation


### 3.2.2 To determine if oil traps are required

If oil flows back into the outdoor unit's compressor, this might cause liquid compression or deterioration of oil return. Oil traps in the rising gas piping can prevent this.

If	Then
The indoor unit is installed higher than the outdoor unit	Install an oil trap every 10 m (height difference).  a Rising gas piping with oil trap b Liquid piping
The outdoor unit is installed higher than the indoor unit	Oil traps are NOT required.

## 3.3 Checking the refrigerant piping

### 3.3.1 Checking refrigerant piping: Setup



- A Setup in case of pair
- B Setup in case of twin
- a Pressure gauge
- b Nitrogen
- c Refrigerant
- d Weighing machine
- e Vacuum pump
- f Stop valve
- g Main piping
- h Refrigerant branch kit
- i Branch piping

### 3.3.2 To check for leaks



#### NOTICE

Do NOT exceed the unit's maximum working pressure (see "PS High" on the unit name plate).



#### NOTICE

Make sure to use a recommended bubble test solution from your wholesaler. Do not use soap water, which may cause cracking of flare nuts (soap water may contain salt, which absorbs moisture that will freeze when the piping gets cold), and/or lead to corrosion of flared joints (soap water may contain ammonia which causes a corrosive effect between the brass flare nut and the copper flare).

- 1 Charge the system with nitrogen gas up to a gauge pressure of at least 200 kPa (2 bar). It is recommended to pressurize to 3000 kPa (30 bar) in order to detect small leaks.
- 2 Check for leaks by applying the bubble test solution to all connections.
- 3 Discharge all nitrogen gas.

### 3.3.3 To perform vacuum drying

- 1 Vacuum the system until the pressure on the manifold indicates  $-0.1$  MPa ( $-1$  bar).
- 2 Leave as is for 4-5 minutes and check the pressure:

If the pressure...	Then...
Does not change	There is no moisture in the system. This procedure is finished.
Increases	There is moisture in the system. Go to the next step.

- 3 Evacuate for at least 2 hours to a pressure on the manifold of  $-0.1$  MPa ( $-1$  bar).
- 4 After turning OFF the pump, check the pressure for at least 1 hour.
- 5 If you do NOT reach the target vacuum or cannot maintain the vacuum for 1 hour, do the following:
  - Check for leaks again.
  - Perform vacuum drying again.




#### NOTICE

Make sure to open the stop valves after installing the refrigerant piping and performing vacuum drying. Running the system with the stop valves closed may break the compressor.



### 3.4 Charging refrigerant

#### 3.4.1 Definitions: L1~L7, H1, H2



(a) Assume that the longest line in the illustration corresponds with the actual longest pipe, and the highest unit in the illustration corresponds with the actual highest unit.

- L1 Main piping
- L2~L7 Branch piping
- H1 Height difference between the highest indoor unit and the outdoor unit
- H2 Height difference between the highest and the lowest indoor unit
- Refrigerant branch kit

#### 3.4.2 To determine the additional refrigerant amount

To determine if adding additional refrigerant is necessary

If	Then
$(L1+L2+L3+L4+L5+L6+L7) \leq$ chargeless length Chargeless length= • 10 m (size-down) • 30 m (standard) • 15 m (size-up)	You do not have to add additional refrigerant.
$(L1+L2+L3+L4+L5+L6+L7) >$ chargeless length	You must add additional refrigerant.  For future servicing, encircle the selected amount in the tables below.



**INFORMATION**

Piping length is the largest one way length of liquid piping.

To determine the additional refrigerant amount (R in kg) (in case of pair)

L1 (standard):	30~40 m	40~50 m	50~60 m <sup>(a)</sup>	60~75 m <sup>(a)</sup>
L1 (size-up):	15~20 m	20~25 m	25~30 m <sup>(a)</sup>	30~35 m <sup>(a)</sup>
R:	0.5 kg	1.0 kg	1.5 kg	2.0 kg

(a) Only for RZQG100~140.

To determine the additional refrigerant amount (R in kg) (in case of twin, triple and double twin)

1 Determine G1 and G2.

G1 (m)	Total length of <x> liquid piping x=Ø9.5 mm (standard) x=Ø12.7 mm (size-up)
G2 (m)	Total length of Ø6.4 mm liquid piping

2 Determine R1 and R2.

If	Then
G1>30 m <sup>(a)</sup>	Use the table below to determine R1 (length=G1-30 m) <sup>(a)</sup> and R2 (length=G2).
G1≤30 m <sup>(a)</sup> (and G1+G2>30 m) <sup>(a)</sup>	R1=0.0 kg. Use the table below to determine R2 (length=G1+G2-30 m) <sup>(a)</sup> .

(a) In case of size-up: Replace 30 m by 15 m.

In case of **standard** liquid pipe size:

	Length			
	0~10 m	10~20 m	20~30 m <sup>(a)</sup>	30~45 m <sup>(a)</sup>
R1:	0.5 kg	1.0 kg	1.5 kg	2.0 kg
R2:	0.3 kg	0.6 kg	0.9 kg	1.2 kg

In case of **size-up** liquid pipe size:

	Length			
	0~5 m	5~10 m	10~15 m <sup>(a)</sup>	15~20 m <sup>(a)</sup>
R1, R2:	0.5 kg	1.0 kg	1.5 kg	2.0 kg

(a) Only for RZQG100~140.

3 Determine the additional refrigerant amount: R=R1+R2.

#### Examples

Layout	Additional refrigerant amount (R)
	Case: Twin, standard liquid pipe size
	1 G1 Total Ø9.5 => G1=35 m
	G2 Total Ø6.4 => G2=7+5=12 m
	Case: G1>30 m
	R1 Length=G1-30 m=5 m => R1=0.5 kg
	R2 Length=G2=12 m => R2=0.6 kg
3 R R=R1+R2=0.5+0.6=1.1 kg	
	Case: Triple, standard liquid pipe size
	1 G1 Total Ø9.5 => G1=5 m
	G2 Total Ø6.4 => G2=20+17+17=54 m
	Case: G1≤30 m (and G1+G2>30 m)
	R1 R1=0.0 kg
	R2 Length=G1+G2-30 m=5+54-30=29 m => R2=0.9 kg
3 R R=R1+R2=0.0+0.9=0.9 kg	

## 3 Installation

### 3.4.3 To determine the complete recharge amount

For RZQG only: When piping length is <5 m, a complete recharge of the unit is required.

To determine the complete recharge amount (kg) (in case of standard liquid pipe size)

Model	Length (m) <sup>(a)</sup>						
	5~10 <sup>(b)</sup>	10~20	20~30	30~40	40~50	50~60	60~75
RZQG71	1.9	2.4	2.9	3.4	3.9	—	—
RZQG100~140	3.0	3.5	4.0	4.5	5.0	5.5	6.0
RZQSG100+125	1.9	2.4	2.9	3.4	3.9	—	—
RZQSG140	3.0	3.5	4.0	4.5	5.0	—	—

- (a) Length = L1 (pair); L1+L2 (twin, triple); L1+L2+L4 (double twin)  
 (b) For RZQG: 3~10 m

To determine the complete recharge amount (kg) (in case of size-up liquid pipe size)

Model	Length (m) <sup>(a)</sup>						
	3~5	5~10	10~15	15~20	20~25	25~30	30~35
RZQG71	1.9	2.4	2.9	3.4	3.9	—	—
RZQG100~140	3.0	3.5	4.0	4.5	5.0	5.5	6.0
RZQSG100+125	—	2.4	2.9	3.4	3.9	—	—
RZQSG140	—	3.5	4.0	4.5	5.0	—	—

- (a) Length = L1 (pair); L1+L2 (twin, triple); L1+L2+L4 (double twin)

To determine the complete recharge amount (kg) (in case of size-down liquid pipe size)

Model	Length (m) <sup>(a)</sup>	
	3~5	5~10
RZQG71	1.9	1.9
RZQG100~140	3.0	3.0
RZQSG100+125	—	1.9
RZQSG140	—	3.0

- (a) Length = L1 (pair); L1+L2 (twin, triple); L1+L2+L4 (double twin)

### 3.4.4 Charging refrigerant: Setup

See "3.3.1 Checking refrigerant piping: Setup" on page 6.

### 3.4.5 To charge refrigerant

**WARNING**


- Only use R410A as refrigerant. Other substances may cause explosions and accidents.
- R410A contains fluorinated greenhouse gases covered by the Kyoto Protocol. Its global warming potential value is 1975. Do NOT vent these gases into the atmosphere.
- When charging refrigerant, always use protective gloves and safety glasses.

**Prerequisite:** Before charging refrigerant, make sure the refrigerant piping is connected and checked (leak test and vacuum drying).

- 1 Connect the refrigerant cylinder to both the service port of the gas stop valve and the service port of the liquid stop valve.
- 2 Charge the additional refrigerant amount.
- 3 Open the stop valves.

### 3.4.6 To fix the fluorinated greenhouse gases label

- 1 Fill in the label as follows:



- a Factory refrigerant charge: see unit name plate  
 b Additional refrigerant amount charged  
 c Total refrigerant charge

- 2 The filled out label must be adhered on the inside of the product and in the proximity of the product charging port (e.g., on the inside of the service cover).

## 3.5 Connecting the electrical wiring

**DANGER: RISK OF ELECTROCUTION**

**WARNING**  
 ALWAYS use multicore cable for power supply cables.

**CAUTION**

For use of units in applications with temperature alarm settings it is recommended to foresee a delay of 10 minutes for signalling the alarm in case the alarm temperature is exceeded. The unit may stop for several minutes during normal operation for "defrosting the unit", or when in "thermostat stop" operation.

### 3.5.1 About electrical compliance

#### RZQ(S)G\_V1 + RZQSG100+125\_Y1

Equipment complying with EN/IEC 61000-3-12 (European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current >16 A and ≤75 A per phase.)

#### RZQG100~140\_Y1 + RZQSG140\_Y1

Equipment complying with:

- EN/IEC 61000-3-12 provided that the short-circuit power  $S_{sc}$  is greater than or equal to the minimum  $S_{sc}$  value at the interface point between the user's supply and the public system.
- EN/IEC 61000-3-12 = European/International Technical Standard setting the limits for harmonic currents produced by equipment connected to public low-voltage systems with input current >16 A and ≤75 A per phase.
- It is the responsibility of the installer or user of the equipment to ensure, by consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power  $S_{sc}$  greater than or equal to the minimum  $S_{sc}$  value.

Model	Minimum $S_{sc}$ value
RZQG100~140_Y1 + RZQSG140_Y1	1170 kVA <sup>(a)</sup>

- (a) This is the most stringent value. For specific product data, see the databooks.



3.5.2 Specifications of standard wiring components

Component	RZQG							RZQSG					
	V1			Y1				V1		Y1			
	71	100	125+140	71	100	125+140	100	125+140	100	125	140		
Power supply cable	MCA <sup>(a)</sup>	20.6 A	32.0 A	33.5 A	14.0 A	21.0 A	22.5 A	32.0 A	33.5 A	17.7 A	19.2 A	22.5 A	
	Voltage	230 V			400 V				230 V		400 V		
	Phase	1~			3N~				1~		3N~		
	Frequency	50 Hz											
	Wire sizes	Must comply with applicable legislation											
Interconnection cables	Minimum cable section of 2.5 mm <sup>2</sup> and applicable for 230 V												
Recommended field fuse	25 A	40 A		16 A	25 A		40 A		20 A		25 A		
Earth leakage circuit breaker	Must comply with applicable legislation												

(a) MCA=Minimum circuit ampacity. Stated values are maximum values (see electrical data of combination with indoor units for exact values).


3.5.3 To connect the electrical wiring on the outdoor unit




NOTICE

- Follow the wiring diagram (delivered with the unit, located at the inside of the service cover).
- Fix the earth wire to the stop valve attachment plate so that it does not slide.
- Make sure the electrical wiring does NOT obstruct proper reattachment of the service cover.

- Remove the service cover.
- Connect the interconnection cables and power supply as follows:




- I, II, III, IV Pair, twin, triple, double twin
- M, S Master, slave
- a Interconnection cables
- b Power supply cable
- c Earth leakage circuit breaker
- d Fuse
- e User interface



- a Switch box
- b Stop valve attachment plate
- c Earth
- d Cable tie
- e Interconnection cable
- f Power supply cable

- Fix the cables (power supply and interconnection cable) with a cable tie to the stop valve attachment plate.
- Route the wiring through the frame and connect it to it.




## 4 Commissioning

Connecting to the frame

When cables are routed from the unit, a protection sleeve for the conduits (PG insertions) can be inserted at the knockout hole.

When you do not use a wire conduit, protect the wires with vinyl tubes to prevent the edge of the knockout hole from cutting the wires.




**A** Inside of the outdoor unit  
**B** Outside of the outdoor unit  
**a** Wire  
**b** Bush  
**c** Nut  
**d** Frame  
**e** Hose

- Reattach the service cover.
- Connect an earth leakage circuit breaker and fuse to the power supply line.

### 3.6 Finishing the outdoor unit installation

#### 3.6.1 To finish the outdoor unit installation

- Insulate and fix the refrigerant piping and interconnection cable as follows:



**a** Gas pipe  
**b** Gas pipe insulation  
**c** Interconnection cable  
**d** Liquid pipe  
**e** Liquid pipe insulation  
**f** Finishing tape

- Install the service cover.

#### 3.6.2 To check the insulation resistance of the compressor



##### NOTICE

If, after installation, refrigerant accumulates in the compressor, the insulation resistance over the poles can drop, but if it is at least 1 MΩ, then the unit will not break down.

- Use a 500 V mega-tester when measuring insulation.
- Do not use a mega-tester for low-voltage circuits.

- Measure the insulation resistance over the poles.

If	Then
≥1 MΩ	Insulation resistance is OK. This procedure is finished.
<1 MΩ	Insulation resistance is not OK. Go to the next step.

- Turn ON the power and leave it on for 6 hours.

**Result:** The compressor will heat up and evaporate any refrigerant in the compressor.

- Measure the insulation resistance again.

## 4 Commissioning



##### NOTICE

NEVER operate the unit without thermistors and/or pressure sensors/switches. Burning of the compressor might result.

### 4.1 Checklist before test run

Do NOT operate the system before the following checks are OK:

<input type="checkbox"/>	The <b>indoor units</b> are properly mounted.
<input type="checkbox"/>	In case a wireless user interface is used: The <b>indoor unit decoration panel</b> with infrared receiver is installed.
<input type="checkbox"/>	The <b>outdoor unit</b> is properly mounted.
<input type="checkbox"/>	The following <b>field wiring</b> has been carried out according to this document and the applicable legislation: <ul style="list-style-type: none"> <li>Between the local supply panel and the outdoor unit</li> <li>Between the outdoor unit and the indoor unit (master)</li> <li>Between the indoor units</li> </ul>
<input type="checkbox"/>	There are <b>NO missing phases</b> or <b>reversed phases</b> .
<input type="checkbox"/>	The system is properly <b>earthed</b> and the earth terminals are tightened.
<input type="checkbox"/>	The <b>fuses</b> or locally installed protection devices are installed according to this document, and have not been bypassed.
<input type="checkbox"/>	The <b>power supply voltage</b> matches the voltage on the identification label of the unit.
<input type="checkbox"/>	There are <b>NO loose connections</b> or damaged electrical components in the switch box.
<input type="checkbox"/>	The <b>insulation resistance</b> of the compressor is OK.
<input type="checkbox"/>	There are <b>NO damaged components</b> or <b>squeezed pipes</b> on the inside of the indoor and outdoor units.
<input type="checkbox"/>	There are <b>NO refrigerant leaks</b> .
<input type="checkbox"/>	The correct pipe size is installed and the <b>pipes</b> are properly insulated.
<input type="checkbox"/>	The <b>stop valves</b> (gas and liquid) on the outdoor unit are fully open.

## 4.2 To perform a test run

This task is only applicable when using the BRC1E52 user interface.

- When using BRC1E51, see the installation manual of the user interface.
- When using BRC1D, see the service manual of the user interface.




**NOTICE**  
Do not interrupt the test run.



**INFORMATION**  
**Backlight.** To perform an ON/OFF action on the user interface, the backlight does not need to be lit. For any other action, it needs to be lit first. The backlight is lit for ±30 seconds when you press a button.

### 1 Perform introductory steps.

#	Action
1	Open the liquid stop valve (A) and gas stop valve (B) by removing the stem cap and turning counterclockwise with a hex wrench until it stops.
2	Close the service cover to prevent electric shocks.
3	Turn ON power for at least 6 hours before starting operation to protect the compressor.
4	On the user interface, set the unit to cooling operation mode.



### 2 Start the test run.

#	Action	Result
1	Go to the home menu.	
2	Press at least 4 seconds.	The Service Settings menu is displayed.
3	Select Test Operation.	
4	Press.	Test Operation is displayed on the home menu. 
5	Press within 10 seconds.	Test run starts.

### 3 Check operation for 3 minutes.

### 4 Check operation of the airflow direction.

#	Action	Result
1	Press. 	
2	Select Position 0. 	
3	Change the position. 	If the airflow flap of the indoor unit moves, operation is OK. If not, operation is not OK.
4	Press. 	The home menu is displayed.

### 5 Stop the test run.

#	Action	Result
1	Press at least 4 seconds. 	The Service Settings menu is displayed.
2	Select Test Operation. 	
3	Press. 	The unit returns to normal operation, and the home menu is displayed.

## 4.3 Error codes when performing a test run

If the installation of the outdoor unit has NOT been done correctly, the following error codes may be displayed on the user interface:

Error code	Possible cause
Nothing displayed (the currently set temperature is not displayed)	<ul style="list-style-type: none"> <li>• The wiring is disconnected or there is a wiring error (between power supply and outdoor unit, between outdoor unit and indoor units, between indoor unit and user interface).</li> <li>• The fuse on the outdoor unit PCB has blown out.</li> </ul>
E3, E4 or L8	<ul style="list-style-type: none"> <li>• The stop valves are closed.</li> <li>• The air inlet or air outlet is blocked.</li> </ul>
E7	There is a missing phase in case of three-phase power supply units. <b>Note:</b> Operation will be impossible. Turn OFF the power, recheck the wiring, and switch two of the three electrical wires.
L4	The air inlet or air outlet is blocked.
U0	The stop valves are closed.

## 5 Technical data

Error code	Possible cause
U2	<ul style="list-style-type: none"> <li>There is a voltage imbalance.</li> <li>There is a missing phase in case of three-phase power supply units. <b>Note:</b> Operation will be impossible. Turn OFF the power, recheck the wiring, and switch two of the three electrical wires.</li> </ul>
U4 or UF	The inter-unit branch wiring is not correct.
UA	The outdoor and indoor unit are incompatible.



### NOTICE

- The reversed phase protection detector of this product only functions when the product starts up. Consequently reversed phase detection is not performed during normal operation of the product.
- The reversed phase protection detector is designed to stop the product in the event of an abnormality when the product is started up.
- Replace two of the three phases (L1, L2, and L3) during reverse-phase protection abnormality.

## 5 Technical data

### 5.1 Wiring diagram

#### 5.1.1 Wiring diagram: Outdoor unit

The wiring diagram is delivered with the unit, located at the inside of the service cover.

#### Notes for RZQ(S)G\_V1:

Notes:	
1	Symbols (see legend).
2	Colours (see legend).
3	This wiring diagram applies only to the outdoor unit.
4	Refer to the wiring diagram sticker (on the back of the service cover) for how to use the BS1~BS4 and DS1 switches.
5	When operating, do not short-circuit protective devices S1PH and S1PL.
6	Refer to the service manual for instructions on how to set the selector switches (DS1). The factory setting of all switches is OFF.
7	Refer to the combination table and the option manual for how to connect the wiring to X6A, X28A and X77A.

#### Notes for RZQ(S)G\_Y1:

Notes:	
1	This wiring diagram applies only to the outdoor unit.
2	Refer to the combination table and the option manual for how to connect the wiring to X6A, X28A and X77A.
3	Refer to the wiring diagram sticker (on the back of the service cover) for how to use the BS1~BS4 and DS1 switches.
4	When operating, do not short-circuit protective device S1PH.
5	Refer to the service manual for instructions on how to set the selector switches (DS1). The factory setting of all switches is OFF.
6	Only for 71 class.










#### Legend for wiring diagrams:

A1P~A2P	Printed circuit board
---------	-----------------------

BS1~BS4	Push button switch
C1~C3	Capacitor
DS1	DIP switch
E1H	Bottom plate heater (option)
F1U~F8U (RZQG71_V1 + RZQSG100_V1)	<ul style="list-style-type: none"> <li>F1U, F2U: Fuse</li> <li>F6U: Fuse (T 3.15 A / 250 V)</li> <li>F7U, F8U: Fuse (F 1.0 A / 250 V)</li> </ul>
F1U~F8U (RZQG100~140_V1 + RZQSG125+140_V1)	<ul style="list-style-type: none"> <li>F1U~F4U: Fuse</li> <li>F6U: Fuse (T 5.0 A / 250 V)</li> <li>F7U, F8U: Fuse (F 1.0 A / 250 V)</li> </ul>
F1U~F8U (RZQ(S)G_Y1)	<ul style="list-style-type: none"> <li>F1U, F2U: Fuse (31.5 A / 250 V)</li> <li>F1U (A2P): Fuse (T 5.0 A / 250 V)</li> <li>F3U~F6U: Fuse (T 6.3 A / 250 V)</li> <li>F7U, F8U: Fuse (F 1.0 A / 250 V)</li> </ul>
H1P~H7P	Light-emitting diode (service monitor is orange)
HAP	Light-emitting diode (service monitor is green)
K1M, K11M	Magnetic contactor
K1R (RZQ(S)G_V1)	Magnetic relay (Y1S)
K1R (RZQ(S)G_Y1)	<ul style="list-style-type: none"> <li>K1R (A1P): Magnetic relay (Y1S)</li> <li>K1R (A2P): Magnetic relay</li> </ul>
K2R (RZQG71_V1 + RZQSG100_V1)	Magnetic relay
K2R (RZQ(S)G_Y1)	<ul style="list-style-type: none"> <li>K2R (A1P): Magnetic relay (E1H option)</li> <li>K2R (A2P): Magnetic relay</li> </ul>
K10R, K13R~K15R	Magnetic relay
K4R	Magnetic relay E1H (option)
L1R~L3R	Reactor
M1C	Motor (compressor)
M1F	Motor (upper fan)
M2F	Motor (lower fan)
PS	Switching power supply
Q1DI	Earth leakage circuit breaker (field supply)
R1~R6	Resistor
R1T	Thermistor (air)
R2T	Thermistor (discharge)
R3T	Thermistor (suction)
R4T	Thermistor (heat exchanger)
R5T	Thermistor (heat exchanger middle)
R6T	Thermistor (liquid)
R7T (RZQG100~140_V1 + RZQSG125+140_V1)	Thermistor (fin)
R7T, R8T (RZQG71_V1 + RZQSG100_V1)	Thermistor (Positive Temperature Coefficient)
R10T (RZQ(S)G_Y1)	Thermistor (fin)
RC	Signal receiver circuit
S1PH	High pressure switch


S1PL	Low pressure switch
TC	Signal transmission circuit
V1D~V4D	Diode
V1R	IGBT power module
V2R, V3R	Diode module
V1T~V3T	Insulated gate bipolar transistor (IGBT)
X6A	Connector (option)
X1M	Terminal strip
Y1E	Electronic expansion valve
Y1S	Solenoid valve (4-way valve)
Z1C~Z6C	Noise filter (ferrite core)
Z1F~Z6F	Noise filter

**Symbols:**



L	Live
N	Neutral
	Field wiring
	Terminal strip
	Connector
	Relay connector
	Connection
	Protective earth
	Noiseless earth
	Terminal
	Option

**Colours:**

BLK	Black
BLU	Blue
BRN	Brown
GRN	Green
ORG	Orange
RED	Red
WHT	White
YLW	Yellow









4P385521-1 0000000M

Copyright 2014 Daikin

**DAIKIN EUROPE N.V.**

Zandvoordestraat 300, B-8400 Oostende, Belgium

4P385521-1 2014.08