

# Service Manual

## VRV4WC+

RWEYQ8, 10,14 T9Y1B



The present publication is drawn up by way of information only and does not constitute an offer binding upon Daikin Europe N.V. Daikin Europe N.V. has compiled the content of this publication to the best of its knowledge. No express or implied warranty is given for the completeness, accuracy, reliability or fitness for particular purpose of its content and the products and services presented therein.

Specifications are subject to change without prior notice. Daikin Europe N.V. explicitly rejects any liability for any direct or indirect damage, in the broadest sense, arising from or related to the use and/or interpretation of this publication. All content is copyrighted by Daikin Europe N.V.

# Table of contents

<b>Part 1. Introduction</b>	<b>9</b>
1.1. Version log	9
1.2. Safety precautions	10
1.2.1. Meaning of symbols	10
1.2.2. Warnings	10
1.2.3. Cautions	12
1.2.4. Information	12
1.3. General operation	13
1.4. How to use	16
1.4.1. Interactive information flow	16
1.4.2. Parts of the book	17
1.4.2.1. The introduction chapter	17
1.4.2.2. The troubleshooting chapter	17
1.4.2.3. The repair chapter	17
1.4.2.4. The maintenance chapter	17
1.4.2.5. Appendices	17
1.4.3. Contact information	17
<b>Part 2. Troubleshooting</b>	<b>19</b>
2.1. Error codes check	19
2.1.1. Error codes via remote controller	19
2.1.1.1. Error codes via wired remote controller BRC1E	19
2.1.1.2. Error codes via wireless remote controller BRC7	21
2.1.2. Error codes via outdoor unit	24
2.1.2.1. How to retrieve error codes	24
2.1.2.2. How to reset error codes	25
2.1.2.3. History of error codes and warnings	26
2.2. Error code based troubleshooting	27
2.2.1. Error code BS and outdoor	28
2.2.2. Error code indoor units	35
2.2.3. Error code VRV IV-Water cooled unit	37
2.2.3.1. "E2" – Earth leakage detection	37
2.2.3.2. "E3" – Discharge pressure abnormality	37
2.2.3.3. "E4" – Suction pressure abnormality	38
2.2.3.4. "E5" – Compressor motor lock	39
2.2.3.5. "E9" – Electronic expansion valve abnormality	40
2.2.3.6. "F3" – Discharge pipe temperature abnormality	41
2.2.3.7. "F4" – Wet operation caution	42
2.2.3.8. "F6" – Refrigerant overcharge detection during test-run	42
2.2.3.9. "H3" – Discharge pressure switch abnormality	43
2.2.3.10. "H9" – Air temperature abnormality	44
2.2.3.11. "HJ" – Faulty watercircuit	44
2.2.3.12. "J3" – Discharge temperature abnormality	45
2.2.3.13. "J4" – Gas temperature PHE-H <sub>2</sub> O abnormality	45
2.2.3.14. "J5" – Suction accumulator inlet temperature abnormality	46
2.2.3.15. "J6" – Liquid Sub-cool heat-exchanger temperature	46
2.2.3.16. "J7" – Liquid temperature abnormality	47
2.2.3.17. "J9" – Purge receiver + gas out SCHEX temperature abnormality	47
2.2.3.18. "JA" – High pressure sensor abnormality	48
2.2.3.19. "JC" – Low pressure sensor abnormality	48
2.2.3.20. "L1" – Main board abnormality	49
2.2.3.21. "L2" – Power Supply quality abnormality	49
2.2.3.22. "L5" – Output overcurrent detection	50
2.2.3.23. "L8" – Inverter overcurrent	51
2.2.3.24. "L9" – Stall prevention	51
2.2.3.25. "LC" – Transmission system abnormality	52

2.2.3.26. "P1" – Ripple DC voltage diode module to power transistors .....	52
2.2.3.27. "P4" – Overheat power module .....	53
2.2.3.28. "PJ" – Capacity setting mismatch inverter board .....	53
2.2.4. System .....	54
2.2.4.1. "U0" – Refrigerant shortage .....	54
2.2.4.2. "U1" – Reverse phase or open phase .....	55
2.2.4.3. "U2" – DC voltage DM <-> PM not permanent available .....	55
2.2.4.4. "U3" – Test run failed .....	56
2.2.4.5. "U4" – Transmission abnormality between outdoor and indoor unit .....	56
2.2.4.6. "U7" – Transmission between systems abnormality .....	57
2.2.4.7. "U9" – Systems abnormality .....	58
2.2.4.8. "UF" – Wiring and piping mismatch .....	59
2.2.4.9. "UH" – Auto-address failure .....	60
2.2.5. Others .....	60
2.3. Symptom based troubleshooting .....	61
2.3.1. None of the units operate .....	62
2.3.2. Operation sometimes stops .....	63
2.3.3. Some indoor units do not operate .....	63
2.3.4. Equipment operates but does not cool or does not heat .....	63
2.3.5. Large operation noise and vibration .....	64
2.4. Component checklist .....	66
2.4.1. VRV IV-Water cooled unit .....	67
2.4.1.1. 4-way valve .....	67
2.4.1.2. AC fan motor inverter cooling .....	70
2.4.1.3. Thermistor value-read-out .....	72
2.4.1.4. High pressure switch .....	73
2.4.1.5. High pressure sensor S1NPH .....	74
2.4.1.6. Low pressure sensor S1NPL .....	76
2.4.1.7. Inverter board A3P .....	78
2.4.1.8. Main board A1P .....	82
2.4.1.9. Thermistors .....	83
2.4.1.10. Compressor .....	87
2.4.1.11. Electronic expansion valve .....	89
2.4.2. System .....	90
2.4.3. Others .....	90
2.5. Other capacity range .....	91

## **Part 3. Repair ..... 93**

3.1. Refrigerant repair procedures .....	93
3.1.1. Refrigerant piping handling .....	93
3.1.2. Refrigerant recovery procedure .....	94
3.1.2.1. Setup without BS units .....	95
3.1.2.2. Setup including BS units .....	96
3.1.3. Preparation for repair .....	97
3.1.3.1. Setup without BS units .....	98
3.1.3.2. Setup including BS units .....	99
3.1.4. Piping repair procedures .....	99
3.2. Service tools .....	100
3.3. Unit specific repair procedures .....	101
3.3.1. Indoor unit .....	101
3.3.2. RWEYQ-T9 .....	102
3.3.2.1. Basic removal .....	102
3.3.2.2. Replacing thermistor .....	110
3.3.2.3. Replacing 4-way valve body .....	111
3.3.2.4. Replacing 4-way valve coil .....	113
3.3.2.5. Replacing compressor .....	114
3.3.2.6. Replacing oil separator .....	117
3.3.2.7. Replacing crankcase heater .....	119
3.3.2.8. Replacing AC fan inverter cooling .....	120
3.3.2.9. Replacing expansion valve body .....	121

3.3.2.10. Replacing expansion valve coil .....	122
3.3.2.11. Replacing high pressure sensor .....	123
3.3.2.12. Replacing high pressure switch .....	124
3.3.2.13. Replacing solenoid valve .....	125
3.3.2.14. Replacing solenoid valve coil .....	127
3.3.2.15. Replacing low pressure sensor .....	128
3.3.2.16. Replacing liquid receiver .....	129
3.3.2.17. Replacing accumulator .....	131
3.3.2.18. Replacing plate heat exchanger H <sub>2</sub> O .....	133
3.3.2.19. Replacing heat exchanger inverter cooling .....	135
3.3.2.20. Replacing reactor .....	137
3.3.2.21. Replacing transformer .....	138
3.3.2.22. Replacing inverter board A3P .....	139
3.3.2.23. Replacing main PCB A1P .....	141
3.3.2.24. Replacing noise filter PCB A2P .....	144
3.3.2.25. Replacing SUB PCB A4P .....	146
3.3.2.26. Replacing Adapter PCB A8P .....	147
3.3.3. Branch Selector (BS) box .....	148
3.3.3.1. Replace control board BS box .....	148
3.3.3.2. Replacing expansion valve coil BS box .....	149

## **Part 4. Maintenance ..... 151**

4.1. Indoor unit .....	151
4.1.1. General maintenance indoor unit .....	151
4.2. RWEYQ-T .....	152
4.2.1. General maintenance RWEYQ-T .....	152

## **Part 5. Appendix ..... 153**

5.1. Field setting .....	155
5.1.1. RWEYQ-T default mode 2 settings .....	155
5.2. Detailed information setting mode .....	156
5.2.1. Indoor unit .....	156
5.2.2. RWEYQ-T9 field settings overview mode1 & 2 .....	157
5.2.3. Remote controller .....	158
5.3. Wiring diagram .....	159
5.3.1. RWEYQ-T9Y1B (380~415V) .....	159
5.3.2. Field wiring .....	160
5.4. Piping diagram .....	161
5.5. Component overview of unit .....	162
5.6. Product specific information .....	163
5.6.1. Component checklist .....	163
5.6.1.1. How to activate inverter test .....	163
5.6.1.2. Component checklist RWEYQ-T9Y1B .....	163
5.6.2. Safety devices .....	164
5.6.2.1. Drop control .....	164
5.6.2.2. Forced Stop .....	164
5.6.3. Control range .....	165
5.6.3.1. Compression operation range .....	165
5.6.4. Performance Characteristics .....	166
5.7. Switch box .....	167
5.7.1. Switch Box RWEYQ-T9Y1B .....	167
5.8. Branch Selector (BS) box .....	168
5.8.1. BS1Q10A, BS1Q16A, BS1Q25A .....	168
5.8.2. BS4Q14A .....	168
5.8.3. BS6Q14A .....	169

5.8.4. BS8Q14A .....	169
5.8.5. BS10Q14A .....	170
5.8.6. BS12Q14A .....	170
5.8.7. BS16Q14A .....	171
5.9. Field information report .....	172

## List of figures

Figure 1-1: VRV4WC+ heat-pump application .....	14
Figure 1-2: VRV4WC+ heat-recovery application .....	15
Figure 2-3: Inverter board transistor/diode check .....	79
Figure 2-4: Compressor motor checking method .....	88
Figure 3-1: Removing the main front plate .....	102
Figure 3-2: Removing the PHE front plate .....	103
Figure 3-3: Removing the top plate .....	104
Figure 3-4: Removing the left side plate .....	105
Figure 3-5: Removing the right side plate .....	106
Figure 3-6: Lowering the switch box .....	107
Figure 3-7: Opening the switch box .....	108
Figure 3-8: Removing the compressor jacket .....	109
Figure 3-9: Replacing a thermistor .....	110
Figure 3-10: Removing the 4-way valve body .....	112
Figure 3-11: Removing the 4-way valve coil .....	113
Figure 3-12: Removing the compressor .....	115
Figure 3-13: Removing the oil separator .....	118
Figure 3-14: Removing the crankcase heater .....	119
Figure 3-15: Removing the AC fan inverter cooling .....	120
Figure 3-16: Removing the expansion valve .....	121
Figure 3-17: Removing expansion valve coil .....	122
Figure 3-18: Removing high pressure sensor .....	123
Figure 3-19: Removing high pressure switch .....	124
Figure 3-20: Removing the solenoid valve body .....	126
Figure 3-21: Removing the solenoid valve coil .....	127
Figure 3-22: Removing low pressure sensor .....	128
Figure 3-23: Removing the liquid receiver .....	130
Figure 3-24: Removing the accumulator .....	132
Figure 3-25: Removing the plate heat exchanger .....	134
Figure 3-26: Removing the heat exchanger inverter cooling .....	136
Figure 3-27: Removing the reactor .....	137
Figure 3-28: Removing the transformer .....	138
Figure 3-29: Removing the inverter board A3P .....	140
Figure 3-30: Removing the main PCB A1P .....	142
Figure 3-31: Removing the noise filter PCB A2P .....	145
Figure 3-32: Removing the SUB PCB A4P .....	146
Figure 3-33: Removing the Adapter PCB A8P .....	147
Figure 3-34: Removing the control board PCB (e.g. for BS box BS4Q14A) .....	148
Figure 3-35: Removing expansion valve coil (e.g. for BS box BS4Q14A) .....	149
Figure 5-1: Check method Wiring BS-Q14A .....	156
Figure 5-2: Wiring diagram .....	159
Figure 5-3: Piping diagram RWEYQ-T9Y1B .....	161

---

Figure 5-4: Component overview RWEYQ-T9Y1B / TATJU/-TAYDU .....	162
Figure 5-5: Performance Characteristics .....	166
Figure 5-6: Switch box - RWEYQ-T9Y1B .....	167
Figure 5-7: BS box - BS1Q10A, BS1Q16A, BS1Q25A .....	168
Figure 5-8: BS box - BS4Q14A .....	168
Figure 5-9: BS box - BS6Q14A .....	169
Figure 5-10: BS box - BS8Q14A .....	169
Figure 5-11: BS box - BS10Q14A .....	170
Figure 5-12: BS box - BS12Q14A .....	170
Figure 5-13: BS box - BS16Q14A .....	171

# Part 1. Introduction

This part contains the following chapters:

Version log.....	9
Safety precautions.....	10
General operation.....	13
How to use .....	16

## 1.1. Version log

Version code	Description	Date
ESIE17-06	Document release	30/10/2017

## 1.2. Safety precautions

The precautions described in this document cover very important topics, follow them carefully.

All activities described in the service manual must be performed by an authorized person.

If you are not sure how to install, operate or service the unit, contact your dealer.

In accordance with the applicable legislation, it might be necessary to provide a logbook with the product containing at least: information on maintenance, repair work, results of tests, stand-by periods, ...

Also, at least, following information must be provided at an accessible place at the product:

- Instructions for shutting down the system in case of an emergency
- Name and address of fire department, police and hospital
- Name, address and day and night telephone numbers for obtaining service

In Europe, EN378 provides the necessary guidance for this logbook.

### 1.2.1. Meaning of symbols

	<b>WARNING</b> Indicates a situation that could result in death or serious injury.
	<b>WARNING: RISK OF ELECTROCUTION</b> Indicates a situation that could result in electrocution.
	<b>WARNING: RISK OF BURNING</b> Indicates a situation that could result in burning because of extreme hot or cold temperatures.
	<b>WARNING: RISK OF EXPLOSION</b> Indicates a situation that could result in explosion.
	<b>WARNING: RISK OF POISONING</b> Indicates a situation that could result in poisoning.
	<b>WARNING: RISK OF FIRE</b> Indicates a situation that could result in fire.
	<b>CAUTION</b> Indicates a situation that could result in equipment or property damage.
	<b>INFORMATION</b> Indicates useful tips or additional information.

### 1.2.2. Warnings

	<b>WARNING</b> Improper installation or attachment of equipment or accessories could result in electric shock, short-circuit, leaks, fire or other damage to the equipment. Only use accessories, optional equipment and spare parts made or approved by Daikin.
---	---

	<p><b>WARNING</b></p> <p>Make sure installation, testing and applied materials comply with applicable legislation (on top of the instructions described in the Daikin documentation).</p>
	<p><b>WARNING</b></p> <p>Make sure the work site environment is clean and safe to work in. Beware of spilled fluids, like water, oil or other substances. Protect bystanders from injury and property from possible damage cause by service works.</p>
	<p><b>WARNING</b></p> <p>Wear adequate personal protective equipment (protective gloves, safety glasses,...) when installing, maintaining or servicing the system.</p>
	<p><b>WARNING</b></p> <p>Tear apart and throw away plastic packaging bags so that nobody, especially children, can play with them. Possible risk: suffocation.</p>
	<p><b>WARNING</b></p> <p>Do NOT touch the air inlet or aluminium fins of the unit.</p>
	<p><b>WARNING</b></p> <ul style="list-style-type: none"> <li>• Do NOT place any objects or equipment on top of the unit.</li> <li>• Do NOT sit, climb or stand on the unit.</li> </ul>
	<p><b>WARNING</b></p> <p>During tests, NEVER pressurize the product with a pressure higher than the maximum allowable pressure (as indicated on the nameplate of the unit).</p>
	<p><b>WARNING</b></p> <ul style="list-style-type: none"> <li>• Never mix different refrigerants or allow air to enter the refrigerant system.</li> <li>• Never charge recovered refrigerant from another unit. Use recovered refrigerant only on the same unit where it was recovered from, or have it recycled at a certified facility.</li> </ul>
	<p><b>WARNING: RISK OF FIRE</b></p> <ul style="list-style-type: none"> <li>• When reconnecting a connector to the PCB, do not apply force or damage the connector or the connector pins on the PCB.</li> </ul>
	<p><b>WARNING: RISK OF BURNING</b></p> <ul style="list-style-type: none"> <li>• Do NOT touch the refrigerant piping, water piping or internal parts during and immediately after operation. It could be too hot or too cold. Give it time to return to normal temperature. If you must touch it, wear protective gloves.</li> <li>• Do NOT touch any accidental leaking refrigerant.</li> </ul>
	<p><b>WARNING</b></p> <p>Always recover the refrigerants. Do NOT release them directly into the environment. Use a recovery pump to evacuate the installation.</p> <p>Take sufficient precautions in case of refrigerant leakage. If refrigerant gas leaks, ventilate the area immediately.</p> <p>Possible risks:</p> <ul style="list-style-type: none"> <li>• Excessive refrigerant concentrations in a closed room can lead to oxygen deficiency.</li> <li>• Toxic gas may be produced if refrigerant gas comes into contact with fire.</li> </ul> <p>Where applicable, pump down the system and close the service valve, before leaving the site if leak was not repaired, to avoid further leaking of the refrigerant.</p>
	<p><b>WARNING: RISK OF ELECTROCUTION</b></p> <ul style="list-style-type: none"> <li>• Turn OFF all power supply before removing the switch box cover, connecting electrical wiring or touching electrical parts. Where applicable, stop the equipment's operation first and allow (refrigerant) pressure to equalize, before turning OFF the power. Disconnect the power supply for more than 1 minute, and measure the voltage at the terminals of main circuit capacitors or electrical components before servicing. The voltage must be less than 50 V DC before you can touch electrical components. For the location of the terminals, refer to "<a href="#">Wiring diagram</a>" on page 159.</li> <li>• Do NOT touch electrical components with wet hands.</li> <li>• Do NOT leave the unit unattended when the service cover is removed.</li> <li>• Protect electric components from getting wet while the service cover is opened.</li> </ul>

**WARNING**

- Only use copper wires.
- All field wiring must be performed in accordance with the wiring diagram and installation manual supplied with the product.
- If the power cable and lead wires have scratches or deteriorated, be sure to replace them. Damaged cable and wires may cause an electrical shock, excessive heat generation or fire.
- Secure all terminal connections and provide proper routing for cables, both inside and outside the switchbox.
- NEVER squeeze bundled cables and make sure they do not come in contact with the piping and sharp edges.
- Make sure no external pressure is applied to the terminal connections.
- Make sure to check the earth wiring. Do NOT earth the unit to a utility pipe, surge absorber, or telephone earth. Improper earth wiring may cause electrical shock.
- Make sure to use a dedicated power circuit. NEVER use a power supply shared by another appliance.
- Make sure to check the required fuses and/or circuit breakers before starting works.

**WARNING**

- After finishing the electrical work, confirm that each electrical component and terminal inside the electrical components box is connected securely.
- Make sure all covers are closed before starting the unit again.

**1.2.3. Cautions****CAUTION**

Provide adequate measures to prevent that the unit can be used as a shelter by small animals. Small animals that make contact with electrical parts can cause malfunctions, smoke or fire.

**CAUTION**

- Make sure water quality complies with EU directive 98/83 EC.
- Check the system for leaks after each repair/modification of the water side.
- Check drainage system(s) after repairs.
- Be careful when tilting units as water may leak.

**1.2.4. Information****INFORMATION**

Make sure refrigerant piping installation complies with applicable legislation. In Europe, EN378 is the applicable standard.

**INFORMATION**

Make sure the field piping and connections are not subjected to stress.

## 1.3. General operation

- VRV IV-Water-cooled unit (1) is typically used for cooling or heating in commercial applications where local restrictions do not allow outdoor A/C equipment to be visible, or when the building does not offer place to install the normal air cooled VRV outdoor unit.
- When the VRV IV-Water-cooled unit is connected without BS boxes (BS = Branch selector), the system operates like a heat-pump unit; all indoor units (3) operate in the same mode (cooling or heating). Refer to figure 1-1 on page 14.
- When the VRV IV-Water-cooled unit is connected via BS boxes (2) to indoor units (3), the system operates like a heat-recovery system: indoor unit(s) at each BS box can operate in cooling or heating individually. Refer to figure 1-2 on page 15.
- VRV IV-Water-cooled unit contains a compressor, and a water cooled plate heat-exchanger instead of the air cooled heat-exchanger.
- VRV IV-Water-cooled unit also contains the inverter driven compressor and the control board.
- The inverter circuit dissipates heat. By field setting [2-74] (see table RWEYQ-T - mode 2 (Field setting mode)) you can set the maximum air temperature allowed in the plant room. When the room temperature exceeds the set temperature, the internal built in evaporator will cool down air discharged through the inverter board back panel (zero energy dissipation function).
- At the water inlet of the plate heat-exchanger (4) of the VRV IV-Water-cooled unit, the standard supplied water filter (5) must be installed.
- Local installed water circuit needs to provide the possibility to:
  - Dissipate heat (example dry-cooler) (6) when the plate heat-exchanger is set to condenser.
  - Absorb heat (example boiler) (7) when the plate heat-exchanger is set to evaporator.
  - The control (8) to switch between heat dissipation or heat source needs to be provided locally.
  - Sufficient water volume (9) to allow control of VRV IV-Water-cooled unit and local control to adjust operation according to the water temperature setting.
  - By field setting [2-50] (see table RWEYQ-T - mode 2 (Field setting mode)), it is possible to use VRV IV-Water-cooled unit in "geothermal" application: use ground source (secondary water loop into ground). In this case it is essential to use a glycol solution in the primary circuit (including plate heat-exchanger of VRV IV-Water-cooled unit). The pump will need to offer higher water flow and higher pressure drop. Refer to pressure drop data in "[Performance Characteristics](#)" on page 166.
  - To easily inspect the operation conditions of the system, it is highly recommended to provide:
    - Gauges (10) at the plate heat-exchanger to see pressure drop = indication of flow rate and restricting filter or plate heat-exchanger.
    - Temperature indicators (11) to show the temperature inlet and outlet = indication of flow rate and operation range equipment.
- The water flow rate through the plate heat-exchanger can be a fixed flow or variable water flow rate. The change of water flow rate in function of load can be covered by (local supplied) inverter pump, or/and variable water flow rate by (local supplied) water modulating valve. The control VRV IV-Water-cooled unit offers an output signal 2 & 10 DCV output by the control. The selection for variable water flow (pump or/and valve) is chosen by changing field setting [2-24] (see table RWEYQ-T - mode 2 (Field setting mode)).
- The VRV IV-Water-cooled unit has 3 refrigerant pipe connections:
  - Refer to figure 1-1 on page 14.  
Without BS boxes use the HP/LP gas pipe (left) (13) + liquid (right) (14) towards the optional refnet(s) towards indoor unit(s).
  - Refer to figure 1-2 on page 15.  
With BS boxes use the 3 connections through refnets to the BS units; HP/LP gas pipe (left) (13) + liquid (right) (14) + suction (15). From the BS box, gas and liquid pipe is connected towards indoor unit(s).

- In cooling mode:
  - The compressor capacity step is controlled based on evaporation temperature. Range of frequency output, see "Control range" on page 165.
  - The plate heat-exchanger is used as condenser.
- In heating mode:
  - The compressor capacity step is controlled based on condensing temperature. Range of frequency output, see "Control range" on page 165.
  - The plate heat-exchanger is used as evaporator.

Figure 1-1: VRV4WC+ heat-pump application





Figure 1-2: VRV4WC+ heat-recovery application




- |  |   |
|--|---|
| 1. VRV IV-Water-cooled unit                | 9. Buffer tank                                    |
| 2. BS box                                  | 10. Pressure gauges                               |
| 3. Indoor unit                             | 11. Temperature indications                       |
| 4. PHE front plate                         | 12. Water pump                                    |
| 5. Water filter                            | 13. High pressure/Low pressure gas pipe to BS box |
| 6. Dry-cooler                              | 14. Liquid pipe to BS box                         |
| 7. Boiler                                  | 15. Suction pipe to BS box                        |
| 8. Heat dissipation or heat source control |   |

## 1.4. How to use

### 1.4.1. Interactive information flow

This Daikin product Service Manual is intended for professional use only. The actions described hereafter, are only to be performed by qualified and certified persons, taking into account the safety precautions mentioned in this manual and the local regulations as well.

By following the diagram below, the reader can find the relevant information related to his/her task. The digital (pdf) version of this book allows direct page access through all active links. When Adobe Acrobat Reader is used, the <Alt> + <Back Arrow> keys or the arrow in the top right-hand corner of this page can be used to return to the previously viewed page.



## 1.4.2. Parts of the book

This Daikin product Service Manual is intended for professional use only. The actions described hereafter, are only to be performed by qualified and certified persons, taking into account the safety precautions mentioned in this manual and the local regulations as well.

As can be observed from the Table of Contents, this manual is split up into several chapters:

### 1.4.2.1. The introduction chapter

The chapter "Introduction" on page 9 includes the safety precautions, this topic and the general operation description of the product(s) this manual refers to.

### 1.4.2.2. The troubleshooting chapter

The chapter "Troubleshooting" on page 19 not only deals with the methods to recognize and resolve occurring error codes; it also describes the methods how to solve a problem that does not immediately trigger an error code. Such problems are referred to as 'symptom based'. Both the error code based and symptom based troubleshooting tables, indicate possible causes, the necessary checks and in case required, how to repair. The possible causes have been sorted to probability of occurrence and speed of execution.

### 1.4.2.3. The repair chapter

The chapter "Repair" on page 93 handles the removal and replacement of the major components in the product and discusses cleaning methods as well if applicable, such as for filters. Where applicable, refrigerant handling precautions are mentioned for certain actions; please consider these carefully for your own safety.

### 1.4.2.4. The maintenance chapter

The chapter "Maintenance" on page 151 of this manual describes the maintenance intervals and procedures to be performed on the product. Remember that a well maintained product, is a more reliable and efficient product.

### 1.4.2.5. Appendices

Finally, the service manual provides in chapter "Appendix" on page 153 valuable reference data such as piping/wiring diagrams, field settings overview and a checklist to be filled in when you need to escalate an issue to your dealer.

## 1.4.3. Contact information

This manual has been made with much care and effort. Use it in your daily jobs, as it has been made for you.

Despite our efforts, there is always a chance some clerical or other mistake has been made during the creation of this manual. We kindly ask you to send the found mistakes, or remarks for improvement, to the no-reply email address [servicemanual@daikineurope.com](mailto:servicemanual@daikineurope.com).



# Part 2. Troubleshooting

This part contains the following chapters:

Error codes check.....	19
Error code based troubleshooting .....	27
Symptom based troubleshooting .....	61
Component checklist .....	66
Other capacity range .....	91


## 2.1. Error codes check

### 2.1.1. Error codes via remote controller

#### 2.1.1.1. Error codes via wired remote controller BRC1E

##### 2.1.1.1.1 How to retrieve error codes

The following message will be displayed on the screen when a malfunction or a warning occurs during operation.









	Operation Status	Display	
Abnormal shut-down	The system stops operating.	The operation lamp (green) starts to blink. The message "Error: Press Menu button" will appear and blink at the bottom of the screen.	
Warning	The system continues its operation.	The operation lamp (green) remains on. The message "Warning: Press Menu button" will appear and blink at the bottom of the screen.	





If an error or warning is present, it will be displayed on the user interface screen: for more information about troubleshooting, refer to "Error code based troubleshooting" on page 27.

2.1.1.1.2 How to reset error codes

In "Error code based troubleshooting" on page 27 you find a description of how to reset the specific error or warning.

2.1.1.1.3 History of error codes

Step	Control Type	Method	Example display	Button location
1	BRC1E51 BRC1E52 BRC1E53	If the backlight is switched off press once any button so that the backlight is activated.		
2	BRC1E51	Press and hold the Cancel button for 4 seconds or longer in the Basic screen. The Field Settings menu is displayed.		 Press and hold the Cancel button for 4 seconds or longer while the backlight is lit.
	BRC1E52 BRC1E53	Press and hold the Cancel button for 4 seconds or longer in the Basic screen. The Service Settings menu is displayed.		
3	BRC1E51	Select <i>Error Record</i> and press the Menu/Enter button. The Error Record menu is displayed.		 Press the Menu/Enter button.
	BRC1E52 BRC1E53	Select <i>Error History</i> and press the Menu/Enter button. The error History menu is displayed.		
4	BRC1E51	Select <i>Remote controller record</i> and press the Menu/Enter button. The error codes and unit No. can be confirmed in the RC Error record screen.		 Press the Menu/Enter button.
	BRC1E52 BRC1E53	Select <i>RC Error History</i> and press the Menu/Enter button. The error codes and unit No. can be confirmed in the RC Error History screen.		

5	BRC1E51	In the Remote Controller record screen the last 10 items are displayed in order.		<ol style="list-style-type: none"> <li>1. Latest record</li> <li>2. Unit no.</li> </ol>
	BRC1E52 BRC1E53	In the RC Error History screen the last 10 items are displayed in order.		
6	BRC1E51	Press the Cancel button in the Remote Controller record screen 3 times. The Basic screen returns.		 <p>Press the Cancel button for 3 times. The basic screen returns.</p>
	BRC1E52 BRC1E53	Press the Cancel button in the RC Error History screen 3 times. The Basic screen returns.		



**INFORMATION**

The indoor unit error history of each indoor unit can be independently consulted. The last 5 items are displayed in order of appearance.

**2.1.1.2. Error codes via wireless remote controller BRC7**


**2.1.1.2.1 How to retrieve error codes**

If the unit stops due to an error, the operation indicating LED on the indoor unit flashes.

The error code can be determined through the wireless remote controller by following the procedure described below.


If an error or warning is present, it will be displayed on the screen: for more information about troubleshooting, refer to ["Error code based troubleshooting" on page 27](#).

1	<p>Press the INSPECTION/TEST button to select "inspection". The equipment enters the inspection mode. The "Unit" indication is displayed and the Unit No. display shows flashing "0" indication.</p>
2	<p>Set the Unit No.</p> <p>Press the UP or DOWN button and change the Unit No. display until the buzzer (*1) is generated from the indoor unit.</p> <p>*1 Number of beeps</p> <p>3 short beeps: Conduct all of the following operations.</p> <p>1 short beep: Conduct steps 3 and 4.</p> <p>Continue the operation in step 4 until a buzzer remains ON. The continuous buzzer indicates that the error code is confirmed.</p> <p>Continuous beep: No abnormality.</p>
3	<p>Press the MODE selector button.</p> <p>The left "0" (upper digit) indication of the error code flashes.</p>
4	<p>Error code upper digit diagnosis</p> <p>Press the UP or DOWN button and change the error code upper digit until the error code matching buzzer (*2) is generated.</p> <ul style="list-style-type: none"> <li>The upper digit of the code changes as shown below when the UP and DOWN buttons are pressed.</li> </ul> <div data-bbox="287 828 925 929" style="text-align: center;"> <p>⇨ "UP" button      ⇩ "DOWN" button</p> </div> <p>*2 Number of beeps</p> <p>Continuous beep: Both upper and lower digits matched. (Error code confirmed)</p> <p>2 short beeps: Upper digit matched.</p> <p>1 short beep: Lower digit matched.</p>
5	<p>Press the MODE selector button.</p> <p>The right "0" (lower digit) indication of the error code flashes.</p>
6	<p>Error code lower digit diagnosis</p> <p>Press the UP or DOWN button and change the error code lower digit until the continuous error code matching buzzer (*2) is generated.</p> <ul style="list-style-type: none"> <li>The lower digit of the code changes as shown below when the UP and DOWN buttons are pressed.</li> </ul> <div data-bbox="287 1344 925 1444" style="text-align: center;"> <p>⇨ "UP" button      ⇩ "DOWN" button</p> </div>



Normal status

Enters inspection mode from normal status when the INSPECTION/ TEST button is pressed.




**2.1.1.2.2 How to reset error codes**

In "Error code based troubleshooting" on page 27 you find a description of how to reset the specific error or warning.

## 2.1.2. Error codes via outdoor unit

### 2.1.2.1. How to retrieve error codes

Troubleshooting by 7-Segment display on the main PCB "A1P"



Legend segment : OFF : ON : BLINKS : hold 5 seconds

7-segment display - Main PCB A1P					
Malfunction code		Malfunction			
Main	Sub	Contents		Location	
E	0	02	Input Err Open	RWEYQ-T9	
		2	01	Earth leakage activated	RWEYQ-T9
	06		Earth leakage input open		
	3	01	01	High pressure switch open	RWEYQ-T9
			02	High pressure abnormal	
		13	13	Stop valve closed	RWEYQ-T9
			18	High pressure abnormal	
	4	01	Low pressure abnormal	RWEYQ-T9	
9	01	01	Coil expansion valve subcool defect	RWEYQ-T9	
		47	Coil expansion valve main defect	RWEYQ-T9	
F	3	01	Discharge temperature abnormal high	RWEYQ-T9	
	6	02	Discharge temperature abnormal low		
H	9	01	Air sensor out of range	RWEYQ-T9	

7-segment display - Main PCB A1P					
Malfunction code			Malfunction		
Main	Sub		Contents	Location	
J	3	16	Discharge thermistor open circuit	RWEYQ-T9	
		17	Discharge thermistor short circuit		
	4	01	Gas thermistor heat-exchanger - out of range	RWEYQ-T9	
	5	01	Thermistor accumulator inlet - out of range	RWEYQ-T9	
		02	Thermistor compressor suction - out of range		
	6	01	Thermistor liquid heat-exchanger - out of range	RWEYQ-T9	
	7	06	Thermistor liquid stop-valve - out of range	RWEYQ-T9	
	9	01	Thermistor gas out sub-cool - out of range		
	A	06	High pressure sensor - open circuit		
		07	High pressure sensor - short circuit		
	C	06	Low pressure sensor - open circuit	RWEYQ-T9	
		07	Low pressure sensor - short circuit		
	L	C	14	Communication error control & inverter board	RWEYQ-T9
P	1	01	Power supply unbalance (> 4%)	RWEYQ-T9	
	J	01	Capacity setting mismatch inverter board	RWEYQ-T9	
U	1	01	Reverse phase detection	RWEYQ-T9	
		04	Reverse phase detection		
	2	01	Inverter charge DC voltage not possible		
		02	Phase missing inverter		
	3	03	Test run not performed		
	4	01	Communication error Outdoor-indoor		
		03	Communication error Outdoor-indoor		
		04	Test run abnormal ended		
	7	01	Warning faulty wiring (at Q1Q2 terminals)		
		02	Malfunction due to faulty wiring		
		11	Exceed number or capacity index indoor units		
	9	01	System error (check indoor malfunction code)		
	A	03	> 1x RDXYQ detected same F1F2-Indoor		RWEYQ-T9
		18	Combination to non-compatible indoor unit (only R410A type indoor)		
	H	01	Auto address indoor (F1F2) malfunction		RWEYQ-T9

For more information about troubleshooting, refer to ["Error code based troubleshooting"](#) on page 27.

### 2.1.2.2. How to reset error codes

- When a problem is solved:
  - System will restart automatically, except for error code JC, JA, L1~L9, U1,UA, UF.
  - Indoor unit operation should be switched off and on again for error JC, JA, L1~L9.
  - Power supply to switch off and delay 10 seconds on again for error U1, UA, UF.

### 2.1.2.3. History of error codes and warnings

As described in above procedure, the latest error or warning codes can be consulted in Monitor mode:

#### 2.1.2.3.1 Control board equipped with 7-segment display (RWEYQ-T9)

Mode 1 - code	Description
17	Last error - forced off
18	2nd last error - forced off
19	3rd last error - forced off

#### 2.1.2.3.2 Content of retry

Through the outdoor PCB, the content of retry can be determined.

Here, you can find the errors that were created before they were displayed on the indoor control device.

#### 2.1.2.3.3 Control board equipped with 7-segment display (RWEYQ-T9)

Mode 1 - code	Description
23	Last error - retry
24	2nd last error - retry
25	3rd last error - retry

The procedure to identify the retry code is similar to retrieving the error code.

## 2.2. Error code based troubleshooting

### Overview of error codes:

Error code BS and outdoor.....	28
Error code indoor units .....	35
Error code VRV IV-Water cooled unit .....	37
"E2" – Earth leakage detection.....	37
"E3" – Discharge pressure abnormality .....	37
"E4" – Suction pressure abnormality .....	38
"E5" – Compressor motor lock .....	39
"E9" – Electronic expansion valve abnormality .....	40
"F3" – Discharge pipe temperature abnormality.....	41
"F4" – Wet operation caution.....	42
"F6" – Refrigerant overcharge detection during test-run .....	42
"H3" – Discharge pressure switch abnormality.....	43
"H9" – Air temperature abnormality .....	44
"HJ" – Faulty watercircuit.....	44
"J3" – Discharge temperature abnormality .....	45
"J4" – Gas temperature PHE-H <sub>2</sub> O abnormality .....	45
"J5" – Suction accumulator inlet temperature abnormality .....	46
"J6" – Liquid Sub-cool heat-exchanger temperature .....	46
"J7" – Liquid temperature abnormality.....	47
"J9" – Purge receiver + gas out SCHEX temperature abnormality.....	47
"JA" – High pressure sensor abnormality .....	48
"JC" – Low pressure sensor abnormality.....	48
"L1" – Main board abnormality .....	49
"L2" – Power Supply quality abnormality .....	49
"L5" – Output overcurrent detection .....	50
"L8" – Inverter overcurrent.....	51
"L9" – Stall prevention .....	51
"LC" – Transmission system abnormality .....	52
"P1" – Ripple DC voltage diode module to power transistors.....	52
"P4" – Overheat power module .....	53
"PJ" – Capacity setting mixmatch inverter board.....	53
System .....	54
"U0" – Refrigerant shortage.....	54
"U1" – Reverse phase or open phase .....	55
"U2" – DC voltage DM <-> PM not permanent available.....	55
"U3" – Test run failed .....	56
"U4" – Transmission abnormality between outdoor and indoor unit .....	56
"U7" – Transmission between systems abnormality .....	57
"U9" – Systems abnormality .....	58
"UF" – Wiring and piping mismatch .....	59
"UH" – Auto-address failure .....	60
Others .....	60

## 2.2.1. Error code BS and outdoor

Main	Sub error code			Error codes related to BS..Q..AA			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
A3	01			Forced stop	Auto recovery	BS unit control board faulty	Check power to BS unit board, check LED "HAP" is blinking, change board
F9		01		Forced stop	Power reset BS unit	coil Y2E (EVH) BS unit open circuit	check winding expansion valve coil Y2E (gas HP) in BS unit connected to indoor showing error
		02		Forced stop	Power reset BS unit	coil Y3E (EVL) BS unit open circuit	check winding expansion valve coil Y3E (gas LP) in BS unit connected to indoor showing error
		05		Forced stop	Power reset BS unit	coil Y1E (EVSC) BS unit open circuit	check winding expansion valve coil Y1E (liquid sub-cool) in BS unit connected to indoor showing error

Main	Sub error code			Error codes related to RWEYQ-T9			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
E1		1		Forced stop	BRC...	Main board abnormality	Check power supply stable
		2		Forced stop	Power reset	Main board defect	Replace board
E2	01	02	03	Forced stop	BRC...	Earth leak detection	Repair part cause earth leakage
	06	07	08	Forced stop	BRC...	Open circuit detection	Re-connect device
E3	01	03	05	Forced stop	BRC...	HP switch opened	Check cause HP actuation
	13	14	15	Forced stop	BRC...	HP liquid check test-run	Open stop valve(s)
E4	01	02	03	Forced stop	BRC...	LP sens detects below 0,07MPa during operation	Check cause of abnormal low pressure during operation
E5	1	2	3	Forced stop	BRC...	inverter compressor lock	Check compressor nr. 1 motor winding
E6	11	13	16	Forced stop	BRC...	inverter board compressor abnormal	Replace inverter board compressor nr.1
	17	19	21	Forced stop	BRC...	inverter board compressor damaged	Replace inverter board compressor nr.1
E9	01	05	08	Forced stop	Power reset	Motor faulty expansion valve Y2E - Sub-cool liquid	check winding expansion valve coil Y2E. Replace coil or main board A1P
	03	06	09	Forced stop	Power reset	Motor faulty expansion valve Y1E - main liquid	check winding expansion valve coil Y1E. Replace coil or main board A1P
	04	07	10	Forced stop	Power reset	Motor faulty expansion valve Y3E - purge receiver	check winding expansion valve coil Y3E. Replace coil or main board A1P
F3	01	03	05	Forced stop	BRC...	high temperature discharge pipe thermistor R12T	Check discharge thermistors, operation expansion valves, refrigerant charge
	02	04	06	Forced stop	BRC...	Cross gas pipes at BS unit	Change field pipe connections
	20	21	22	Forced stop	BRC...	high temperature compressor body thermistor R13T	Check compressor body thermistor, operation expansion valves, refrigerant charge
F4		01		Forced stop	Power reset	Liquid back alarm	verify heat-exchange efficiency

Main	Sub error code			Error codes related to RWEYQ-T9			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
F6		02		Forced stop	Power reset	Refrigerant over-charge by high pressure sensor	Verify following sensor, replace if faulty:R12T,S1NPH. Verify refrigerant charge.
H3	2	4	6	Forced stop	BRC...	Connection malfunction main board-inverter	Check communication main board to inverter pcb compressor.
H9	01	02	03	Forced stop	Auto recovery	R1T= air thermistor: out of range	Check resistance R1T=air thermistor, sub board A1P, connector X11A pin1+2
HJ	01	02	03	Forced stop	Power reset	insufficient water flow through PHE-H <sub>2</sub> O. When PHE-H <sub>2</sub> O evaporator Tevapo below 0°C	Adjust water flow rate, or correct field wiring flow switch input, or adjust operation of valve(s) in water circuit.
	06	13	14	Forced stop	BRC...	fault detection operation of (optional) modulation water valve.	Correct wiring to (optional) modulating water valve.
	15	16	17	Forced stop	BRC...	R9T= thermistor H <sub>2</sub> O inlet (optional): out of range	Check resistance R9T=thermistor H <sub>2</sub> O inlet, main board A1P, terminal X2M nr.7+8
	18	19	20	Forced stop	BRC...	R10T= thermistor H <sub>2</sub> O outlet (optional): out of range	Check resistance R10T=thermistor H <sub>2</sub> O outlet, main board A1P, terminal X2M nr.9+10
J3	17	23	29	Forced stop	BRC...	R12T Discharge pipe thermistor: out of range	Check resistance R12T=discharge thermistor, main board A1P, connector X19A pin1+2
	48	50	52	Forced stop	BRC...	R13T compressor body thermistor: out of range	Check resistance R13T= compressor body thermistor, main board A1P, connector X19A pin3+4
J4	02			Forced stop	BRC...	R4T Thermistor gas PHE-H <sub>2</sub> O: out of range.	Check resistance R4T= thermistor gas PHE-H <sub>2</sub> O, main board A1P, connector X30A pin3+4
J5	01	03	05	Forced stop	BRC...	R3T= thermistor accumulator inlet: out of range	Check resistance R3T= thermistor accumulator inlet, main board A1P, connector X30A pin1+2
J6	01	02	03	Forced stop	BRC...	R7T thermistor liquid PHE-H <sub>2</sub> O: out of range	Check resistance R7T= thermistor liquid PHE-H <sub>2</sub> O,main board A1P, connector X30A pin9+10
J7	01	02	03	Forced stop	BRC...	R6T= thermistor liquid receiver↔SCHex: out of range	Check resistance R6T= thermistor liquid receiver↔SCHex, main board A1P, pcb connector X30A pin7+8
	06	07	08	Forced stop	BRC...	R8T= thermistor liquid SCHex↔stop valve: out of range	Check resistance R8T= thermistor liquid SCHex↔ Stop valve, main pcb A1P, connector X29A pin5+6
	18	19	20	Forced stop	BRC...	R11T= thermistor Y2E↔SCPHE: out of range	Check resistance R11T= thermistor Y2E↔SCPHE, main pcb A1P, connector X18A pin1+3

Main	Sub error code			Error codes related to RWEYQ-T9			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
J9	17			Forced stop	BRC...	R2T= thermistor gas outlet ZDP circuit: out of range	Check resistance R2T= thermistor gas outlet ZDP circuit, sub board A4P, connector X12A pin1+2
JA	01	02	03	Forced stop	BRC...	S1NPH = high pressure sensor: out of range	Check voltage S1NPH = high pressure sensor, main board A1P, connector X32A: check 5VDC pin 4+3, input pin 1+3
JC	01	02	03	Forced stop	BRC...	S1NPL = low pressure sensor: out of range	Check voltage S1NPL = low pressure sensor, main board A1P, connector X31A: check 5VDC pin 4+3, input pin 2+3
L1	1	7	11	Forced stop	BRC...	Inverter pcb A3P malfunction	Replace A3P inverter board
	2	8	12	Forced stop	BRC...	pcb A3P current detection primary circuit	Check possible causes overcurrent inverter circuit compressor
	3	9	13	Forced stop	BRC...	pcb A3P current detection secondary circuit	Check possible causes overcurrent inverter circuit compressor nr.1
	4	10	14	Forced stop	BRC...	pcb A3P transistor error	Power transistor check, replace A3P inverter pcb
	5	15	16	Forced stop	BRC...	pcb A3P hardware fault	Replace A3P inverter board
	36	38	40	Forced stop	BRC...	pcb A3P Eeprom fault	Replace A3P inverter board
	47	49	51	Forced stop	BRC...	pcb A3P 16VDC abnormal	Check voltage A3P inverter board, replace A3P
L2	01	02	03	Warning	Power reset outdoor	50Hz zero crossing error during test-run	Adjust power supply quality frequency 50 Hz $\pm$ 3%
	04	05	06	Warning	Power reset outdoor	50Hz zero crossing error during normal operation	Adjust power supply quality frequency 50 Hz $\pm$ 3%
L4	01	02	03	Forced stop	BRC...	A3P= inverter board, high fin temperature	Check air circulation + operation fan M1F+M2F, sub board A4P, connector X3A output 230VAC
L5	3	5	7	Forced stop	BRC...	A3P= inverter board, short circuit current	Check inverter circuit + compressor + HP-LP < 0,3 MPa prior to start compressor
L8	3	6	7	Forced stop	BRC...	pcb A3P overcurrent after start-up operation	Check inverter circuit + compressor
L9	1	5	6	Forced stop	BRC...	pcb A3P overcurrent during start-up operation	Check inverter circuit + compressor + HP-LP < 0,3 MPa prior to start compressor
LC	01			Forced stop	BRC...	Transmission error between A1P - A3P	Check connection A1P main board ↔ A3P inverter board ↔ A4P auxiliary board
P1	01	02	03	Warning	Auto recovery	Unbalance power supply > 4% inverter board A3P	Check power supply unbalance maximum 2% X1M main terminals ↔ A2P Noise filter ↔ A3P Inverter board
P4	01	04	05	Warning	Auto recovery	A3P fin thermistor faulty	Replace inverter board A3P

Main	Sub error code			Error codes related to RWEYQ-T9			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
PJ	4	5	6	Forced stop	power reset	Incorrect type of inverter board	Adjust horsepower setting main board, or change inverter board correct type
U0				Warning	Auto recovery	Refrigerant shortage detection - warning	Recover and recharge correct refrigerant charge, replace not correct operating expansion valve(s)
		5		Warning	Auto recovery	Refrigerant shortage detection - abnormality	Recover and recharge correct refrigerant charge, replace not correct operating expansion valve(s)
		6		Warning	Auto recovery	Refrigerant shortage detection - heating	Recover and recharge correct refrigerant charge, replace not correct operating expansion valve(s)
U1	1	5	7	Forced stop	Power Reset outdoor	Reverse phase detection L1-L3	Check presence of phase L3 at pcb A1P, correct phase sequence at terminal X1M
	4	6	8	Forced stop	Power Reset outdoor	Reverse phase detection L1-L3 power-on	Check presence of phase L3 at pcb A1P, correct phase sequence at terminal X1M
U2	01	08	11	Forced stop	Auto recovery	pcb A3P low voltage	Check voltage to A3P, closed contact A7P terminals L31+L32
	02	09	12	Forced stop	Auto recovery	pcb A3P phase missing	Check phases to A3P, change A3P
	03	10	13	Forced stop	Auto recovery	Capacitor(s)- DC circuit inverter not charging	Check phases to A3P, change A3P
U3	02			Forced stop	Restart test-run	Test-run interrupted manually	Restart test-run outdoor
	03			Forced stop	Restart test-run	Test-run not performed yet	Start test-run outdoor
	04			Forced stop	Restart test-run	test-run end abnormal	Check indoor unit error code
	05			Forced stop	Restart test-run	test-run abort initial transmission	check communication-restart test-run outdoor
	06			Forced stop	Restart test-run	test-run abort normal transmission	check communication-restart test-run outdoor
	07			Forced stop	Restart test-run	test-run abort transmission abnormal	check communication-restart test-run outdoor
	08			Forced stop	Restart test-run	test-run abort transmission all units	check communication-restart test-run outdoor
U4	01			Forced stop	Auto recovery	communication error F1F2 between outdoor & indoor	Check communication between outdoor units, power supply outdoor
	03			Forced stop	Auto recovery	communication error because of faulty part at Indoor unit	check indoor units indicating error related to indoor unit (error start with A or C).

Main	Sub error code			Error codes related to RWEYQ-T9			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
U7		01		Forced stop	Auto recovery	Error DTA104A61,62	(refer to option handbook)
		02		Forced stop	Auto recovery	error initialisation DTA104A61,62	Check dip switch settings DTA104A61,62 (refer to option handbook)
	03	04	05	Forced stop	Auto recovery	communication error outdoor unit	Check communication between main outdoor unit and sub outdoor units.
		06		Forced stop	Auto recovery	Multi address abnormality	Check address each outdoor unit in same multi-outdoor system
		07		Forced stop	Auto recovery	More than 3 units in multi combination (Q1Q2)	Change installation to maximum 3 outdoor units same system
		11		Forced stop	Auto recovery	Test run detects > 64 indoor units same outdoor or index >200%	change installation to maximum 64 indoor units and limit connection ratio outdoor / indoor max.200%
		24		Caution	Power reset DTA104	Duplication address setting multiple optional boards DTA104A61,62.	Change to unique address on each optional board DTA104A61,62 in same F1F2 OUT/D bus.
U9		01		Forced stop	Auto recovery	Minimum 1 indoor unit detects system error (UA,U4,UH,A0)	Follow troubleshooting error code shown on indoor controllers other than U9

Main	Sub error code			Error codes related to RWEYQ-T9			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
UA		0		Forced stop		CT address outdoor duplication	Change installation with only R410A type indoor units
		03		Forced stop		Mix of R22,R407C and R410A indoor units detected.	Change installation with only R410A type indoor units
		16		Forced stop	Auto recovery	More than 64 indoor units detected same system	change installation to have maximum 64 indoor units to same system
		17		Forced stop	Auto recovery	Local setting abnormality	Verify and return field settings outdoor to factory value.
		18		Forced stop		Outdoor unit not compatible to indoor units (refrigerant type)	Change installation with only R410A type indoor units connect to this outdoor unit(s)
		19		Forced stop	Auto recovery	Local set alarm	Verify and return field settings outdoor to factory value.
		20		Forced stop	Auto recovery	Outdoor unit not compatible in multi-combination	Change outdoor unit(s) to have correct combination.
		21		Alarm	Auto recovery	BPMK units detected	change installation without BPMK units.
		22		Alarm	Auto recovery	Single installation abnormality	Change installation only published combination is used.
		23		Alarm	Auto recovery	BS unit too high index indoor connected	Change installation BS unit within published index.
		25		Alarm	Auto recovery	BS main bus zone alarm	Change field wiring between outdoor and BS units to have correct communication.
		26		Alarm	Auto recovery	BS branch bus zone alarm	Change field wiring between BS units to have correct communication.
		28		Alarm	Auto recovery	Other than BS-Q-A detected	Only use BS-Q-A to VRV4 heat-recovery system
		29		Alarm	Auto recovery	BS unit too low index indoor connected	Change installation BS unit within published index.
		38		Forced stop	Auto recovery	Altherma Hydro unit detected	Only hydro units LT model HXY-A7 and HT model HXHD125 contactable
		39		Forced stop	Auto recovery	incorrect combination units	Change installation only published combination is used.
		43		Forced stop	Auto recovery	incorrect combination	Change installation only published combination is used.
		50		Forced stop	Auto recovery	HT hydro unit connected to BS unit	change installation HT hydro unit without BS unit
		51		Forced stop	Auto recovery	Only Hydro units detected.	System must detected minimum 50% indoor units connected to BS unit(s)
	53		Forced stop	Power reset	pcb BS unit wrong dip switch setting	Check dip switches BS unit	
UH	01			Forced stop	Auto recovery	Auto address F1f2 bus inconsistency	Wait till initialisation outdoor is end, Perform cross wiring check.

Main	Sub error code			Error codes related to RWEYQ-T9			
Error	Main	Sub1	Sub2	Status outdoor	Reset	Cause	Solution
UF		01		Forced stop	Auto recovery	Test run outdoor - Auto address F1f2 bus inconsistency	Wait till initialisation outdoor is end, Perform cross wiring check.
		05		Forced stop	perform test-run	Test run detect stop valves closed or incorrect.	Open stop valves, verify field piping among outdoor unit(s) and BS unit(s)
		11		Forced stop	perform test-run	connection ratio exceed allowed upper%	Remove number of indoor units to be within allowed connection ratio

## 2.2.2. Error code indoor units



## INFORMATION

The Error code indoor unit table listed below is only for your information, as some error codes are directly related to the indoor unit and not to the outdoor unit.

For details refer to the "ESIE15-11 Service Manual VRV4 indoor units".

Main	Sub error code	Error codes related to FX..Q-M/N/P/A			
Error	Main	Status outdoor	Reset	Cause	Solution
A3		Cool thermo off	Auto recovery	Float switch open during thermo on (cooling)	Check float switch status, drain pipe no blockage, drain pipe raiser < 600 mm.
A6	01	Thermo off	BRC1..	Fan motor locked	Rpm counter no signal from motor to indoor main board when output.
	10	Thermo off	BRC1..	Fan motor overcurrent	Check motor power circuit. Replace fan motor / indoor board.
	11	Thermo off	BRC1..	Fan motor locked	Rpm counter no signal at off condition.
AH	03	Warning	BRC1..	Communication error main PCB / self cleaning PCB	Check wire harness connections.
	04	Warning	BRC1..	Dust detection sensor error	Check wire harness connections.
	05	Warning	BRC1..	Dust collection error	Check for clogging by dust between brush-arm and dust collector box.
	06	Warning	BRC1..	Air filter rotation error	Check rotation mechanism air filter.
	07	Warning	BRC1..	Damper rotation error	Check rotation mechanism damper.
	08	Warning	BRC1..	Filter cleaning time error	Filter auto cleaning program could not be performed 24 hr operation.
	09	Warning	BRC1..	Auto self cleaning disabled	Check field settings to enable auto filter cleaning.
AF		Thermo off	BRC1..	Float switch open during thermo off	Check for drain water returning from other indoor, expansion valve correct closing thermo off.
AJ	01	Thermo off	Auto recovery	Capacity adaptor missing	Add corresponding capacity adaptor onto spare part PCB
	02	Thermo off	Power reset	Incorrect expansion valve motor	Use correct expansion valve motor (between gear type and direct drive).
C1	01	Thermo off	Auto recovery	Communication error main PCB / inverter PCB fan motor	Check for communication between main PCB and inverter PCB fan motor.
	02	Thermo off	Auto recovery	Communication error main PCB / auxiliary PCB	Check for communication between main PCB and inverter PCB fan motor.
C4	02	Thermo off	Auto recovery	Coil thermistor short circuit	Check coil thermistor resistance.
	03	Thermo off	Auto recovery	Coil thermistor open circuit	Check wire harness connections coil thermistor.
C5	02	Thermo off	Auto recovery	Gas thermistor short circuit	Check gas thermistor resistance.
	03	Thermo off	Auto recovery	Gas thermistor open circuit	Check wire harness connections gas thermistor.
C6	01	Thermo off	Auto recovery	Faulty combination main PCB - inverter PCB fan motor	Change inverter PCB fan motor correct type.

Main	Sub error code	Error codes related to FX..Q-M/N/P/A			
Error	Main	Status outdoor	Reset	Cause	Solution
C9	02	Thermo off	Auto recovery	Air thermistor short circuit	Check air thermistor resistance.
	03	Thermo off	Auto recovery	Air thermistor open circuit	Check wire harness connections air thermistor.
CJ	02	Thermo off	Auto recovery	Air thermistor BRC... short circuit	Check air thermistor BRC... resistance.
	03	Thermo off	Auto recovery	Gas thermistor open circuit	Check wire soldering air thermistor BRC... .
CE	01	Thermo off	Auto recovery	No signal from optional presence sensor	Check wire harness connections
	02	Thermo off	Auto recovery	No signal from optional floor temperature sensor	Check wire harness connections
	03	Thermo off	Auto recovery	Faulty signal from optional floor temperature sensor	Check pins connector no short circuit
	04	Thermo off	Auto recovery	High temperature detection or electric noise floor temperature sensor	Check resistance floor temperature sensor
U4	01	Thermo off	Auto recovery	Communication error indoor - BS unit	Check communication between BS unit and indoor unit(s)
U9		Thermo off	Auto recovery	Communication error other indoor unit - BS unit	Check other indoor units with error other than U9
UA	13	Thermo off	Power reset	Indoor unit refrigerant type not compatible to outdoor unit	Change system lay out - remove this indoor unit from system
	15	Thermo off	Power reset	Outdoor unit is not compatible to self cleaning panel (up to VRV7)	Mount standard decoration panel

## 2.2.3. Error code VRV IV-Water cooled unit

### 2.2.3.1. "E2" – Earth leakage detection

Trigger	Effect	Reset
Main board "A1P" detects earth leakage detection power supply unit higher than (see "Safety devices" on page 164).	Unit will stop operating.	Power Reset
Connector unplugged from X101A on main board "A1P".		Reconnect plug to X101A.

Possible cause	Check	Corrective action
Earth leakage of electric component in unit.	Check by megger: <ul style="list-style-type: none"> <li>the different coils (of solenoid valves &amp; 4 way-valves), fan motors (for cooling inverter).</li> <li>compressor motor.</li> </ul>	Replace the faulty part; depending on check, related coil fan motor for cooling inverter, compressor.
Connector or wire broken of the current core.	Resistance current core 45~50 ohm.	Replace current core when open circuit.
Faulty main PCB "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals on main board.</li> <li>Check if the correct spare part is installed.</li> <li>Check if main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals. (see "Replacing main PCB A1P" on page 141).</li> </ul>
Refrigerant overcharge.	Check for refrigerant overcharge. Refer to the name plate for the correct charge.	Charge the correct refrigerant amount when required.
Humidity in refrigerant. (ice formation in expansion valve)	Check for humidity in the refrigerant.	In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant.

### 2.2.3.2. "E3" – Discharge pressure abnormality

Trigger	Effect	Reset
High pressure switch opens due to measured pressure higher than (see "Safety devices" on page 164).	Unit will stop operating.	Automatic reset when high pressure drops below (see "Safety devices" on page 164) and user interface operation ==> off ==> on.
High pressure control (measured pressure higher than (see "Safety devices" on page 164) occurs (see "Safety devices" on page 164) times within (see "Safety devices" on page 164) minutes).		

Possible cause	Check	Corrective action
Insufficient water flow through H <sub>2</sub> O plate heat-exchanger.	Check by flow meter and manometer on water inlet and outlet. Compare to published graph (see "Performance Characteristics" on page 166).	Adjust the water flow by the (local installed) water pump.
Water inlet temperature above upper limit.	Water inlet temperature should be below 45°C.	Adjust the control of the (local installed) water circuit to drop water inlet temperature between 10 & 45°C.

Possible cause	Check	Corrective action
Blocked H <sub>2</sub> O plate heat exchanger (condenser).	<ul style="list-style-type: none"> <li>Are the heat exchangers clean?</li> <li>Check by flow meter and manometer on water inlet and outlet.</li> <li>Compare to published graph (see <a href="#">"Performance Characteristics" on page 166</a>).</li> </ul>	Clean heat exchangers.
Faulty high pressure sensor.	Check high pressure sensor (see <a href="#">"High pressure sensor S1NPH" on page 74</a> ).	Replace high pressure sensor when required (see <a href="#">"Replacing high pressure sensor" on page 123</a> )
Faulty high pressure switch.	Check high pressure switch.	Replace high pressure switch.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals. (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Refrigerant overcharge.	Check for refrigerant overcharge. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
Humidity in refrigerant. (ice formation in expansion valve)	Check for humidity in the refrigerant.	In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant.
None condensable gas (e.g air or nitrogen) in refrigerant.	Check for none condensable gas in refrigerant	In case of suspicion of none condensable gas, recover, vacuum and recharge with virgin refrigerant.
Refrigerant is contaminated.	Check for none condensable gas in refrigerant.	In case of suspicion of none condensable gas, recover, vacuum and recharge refrigerant.
Stop valve is closed.	Check if stop valve is open.	Open stop valve when required.

### 2.2.3.3. "E4" – Suction pressure abnormality

Trigger	Effect	Reset
When refrigerant pressure is below (see <a href="#">"Safety devices" on page 164</a> ) for 5 minutes (see <a href="#">"Safety devices" on page 164</a> ).	Unit will stop operating.	Automatic reset when low pressure drops raises above (see <a href="#">"Safety devices" on page 164</a> ) & operation indoor on ==> off ==> on.

Possible cause	Check	Corrective action
Blocked H <sub>2</sub> O plate heat exchanger (evaporator).	Are the heat exchangers clean?	Clean heat exchangers.
Insufficient water flow through H <sub>2</sub> O plate heat-exchanger.	Check by flow meter and manometer on water inlet and outlet. Compare to published graph (see <a href="#">"Performance Characteristics" on page 166</a> ).	Adjust the water flow by the (local installed) water pump.
Water inlet temperature below lower limit.	Water inlet temperature should be continuous. <ul style="list-style-type: none"> <li>Pure water: above 15°C.</li> <li>Brine solution: above -5°C.</li> </ul>	Adjust the control of the (local installed) water circuit to raise water inlet temperature above: <ul style="list-style-type: none"> <li>Pure water: above 15°C.</li> <li>Brine solution: above -5°C.</li> </ul>
Blocked H <sub>2</sub> O plate heat exchanger (condenser).	<ul style="list-style-type: none"> <li>Is the H<sub>2</sub>O plate heat exchanger clean?</li> <li>Check by flow meter and manometer on water inlet and outlet.</li> <li>Compare to published graph (see <a href="#">"Performance Characteristics" on page 166</a>).</li> </ul>	Clean H <sub>2</sub> O plate heat exchangers.
Refrigerant shortage.	Check for refrigerant shortage. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.

Possible cause	Check	Corrective action
Expansion valve evaporator not opening. Evaporator = <ul style="list-style-type: none"> <li>Indoor cooling mode</li> <li>H<sub>2</sub>O PHE heating mode.</li> </ul>	Check operation expansion valves.	Replace faulty part expansion valve (coil or body).
Abnormal drop of low pressure, caused by inadequate refrigerant, abnormal refrigerant piping system or faulty electronic expansion valve.	<ul style="list-style-type: none"> <li>Check for possible blockage. Blockages can be checked by measuring the refrigerant/pipe temperature.</li> <li>Sudden drop in temperature could indicate a blockage (remark: this is not valid for the expansion valve).</li> </ul>	Replace the blocked part.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Bad contact through pressure sensor cable.	Check if pressure sensor connector is properly connected to the outdoor PCB board.	Connect or replace sensor cable when required.
Faulty low pressure sensor.	Check low pressure sensor (see <a href="#">"Low pressure sensor S1NPL" on page 76</a> ).	Replace low pressure sensor when required (see <a href="#">"Replacing low pressure sensor" on page 128</a> ).

#### 2.2.3.4. "E5" – Compressor motor lock

Trigger	Effect	Reset
Compressor overload is detected (see <a href="#">"Safety devices" on page 164</a> ).	Unit will stop operating.	Manual reset via user interface.

Possible cause	Check	Corrective action
Faulty discharge pipe thermistor (crank-case heater never energized).	Check discharge pipe thermistor (see <a href="#">"Thermistors" on page 83</a> ).	Replace discharge pipe thermistor when required.
Faulty overload protection inverter board "A3P".	<ul style="list-style-type: none"> <li>Check resistor inverter board "A3P" not open circuit.</li> <li>Perform "power transistor check" (see <a href="#">"How to activate inverter test" on page 163</a>) to confirm 6 transistors output is present (use inverter analyser instead of U/V/W compressor).</li> </ul>	Replace inverter board "A3P" (see <a href="#">"Replacing inverter board A3P" on page 139</a> ).
Faulty expansion valve.	Check the expansion valve (see <a href="#">"Electronic expansion valve" on page 89</a> ).	Replace the expansion valve body (see <a href="#">"Replacing expansion valve body" on page 121</a> ) or motor (see <a href="#">"Replacing expansion valve coil" on page 122</a> ) when required.
Faulty 4-way valve coil.	Check the 4-way valve coil (see <a href="#">"4-way valve" on page 67</a> ).	Replace the 4-way valve coil (see <a href="#">"Replacing 4-way valve coil" on page 113</a> ).
Refrigerant circuit is clogged.	Check for possible blockage (oil return circuit from oil separator to suction pipe).	Replace blocked part when required.
Faulty 4-way valve body, blocked.	Check the 4-way valve body (see <a href="#">"4-way valve" on page 67</a> ).	Replace the 4-way valve body when required (see <a href="#">"Replacing 4-way valve body" on page 111</a> ).
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

Possible cause	Check	Corrective action
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P" (see <a href="#">"Inverter board A3P" on page 78</a>).</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Restore the power to main board "A1P" to reset "standby" mode of inverter board "A3P".</li> <li>Replace the inverter board "A3P" if reset power "A1P" fails (see <a href="#">"Replacing inverter board A3P" on page 139</a>).</li> </ul>
Refrigerant overcharge.	Check for refrigerant overcharge. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
Refrigerant shortage.	Check for refrigerant shortage. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
Humidity in refrigerant (ice formation in expansion valve).	Check for humidity in the refrigerant.	In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant.
Non condensable gas.(e.g. air, nitrogen) in refrigerant circuit.	Check for non condensable gas in refrigerant.	In case of suspicion of non condensable gas, recover, vacuum and recharge with virgin refrigerant.
Stop valve is closed.	Check if stop valve is open.	Open stop valve when required.

### 2.2.3.5. "E9" – Electronic expansion valve abnormality

Trigger	Effect	Reset
No continuity of expansion valve coil	Unit will stop operating.	Power reset unit.

Possible cause	Check	Corrective action
Faulty expansion valve. Refer to sub-code for location.	Check the expansion valve (see <a href="#">"Electronic expansion valve" on page 89</a> ).	Replace the expansion valve body (see <a href="#">"Replacing expansion valve body" on page 121</a> ) or motor (see <a href="#">"Replacing expansion valve coil" on page 122</a> ) when required.
Wet operation.	<ul style="list-style-type: none"> <li>Check for wet operation. Wet operation can be detected by checking the suction superheat.</li> <li>If the suction superheat is 0°C then liquid refrigerant is returned to the compressor.)</li> </ul>	In case wet operation was detected, confirm the cause: <ul style="list-style-type: none"> <li>Refrigerant overcharge.</li> <li>Faulty expansion valve.</li> </ul>
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty thermistor.	Check thermistors Stop unit for 15 minutes. Use monitoring device to check all thermistors show same value 2°C (except R12T discharge thermistor & R13T body thermistor)	Replace thermistor when required (see <a href="#">"Replacing thermistor" on page 110</a> ).
Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power reset RWEYQ-T.
Faulty low pressure sensor.	Check pressure sensor (see <a href="#">"Low pressure sensor S1NPL" on page 76</a> ).	Replace pressure sensor when required (see <a href="#">"Replacing low pressure sensor" on page 128</a> ).
External factory (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while).	Check for source which could cause electrical interference.	Avoid electrical interference.

## 2.2.3.6. "F3" – Discharge pipe temperature abnormality

Trigger	Effect	Reset
Discharge or body temperature is too high: <ul style="list-style-type: none"> <li>If the discharge temperature detected is above A°C, D times within E min.</li> <li>If within E min the discharge temperature or body temperature detected E times above B°C for F min.</li> </ul> Refer to "Product specific information" on page 163 for values of A, B, D, E, F.	Unit will not stop operating.	Automatic reset when temperature drops below C°C. Refer to "Product specific information" on page 163 for values of C.
	Unit will stop operating.	Manual reset via remote controller.

Possible cause	Check	Corrective action
Refrigerant shortage.	Check for refrigerant shortage. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
Humidity in refrigerant (ice formation in expansion valve).	Check for humidity in the refrigerant.	In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant.
Non condensable gas (e.g. air, nitrogen) in refrigerant.	Check for non condensable gas in refrigerant.	In case of suspicion of non condensable gas, recover, vacuum and recharge with virgin refrigerant.
Stop valve is closed.	Check if stop valve is open.	Open stop valve when required.
Faulty 4-way valve coil.	Check the 4-way valve coil (see "4-way valve" on page 67).	Replace the 4-way valve coil (see "Replacing 4-way valve coil" on page 113).
Faulty expansion valve body.	Check the expansion valve (see "Electronic expansion valve" on page 89).	Replace the expansion valve body (see "Replacing expansion valve body" on page 121) or motor (see "Replacing expansion valve coil" on page 122) when required.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see "Replacing main PCB A1P" on page 141).</li> </ul>
Faulty discharge pipe thermistor.	Check discharge pipe thermistor (see "Thermistors" on page 83).	Replace discharge pipe thermistor when required.
Faulty high pressure sensor.	Check high pressure sensor ("High pressure sensor S1NPH" on page 74).	Replace high pressure sensor when required (see "Replacing high pressure sensor" on page 123).
Faulty air thermistor "R1T". (used for correction of discharge temperature).	Check air thermistor "R1T" (see "Thermistors" on page 83).	Replace air thermistor "R1T" when required.
Faulty compressor (internal bypass).	Check if low compression ratio and low current to compressor at high frequency step.	Replace compressor.

## 2.2.3.7. "F4" – Wet operation caution

Trigger	Effect	Reset
Discharge superheat is < 10°.	System keeps running.	Discharge superheat > 15°C.

Possible cause	Check	Corrective action
Refrigerant Overcharge.	Check for refrigerant overcharge. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
None condensable gas in refrigerant resulting in high discharge pressure & low discharge temperature.	Check for none condensable gas in refrigerant.	In case of suspicion of none condensable gas, recover, vacuum and recharge with virgin refrigerant.
Faulty expansion valve body.	Check the expansion valve (see <a href="#">"Electronic expansion valve" on page 89</a> ).	Replace the expansion valve body (see <a href="#">"Replacing expansion valve body" on page 121</a> ) or motor (see <a href="#">"Replacing expansion valve coil" on page 122</a> ) when required.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty discharge pipe thermistor.	Check discharge pipe thermistor (see <a href="#">"Thermistors" on page 83</a> ).	Replace discharge pipe thermistor when required.
Faulty high pressure sensor.	Check high pressure sensor ( <a href="#">"High pressure sensor S1NPH" on page 74</a> ).	Replace high pressure sensor when required (see <a href="#">"Replacing high pressure sensor" on page 123</a> ).
Faulty air thermistor "R1T". (used for correction of discharge temperature)	Check air thermistor "R1T" (see <a href="#">"Thermistors" on page 83</a> )	Replace air thermistor "R1T" when required.
Indoor room temperature too low.	Check indoor room temperature does not drop below 20°C.	Warm up the rooms above 20°C.

## 2.2.3.8. "F6" – Refrigerant overcharge detection during test-run

Trigger	Effect	Reset
Discharge superheat is < 10° when solenoid valve hot-gas "Y5" is closed.	Test-run is interrupted.	1 x BS3 "Return".

Possible cause	Check	Corrective action
Refrigerant Overcharge.	Check for refrigerant overcharge. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
None condensable gas in refrigerant resulting in high discharge pressure & low discharge temperature.	Check for none condensable gas in refrigerant.	In case of suspicion of none condensable gas, recover, vacuum and recharge with virgin refrigerant.
Faulty expansion valve body.	Check the expansion valve (see <a href="#">"Electronic expansion valve" on page 89</a> ).	Replace the expansion valve body (see <a href="#">"Replacing expansion valve body" on page 121</a> ) or motor (see <a href="#">"Replacing expansion valve coil" on page 122</a> ) when required.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty discharge pipe thermistor.	Check discharge pipe thermistor (see <a href="#">"Thermistors" on page 83</a> ).	Replace discharge pipe thermistor when required.

Possible cause	Check	Corrective action
Faulty high pressure sensor.	Check high pressure sensor ("High pressure sensor S1NPH" on page 74).	Replace high pressure sensor when required (see "Replacing high pressure sensor" on page 123).
Faulty air thermistor "R1T". (used for correction of discharge temperature)	Check air thermistor "R1T" (see "Thermistors" on page 83).	Replace air thermistor "R1T" when required.
Indoor room temperature too low.	Check indoor room temperature does not drop below 20°C.	Warm up the rooms above 20°C.

### 2.2.3.9. "H3" – Discharge pressure switch abnormality

Trigger	Effect	Reset
High pressure switch opens due to measured pressure higher than (see "Safety devices" on page 164).	Unit will stop operating.	Automatic reset when high pressure drops below (see "Safety devices" on page 164) and user interface operation ==> off ==> on.
High pressure control (measured pressure higher than (see "Safety devices" on page 164) occurs (see "Safety devices" on page 164) times within (see "Safety devices" on page 164) minutes.		

Possible cause	Check	Corrective action
Insufficient water flow through H <sub>2</sub> O plate heat-exchanger.	Check by flow meter and manometer on water inlet and outlet. Compare to published graph (see "Performance Characteristics" on page 166).	Adjust the water flow by the (local installed) water pump.
Water inlet temperature above upper limit.	Water inlet temperature should be below 45°C.	Adjust the control of the (local installed) water circuit to drop water inlet temperature between 10 & 45°C.
Blocked H <sub>2</sub> O plate heat exchanger (condenser).	<ul style="list-style-type: none"> <li>Are the heat exchangers clean?</li> <li>Check by flow meter and manometer on water inlet and outlet.</li> <li>Compare to published graph (see "Performance Characteristics" on page 166).</li> </ul>	Clean heat exchangers.
Faulty high pressure sensor.	Check high pressure sensor (see "High pressure sensor S1NPH" on page 74).	Replace high pressure sensor when required (see "Replacing high pressure sensor" on page 123).
Faulty high pressure switch.	Check high pressure switch.	Replace high pressure switch.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals. (see "Replacing main PCB A1P" on page 141).</li> </ul>
Refrigerant overcharge.	Check for refrigerant overcharge. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
Humidity in refrigerant. (ice formation in expansion valve)	Check for humidity in the refrigerant.	In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant.
None condensable gas (e.g. air or nitrogen) in refrigerant.	Check for none condensable gas in refrigerant	In case of suspicion of none condensable gas, recover, vacuum and recharge with virgin refrigerant.
Refrigerant is contaminated.	Check for none condensable gas in refrigerant.	In case of suspicion of none condensable gas, recover, vacuum and recharge refrigerant.
Stop valve is closed.	Check if stop valve is open.	Open stop valve when required.

## 2.2.3.10. "H9" – Air temperature abnormality

Trigger	Effect	Reset
Thermistor air "R1T" out of range (<-47°C or > 108°C).	Forced stop.	<ul style="list-style-type: none"> <li>Thermistor air "R1T" in of range (&gt; -47°C &amp; &lt; 108°C) +</li> <li>User interface on ==&gt; off ==&gt; on.</li> </ul>

Possible cause	Check	Corrective action
Thermistor air "R1T" wire broken or short circuit.	Check wires on connector X11A pin 1+2 auxiliary board A4P.	Replace thermistor air "R1T".
Faulty thermistor air "R1T".	Check thermistor air "R1T" (see " <a href="#">Thermistors</a> " on page 83).	Replace thermistor air "R1T" when required.
Faulty SUB PCB "A4P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if main board "A4P" receives power 16VDC on connector X10A.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the SUB PCB "A4P".</li> <li>Replace SUB PCB "A4P" when HAP LED is not blinking in regular intervals (see "<a href="#">Replacing SUB PCB A4P</a>" on page 146).</li> </ul>
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if output on connector X37A on the main board "A1P" is 16VDC.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see "<a href="#">Replacing main PCB A1P</a>" on page 141).</li> </ul>

## 2.2.3.11. "HJ – Faulty watercircuit

Trigger	Effect	Reset
<ul style="list-style-type: none"> <li>Evaporation &lt; 0°C when H<sub>2</sub>O plate heat-exchanger is used as evaporator.</li> <li>Fault detection (optional) modulating water valve.</li> <li>Fault (optional) water thermistor.</li> </ul>	Unit will stop operating	<ul style="list-style-type: none"> <li>Reset power supply.</li> <li>User interface on ==&gt; off ==&gt; on. Remove cause.</li> <li>Replace faulty thermistor.</li> </ul>

Possible cause	Check	Corrective action
Blocked H <sub>2</sub> O plate heat exchanger (evaporator).	Are the heat exchangers clean?	Clean heat exchangers.
Insufficient water flow through H <sub>2</sub> O plate heat-exchanger.	Check by flow meter and manometer on water inlet and outlet. Compare to published graph (see " <a href="#">Performance Characteristics</a> " on page 166).	Adjust the water flow by the (local installed) water pump.
Water inlet temperature below lower limit.	Water inlet temperature should be continuous: <ul style="list-style-type: none"> <li>Pure water: above 15°C.</li> <li>Brine solution: above -5°C.</li> </ul>	Adjust the control of the (local installed) water circuit to raise water inlet temperature above: <ul style="list-style-type: none"> <li>Pure water: above 15°C.</li> <li>Brine solution: above -5°C.</li> </ul>
Blocked H <sub>2</sub> O plate heat exchanger (condenser).	Is the H <sub>2</sub> O plate heat exchanger clean? Check by flow meter and manometer on water inlet and outlet. Compare to published graph (see " <a href="#">Performance Characteristics</a> " on page 166).	Clean H <sub>2</sub> O plate heat exchanger.
Expansion valve evaporator not opening. Evaporator = H <sub>2</sub> O Plate heat-exchanger in heating mode.	Check operation expansion valves.	Replace faulty part expansion valve (coil or body).
Incorrect field wiring to (optional) modulating H <sub>2</sub> O valve.	At power-on of A1P: valve switching sequence close ==> open ==> close.	Correct field wiring to (optional) modulating H <sub>2</sub> O valve.

Possible cause	Check	Corrective action
Faulty (optional) modulating H <sub>2</sub> O valve.	At power-on of A1P: valve switching sequence close ==> open ==> close.	Replace (optional) modulating H <sub>2</sub> O valve.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Thermistor water inlet (R9T) or outlet (R10T) not correct mounted to water pipe.	Check firm contact thermistor to water piping (local installation).	Fix thermistor firmly to water pipe.
Faulty H <sub>2</sub> O flow sensor. (part of optional modulating H <sub>2</sub> O valve)	Check H <sub>2</sub> O flow sensor.	Replace H <sub>2</sub> O flow sensor.

### 2.2.3.12. "J3" – Discharge temperature abnormality

Trigger	Effect	Reset
<ul style="list-style-type: none"> <li>Warning: Thermistor discharge pipe "R12T"-thermistor body compressor "R13T" &lt; 20°C,</li> <li>Discharge pipe abnormal detection: <ul style="list-style-type: none"> <li>&gt;165°C when compressor = 0Hz,</li> <li>-20°C when compressor &gt; 0Hz.</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>Warning on user interface, units keeps running.</li> <li>Forced stop.</li> </ul>	<ul style="list-style-type: none"> <li>Thermistor discharge pipe "R12T"-thermistor body "R13T" 15°C.</li> <li>User interface on ==&gt; off ==&gt; on.</li> </ul>

Possible cause	Check	Corrective action
Thermistor "R12T" or "R13T" not fixed to compressor.	<ul style="list-style-type: none"> <li>Check thermistor discharge pipe "R12T" inserted into sensor holder + insulation.</li> <li>Check thermistor body compressor "R13T" inserted into clip body of compressor.</li> </ul>	<ul style="list-style-type: none"> <li>Insert thermistor discharge pipe "R12T" into holder of discharge pipe. Mount insulation.</li> <li>Insert thermistor body compressor "R13T" into clip of body of compressor.</li> </ul>
Faulty thermistor discharge pipe "R12T".	Check thermistor discharge pipe (see <a href="#">"Thermistors" on page 83</a> ).	Replace thermistor discharge pipe "R12T" when required.
Faulty thermistor body compressor "R13T".	Check thermistor body compressor (see <a href="#">"Thermistors" on page 83</a> ).	Replace thermistor body compressor "R13T" when required.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty compressor	Check compression > 3 and current > 5 Amp.	Replace compressor.

### 2.2.3.13. "J4" – Gas temperature PHE-H<sub>2</sub>O abnormality

Trigger	Effect	Reset
Thermistor gas temperature PHE-H <sub>2</sub> O "R4T" out of range (<-47°C or >108°C)	Forced stop.	<ul style="list-style-type: none"> <li>Thermistor Gas PHE-H<sub>2</sub>O "R4T" in range (&gt; -47°C &amp; &lt; 108°C).</li> <li>User interface on ==&gt; off ==&gt; on.</li> </ul>

Possible cause	Check	Corrective action
Thermistor gas temperature PHE-H <sub>2</sub> O "R4T" wire broken or short circuit.	Check wires on connector X30A pin 3+4.	Replace thermistor gas temperature PHE-H <sub>2</sub> O "R4T".

Possible cause	Check	Corrective action
Faulty thermistor gas temperature PHE-H <sub>2</sub> O "R4T"	Check thermistor gas temperature PHE-H <sub>2</sub> O "R4T" (see <a href="#">"Thermistors" on page 83</a> ).	Replace thermistor gas temperature PHE-H <sub>2</sub> O "R4T" when required.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

### 2.2.3.14. "J5" – Suction accumulator inlet temperature abnormality

Trigger	Effect	Reset
Thermistor suction accumulator inlet "R3T" out of range (<-47°C or >108°C)	Forced stop.	<ul style="list-style-type: none"> <li>Thermistor suction accumulator inlet "R3T" in range (&gt; -47°C &amp; &lt; 108°C).</li> <li>User interface on ==&gt; off ==&gt; on.</li> </ul>

Possible cause	Check	Corrective action
Thermistor suction accumulator inlet "R3T" wire broken or short circuit.	Check wires on connector X30A pin 1+2.	Replace thermistor suction accumulator inlet "R3T".
Faulty thermistor suction accumulator inlet "R3T".	Check thermistor suction accumulator inlet "R3T" (see <a href="#">"Thermistors" on page 83</a> ).	Replace thermistor suction accumulator inlet "R3T" when required.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

### 2.2.3.15. "J6" – Liquid Sub-cool heat-exchanger temperature

Trigger	Effect	Reset
Thermistor liquid sub cool heat exchanger "R7T" out of range (<-47°C or >108°C)	Forced stop.	<ul style="list-style-type: none"> <li>Thermistor liquid sub cool heat exchanger "R7T" in range (&gt; -47°C &amp; &lt; 108°C).</li> <li>User interface on ==&gt; off ==&gt; on.</li> </ul>

Possible cause	Check	Corrective action
Thermistor liquid sub cool heat exchanger "R7T" wire broken or short circuit.	Check wires on connector X30A pin 9+10.	Replace thermistor liquid sub cool heat exchanger "R7T".
Faulty thermistor liquid sub cool heat exchanger "R7T".	Check thermistor liquid sub cool heat exchanger "R7T" (see <a href="#">"Thermistors" on page 83</a> ).	Replace thermistor liquid sub cool heat exchanger "R7T" when required.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

2.2.3.16. "J7" – Liquid temperature abnormality

Trigger	Effect	Reset
Thermistor between: <ul style="list-style-type: none"> <li>liquid receiver &lt;-&gt; Sub-cool heat-exchanger "R6T" out of range (&lt;-47°C or &gt; 108°C).</li> <li>liquid stop valve &lt;-&gt; Sub-cool heat-exchanger "R8T" out of range (&lt;-47°C or &gt; 108°C).</li> <li>liquid expansion valve "Y2E" &lt;-&gt; Sub-cool heat-exchanger "R11T" out of range (&lt;-47°C or &gt; 108°C).</li> </ul>	Forced stop.	<ul style="list-style-type: none"> <li>Thermistor liquid in range (&gt; -47°C &amp; &lt; 108°C):                             <ul style="list-style-type: none"> <li>liquid receiver &lt;-&gt; Sub-cool heat-exchanger "R6T" +</li> <li>liquid stop valve &lt;-&gt; Sub-cool heat-exchanger "R8T"+</li> <li>liquid expansion valve "Y2E" &lt;-&gt; Sub-cool heat-exchanger "R11T".</li> </ul> </li> <li>User interface on ==&gt; off ==&gt; on.</li> </ul>

Possible cause	Check	Corrective action
Thermistor liquid wire broken or short circuit.	Check wires on connector: <ul style="list-style-type: none"> <li>X30A pin 7 + 8 ("R6T")</li> <li>X29A pin 5+ 6 ("R8T")</li> <li>X18A pin 1+ 3 ("R11T")</li> </ul>	Replace thermistor liquid: <ul style="list-style-type: none"> <li>liquid receiver &lt;-&gt; Sub-cool heat-exchanger "R6T"</li> <li>liquid stop valve &lt;-&gt; Sub-cool heat-exchanger "R8T"</li> <li>liquid expansion valve "Y2E" &lt;-&gt; Sub-cool heat-exchanger "R11T".</li> </ul>
Faulty thermistor liquid.	Check (see <a href="#">"Thermistors" on page 83</a> ): <ul style="list-style-type: none"> <li>liquid receiver &lt;-&gt; Sub-cool heat-exchanger "R6T"</li> <li>liquid stop valve &lt;-&gt; Sub-cool heat-exchanger "R8T"</li> <li>liquid expansion valve "Y2E" &lt;-&gt; Sub-cool heat-exchanger "R11T".</li> </ul>	Replace thermistor liquid when required. <ul style="list-style-type: none"> <li>liquid receiver &lt;-&gt; Sub-cool heat-exchanger "R6T" X30A pin 7+8.</li> <li>liquid stop valve &lt;-&gt; Sub-cool heat-exchanger "R8T" X29A pin 5+6.</li> <li>liquid expansion valve "Y2E" &lt;-&gt; Sub-cool heat-exchanger "R11T" X18A pin 1+3.</li> </ul>
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

2.2.3.17. "J9" – Purge receiver + gas out SCHEX temperature abnormality

Trigger	Effect	Reset
Thermistor purge receiver + gas outlet sub cool heat exchanger "R5T" out of range (<-47°C or >108°C)	Forced stop.	<ul style="list-style-type: none"> <li>Thermistor purge receiver + gas outlet sub cool heat exchanger "R5T" in range (&gt; -47°C &amp; &lt; 108°C).</li> <li>User interface on ==&gt; off ==&gt; on.</li> </ul>

Possible cause	Check	Corrective action
Thermistor purge receiver + gas outlet sub cool heat exchanger "R5T" wire broken or short circuit.	Check wires on connector X30A pin 5+6.	Replace thermistor purge receiver + gas outlet sub cool heat exchanger "R5T".
Faulty thermistor purge receiver + gas outlet sub cool heat exchanger "R5T".	Check thermistor purge receiver + gas outlet sub cool heat exchanger "R5T" (see <a href="#">"Thermistors" on page 83</a> ).	Replace thermistor purge receiver + gas outlet sub cool heat exchanger "R5T" when required.

Possible cause	Check	Corrective action
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

### 2.2.3.18. "JA" – High pressure sensor abnormality

Trigger	Effect	Reset
High pressure sensor detects an abnormal value for 3 minutes during operation compressor (> 4,5 MPa or < -0,05 MPa).	Unit will stop operating.	Manual reset via user interface.

Possible cause	Check	Corrective action
High pressure sensor connector disconnected.	Connection plug of high pressure sensor is mounted (on correct connector).	Connect plug of high pressure sensor to (correct) connector.
Faulty high pressure sensor.	Check high pressure sensor (see <a href="#">"High pressure sensor S1NPH" on page 74</a> ).	Replace high pressure sensor when required (see <a href="#">"Replacing high pressure sensor" on page 123</a> ).
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Operation outside operation range	Water inlet temperature 10~45°C	Correct (local installed) water circuit to improve water supply temperature within published operation range.

### 2.2.3.19. "JC" – Low pressure sensor abnormality

Trigger	Effect	Reset
Low pressure sensor detects an abnormal value for 3 minutes during operation compressor. (> 1,7 MPa or < -0,05 MPa).	Unit will stop operating.	Manual reset via user interface.

Possible cause	Check	Corrective action
Low pressure sensor connector disconnected.	Connection plug of low pressure sensor is mounted (on correct connector).	Connect plug of low pressure sensor to (correct) connector.
Faulty low pressure sensor.	Check low pressure sensor (see <a href="#">"Low pressure sensor S1NPL" on page 76</a> ).	Replace low pressure sensor when required (see <a href="#">"Replacing low pressure sensor" on page 128</a> ).
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Operation outside operation range	Water inlet temperature 10~45°C	Correct (local installed) water circuit to improve water supply temperature within published operation range.

## 2.2.3.20. "L1" – Main board abnormality

Trigger	Effect	Reset
Main board "A1P" detects current/voltage errors.	Unit will stop operating.	Manual reset via user interface. Power reset RWEYQ-T.

Possible cause	Check	Corrective action
Blown fuse.	Check fuse on main board "A1P".	Replace fuse if blown.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P".</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P".</li> </ul>
Faulty compressor "M1C"	<ul style="list-style-type: none"> <li>Check compressor (see <a href="#">"Compressor" on page 87</a>).</li> <li>Check connections and wiring of the compressor.</li> <li>Check expansion valve (liquid back issue) (see <a href="#">"Electronic expansion valve" on page 89</a>).</li> <li>Check the refrigerant charge. Refer to the nameplate for correct charge.</li> </ul>	<ul style="list-style-type: none"> <li>Replace compressor when required (see <a href="#">"Replacing compressor" on page 114</a>).</li> <li>Investigate reason of breakdown.</li> <li>Replace expansion valve when required (see <a href="#">"Replacing expansion valve body" on page 121</a>).</li> <li>Fix possible leak.</li> </ul>
Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power reset via compressor module.
Faulty capacity setting on main board "A1P".	<ul style="list-style-type: none"> <li>Check if the correct capacity setting is made.</li> <li>Check if the correct spare part is installed.</li> </ul>	Adjust capacity setting when required.
External factor (e.g. electrical noise). (cause when error is reset after power reset, and error happens again after a while).	Check for source which could cause electrical interference.	Avoid electrical interference. Respect minimum distance to other electric appliance (refer to installation manual).

## 2.2.3.21. "L2" – Power Supply quality abnormality

Trigger	Effect	Reset
Main board "A1P" detects trouble "zero crossing": power supply main board "A1P" checks L1-N sinus cross each half period sinus (10 milli-seconds if 50Hz power supply).	Unit stops 3 minutes and retry. (infinite cycle).	Guard timer 3 minutes.

Possible cause	Check	Corrective action
Power supply incorrect frequency.	Check power supply is 50 or 60 Hz $\pm$ 3%.	Correct power supply (especially if use of power generator)
External factory (e.g. electrical noise). (cause when error is reset after power reset, and error happens again after a while).	Check for source which could cause electrical interference.	Avoid electrical interference. Respect minimum distance to other appliance (refer to installation manual).

Possible cause	Check	Corrective action
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals. (see <a href="#">"Replacing main PCB A1P" on page 141</a>)</li> </ul>
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P".</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P".</li> </ul>

### 2.2.3.22. "L5" – Output overcurrent detection

Trigger	Effect	Reset
Inverter board "A3P" detects overcurrent to power transistor	Unit will stop operating.	Manual reset via user interface.

Possible cause	Check	Corrective action
Refrigerant circuit is clogged.	Check for possible blockage.	Replace blocked part when required.
Humidity in refrigerant (ice formation in expansion valve).	Check for humidity in the refrigerant.	In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant.
Non condensable gas (e.g. air, nitrogen) in refrigerant.	Check for non condensable gas in refrigerant.	In case of suspicion of non condensables, recover, vacuum and recharge with virgin refrigerant.
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P".</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P".</li> </ul>
Faulty compressor "M1C"	<ul style="list-style-type: none"> <li>Check compressor (see <a href="#">"Compressor" on page 87</a>).</li> <li>Check connections and wiring of the compressor.</li> <li>Check expansion valve (liquid back issue) (see <a href="#">"Electronic expansion valve" on page 89</a>).</li> <li>Check the refrigerant charge. Refer to the nameplate for correct charge.</li> </ul>	<ul style="list-style-type: none"> <li>Replace compressor when required (see <a href="#">"Replacing compressor" on page 114</a>).</li> <li>Investigate reason of breakdown.</li> <li>Replace expansion valve when required (see <a href="#">"Replacing expansion valve body" on page 121</a>).</li> <li>Fix possible leak.</li> </ul>
Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power reset via outdoor unit.

## 2.2.3.23. "L8" – Inverter overcurrent

Trigger	Effect	Reset
When inverter board detects overcurrent to compressor (except during start-up) is detected.	Unit will stop operating.	Manual reset via user interface.

Possible cause	Check	Corrective action
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P".</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P".</li> </ul>
Faulty compressor "M1C"	<ul style="list-style-type: none"> <li>Check compressor (see "<a href="#">Compressor</a>" on page 87).</li> <li>Check connections and wiring of the compressor.</li> <li>Check expansion valve (liquid back issue) (see "<a href="#">Electronic expansion valve</a>" on page 89).</li> <li>Check the refrigerant charge. Refer to the nameplate for correct charge.</li> </ul>	<ul style="list-style-type: none"> <li>Replace compressor when required (see "<a href="#">Replacing compressor</a>" on page 114).</li> <li>Investigate reason of breakdown.</li> <li>Replace expansion valve when required (see "<a href="#">Replacing expansion valve body</a>" on page 121).</li> <li>Fix possible leak.</li> </ul>
Refrigerant circuit is clogged.	Check for possible blockage.	Replace blocked part when required.
Refrigerant overcharge.	Check for refrigerant overcharge. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
Refrigerant is contaminated.	-	Replace refrigerant.

## 2.2.3.24. "L9" – Stall prevention

Trigger	Effect	Reset
Inverter board detects compressor over-current or no rotation at start up.	Unit will stop operating.	Manual reset via user interface.

Possible cause	Check	Corrective action
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P".</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P".</li> </ul>
Faulty compressor "M1C"	<ul style="list-style-type: none"> <li>Check compressor (see "<a href="#">Compressor</a>" on page 87).</li> <li>Check connections and wiring of the compressor.</li> <li>Check expansion valve (liquid back issue) (see "<a href="#">Electronic expansion valve</a>" on page 89).</li> <li>Check the refrigerant charge. Refer to the nameplate for correct charge.</li> </ul>	<ul style="list-style-type: none"> <li>Replace compressor when required (see "<a href="#">Replacing compressor</a>" on page 114).</li> <li>Investigate reason of breakdown.</li> <li>Replace expansion valve when required (see "<a href="#">Replacing expansion valve body</a>" on page 121).</li> <li>Fix possible leak.</li> </ul>
Refrigerant circuit is clogged.	Check for possible blockage.	Replace blocked part when required.
Refrigerant condition is not OK (HP-LP > 0,2 MPa at start-up).	Check refrigerant condition.	-

## 2.2.3.25. "LC" – Transmission system abnormality

Trigger	Effect	Reset
No transmission between main board "A1P" <-> SUB PCB "A4P" <-> inverter board "A3P".	Unit will stop operating.	Automatic reset.

Possible cause	Check	Corrective action
Internal wiring is not OK.	Check if wiring between PCB's (see " <a href="#">Wiring diagram</a> " on page 159).	Correct wiring.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> <li>Remove X20A from "A1P": check presence <math>\pm 12\text{VDC}</math></li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see "<a href="#">Replacing main PCB A1P</a>" on page 141).</li> </ul>
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P".</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P".</li> </ul>
Faulty SUB PCB "A4P".	Check auxiliary board receives 16VDC on connector "X10A".	Replace SUB PCB "A4P" when HAP LED is not blinking once in regular intervals.
Faulty noise filter "A2P".	Check 3 phase output is present.	Replace noise filter "A2P".
Faulty capacity setting on main board "A1P".	Check if the correct capacity setting is made. Check if the correct spare part is installed.	Adjust capacity setting when required.
External factor (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while).	Check for source which could cause electrical interference.	Avoid electrical interference. Respect minimum distance to other electric appliance (refer to installation manual).

## 2.2.3.26. "P1" – Ripple DC voltage diode module to power transistors

Trigger	Effect	Reset
Inverter board "A3P" detects power unbalance > 4%.	Unit will stop operating.	Manual reset via user interface. Automatic reset power unbalance.

Possible cause	Check	Corrective action
Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power reset via compressor module.
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P" (see "<a href="#">Inverter board A3P</a>" on page 78).</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P" (see "<a href="#">Replacing inverter board A3P</a>" on page 139).</li> </ul>

## 2.2.3.27. "P4" – Overheat power module

Trigger	Effect	Reset
Inverter board "A3P" detects high temperature at power module.	Unit will stop operating.	Manual reset via user interface. Automatic reset temperature.

Possible cause	Check	Corrective action
Faulty AC fan motor cooling inverter.	<ul style="list-style-type: none"> <li>Check if plug to connector correctly mounted X3A on SUB PCB "A4P".</li> <li>Check 230VAC power to SUB PCB "A4P".</li> <li>Check AC fan motor (see <a href="#">"AC fan motor inverter cooling" on page 70</a>).</li> </ul>	<ul style="list-style-type: none"> <li>Reconnect plug to connector X3A on auxiliary board "A4P".</li> <li>Fix 230VAC power to auxiliary board "A4P"</li> <li>Replace AC fan motor (see <a href="#">"Replacing AC fan inverter cooling" on page 120</a>).</li> </ul>
Insufficient air circulation.	Check for obstruction grills casing.	Remove obstruction grills casing.
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check inverter board "A3P" (see <a href="#">"Inverter board A3P" on page 78</a>).</li> <li>Check if the alive led is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P" (see <a href="#">"Replacing inverter board A3P" on page 139</a>).</li> </ul>
Faulty or disturbance of the power supply: only 2 phase to diode module.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power reset via compressor module.
Faulty fin thermistor.	Compare fin temperature to ambient (with checker Type III) after unit is stopped for minimum 30 minutes.	If fin temperature shows abnormal value at stop, replace inverter board "A3P" (see <a href="#">"Replacing inverter board A3P" on page 139</a> ).

## 2.2.3.28. "PJ" – Capacity setting mismatch inverter board

Trigger	Effect	Reset
Main board "A1P" detects other type inverter board than set in EEPROM (factory mounted board) or dipperswitches (spare part board).	Unit will stop operating.	Manual reset via user interface. Power reset RWEYQ-T.

Possible cause	Check	Corrective action
Capacity setting main board "A1P" does not correspond to detected inverter board.	Check if capacity setting is made correctly. Read out size from outdoor board (1-21) and user interface.	Make correct capacity setting on main board "A1P".
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals. (see <a href="#">"Replacing main PCB A1P" on page 141</a>)</li> </ul>
Faulty inverter board "A3P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the inverter board "A3P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the inverter board "A3P".</li> <li>Replace inverter board "A3P" when HAP LED is not blinking in regular intervals. (see <a href="#">"Replacing inverter board A3P" on page 139</a>).</li> </ul>

## 2.2.4. System

### 2.2.4.1. "U0" – Refrigerant shortage

Trigger	Effect	Reset
Refrigerant shortage detected when low pressure sensor "SENPL" < 0.05MPa and superheat > 20°C	Unit continues operating.	Automatic reset (automatic if LP > 3.0 MPa & Superheat suction (Taccumulator - Tevaporation) < 15°C).
		Power reset RWEYQ-T.

Possible cause	Check	Corrective action
Refrigerant shortage.	Check for refrigerant shortage. Refer to the nameplate for the correct charge.	Charge the correct refrigerant amount when required.
Stop valve is closed.	Check stop valves.	Open stop valve when required.
Humidity in refrigerant. (ice formation in expansion valve).	Check for humidity in the refrigerant.	In case of suspicion of humidity, recover, vacuum and recharge with virgin refrigerant.
None condensable gas (e.g. air, nitrogen) in refrigerant.	Check for none condensable gas in refrigerant.	In case of suspicion of none condensable gas, recover, vacuum and recharge with virgin refrigerant.
Faulty thermistor gas PHE-H <sub>2</sub> O "R4T".	Check thermistor gas PHE-H <sub>2</sub> O "R4T"	Replace thermistor gas PHE-H <sub>2</sub> O "R4T" when required.
Faulty thermistor discharge pipe "R12T".	Check thermistor discharge pipe "R12T".	Replace thermistor discharge pipe "R12T" when required.
Faulty low pressure sensor "SENSP".	Check low pressure sensor "SENSPL".	Replace Low pressure sensor "SENSPL" when required.
Faulty compressor.	<ul style="list-style-type: none"> <li>Check compressor (see "<a href="#">Compressor</a>" on page 87).</li> <li>Check connections and wiring of the compressor.</li> <li>Check expansion valve (liquid back issue) (see "<a href="#">Electronic expansion valve</a>" on page 89).</li> <li>Check the refrigerant charge. Refer to the nameplate for the correct charge.</li> </ul>	<ul style="list-style-type: none"> <li>Replace compressor when required (see "<a href="#">Replacing compressor</a>" on page 114).</li> <li>Investigate reason of breakdown.</li> <li>Replace expansion valve when required (see "<a href="#">Replacing expansion valve body</a>" on page 121).</li> <li>Fix possible leak.</li> </ul>
Faulty expansion valve.	Check the expansion valve (see " <a href="#">Electronic expansion valve</a> " on page 89).	Replace the expansion valve body (see " <a href="#">Replacing expansion valve body</a> " on page 121) or coil (see " <a href="#">Replacing expansion valve coil</a> " on page 122) when required.

## 2.2.4.2. "U1" – Reverse phase or open phase

Trigger	Effect	Reset
Main board "A1P" detects incorrect power supply (missing phase or reverse rotation).	Unit will stop operating.	Power reset unit.

Possible cause	Check	Corrective action
Incorrect sequence 3 phase.	Check rotation sequence power supply.	Correct sequence 3 phase power supply.
Missing phase.	Check presence 3 phases.	Trace location where phase is interrupted between main power supply source and Main board "A1P".
Faulty main board "A1P"	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power reset via outdoor unit.
Faulty capacity setting on main board "A1P".	<ul style="list-style-type: none"> <li>Check if the correct capacity setting is made.</li> <li>Check if the correct spare part is installed.</li> </ul>	Adjust capacity setting when required.

## 2.2.4.3. "U2" – DC voltage DM &lt;-&gt; PM not permanent available

Trigger	Effect	Reset
There is no zero-cross detected in approximately 10 seconds (main board "A1P").	Unit will stop operating.	Power reset unit.
Abnormal voltage drop (< 212-254 V) is detected by the DC voltage detection circuit.	Unit will stop operating.	Automatic restart after compressor stand-by of 3 minutes.
Abnormal voltage rise is detected by the over-voltage detection circuit.	Unit will stop operating.	Automatic restart after compressor stand-by of 3 minutes.

Possible cause	Check	Corrective action
Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power reset via compressor module.
Reactor(s) open circuit.	Check continuity reactor coil.	Replace reactor if coil open circuit.
Fuse broken noise filter.	Check fuse on noise filter.	Replace noise filter is fuse open circuit.
Defective DC voltage detection circuit.	Check PCB with DC voltage detection circuit.	Replace inverter board "A3P" when required.
Defective over-voltage detection circuit.	Check PCB with over-voltage detection circuit.	Replace inverter board "A3P" when required.
Faulty compressor "M1C"	<ul style="list-style-type: none"> <li>Check compressor (see <a href="#">"Compressor" on page 87</a>).</li> <li>Check connections and wiring of the compressor.</li> <li>Check expansion valve (liquid back issue) (see <a href="#">"Electronic expansion valve" on page 89</a>).</li> <li>Check the refrigerant charge. Refer to the nameplate for the correct charge.</li> </ul>	<ul style="list-style-type: none"> <li>Replace compressor when required (see <a href="#">"Replacing compressor" on page 114</a>).</li> <li>Investigate reason of breakdown.</li> <li>Replace expansion valve when required (see <a href="#">"Replacing expansion valve" on page 121</a>).</li> <li>Fix possible leak.</li> </ul>

Possible cause	Check	Corrective action
Momentary drop of voltage.	-	Wait until compressor restarts.
Momentary power failure.	-	Wait until compressor restarts.
Faulty main board "A1P"	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

#### 2.2.4.4. "U3" – Test run failed

Trigger	Effect	Reset
Test run not performed at first installation.	Unit can not be operated.	Perform test run.
Pipe length data missing.	Unit can not be operated.	Perform test run.
Test-run interrupted by button on main board "A1P".	Unit can not be operated.	Restart test run.

Possible cause	Check	Corrective action
Test run was not started prior to normal operation.		Start test run from outdoor unit.
Test run could not start because initialisation was not completed.	Check communication is initialised prior to launch test-run.	Restart test run from outdoor unit.
Test run was interrupted manually by pressing BS1 "Mode" button.		Restart test run from outdoor unit.
Test run was interrupted by safety device.	Check error history outdoor unit.	Follow troubleshooting according to error code.

#### 2.2.4.5. "U4" – Transmission abnormality between outdoor and indoor unit

Trigger	Effect	Reset
Data sent from unit cannot be received normally, content of the sent data is abnormal.	Unit will stop operating.	Automatic restore.

Possible cause	Check	Corrective action
Faulty or disturbance of the power supply (imbalance > 10%). Power drop. Short circuit.	Check if the power supply is conform to the regulations. No fluctuations in frequency.	Adjust power supply when required. Power unit.
Wiring abnormality between RWEYQ-T and indoor unit and BS unit (in case of heat-recovery application).	Check wiring between RWEYQ-T and indoor units and BS unit (in case of heat-recovery application).	<ul style="list-style-type: none"> <li>Adjust wiring between RWEYQ-T and indoor units and BS unit (in case of heat-recovery application).</li> <li>Replace wiring between indoor units and RWEYQ-T, and BS unit (in case of heat-recovery application) when required.</li> </ul>
At time of test-run when any indoor unit or BS unit (in case of heat-recovery application) detects a fault of component.	<ul style="list-style-type: none"> <li>Set system into fan-only.</li> <li>Operate indoor units to check indoor error.</li> </ul>	<ul style="list-style-type: none"> <li>Repair cause of indoor unit fault code.</li> <li>Restart test-run RWEYQ-T.</li> </ul>
Faulty main board "A1P"	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

Possible cause	Check	Corrective action
Faulty board BS unit (in case of heat-recovery application).	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the board BS unit receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the board BS unit.</li> <li>Replace board BS unit when HAP LED is not blinking in regular intervals (see <a href="#">"Replace control board BS box" on page 148</a> and <a href="#">"Replacing expansion valve coil BS box" on page 149</a>).</li> </ul>
Faulty indoor unit main board.	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the indoor main PCB receives power.</li> </ul>	Adjust the power to the indoor main PCB. Replace indoor main PCB when HAP LED is not blinking in regular intervals (refer to service manual ESIE15-11).
Missing indoor unit or BS unit (in case of heat-recovery application) since end of initialisation.	<ul style="list-style-type: none"> <li>Check number indoor units and BS units (in case of heat-recovery application) monitoring mode (see <a href="#">"Field setting" on page 155</a>).</li> <li>Check number indoor units start fan when making "cross wiring check" (see <a href="#">"Field setting" on page 155</a>).</li> <li>Check communication BS indoor by dip switches BS unit. (see <a href="#">"Field setting" on page 155</a>).</li> </ul>	Switch on power supply indoor unit(s) or/and BS unit (in case of heat-recovery application) missing from initial initialisation.

#### 2.2.4.6. "U7" – Transmission between systems abnormality

Trigger	Effect	Reset
<ul style="list-style-type: none"> <li>Communication problem between systems.</li> <li>Conflict settings DTA104A61,62 and detected configuration.</li> </ul>	<ul style="list-style-type: none"> <li>Units will not operate.</li> <li>Units will operate.</li> </ul>	<ul style="list-style-type: none"> <li>Auto restore when communication is normal.</li> <li>Correct settings DTA104A61,62 and detected configuration RWEYQ-T.</li> </ul>

Possible cause	Check	Corrective action
Faulty wiring between main board "A1P" (example Q1Q2 loop).	Check wiring between main boards "A1P".	Correct wiring between outdoor main boards "A1P" when required.
Faulty main board "A1P"	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
When multiple systems are wired to be same cool/heat zone: no master cool/heat unit set.	Check setting on linked main boards "A1P": 1 unit needs setting mode 2-0-1, the other units in same zone 2-0-2.	Adjust field setting on main board "A1P" to have 1 cool/heat master and minimum 1 cool/heat slave.
Faulty wiring or setting for zone cool-heat control through optional board DTA104A61,62.	<ul style="list-style-type: none"> <li>Check wiring between main boards "A1P" (F1/F2-Outd) and DTA104A61,62.</li> <li>Check led HAP on option PCB DTA104A61,62 blinks.</li> <li>Check dip switch setting option PCB DTA104A61,62.</li> <li>Check address setting main PCB compressor module: for zone cool-heat control = mode2-1.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the wiring between main boards "A1P" and optional board DTA104A61,62.</li> <li>Adjust the setting to the main board "A1P".</li> <li>Adjust power supply (16 VDC) to DTA104A61,62.</li> <li>Replace main board "A1P" (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

Possible cause	Check	Corrective action
Faulty wiring or setting for LNOP/Demand control through optional board DTA104A61,62.	<ul style="list-style-type: none"> <li>Check dip switch setting DTA104A61,62.</li> <li>Check address setting main board "A1P": for Cool/heat zone mode 2-1, for LNOP or/and Demand = mode2-2.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the wiring between main boards "A1P" and optional board DTA104A61,62.</li> <li>Adjust the setting to the main boards "A1P".</li> <li>Replace main board "A1P" (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>

### 2.2.4.7. "U9" – Systems abnormality

Trigger	Effect	Reset
Any indoor unit fault prevents system to start.	Units will stop operating.	Automatic restore.

Possible cause	Check	Corrective action
Minimum 1 indoor unit detects a fault that does not allow system to operate.	Check all indoor units for error code (start with A or C).	Perform troubleshooting indoor unit according to error code found during check method.
Wiring abnormality between indoor units <-> RWEYQ-T and <-> BS unit (in case of heat-recovery application).	Check wiring between indoor units <-> RWEYQ-T or/and <-> BS unit (in case of heat-recovery application).	Adjust wiring between indoor units <-> RWEYQ-T or/and <-> BS unit (in case of heat-recovery application) when required. Replace wiring between indoor units <-> RWEYQ-T or/and <-> BS unit (in case of heat-recovery application) when required.
Faulty main board "A1P"	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty board BS unit (in case of heat-recovery application).	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the board BS unit receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the board BS unit.</li> <li>Replace board BS unit when HAP LED is not blinking in regular intervals (see <a href="#">"Replace control board BS box" on page 148</a> and <a href="#">"Replacing expansion valve coil BS box" on page 149</a>).</li> </ul>
Faulty indoor unit main board.	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the indoor main PCB receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the indoor main PCB.</li> <li>Replace indoor main PCB when HAP LED is not blinking in regular intervals (refer to service manual ESIE15-11).</li> </ul>
Missing indoor unit or heat-exchanger module since end of initialisation.	<ul style="list-style-type: none"> <li>Check number indoor units monitoring mode mode1-code 5 (for 5 hp), or code 10 (for 8 hp) (see <a href="#">"Field setting" on page 155</a>.)</li> <li>Check number indoor units start fan when making "cross wiring check" mode 2-code 5 (see <a href="#">"Field setting" on page 155</a>).</li> </ul>	Switch on power supply indoor unit(s) and/or BS unit (in case of heat-recovery application) missing from initial initialisation.

## 2.2.4.8. "UF" – Wiring and piping mismatch

Trigger	Effect	Reset
During test-run, minimum 1 indoor unit fails "cross pipe check" or judgment closed stop valve(s)	Unit will stop operating.	Perform test-run again.

Possible cause	Check	Corrective action
Faulty wiring between indoor units, RWEYQ-T and BS unit (in case of heat-recovery application).	Check "cross wiring check" (mode 2-5) to confirm correct indoor units running fan.	Correct field wiring.
Incorrect connection between RWEYQ-T and indoor or BS unit (in case of heat-recovery application).	<ul style="list-style-type: none"> <li>If RWEYQ-T used as heat-pump, gas pipe should be left side. Middle stop valve should not be used.</li> <li>If RWEYQ-T used as heat-recovery, left gas pipe = dual pressure, middle pipe = suction, right = liquid.</li> </ul>	<ul style="list-style-type: none"> <li>Change field pipe connections. Close all stop valves,</li> <li>Set system in recovery mode,</li> <li>Recover refrigerant,</li> <li>Change field piping,</li> <li>Air tight test,</li> <li>Vacuum field piping,</li> <li>Recharge recovered amount,</li> <li>Open stop valves,</li> <li>Restart test-run.</li> </ul>
Refrigerant shortage (incorrect charge/leakage).	Check for refrigerant shortage. Perform a leak test.	If required, repair the leak and charge the correct amount of refrigerant.
Refrigerant circuit is clogged.	Check for possible blockage Blockages can be checked by measuring the refrigerant/pipe temperature. Sudden drop in temperature could indicate a blockage (remark: this is not valid for the expansion valve).	<ul style="list-style-type: none"> <li>Check piping for narrow passage (kink in pipe).</li> <li>Check for blocked refnet (excessive welding result into internal blockage): apply pressure from liquid service port, set outdoor to 2-21 recovery mode, confirm pressure gas service port raises.</li> </ul>
Incorrect indoor unit coil thermistor.	<ul style="list-style-type: none"> <li>Check mounting of coil thermistor to indoor unit heat-exchanger (refer to service manual ESIE15-11).</li> <li>Check resistance of coil thermistor.</li> <li>Operate indoor unit in fan-only (&gt; 30 minutes), check air thermistor and coil thermistor are about same value (service checker, D-checker or user interface).</li> </ul>	<ul style="list-style-type: none"> <li>Correct position of coil thermistor indoor unit into thermistor holder.</li> <li>Replace coil thermistor if resistance value is incorrect.</li> </ul>
Stop valve closed at RWEYQ-T.	Remove cap of stop valves to check position of internal shaft.	Open stop valve(s).

## 2.2.4.9. "UH" – Auto-address failure

Trigger	Effect	Reset
A wrong connection is detected by checking the combination of the indoor and main board "A1P".	Operation halt due to missing auto-address indoor unit.	Reset communication from main board "A1P".

Possible cause	Check	Corrective action
Initialisation not completed between main board "A1P" and indoor unit(s).	Indication main board "A1P". Check system data (user interface).	Wait till initialisation is completed before starting indoor unit operation.
Missing phase (for 3 phase models).	Check power supply.	Fix power supply.
Faulty main board "A1P".	<ul style="list-style-type: none"> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check if the main board "A1P" receives power.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the power to the main board "A1P".</li> <li>Replace main board "A1P" when HAP LED is not blinking in regular intervals (see <a href="#">"Replacing main PCB A1P" on page 141</a>).</li> </ul>
Faulty indoor board.	<ul style="list-style-type: none"> <li>Check if error still occurs after turning off power and turning it back on again.</li> <li>Check if the indoor PCB receives power.</li> <li>Check if the HAP LED is blinking in regular intervals.</li> <li>Check if the correct spare part is installed.</li> <li>Check the wiring to indoor PCB.</li> </ul>	<ul style="list-style-type: none"> <li>Adjust power to the indoor PCB.</li> <li>Replace indoor PCB when HAP LED is not blinking in regular intervals.</li> <li>Install correct spare part or update indoor PCB.</li> <li>Adjust wiring to indoor PCB when required.</li> </ul>
Internal wiring is not OK.	Check if wiring between "A1P" board and terminal strip indoor units and BS unit (in case of heat-recovery application) is correct (see <a href="#">"Wiring diagram" on page 159</a> ).	Correct wiring.
Wiring abnormality main board "A1P" <-> indoor unit.	Check wiring between main board "A1P" <-> indoor unit.	<ul style="list-style-type: none"> <li>Adjust wiring main board "A1P" &lt;-&gt; indoor unit when required.</li> <li>Replace wiring main board "A1P" &lt;-&gt; indoor unit when required.</li> </ul>
Mismatch of main board "A1P" and indoor units.	Verify connection on combination data-base.	Replace indoor units when required.
Defective DC voltage detection circuit.	<ul style="list-style-type: none"> <li>Check that 16VDC present at: <ul style="list-style-type: none"> <li>indoor main board "A1P" connector X35A.</li> <li>main board "A1P" RWEYQ-T connector X37A.</li> </ul> </li> <li>Check VRV indoor board <math>\pm 16</math> DCV at F1F2 and pins connector X35.</li> </ul>	<ul style="list-style-type: none"> <li>Replace main board "A1P" when required.</li> <li>Replace VRV indoor board when required.</li> </ul>
Incorrect voltage.	Check supply voltage.	Adjust when required.
External factor (e.g. electrical noise) (cause when error is reset after power reset, and error happens again after a while).	Check for source which could cause electrical interference.	Avoid electrical interference. Respect minimum distance to other electric appliance (refer to installation manual).

## 2.2.5. Others

Not applicable.

## 2.3. Symptom based troubleshooting

### Overview of symptom based error situations:

None of the units operate .....	62
Operation sometimes stops.....	63
Some indoor units do not operate .....	63
Equipment operates but does not cool or does not heat.....	63
Large operation noise and vibration .....	64

### 2.3.1. None of the units operate

Possible failures	Root cause	Check	Corrective action
<b>Root cause category: Component - electrical</b>			
Units does not operate.	Missing power supply to outdoor unit.	Check the rated voltage is supplied.	Restore the power supply.
	Power supply outdoor unit missing phase or reverse phase.	When trouble with power supply, fault indication will appear (UH, LC or U1 respectively L1,L2,L3 missing) on RWEYQ-T9.	Arrange correct power supply to RWEYQ-T9.
<b>Root cause category: Installation</b>			
Indoor units show fan-only mode.	Initialisation not completed.	<ul style="list-style-type: none"> <li>Check indication main board outdoor unit initialisation end (segment display off).</li> <li>Check that during initialisation, signal F1F2/IND changes between approx. 16V &amp; 0 VDC.</li> <li>Check HAP service LED BS units (if present) blink.</li> </ul>	<ul style="list-style-type: none"> <li>Wait till initialisation ended (max.12 min. from power-on).</li> <li>If initialisation &gt; 12 min., check DCV of F1F2 connections:                             <ul style="list-style-type: none"> <li>at BS units (when RWEYQ-T9 used as heat-recovery,</li> <li>indoor units,</li> </ul>                             if always 0VDC, check F1F2 wiring (open or short circuit) &amp; main pcb A1P.                         </li> <li>If 230VAC power present, replace pcb BS unit (if present) or indoor unit if HAP on pcb is off.</li> </ul>
Units do not operate	Mismatch of combination outdoor unit, BS unit (if present) and/or indoor units.	Check type of BS unit and indoor units (only VRV type are compatible & LT hydro-box HXY-A and HT hydro-box HXHD125A without BS unit)	Install match of combination outdoor unit, BS units and indoor units, LT hydro-box HXY-A, HT hydro-box HXHD125A.
	Indoor unit no controller (no control "BRC..." Or no DCS...+ group number)	<ul style="list-style-type: none"> <li>Check presence of central control (DCS...) &amp; group numbers are found.</li> <li>Check presence of central control (DCS...) &amp; group numbers are found.</li> </ul>	<ul style="list-style-type: none"> <li>If no central control device DCS..., connected wired control BRC...</li> <li>If only central control &amp; no indoor found, use wired control BRC... to set each indoor group number.</li> </ul>
<b>Root cause category: Operating conditions</b>			
Units do not operate.	requests cool/heat master indoor unit: <ul style="list-style-type: none"> <li>no BS units: among all indoor units.</li> <li>+ BS units: check if more than 1 indoor to same BS unit.</li> </ul>	Check symbol on wired remote control is off or on. 	If symbol blinks, confirm a VRV indoor unit as cool/heat master (press once cool/heat selector button).

### 2.3.2. Operation sometimes stops

Possible failures	Root cause	Check	Corrective action
<b>Root cause category: Component - electrical</b>			
Operation sometimes stops.	A power failure of 2 to 10 cycles can stop the air-conditioner operation (operation lamp off).	Check the power supply.	Restore the power supply.
<b>Root cause category: Operating conditions</b>			
Cooling/heating operation stops for 3 minutes and restarts.	Outdoor unit stops by "retry" by safety device: HP or LP, or current or discharge temperature, or current).	Check the retry error code (refer to " <a href="#">Error codes via outdoor unit</a> " on page 24).	Follow troubleshooting according to the error code found in the retry (refer to " <a href="#">Error code based troubleshooting</a> " on page 27).

### 2.3.3. Some indoor units do not operate

Possible failures	Root cause	Check	Corrective action
<b>Root cause category: Installation</b>			
Some indoor units do not operate.	Outdoor units, BS unit (if present) or/and indoor unit(s) are not compatible.	Check to make sure that the BS unit (if present) & indoor units are compatible with the RWEYQ-T9 unit.	Install compatible units.
	Indoor board does not receive power supply.	<ul style="list-style-type: none"> <li>Check presence 230 VAC.</li> <li>Check fuse(s) on board.</li> <li>Check HAP blinks.</li> </ul>	<ul style="list-style-type: none"> <li>Reconnect power supply.</li> <li>Replace fuse.</li> <li>Replace indoor unit pcb.</li> </ul>
	BS unit board (if present) does not receive power supply	<ul style="list-style-type: none"> <li>Check presence 230 VAC.</li> <li>Check fuse(s) on board.</li> <li>Check HAP blinks.</li> </ul>	<ul style="list-style-type: none"> <li>Reconnect power supply.</li> <li>Replace fuse.</li> <li>Replace BS unit pcb.</li> </ul>

### 2.3.4. Equipment operates but does not cool or does not heat

Possible failures	Root cause	Check	Corrective action
<b>Root cause category: Installation</b>			
Equipment operates but does not cool or does not heat.	Piping/wiring mismatch.	Perform "wiring/piping check" from outdoor unit. (refer to installation manual)	Adjust piping/wiring.
		Perform "wiring" check from BS unit (multi BS unit BS4~16Q14A). Refer to " <a href="#">Check method Wiring BS-Q14A</a> " on page 156).	Adjust wiring.
	Insufficient refrigerant in the refrigerant system.	Diagnosis by service port pressure and operating current.	Recharge the unit when required.

Possible failures	Root cause	Check	Corrective action
<b>Root cause category: Component - Mechanical</b>			
Equipment operates but does not cool or does not heat.	Incorrect thermistor values.	Check if all thermistors are still firmly attached in there thermistor pocket.	Remount the thermistor if it is not correct installed in the pocket.
	Expansion valve incorrect operation at BS unit (gas side) or indoor unit (liquid side).	Check operation of expansion valve.	Replace expansion valve body.
	Cross piping: <ul style="list-style-type: none"> <li>If BS unit present: among BS units or/and indoor unit.</li> <li>Without BS: wiring and refrigerant between RWEYQ-T9 and indoor units</li> </ul>	Operate indoor unit(s) to same RWEYQ-T9 unit to confirm no cross piping	Change field wiring between RWEYQ-T9, BS units (if present) and indoor units.
<b>Root cause category: Component - Electrical</b>			
Equipment operates but does not cool or does not heat.	Faulty operation of the electronic expansion valve.	Set the units to cooling operation, and compare the temperatures of the liquid side connection pipes of the connection section among the rooms. This to check the opening and closing operation of the electronic expansion valves of the individual units.	<ul style="list-style-type: none"> <li>Replace the coil and/or body of the indoor unit(s) indicating faulty operation of the expansion valve.</li> <li>Replace the coil of BS unit "EVL" if indoor expansion valve is working correctly.</li> </ul>

### 2.3.5. Large operation noise and vibration

Possible failures	Root cause	Check	Corrective action
<b>Root cause category: Component - Electrical</b>			
Large operation noise and vibration.	Instable output voltage of the inverter PCB.	Verify the operation of the inverter via the inverter checker.	Replace the inverter PCB when the inverter check is not OK.

Possible failures	Root cause	Check	Corrective action
<b>Root cause category: Installation</b>			
Large operation noise and vibration.	Indoor or/and BS unit(s) is not installed according the installation manual.	Check to make sure that the required spaces for the installation are provided.	Install the unit according the installation manual.
		Operate some indoor in cooling & other in heating - check that middle pipe all BS units (if present) warms up when outdoor operates ± 5 minutes.	Change field pipe connection BS unit (if present) to have warm pipe middle pipe of BS.
	Gas pipes crossed at RWEYQ-T9	Operate at least 1 indoor unit in heating mode. Right side pipe at RWEYQ-T9 should become warm. Suction gas pipe at RWEYQ-T9 (middle pipe) should not warm.	Recover refrigerant and change pipe connections at RWEYQ-T9 to have right side gas pipe high pressure side.
	Gas pipes crossed at BS units (if present)	Operate at least 1 indoor unit in heating mode. Middle pipe of inlet BS unit should become warm. Gas pipe at BS unit should not warm.	Recover refrigerant and change pipe connections at inlet of BS unit(s) to have middle pipe high pressure side.
	Liquid compression.	<ul style="list-style-type: none"> <li>Check indoor unit thermistors gas and coil.</li> <li>Check expansion valve of evaporator controls the superheat (default 5°C).</li> <li>Check refrigerant charge.</li> </ul>	<ul style="list-style-type: none"> <li>Replace thermistor(s) if faulty signal.</li> <li>Replace expansion valve coil or/and body when thermistors are correct.</li> <li>Recover and weight the refrigerant and recharge correct value.</li> </ul>
	Flash gas liquid pipe.	<ul style="list-style-type: none"> <li>Check expansion valve of evaporator controls the superheat (default 5°C): when tend to open fully: poor supply of liquid.</li> <li>Check field piping at BS units (if present) and indoor unit: minimum 0.5 m straight pipes.</li> </ul>	<ul style="list-style-type: none"> <li>Replace thermistor(s) if faulty signal.</li> <li>Replace expansion valve coil or/and body when thermistors are correct.</li> <li>Recover and weight the refrigerant and recharge correct amount.</li> <li>Adjust field piping to have minimum 0.5 m straight pipe at BS units (if present) and indoor units.</li> </ul>
	BS units (if present): change over indoor unit between high and low pressure (heating & cooling).	Check field setting outdoor 2-56. When setting >0, in heating mode, at thermostat-off or/and operation off, after 5 minutes indoor unit is changed to low pressure side. When thermostat-on or/and operation -on, indoor unit is set back to high pressure.	Disable the heating capacity-less (outdoor setting 2-56-0) and eventually equalisation time (setting 2-71) when complaint at time of change over cooling-heating request from indoor unit

## 2.4. Component checklist

**Overview of component checklists:**

VRV IV-Water cooled unit.....	67
4-way valve.....	67
AC fan motor inverter cooling.....	70
Thermistor value-read-out.....	72
High pressure switch.....	73
High pressure sensor S1NPH.....	74
Low pressure sensor S1NPL.....	76
Inverter board A3P.....	78
Main board A1P.....	82
Thermistors.....	83
Compressor.....	87
Electronic expansion valve.....	89
System.....	90
Others.....	90

## 2.4.1. VRV IV-Water cooled unit

### 2.4.1.1. 4-way valve

Technical specification		Description	
<p>The 4 way valve is controlled from a pilot valve set in position by a magnetic coil:</p> <ul style="list-style-type: none"> <li>Y6S 4Way valve HP/LP gas indoor:           <ul style="list-style-type: none"> <li>0V = suction pressure to indoor,</li> <li>230VAC = discharge pressure to indoor.</li> </ul> </li> <li>Y7S 4Way valve H<sub>2</sub>O PHE:           <ul style="list-style-type: none"> <li>0V = discharge pressure to H<sub>2</sub>O PHE,</li> <li>230VAC = suction pressure to H<sub>2</sub>O PHE.</li> </ul> </li> </ul>		<p>The 4-way valve directs the super-heated refrigerant discharged from the compressor to the indoor heat exchanger in case of heating operation or to the outdoor H<sub>2</sub>O heat exchanger in case of</p> <ul style="list-style-type: none"> <li>cooling operation,</li> <li>oil return in heating mode in case of heat-pump application.</li> </ul>	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167	See "Component overview of unit" on page 162.
Check procedure			
Mechanical check			

- Switch off the Daikin indoor unit(s) via the user interface.
- Switch off the power supply to the unit with the field supplied circuit breaker.
- Remove plate work when required, refer to "Basic removal" on page 102.
- Loosen the screw and remove the coil from the 4-way valve (refer to "Replacing 4-way valve coil" on page 113).



#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

- Unplug 4-way valve connector from the main board "A1P".

Component no.	Location	Description
X7A	A1P	4-way valve HP/LP gas indoor
X8A	A1P	4-way valve H <sub>2</sub> O PHE

- Switch on the power supply to the unit with the field supplied circuit breaker.
- Switch on the Daikin indoor unit(s) via the user interface, start cooling operation
  - 4-way valve connected to the H<sub>2</sub>O plate heat-exchanger:
    - If the gas temperature at the H<sub>2</sub>O plate the heat exchanger drops, the 4-way valve is stuck in heating position (refer to "Replacing 4-way valve body" on page 111).
    - If the gas temperature at the H<sub>2</sub>O plate the heat exchanger rises, proceed with next step 8.
    - If the temperature at the H<sub>2</sub>O plate the heat exchanger does not change, check the refrigerant pressure by connecting a manifold to one of the service ports.
      - If pressure = 0 barG, perform a pressure test and fix any leaks.
      - If there is no pressure difference HP-LP, or the 4-way valve is stuck in the middle, confirm by determining the position of the 4-way valve as described below and replace the 4-way valve (refer to "Replacing 4-way valve body" on page 111). or the compressor fails compression (internal bypass). Replace the compressor.

(b) 4-way valve connected to the HP/LP stop valve:

- If the gas temperature towards the indoor units raises, the 4-way valve is stuck in heating position (refer to ["Replacing 4-way valve body" on page 111](#)).
- If the gas temperature towards the indoor units drops, proceed with next step 8.
- If the temperature towards the indoor units does not change, check the refrigerant pressure by connecting a manifold to one of the service ports.
  - If pressure = 0 barG, perform a pressure test and fix any leaks.
  - If there is no pressure difference HP-LP, or the 4-way valve is stuck in the middle, confirm by determining the position of the 4-way valve as described below and replace the 4-way valve (refer to ["Replacing 4-way valve body" on page 111](#)). or the compressor fails compression (internal bypass). Replace the compressor.



#### CAUTION - RISK OF LIQUID ENTERING THE COMPRESSOR

To prevent damage to the compressor the step below must only be done once.

8. While listening to the 4-way valve, place a round permanent magnet on the core of the solenoid valve. If you do not hear the 4-way valve switching, it must be replaced (refer to ["Replacing 4-way valve body" on page 111](#)).

#### Electrical check

1. Switch off Daikin unit via the user interface.
2. Switch off the power supply to the unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).
4. Switch on the Daikin unit, start heating operation.



#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

5. Measure the voltage on 4-way valve connector:

Connector no.	Location	Description
X7A	A1P	4-way valve HP/LP gas indoor
X8A	A1P	4-way valve H <sub>2</sub> O PHE

- If the measured voltage, does not range 220-240 VAC during switching,
  - stop unit from user interface.
  - once compressor stopped, unplug 4-way valve connector from main board "A1P" (connector see table above).
  - measure the voltage directly on the main board "A1P"(connector see table above).
- If the voltage, measured directly on the main board "A1P" does range 220-240 VAC during switching, replace the 4-way valve coil (refer to ["Replacing 4-way valve coil" on page 113](#)).




#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

6. Unplug 4-way valve connector from PCB and measure the resistance of the 4-way valve coil. If the measured resistance does not range 1000 - 2000 Ω, replace the 4-way valve coil (refer to ["Replacing 4-way valve coil" on page 113](#)).
7. Switch on the Daikin indoor unit(s). Start cooling operation.
  - If the temperature after the indoor unit heat exchanger rises, the control of the 4-way valve is wrong. Replace main PCB (refer to ["Replacing main PCB A1P" on page 141](#)).

**Determine the position of the 4-way valve**

1. Switch off Daikin unit via the user interface.
2. Switch off the power supply to the unit with the field supplied circuit breaker.
3. Slide a magnet over the front and the rear of the 4-way valve body and sense the attraction of the magnet to determine the valve position.
4. If the magnet is attracted in positions A,A' or B,B', the 4-way valve is OK; if the magnet is attracted in positions C,C' the 4-way valve must be replaced (refer to ["Replacing 4-way valve body" on page 111](#)).



2.4.1.2. AC fan motor inverter cooling

Technical specification		Description	
The unit RWEYQ-T9Y1B contains 2 AC fan motors running parallel from same output signal. Each fan assembly contains: <ul style="list-style-type: none"> <li>• an AC motor equipped with a single connector for 230VAC power supply,</li> <li>• a 5 blade fan propeller.</li> </ul>		The fan motor location behind the switchbox operates when the inverter temperature requires cooling.	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. SUB PCB A4P, item 7 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 34 and 35 in Figure 5-4 on page 162.
Check procedure			
Mechanical check			

1. Switch off the Daikin unit via the user interface.
2. Switch of the power supply of the unit with the field supplied circuit breaker.
3. Check all electrical connections of the fan motor.
4. Check all electrical connections of the power supply.
5. Check propeller rotates free.

Electrical check

Without power supply

1. Switch off the power supply to the unit with the field supplied circuit breaker.
2. Disconnect plug at fan motor, refer to the table below.
3. Measure the circuits using the table below.  
At plug X3A, resistance is 1/2 for RWEYQ-T9Y1B (2 fan motors are wired parallel)

RWEYQ-T9Y1B	
Symbols wiring diagram	
Check Method	Resistance check 2.075 kΩ (20°C) (tolerance ±10%)

**With power supply**

1. Reconnect the plug of the fan motor.
2. Switch on the power supply to the unit with the field supplied circuit breaker.
3. Start indoor unit by User interface.
4. Confirm output 230VAC when inverter temperature reaches  $\pm 65^{\circ}\text{C}$ . (fin temperature read out by service checker TypeIII).
5. Confirm the 2 motors run when output 220VAC is measured on connector X3A SUB PCB "A4P".
6. Confirm motor does not make abnormal noise.
7. Check air circulation:  $\pm 1.6\text{m}^3/\text{min}$  per fan.

## 2.4.1.3. Thermistor value-read-out

Technical specification		Description	
NTC-type thermistor: <ul style="list-style-type: none"> <li>when °C up -&gt; kΩ down.</li> <li>when °C down -&gt; kΩ up.</li> </ul>		The thermistors of the unit can be verified by connecting Service Checker Typelll or D-checker. The value of limited number of sensors & outputs can be displayed by the segment display.	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. SUB PCB A4P, item 7 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 34 and 35 in Figure 5-4 on page 162.
Check procedure			

**Read by monitoring tool (service checker Typelll or D-checker)**

- Switch off the Daikin unit via the user interface.
- Confirm unit stops operation.
- Wait for about 15 minutes before checking value of thermistors.
- Compare deviation of read out (maximum 5% to ambient temperature).
- If any thermistor read out shows "out of range", use the electric check method to judge if change of thermistor (resistance check fails) or main board (resistance check pass).
  - Type 1: out of range if < -47°C or > 103°C.
  - Type 2: out of range if < -34°C or > 183°C.

**Read by "digital gauge" main board**

- Enter the mode 1: 1 x BS1 "Mode",
- Scroll to the related item (see Table 2-1 on page 72) push BS2 button "Set a number of times till flashing number shows the indicated number in mode 1 (see Table 2-1 on page 72),
- View value: 1 x BS3 "Return"
- Return to top list: 1 x BS3 "Return".
- To view other sensor, return to step 2
- To end monitoring mode, 1 x BS1 "Mode".

**Table 2-1: Table display data by Segment display main board "A1P", read out per module**

Mode 1	Description display	Mode 1	Description display
42	actual Pc (Mpa)	53	Actual gas °C PHE H2O (R4T - "Tg")
43	actual Pe (Mpa)	54	Actual liquid receiver °C (R6T - "TL")
44	Actual Frequency output (Hz)	56	Compressor hours (display= hours/100)
45	Actual pulses Y1E (display = pulses/10)	57	Actual Output X2M 2«3 (0~10VDC)
46	Actual pulses Y2E (display = pulses/10)	58	Actual H2O inlet °C (R9T)
47	Actual discharge pipe °C (R12T - "Tdi")	59	Actual H2O inlet °C (R10T)
48	spare item	60	Actual compressor body °C (R13T - "Ti")
49	spare item	61	Actual r410A liquid °C H2O PHE (R7T - "Tb")
50	Actual air °C (R1T - "Ta")	62	Actual liquid °C outlet Y2E (R11T - "Tm")
51	Actual Accumulator inlet °C (R3T - "Ts")	63	Actual liquid °C stop valve liquid (R8T - "Tsc")
52	Actual gas outlet °C Sub-cool (R5T - "Tsh")	64	Actual air °C (R1T - "Ta")
		65	Actual gas °C ZED circuit (R2T - "Tev")

### 2.4.1.4. High pressure switch

Technical specification		Description	
The high pressure switch has a normally closed contact. If the pressure exceeds 41.7 (+0 / -1) bar the contact will open. If the pressure drops below 32 ( $\pm$ 2) bar the contact will close.		The high pressure switch is a safety component that stops the compressor if abnormal high pressure is detected in the refrigerant circuit.	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Main PCB A1P, item 4 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 38 in Figure 5-4 on page 162.
Check procedure			
Electrical check			

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.

#### PROCEDURE

1. Disconnect the high pressure switch connector from main board "A1P".
  2. Connect a gauge to the service port of the HP/LP gas stop valve.
  3. Confirm that saturation pressure corresponds to ambient temperature ( $\pm$  0.5 MPa)
  4. Check whether the contact of the pressure switch is closed (by stopping the unit, the standing pressure in the system should drop below 3.0 MPa).
    - In case of an open contact and the gauge indicates a pressure below 3.0 MPa, replace the high pressure switch. Refer to "Replacing high pressure switch" on page 124.
    - In case of a closed contact and the standing pressure is below 3.0 MPa, check the switching characteristics of the high pressure switch.
      - Recover the refrigerant.
      - Pressurize the refrigerant circuit at 41.7 bar with nitrogen.
      - Measure the switch contacts between the high pressure switch connector: pins 1-2. The switch must be open. Replace the high pressure switch if the contact is not open, refer to "Replacing high pressure switch" on page 124.
      - Reduce the pressure below 3.0 MPa, the contact should close. If it remains open, replace the high pressure switch, refer to "Replacing high pressure switch" on page 124.
- If above checks did not show any abnormality, the E3 fault may be caused by:
- Faulty main board "A1P".
  - Micro power failure

2.4.1.5. High pressure sensor S1NPH

Technical specification		Description	
The pressure sensor is an analogue pressure sensor. The main board "A1P" supplies 5VDC to the pressure sensor. The sensor changes output to main board according to corresponding pressure - refer to graph in step 3 of the procedure		The pressure sensor measures the pressure in the high pressure section of the refrigerant circuit.	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Main PCB A1P, item 4 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 37 in Figure 5-4 on page 162.
Check procedure			
Electrical check			


PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Remove plate work when required, refer to "Basic removal" on page 102.

PROCEDURE

1. Connect a pressure gauge to the pressure service port of the HP/LP gas stop valve, and read the pressure.
2. Start the unit from the user interface in heating mode.
3. Wait till the coil of 4-way valve Y6S is energized.

From the graph below, determine the expected high pressure sensor output signal.



P<sub>H</sub>: High pressure (MPa)


V<sub>H</sub>: Output voltage [high side] VDC

$$P_H = 1.38 V_H - 0.69$$

4. Power the Daikin unit.

	<p><b>INFORMATION</b></p> <p>To know where to plug in the high pressure sensor connector, refer to "Component checklist" on page 163.</p>
--	---

5. Measure the voltage across high pressure sensor connector: pin 1-3 on the PCB; compare the measured voltage with the expected voltage (refer to the graph in step3).



6. In case no voltage is measured across high pressure sensor connector: pin 1-3; do following checks:

**INFORMATION**

If 1 or more checks fail, replace the high pressure sensor.

**Check 1**

1. Check main PCB (refer to "[Main board A1P](#)" on page 82).

**Check 2**

1. Check if the high pressure sensor connector is plugged into the main board "A1P" connector X32A

**Check 3**

1. Measure the voltage across high pressure sensor connector: pin 4-3; the measured voltage must be 5 VDC. If not replace the SUB PCB "A4P" (refer to "[Replacing SUB PCB A4P](#)" on page 146).

2.4.1.6. Low pressure sensor S1NPL

Technical specification		Description	
The pressure sensor is an analogue pressure sensor. The main board "A1P" supplies 5VDC to the pressure sensor. The sensor changes output to main board according to corresponding pressure - refer to graph in step 3 of the procedure		The pressure sensor measures the pressure in the low pressure section of the refrigerant circuit.	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Main PCB A1P, item 4 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 36 in Figure 5-4 on page 162.
Check procedure			
Electrical check			


PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Remove plate work when required, refer to "Basic removal" on page 102.

PROCEDURE

1. In case of a VRV4WC+ heat-pump application, connect a pressure gauge to the pressure service port of the HP/LP gas stop valve, and read the pressure.  
  
In case of a VRV4WC+ heat-recovery application, connect a pressure gauge to the pressure service port of the suction stop valve, and read the pressure.
2. Start the unit from the user interface in cooling mode.
3. Wait till the coil of 4-way valve Y6S is energized.

From the graph below, determine the expected high pressure sensor output signal.



PL: Low pressure (MPa)

VL: Output voltage [high side] VDC


$$P_L = 0.57 V_L - 0.28$$

4. Power the Daikin unit.

**INFORMATION**

To know where to plug in the low pressure sensor connector, refer to "Component checklist" on page 163.

5. Measure the voltage across low pressure sensor connector: pin 2-3 on the PCB; compare the measured voltage with the expected voltage (refer to graph in step 3).



6. In case no voltage is measured across low pressure sensor connector: pin 2-3; do following checks:

**INFORMATION**

If 1 or more checks fail, replace the low pressure sensor.

**Check 1**

1. Check main PCB (refer to "Main board A1P" on page 82).

**Check 2**

1. Check if the low pressure sensor connector is plugged into the main board "A1P" connector X31A

**Check 3**

1. Measure the voltage across low pressure sensor connector: pin 4-3; the measured voltage must be 5 VDC. If not replace the SUB PCB "A4P" (refer to "Replacing SUB PCB A4P" on page 146).

## 2.4.1.7. Inverter board A3P

Technical specification		Description	
The inverter board contains: <ul style="list-style-type: none"> <li>• Diode module: converts 3 phase AC power to a DC voltage = <math>1.73 * ACV</math> (RMS).</li> <li>• Power module: converts DC voltage into PWM output.</li> </ul>		The inverter PCB outputs 3 phase PWM voltage to the compressor motor windings. The target rotation speed is set by main PCB based offset to target saturated pressure.  Rotation speed can be lowered preventively when reaching abnormal level on low pressure, high pressure, current, discharge pipe temperature or inverter temperature.	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Inverter PCB A3P, item 6 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162.
Check procedure			

## Mechanical check

1. Check the inverter board "A3P" for cracks, replace main PCB, refer to ["Replacing inverter board A3P" on page 139](#).
2. Check the inverter board "A3P" for burned components, replace inverter board, refer to ["Replacing inverter board A3P" on page 139](#).
3. If any mechanical damage, replace inverter PCB, refer to ["Replacing inverter board A3P" on page 139](#).

## Electrical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the power supply of the unit with the field supplied circuit breaker.
3. Remove plate work when required (refer to ["Basic removal" on page 102](#)).
4. Open the compressor insulation, refer to ["Removing the compressor jacket" on page 109](#).

**WARNING: RISK OF ELECTROCUTION**

The smoothing capacitor must discharge below 10 VDC before removing the compressor wiring.


5. Measure the 500 VDC check point, refer to ["Component checklist" on page 163](#) and wait until it drops below 10 VDC.

**INFORMATION**

Note the position of the cables on the compressor wire terminals to allow identical wiring during re-installation.

6. Disconnect the Faston connectors U, V and W from the compressor.
7. Using a multimeter in diode measurement, check the compressor inverter board as described in the illustration and table below.

Figure 2-3: Inverter board transistor/diode check



Prior to check, ensure no power Present on board





Table 2-2: Transistor/diode check of compressor inverter

Diode Module Check Method	Diode check		-			Power Module Check Method	Diode check		-		
	DCV		④	⑤	⑥		DCV read out		⑦	⑧	⑨
	+	①	0.4	0.4	0.4		+	③	O.L.	O.L.	O.L.
		②	O.L.	O.L.	O.L.			②	0.4	0.4	0.4
	Diode check		+				Diode check		+		
	DCV		④	⑤	⑥		DCV read out		⑦	⑧	⑨
	-	①	O.L.	O.L.	O.L.		-	③	0.4	0.4	0.4
		②	0.4	0.4	0.4			②	O.L.	O.L.	O.L.

O.L. = Open Loop ( $\infty$ )

**Check connectors reconnected to the compressor**

1. Switch off the Daikin unit via the user interface.
2. Switch off the power supply of the unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Open the compressor insulation, refer to "Removing the compressor jacket" on page 109.
5. Remove the cover from the compressor terminal.



**WARNING: RISK OF ELECTROCUTION**

The smoothing capacitor must discharge below 10 VDC before removing the compressor wiring.

6. Measure the 500 VDC check point, refer to "Component checklist" on page 163 and wait until it drops below 10 VDC.



**INFORMATION**

Note the position of the cables on the compressor wire terminals to allow identical wiring during re-installation.

7. Disconnect the compressor wires and connect the compressor wires to the Inverter Analyzer (SPP number 1368521).



8. Power the Daikin unit.



**WARNING**

Electrical shock hazard. Do not touch live wires.

9. Activate the inverter test (refer to "[Component checklist](#)" on page 163).
10. Check that all LED's on the Inverter Analyzer are blinking 10 times/second; if not, replace the inverter board (refer to "[Replacing inverter board A3P](#)" on page 139).
11. Switch off the power supply of the unit with the field supplied circuit breaker.
12. Wait a few minutes and confirm that the LED's on the Inverter Analyzer are off.  
2 LED's will shortly light up & reduce brightness till the DC voltage is discharged.
13. Disconnect the Inverter Analyzer from the U V W wiring.

**CAUTION**

When wiring the compressor, observe U V W as indicated on the compressor.

**CAUTION**

When above described test on inverter board is correct, first check the compressor motor windings before operating the equipment (refer to "[Compressor](#)" on page 87):

1. Check the correct resistance between U/V/W and
2. No earth leakage (use a Megger minimum 500 VDC) between ground and each U/V/W (minimum 1 MOhm).

14. Reconnect the U V W leads to the compressor.

## 2.4.1.8. Main board A1P

Technical specification		Description	
The main board contains a high voltage circuit (230VAC) output to coils of solenoid valves, and a low voltage circuit for communication (16 VDC), energize relays & expansion valve coils (12 VDC) and processor (5 VDC).		The main PCB judges rotation direction of power supply (L1 & L3 to N), input of temperature and pressure, output to multiple components based on logic of processor.	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Main PCB A1P, item 4 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162.
Check procedure			
Mechanical check			

1. Check the main board "A1P" for cracks, replace main board "A1P", refer to ["Replacing main PCB A1P" on page 141](#).
2. Check the main board "A1P" for burned components, replace main board "A1P", refer to ["Replacing main PCB A1P" on page 141](#).
3. If any mechanical damage, replace main board "A1P", refer to ["Replacing main PCB A1P" on page 141](#).

## Electrical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the power supply to the unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).
4. Switch on the power supply of the unit with the field supplied circuit breaker.
5. Check if the HAP LED is blinking in regular intervals (1 time per second), if not blinking check if low DC voltage present, refer to ["Component checklist" on page 163](#). If low DC voltage check OK, replace the main PCB board, refer to ["Replacing main PCB A1P" on page 141](#).
6. Measure the supply voltage to the main PCB board: there should be  $\pm 230$  V (230 VAC power supply check, refer to ["Component overview of unit" on page 162](#)).
7. If the voltage is not correct check main power supply. If present 400 V (L1-L2-L3) and 230 V (L1-N) go next step. If not, check noise filter "A2P" input and output voltage. If no output voltage, replace noise filter "A2P".
8. Check status of fuses on main board FU1 and FU2. If OK, go to step 10.
9. If fuses damaged, check status of varistors F1S & F2S. If any crack, overvoltage on power supply broke varistors and fuses. Replace main board "A1P"; refer to ["Replacing main PCB A1P" on page 141](#).
10. Check presence 16 VDC at connector X37A on main board "A1P". If no voltage, replace main board "A1P"

2.4.1.9. Thermistors

Technical specification	Description
<p>2 Types of thermistors are NTC type (negative temperature coefficient):</p> <ul style="list-style-type: none"> <li>• Type-1 thermistor = Standard type of thermistor, is used for all thermistors, except “R12T” &amp; “R13T”.</li> <li>• Type-2 thermistor = High temperature thermistor discharge pipe “R12T” &amp; thermistor body “R13T”.</li> <li>• The resistance vs. temperature characteristics is shown in below table “Thermistor resistance / temperature characteristics (type 1 &amp; 2)”.</li> </ul>	<p>The thermistors are used to measure the temperature at multiple locations inside the Daikin unit. The measured temperatures are processed by the main board. All thermistors are connected to the main board, except the “R1T” &amp; “R2T” are connected to the auxiliary board “A4P”.</p>

**Location**

Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Main PCB A1P, item 4 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 21 till 33 (R1T ~R13T) in Figure 5-4 on page 162.

**Check procedure**

**Check with monitoring tool**

1. Switch off the Daikin unit via the user interface.
2. Confirm unit stopped operation.
3. Wait for about 15 minutes before checking value of thermistors.
4. Compare deviation of read out (maximum 5% to ambient temperature).
5. If any thermistor read out shows “out of range”, use the electric check method to judge if change of thermistor (resistance check fails) or main PCB (resistance check pass).
  - out of range if < -47°C or > 108°C.

**Mechanical check**

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Locate the thermistor and check if thermal contact with the piping or ambient is ensured.

**Electrical check**

	<p><b>INFORMATION</b></p>
<p>If a thermistor check fails, replace the thermistor.</p>	

1. Switch off the Daikin unit via the user interface.
2. Switch off the power supply to unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.

4. Based on the error code (& sub-code) (see ["Error code BS and outdoor" on page 28](#)), select the thermistor that must be checked.
5. Measure the temperature of the thermistor using a contact thermometer.

**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

6. Unplug the connector from the appropriate board and measure the resistance between the pins listed in the error code table (see ["Error code BS and outdoor" on page 28](#)).
  - Compare the measured resistance compared to the tables below:
    - Type 1 thermistor, reference point at 20°C = 25kΩ (& vice versa at 25°C = 20kΩ)
    - Type 2 thermistor reference point at 80°C = 25kΩ
7. If the measured resistance does not match the listed value, the thermistor must be replaced. If resistance value matches, replace main board "A1P" (refer to ["Replacing main PCB A1P" on page 141](#)).

**INFORMATION**

All thermistors have a tolerance of 5%.

E.g. R3T - main PCB - connector, see table ["Component overview of unit" on page 162](#) - type 1

- Measured temperature with contact thermometer: 23.1°C.
- Unplug the sensor and measure the resistance, see table ["Component overview of unit" on page 162](#).
- The resistance values are defined by below table "Thermistor resistance / temperature characteristics (type 2)":
  - Resistance at 23°C: 21.85 kΩ.
  - Resistance at 24°C: 20.90 kΩ.
- The measured value 21.86 kΩ is inside the range, thermistor R3T passes the check.


**INFORMATION**

The user interface allows to monitor most thermistors.

If the measured resistance of the thermistor matches the temperature measured with the contact thermometer but the temperature for the corresponding thermistor is not correct on the user interface display, replace applicable PCB.

Table 2-3: Thermistor resistance / temperature characteristics (type 1)

Sensor type 1	
T°C	kΩ
-30	361.772
-25	265.470
-20	196.920
-15	147.569
-10	111.658
-5	85.261
0	65.671
5	50.995
10	39.915
15	31.480
20	25.006
25	20.000
30	16.101
35	13.043
40	10.628
45	8.710
50	7.176
55	5.941
60	4.944
65	4.135
70	3.476
75	2.935
80	2.489
85	2.121
90	1.814
95	1.558
100	1.343
105	1.161




Reference point thermistor



Table 2-4: Thermistor resistance / temperature characteristics (type 2)

Sensor type 2	
T°C	kΩ
-30	3257.371
-25	2429.222
-20	1827.883
-15	1387.099
-10	1061.098
-5	817.933
0	635.083
5	496.571
10	391.007
15	309.951
20	247.270
25	198.467
30	160.224
35	130.070
40	106.152
45	87.073
50	71.770
55	59.474
60	49.518
65	41.417
70	34.792
75	29.350
80	24.859
85	21.136
90	18.038
95	15.449
100	13.277
105	11.440
110	9.890
115	8.579
120	7.465
125	6.516
130	5.704
135	5.007
140	4.408
145	3.891
150	3.443



Reference point thermistor



## 2.4.1.10. Compressor

Technical specification		Description	
Scroll compressor with medium pressure liquid injection.		<p>The compressor sucks the refrigerant gas from the evaporator and discharges to the condenser.</p> <p>The rotation speed is changed by the inverter board "A3P" in function of offset to actual to target saturation temperature</p> <ul style="list-style-type: none"> <li>• in case of cooling: evaporation,</li> <li>• in case of heating: condensation.</li> </ul>	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Item 6 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 1 in Figure 5-4 on page 162
Check procedure			

#### Preliminary check

1. Check if the Daikin unit is connected to earth.
2. Check if the stop valve is open.

#### Mechanical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the power supply to the unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Open the compressor insulation, refer to "Removing the compressor jacket" on page 109.
5. Check if the condition of the compressor dampers and piping is correct.
6. Check the transport plate is slide away from the compressor.

#### Electrical check

1. Switch off the Daikin unit via the user interface.
2. Switch off the power supply to the unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Open the compressor insulation, refer to "Removing the compressor jacket" on page 109.
5. Remove U-V-W wires from compressor.
6. Check the motor windings: U-V-W:  $\pm 0.474\Omega$  (use meter equipped with "Wheatstone bridge" allow read out milli- $\Omega$ . If resistance is outside tolerance 5%, the compressor needs to be replaced.  
Refer to Figure 2-4 on page 88 and Table 2-5 on page 88
7. Megger the compressor using 500 or 1000 VDC, the insulation must be higher than 3 M $\Omega$ . If insulation resistance is less than 3M $\Omega$ , the compressor needs to be replaced.

8. Reconnect the U-V-W wires to the compressor.

Refer to [Figure 2-4 on page 88](#)



**INFORMATION**

Note the position of the cables on the compressor wire terminals to allow identical wiring during re-installation.

9. Close the cover of the motor windings compartment. Mount back the compressor insulation.


10. Switch on power supply to unit.

11. Switch on the unit from the user interface. When compressor operates,

- Measure the U, V, W inverter voltages  
All voltages must be identical, if not, replace the inverter board "A3P" (refer to ["Replacing inverter board A3P" on page 139](#)).
- Measure the current in each phase.  
The current for each phase should be identical (refer to ["Product specific information" on page 163](#)).  
If current is not balanced among the phases, it can be decided to preventively replace the compressor, refer to ["Replacing compressor" on page 114](#).

**Figure 2-4: Compressor motor checking method**

**Prior to check, ensure no power is present on board**



**Table 2-5: Resistance check compressor motor winding**

Resistance check compressor motor winding (ohm +/- 5%)			
JT16KAVDKYR	U	V	W
U		0,47	0,47
V	0,47		0,47
W	0,47	0,47	

## 2.4.1.11. Electronic expansion valve


Technical specification		Description	
<p>The electronic expansion valve has a hermetically sealed body. The coil is slide onto the body. To lock or unlock, turn the coil <math>\pm 45</math>degree.</p> <p>Main board outputs the required pulses to the related coil:            Y1E (Main): 3000 pulses,            Y2E (Sub-cool): 480 pulses,            Y3E (Purge): 480 pulses.</p>		<p>The electronic expansion valve is used:</p> <ul style="list-style-type: none"> <li>To control the flow of refrigerant. Depending on location, the trigger point is sub-cool or superheat.</li> <li>To stop the flow of refrigerant completely when closing (= 0 pulses).</li> </ul>	
Location			
Piping diagram	Wiring diagram	Switch box	Component overview of unit
See "Piping diagram" on page 161.	See "Wiring diagram" on page 159.	See "Switch box" on page 167. Main PCB A1P, item 4 in Figure 5-6 on page 167.	See "Component overview of unit" on page 162. Item 18, 19 and 20 in Figure 5-4 on page 162.
Check procedure			
Mechanical check			

- Switch off the Daikin unit via the user interface.
- Switch off the Daikin unit with the field supplied circuit breaker.
- Switch on the Daikin unit and listen to the expansion valve assembly. If the expansion valve body does not create a latching sound, continue with the electrical check.
- Switch off the Daikin unit via the user interface.
- Switch off the Daikin unit with the field supplied circuit breaker.
- Remove plate work when required (refer to "Basic removal" on page 102).
- Remove the expansion valve coil from the expansion valve body.
- Slide the magnet (tool part N° 99S0038 for small type expansion valve, 999133T for large type expansion valve) over the expansion valve body and gently rotate the magnet to manually operate the expansion valve body clockwise (closing) and counterclockwise (opening).
- If it is not possible to open the expansion valve body with the magnet, the expansion valve body is blocked and the expansion valve body must be replaced (refer to "Replacing expansion valve body" on page 121).

## Electrical check

- Switch off the Daikin unit via the user interface.
- Switch off the Daikin unit with the field supplied circuit breaker.
- Remove plate work when required (refer to "Basic removal" on page 102).
- Check if the electrical connector of the expansion valve coil was correctly connected to the main board "A1P". If not, connect the electrical connector.

5. Disconnect the electrical connector of the expansion valve coil and check the continuity between below pins using a multi meter. It should be ± the same value.
- Connector pin 1-6: connected
  - Connector pin 2-6: connected
  - Connector pin 3-6: connected
  - Connector pin 4-6: connected



6. If one or more of the windings have no continuity, replace the expansion valve coil, "[Replacing expansion valve coil](#)" on [page 122](#).

Plug no.	Coil no.	Wire color	
		480 pulses	3000 pulses
1	1	orange	white
2	2	red	yellow
3	3	yellow	orange
4	4	black	blue
6	com	grey	red
Resistance		46 Ω (±3 Ω)	150 Ω (±15 Ω)
Symbol	Color plug	Connector reference	Location (board)
Y1E	Black	X21A	A1P
Y2E	White	X22A	A1P
Y3E	Yellow	X25A	A1P

### 2.4.2. System

Not applicable.

### 2.4.3. Others

Not applicable.

## 2.5. Other capacity range

Not applicable.



## Part 3. Repair

This part contains the following chapters:

Refrigerant repair procedures .....	93
Service tools .....	100
Unit specific repair procedures .....	101

### 3.1. Refrigerant repair procedures

Overview:


Refrigerant piping handling .....	93
Refrigerant recovery procedure.....	94
Preparation for repair .....	97
Piping repair procedures .....	97
Indoor unit .....	101
RWEYQ-T9 .....	102

#### 3.1.1. Refrigerant piping handling

- Make sure the applied pressure is never higher than the unit design pressure as indicated on the nameplate (PS).
- Work according the F-gas regulation and/or local regulations.
- Make sure the correct amount of refrigerant according the F-gas regulation label on the unit (factory + additional where required) is charged after repair.
- Make sure to use the appropriate equipment and tools according to the refrigerant and unit type.
- Charge non-azeotropic refrigerant (e.g. R-410A) always in a liquid state.
- Make sure to use a digital scale (no charging cylinder).
- Execute correct vacuum drying procedure after repair work:
  - $\leq$  -100,7 kPa or 5 Torr or 760 mmHg for at least 1 hour.
  - Connect the unit according the available service ports, refer to "[Refrigerant recovery procedure](#)" on page 94.
  - Use related field setting where necessary to open expansion valve/solenoid valve.

### 3.1.2. Refrigerant recovery procedure

1. Set outdoor 2-21-1, BS3 "return" press 2x => indication "t01.  
Refrigerant recovery mode (2-21-1)




Remark:

If power supply is not available, open expansion valves RWEYQ-T9 by using the special service tool "permanent magnet":

- For Y1E: magnet diameter 22.0 mm (tool part N° 999133T),
- For Y2E & Y3E: magnet diameter 17.5 mm (tool part N° 99S0038).

3.1.2.1. Setup without BS units

2. Connect vacuum pump, manifold, recovery unit and refrigerant bottle to layout below.




Purpose	Service port outdoor			Valve manifold				BYP	Valve recovery unit			Valve bottle	Operate	
	OL	OS	OD	L	V	R	H		RC1	RC2	RC3	RB	VP	RU
Connections	C	C	C	C	C	C	C	C	C	C	Rec	C	×	×
Start Vacuuming	C	C	C	O	O	O	O	O	O	O	Rec	C	✓	×
End vacuuming	C	C	C	O	C	O	O	C	O	O	Rec	O	×	×
Recover liquid	O	C	O	C	C	O	O	C	1/2	O	Rec	O	×	✓
Recover gas	O	C	O	O	C	O	O	C	O	O	Rec	O	×	✓
Purge	O	C	O	C	C	C	C	C	*	O	Pur	O	×	✓
Disconnect	C	C	C	C	C	C	C	C	C	C	Rec	C	×	×
End recovery	Press button BS3 "return" 1x => indication blank (normal)											×	×	

OL= outdoor liquid, OS= outdoor suction, OD= outdoor discharge, C= closed, O= open, 1/2: between indication "liquid" & "gas", Rec= recovery, Pur: purge, VP= vacuum pump, RU= recovery unit, \* Change Inlet valve RC1 gradually to "purge" when pressure drops

3.1.2.2. Setup including BS units

1. Connect vacuum pump, manifold, recovery unit and refrigerant bottle to layout below.




	Service port outdoor			Valve manifold					BYP	Valve recovery unit			Valve bottle	Valve HP/LP	Operate	
	OL	OS	OD	L	V	R	H	RC1		RC2	RC3	RB			DP	VP
Purpose	OL	OS	OD	L	V	R	H	BYP	RC1	RC2	RC3	RB	DP	VP	RU	
Connections	C	C	C	C	C	C	C	C	C	C	Rec	C	C	×	×	
Start Vacuuming	C	C	C	O	O	O	O	O	O	O	Rec	C	O	✓	×	
End vacuuming	C	C	C	O	C	O	O	C	O	O	Rec	O	O	×	×	
Recover liquid	O	O	O	C	C	O	O	C	1/2	O	Rec	O	C	×	✓	
Recover gas	O	O	O	O	C	O	O	C	O	O	Rec	O	O	×	✓	
Purge	O	O	O	C	C	C	C	C	*	O	Pur	O	C	×	✓	
Disconnect	C	C	C	C	C	C	C	C	C	C	Rec	C	C	×	×	
End recovery	Press button BS3 "return" 1x => indication blank (normal)													×	×	
OL= outdoor liquid, OS= outdoor suction, OD= outdoor discharge, C= closed, O= open, 1/2: between indication "liquid" & "gas", Rec= recovery, Pur: purge, VP= vacuum pump, RU= recovery unit, * Change Inlet valve RC1 gradually to "purge" when pressure drops																



3.1.3.1. Setup without BS units

1. Connect vacuum pump, manifold, Nitrogen cylinder to layout below.




Purpose	Service port outdoor			Valve manifold				N2
	OL	OS	OD	L	V	R	H	BYP
Vacuuming	C	C	C	O	O	O	O	O
Pressurize	C	C	C	O	C	O	O	C

OL= outdoor liquid pressure, OS= outdoor suction pressure, OD= outdoor dual pressure

3.1.3.2. Setup including BS units

1. Connect vacuum pump, manifold, Nitrogen cylinder to layout below.



Purpose	Service port outdoor			Valve manifold				N2
	OL	OS	OD	L	V	R	H	BYP
Vacuuming	O	O	O	O	O	O	O	C
Pressurize	O	O	O	O	C	O	O	O

OL= outdoor liquid pressure, OS= outdoor suction pressure, OD= outdoor dual pressure

3.1.4. Piping repair procedures


- Make sure to cover open pipe ends during repair work so no dust or moisture can enter.
- Make sure to re-apply insulation removed during repair.
- Pipe expansion / flare making:
  - Remove any burrs on the cut surface and use correct tool such as reamer or scraper (note that excessive deburring can thin the pipe walls and cause cracking of the pipe).
  - Make sure the flare connections at the indoor unit(s) has (have) the correct size (use a flare gauge).
  - Make sure no particles remain in the piping.
  - Apply just a drop of refrigerant oil on the inner surface of the flare.
  - Make sure the flare connection is tightened with the correct torque (torque values refer to installation manual).
- Brazing:
  - Use correct brazing tool.
  - Use a phosphor copper filler metal (silver composition of 0 to 2%). Do not use flux material.
  - Flush the piping before brazing with nitrogen to avoid oxidation of the inside of the copper tubes (nitrogen purity ≥ 99,99%).

## 3.2. Service tools

For an overview of the applicable service tools, please check the Daikin Business Portal of your country.

Country	Link Daikin Business Portal
Belgium	<a href="https://my.daikin.eu/dab/nl_BE/home.html">https://my.daikin.eu/dab/nl_BE/home.html</a> <a href="https://my.daikin.eu/dab/fr_BE/home.html">https://my.daikin.eu/dab/fr_BE/home.html</a>
Central Europe	<a href="https://my.daikin.eu/dace-at/de_AT/home.html">https://my.daikin.eu/dace-at/de_AT/home.html</a>
France	<a href="https://my.daikin.eu/daf/fr_FR/home.html">https://my.daikin.eu/daf/fr_FR/home.html</a>
Germany	<a href="https://my.daikin.eu/dag/de_DE/home.html">https://my.daikin.eu/dag/de_DE/home.html</a>
Middle East & Africa	<a href="https://my.daikin.eu/dame/en_US/home.html">https://my.daikin.eu/dame/en_US/home.html</a>
Netherlands	<a href="https://my.daikin.eu/danl/nl_NL/home.html">https://my.daikin.eu/danl/nl_NL/home.html</a>
Poland	<a href="https://my.daikin.eu/content/dapo/pl_PL/home.html">https://my.daikin.eu/content/dapo/pl_PL/home.html</a>
Portugal	<a href="https://my.daikin.eu/dapt/pt_PT/home.html">https://my.daikin.eu/dapt/pt_PT/home.html</a>
Spain	<a href="https://my.daikin.es/dacs/es_ES/home.html">https://my.daikin.es/dacs/es_ES/home.html</a>
Sweden	<a href="https://my.daikin.eu/dasw/sv_SE/home.html">https://my.daikin.eu/dasw/sv_SE/home.html</a>
United Kingdom	<a href="https://my.daikin.eu/dauk/en_GB/home.html">https://my.daikin.eu/dauk/en_GB/home.html</a>
Other	<a href="https://my.daikin.eu/content/denv/en_US/login.html">https://my.daikin.eu/content/denv/en_US/login.html</a>

In case you do not have yet access to the Daikin Business portal, please contact the Daikin distributor in your country to be registered and receive a valid password.



To observe and judge operation condition of system, the input and output signals of RWEYQ-T9 and indoor units can be monitored by using following service tools:

- D-checker. The software and the extra required data labels can be found in the portal - Applications - Software finder - in the "Search" window: checker. Choose "D-checker".
- Checker typelll. Upgrade the software by included patch to operate minimum software version 1-60. Full software installation (if first time installing CheckerIII software) and patch can be found in the portal - Applications - Software finder - in the "Search" window: checker. Choose "CheckerIII".

You will then find a button "Service tools" which gives you an overview on which service tool to use for which product. Also additional information on the service tool (instruction, latest software) can be found there.

## 3.3. Unit specific repair procedures

### Overview:

Indoor unit .....	101
RWEYQ-T9 .....	102
Basic removal .....	102
Replacing thermistor .....	110
Replacing 4-way valve body .....	111
Replacing 4-way valve coil .....	113
Replacing compressor .....	114
Replacing oil separator .....	117
Replacing crankcase heater .....	119
Replacing AC fan inverter cooling .....	120
Replacing expansion valve body .....	121
Replacing expansion valve coil .....	122
Replacing high pressure sensor .....	123
Replacing high pressure switch .....	124
Replacing solenoid valve .....	125
Replacing solenoid valve coil .....	127
Replacing low pressure sensor .....	128
Replacing liquid receiver .....	129
Replacing accumulator .....	131
Replacing plate heat exchanger H <sub>2</sub> O .....	133
Replacing heat exchanger inverter cooling .....	135
Replacing reactor .....	137
Replacing transformer .....	138
Replacing inverter board A3P .....	139
Replacing main PCB A1P .....	141
Replacing noise filter PCB A2P .....	144
Replacing SUB PCB A4P .....	146
Replacing Adapter PCB A8P .....	147
Branch Selector (BS) box .....	148
Replace control board BS box .....	148
Replacing expansion valve coil BS box .....	149

### 3.3.1. Indoor unit

Not applicable.

### 3.3.2. RWEYQ-T9

#### 3.3.2.1. Basic removal

##### 3.3.2.1.1 Removing main front plate

###### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.

###### PROCEDURE

###### Removal

1. Loosen and remove the 7 screws (1) that fix the main front plate (2).
2. Lift the main front plate (2) and push it slightly backwards, before lifting and removing it from the unit.

**Figure 3-1: Removing the main front plate**



###### Installation

1. Proceed in reverse order.

### 3.3.2.1.2 Removing PHE front plate

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102](#).

#### PROCEDURE

##### Removal

1. Loosen and remove the 5 screws (1) that fix the PHE front plate (2).
2. Remove the PHE front plate (2) from the unit.

**Figure 3-2: Removing the PHE front plate**



##### Installation

1. Proceed in reverse order.

### 3.3.2.1.3 Removing top plate

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.

#### PROCEDURE

##### Removal

1. Loosen and remove the 3 screws (1) that fix the top plate (2).
2. Lift the top plate (2) at the front and remove it from the unit.

**Figure 3-3: Removing the top plate**



##### Installation

1. Proceed in reverse order.

### 3.3.2.1.4 Removing left side plate

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the PHE front plate, refer to ["Removing PHE front plate" on page 103](#).
4. Remove the top plate, refer to ["Removing top plate" on page 104](#).

#### PROCEDURE

##### Removal

1. Loosen the 5 screws (1) that fix the left side plate (2).
2. Lift the left side plate (2) and remove it from the unit.

*Figure 3-4: Removing the left side plate*



##### Installation

1. Proceed in reverse order.

### 3.3.2.1.5 Removing right side plate

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the top plate, refer to "Removing top plate" on page 104.

#### PROCEDURE

##### Removal

1. Loosen the 4 screws (1) that fix the right side plate (2).
2. Lift the right side plate (2) and remove it from the unit.

**Figure 3-5: Removing the right side plate**



##### Installation

1. Proceed in reverse order.

### 3.3.2.1.6 Lowering switch box

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102](#).

#### PROCEDURE

##### Removal

1. Loosen and remove the 2 screws (1) that fix the switch box (2).




#### INFORMATION

Use a solid support with a height of approximately 8 inch.

2. Place a support (3) for the switch box in front of the switch box (2).
3. Lower the switch box (2) until it rests on the support (3).

**Figure 3-6: Lowering the switch box**



##### Installation

1. Proceed in reverse order.

### 3.3.2.1.7 Opening switch box

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to "[Removing main front plate](#)" on page 102.

#### PROCEDURE

##### Removal

1. Loosen and remove the 4 screws (1) that fix the switch box cover (2).
2. Lift and remove the switch box cover (2).

*Figure 3-7: Opening the switch box*



##### Installation

1. Proceed in reverse order.

### 3.3.2.1.8 Removing the compressor jacket

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102.](#)
4. Lower the switch box, refer to ["Lowering switch box" on page 107.](#)

#### PROCEDURE

##### Removal

1. Detach the velcro strips (1).
2. Remove the top jacket (2) from the compressor.
3. Detach the velcro strips (1) and remove the body jacket (3) from the compressor.

**Figure 3-8: Removing the compressor jacket**



##### Installation

1. Proceed in reverse order.

### 3.3.2.2. Replacing thermistor

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, see "Basic removal" on page 102.

#### PROCEDURE

##### Removal

1. Locate thermistor that needs to be replaced, see "Component overview of unit" on page 162.
2. Cut the cable ties (1) that fix the insulation (3) and the thermistor wire (2).
3. Cut the insulation (3) and remove it.
4. Pull the clip (5) that fixes the thermistor (6).
5. Remove the thermistor (6) from the thermistor holder (4).

**Figure 3-9: Replacing a thermistor**



##### Installation

1. Proceed in reverse order.

### 3.3.2.3. Replacing 4-way valve body

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Recover the refrigerant, refer to "[Refrigerant recovery procedure](#)" on page 94.
4. Remove plate work when required, refer to "[Basic removal](#)" on page 102.
5. Remove the 4-way valve coil, refer to "[Replacing 4-way valve coil](#)" on page 113.
6. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
7. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Remove any parts that block the way to the 4-way valve.
2. Cut the 3 pipes connected to the 4-way valve pipes (1).



#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.


3. Remove the 4-way valve (2).
4. Supply nitrogen to the piping circuit.
5. Heat the 4-way valve pipes (1) using an oxygen acetylene torch.
6. When the solder is liquid, remove the 4-way valve pipes (1).



#### INFORMATION

The stop end plug must be installed on the spare 4-way valve.

7. Heat the stop end plug (3) using an oxygen acetylene torch.
8. When the solder is liquid, remove the stop end plug (3).

**Figure 3-10: Removing the 4-way valve body****Installation****WARNING**

Overheating the 4-way valve will damage or destroy it.

1. Wrap a wet rag around the 4-way valve (2).
2. Proceed in reverse order.

### 3.3.2.4. Replacing 4-way valve coil

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Open the switch box, refer to "Basic removal" on page 102.

#### PROCEDURE

##### Removal

1. Loosen and remove the screw (1) that fixes the 4-way valve coil (2).
2. Cut the cable ties that fix the 4-way valve coil wiring.




#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

3. Unplug 4-way valve connector from PCB.
4. Remove the 4-way valve coil from the 4 way valve.

**Figure 3-11: Removing the 4-way valve coil**



##### Installation

1. Proceed in reverse order.

### 3.3.2.5. Replacing compressor

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Recover the refrigerant, refer to "[Refrigerant recovery procedure](#)" on page 94.
4. Remove plate work when required, refer to "[Basic removal](#)" on page 102.
5. Lower the switch box, refer to "[Lowering switch box](#)" on page 107.
6. Remove the compressor jacket, refer to "[Removing the compressor jacket](#)" on page 109.
7. Remove the crankcase heater, refer to "[Replacing crankcase heater](#)" on page 119.
8. Remove any part that blocks the way to the compressor.
9. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
10. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Remove the terminal cover (1).
2. Take a picture of the wiring and unplug the compressor wiring (2).
3. Cut the cable ties (3) that fix the insulation (4).
4. Slide the insulation (4) upwards.
5. Remove the thermistor (5) from the thermistor holder, put the thermistor away from the compressor.
6. Remove the clip (6) from the thermistor holder.
7. Loosen and remove the screw (7) that fixes the clamp (8).
8. Loosen and remove the screw (9) that fixes the clamp (10).



#### INFORMATION

The clamp (12) must be installed on the spare compressor.

9. Loosen and remove the screws (11) that fix the clamp (12).
10. Using a pipe cutter, cut the 3 compressor pipes (13) below the soldered joint.
11. Loosen and remove the 3 bolts (15) that fix the compressor (14).
12. Remove the compressor (14).
13. Remove the dampers (16) with bushings (17) from the compressor (14).




#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

14. Supply nitrogen to the piping circuit.

15. Heat the 3 compressor pipes (13) using an oxygen acetylene torch.
16. When the solder is liquid, remove the 3 compressor pipes (13).
17. Cut the nitrogen supply when the piping has cooled down.

Figure 3-12: Removing the compressor



- |                      |                             |
|----------------------|-----------------------------|
| 1. Terminal cover    | 10. Clamp                   |
| 2. Compressor wiring | 11. Screw                   |
| 3. Cable ties        | 12. Clamp                   |
| 4. Insulation        | 13. Compressor pipe         |
| 5. Thermistor        | 14. Compressor              |
| 6. Clip              | 15. Bolt                    |
| 7. Screw             | 16. Dampers                 |
| 8. Clamp             | 17. Bushing                 |
| 9. Screw             | 18. Compressor wiring label |

## Installation

	<b>CAUTION</b>
The oil in the compressor is hygroscopic. Remove the caps from the compressor piping as late as possible.	
	<b>INFORMATION</b>
Before installing a new compressor, determine the cause of the compressor failure and take all required corrective actions.	
	<b>INFORMATION</b>
If the dampers are worn, replace the dampers. The bushings inside the dampers are recuperated for use with the new dampers.	
	<b>INFORMATION</b>
Install the compressor sound insulation in the same location.	

1. When installing the new compressor, remove the caps from the compression pipe and the suction pipe as late as possible.
2. Check damper status, replace when worn.
3. First install the 3 (new) dampers (without the bushings) on the new compressor.
4. Install the 3 bushings (17) in the dampers.
5. When soldering the compressor pipes, cover the compressor pipes with a wet cloth to prevent overheating the compressor (and the oil in the compression pipe).
6. Reconnect the compressor wires as indicated on the compressor wiring label (18).
7. Proceed in reverse order.

### 3.3.2.6. Replacing oil separator

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Recover the refrigerant, refer to "[Refrigerant recovery procedure](#)" on page 94.
4. Remove plate work when required, refer to "[Basic removal](#)" on page 102.
5. Lower the switch box, refer to "[Lowering switch box](#)" on page 107.
6. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
7. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Loosen and remove the 3 bolts (4) that fix the oil separator (6).
2. Loosen and remove the 2 screws (5) that fix the oil separator (6).
3. Using a pipe cutter, cut the oil separator pipe (1) below the soldered joint.




#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

4. Supply nitrogen to the piping circuit.
5. Heat and separate the oil separator pipe (2) without damaging it.
6. Heat and separate the oil separator pipe (3) without damaging it.
7. Remove the oil separator pipe.
8. Remove the oil separator (6).
9. Heat the oil separator pipe (1) using an oxygen acetylene torch.
10. When the solder is liquid, remove the oil separator pipe (1).

Figure 3-13: Removing the oil separator



- 1. Liquid receiver pipe
- 2. Liquid receiver pipe
- 3. Liquid receiver pipe

- 4. Bolt
- 5. Screw
- 6. Oil separator

**Installation**

- 1. Proceed in reverse order.

### 3.3.2.7. Replacing crankcase heater

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Lower the switch box, refer to "Lowering switch box" on page 107.
5. Open but do not remove the compressor jacket, refer to "Removing the compressor jacket" on page 109.

#### PROCEDURE

##### Removal



#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

1. Unplug crankcase heater connector from PCB.
2. Detach the spring (1) that fixes the crankcase heater (2) on the compressor.
3. Cut all cable ties that fix the crankcase heater wiring.
4. Remove the crankcase heater (2).

Figure 3-14: Removing the crankcase heater



##### Installation



#### INFORMATION

Replace all cable ties that were cut during removal.

1. Proceed in reverse order.

### 3.3.2.8. Replacing AC fan inverter cooling

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Open the switch box, refer to "Opening switch box" on page 108.

#### PROCEDURE

##### Removal

1. Loosen the 7 screws (1) that fix reactor plate (2) to the switch box (3).
2. Temporarily attach the reactor plate (2) to the switch box (3) using a cable tie (4).
3. Loosen the 4 screws (7) that fix the AC fan (6) to the switch box (3).
4. Disconnect the 2 Faston connectors (5) from the AC fan (6).
5. Remove the AC fan (6) from the reactor plate (2).

**Figure 3-15: Removing the AC fan inverter cooling**



##### Installation

1. Proceed in reverse order.

### 3.3.2.9. Replacing expansion valve body

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Recover the refrigerant (refer to "Refrigerant recovery procedure" on page 94).
5. Remove the expansion valve coil (refer to "Replacing expansion valve coil" on page 122).
6. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
7. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Cut the 2 expansion valve pipes (1).
2. Remove the expansion valve (2).




#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

3. Supply nitrogen to the piping circuit.
4. Using an oxygen acetylene torch, heat the 2 expansion valve pipes (1).
5. When the solder material is liquid, pull the 2 expansion valve pipes (1).
6. Cut the nitrogen supply when the piping has cooled down.

**Figure 3-16: Removing the expansion valve**



##### Installation

1. Wrap a wet rag around the expansion valve (2).



#### WARNING

Overheating the expansion valve will damage or destroy it.

2. Proceed in reverse order.

### 3.3.2.10. Replacing expansion valve coil

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).

#### PROCEDURE

##### Removal

1. Pull the expansion valve coil (1) to remove it from the expansion valve body (2).
2. Cut all cable ties that fix the expansion valve coil wiring.




#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

3. Unplug the expansion valve coil connector, see ["Component checklist" on page 163](#).

**Figure 3-17: Removing expansion valve coil**



##### Installation



#### INFORMATION

Replace all cable ties that were cut during removal.

1. Proceed in reverse order.
2. When installing the expansion valve coil (1), lock it on the expansion valve body (2).

### 3.3.2.11. Replacing high pressure sensor

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).

#### PROCEDURE

##### Removal

1. Unplug the high pressure sensor connector, refer to ["Component checklist" on page 163](#).
2. Cut the cable ties that fix the high pressure sensor wiring.




#### CAUTION

The nut (1) must be locked to prevent damage to the piping.

3. Lock the nut (1) with a 14 mm spanner.
4. Loosen and remove the high pressure sensor (2) with a 9/16" spanner.

**Figure 3-18: Removing high pressure sensor**



1. Nut

2. High pressure sensor

##### Installation



#### CAUTION

The nut (1) must be locked to prevent damage to the piping.

1. Proceed in reverse order.

### 3.3.2.12. Replacing high pressure switch

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "Basic removal" on page 102.
4. Recover the refrigerant, refer to "Refrigerant recovery procedure" on page 94.
5. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
6. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Unplug the high pressure switch Faston connector (1).

	<p><b>CAUTION</b></p> <p>The maximum applied Nitrogen pressure must not exceed 0.02 MPa.</p>
---	--

2. Supply nitrogen to the piping circuit.
3. Heat the high pressure switch pipe (2) using an oxygen acetylene torch.
4. When the solder is liquid, pull the pressure switch (3).
5. Cut the nitrogen supply when the piping has cooled down.

**Figure 3-19: Removing high pressure switch**

	<p>1</p> <p>3</p> <p>2</p>
<p>1. Faston connector</p> <p>2. High pressure switch pipe</p>	<p>3. High pressure switch</p>

##### Installation

	<p><b>CAUTION</b></p> <p>Overheating the high pressure switch will damage or destroy it.</p>
---	--

1. Wrap a wet rag around the high pressure sensor.
2. Proceed in reverse order.

### 3.3.2.13. Replacing solenoid valve

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).
4. Recover the refrigerant, refer to ["Refrigerant recovery procedure" on page 94](#).
5. Remove solenoid valve coil, refer to ["Replacing solenoid valve coil" on page 127](#).
6. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
7. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal


1. Cut the solenoid valve body pipes (1).
2. Remove the solenoid valve body (2).



#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

3. Supply nitrogen to the piping circuit.
4. Using an oxygen acetylene torch, heat the solder connections of the solenoid valve body pipes (1).
5. When the solder material is liquid, pull the solenoid valve body pipes (1).
6. Cut the nitrogen supply when the piping has cooled down.

**Figure 3-20: Removing the solenoid valve body****Installation****WARNING**

Overheating the solenoid valve body (2) will damage or destroy it.

1. Wrap a wet rag around the solenoid valve body (2).
2. Proceed in reverse order.

### 3.3.2.14. Replacing solenoid valve coil

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102.](#)

#### PROCEDURE

##### Removal

1. Loosen and remove the screw (1) that fixes the solenoid valve coil (2) to the solenoid valve (3).
2. Remove the solenoid valve coil (2) from the solenoid valve (3).
3. Cut all tie wraps that fix the solenoid valve coil (2) wiring.




#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

4. Unplug the solenoid valve connector from the PCB, see ["Component checklist" on page 163.](#)

**Figure 3-21: Removing the solenoid valve coil**



#### Installation



#### INFORMATION

Replace all tie wraps that were cut during removal.

1. Proceed in reverse order.

### 3.3.2.15. Replacing low pressure sensor

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).

#### PROCEDURE

##### Removal

1. Unplug the low pressure sensor connector, refer to ["Component checklist" on page 163](#).
2. Cut the cable ties that fix the high pressure sensor wiring.




#### CAUTION

The nut (1) must be locked to prevent damage to the piping.

3. Lock the nut (1) with a 14 mm spanner.
4. Loosen and remove the low pressure sensor (2) with a 9/16" spanner.

**Figure 3-22: Removing low pressure sensor**



1. Nut

2. Low pressure sensor

##### Installation

1. Proceed in reverse order.



#### CAUTION

The nut (1) must be locked to prevent damage to the piping.

### 3.3.2.16. Replacing liquid receiver

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to "[Refrigerant recovery procedure](#)" on page 94.
4. Lower the switch box, refer to "[Lowering switch box](#)" on page 107.
5. Recover the refrigerant, refer to "[Refrigerant recovery procedure](#)" on page 94.
6. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
7. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Loosen and remove the 2 screws (3) that fix the bracket (4) to the liquid receiver (2).
2. Loosen and remove the 2 screws (6) that oil separator to the liquid receiver (2).
3. Loosen and remove the 4 screws (5) that fix the liquid receiver (2).
4. Using a pipe cutter cut the 2 pipes (1) between soldering joint and the liquid receiver (2).
5. Using a pipe cutter cut the pipe (7) between soldering joint and the liquid receiver (2).
6. Remove the liquid receiver (2).



#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

7. Supply nitrogen to the piping circuit.
8. Heat the 3 pipes (1, 7) using an oxygen acetylene torch.
9. When the solder is liquid, remove the 3 oil separator pipes (1, 7).
10. Cut the nitrogen supply when the piping has cooled down.

Figure 3-23: Removing the liquid receiver



- 1. Liquid receiver pipe
- 2. Liquid receiver
- 3. Screw
- 4. Bracket

- 5. Screw
- 6. Screw
- 7. Liquid receiver pipe

**Installation**

- 1. Proceed in reverse order.

### 3.3.2.17. Replacing accumulator

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).
4. Lower the switch box, refer to ["Lowering switch box" on page 107](#).
5. Recover the refrigerant, refer to ["Refrigerant recovery procedure" on page 94](#).



#### CAUTION

The solenoid valve and coil (1) will be re-installed after replacing the accumulator.  
Do not cut the solenoid valve pipes, cut the oil return accumulator pipe.

6. Remove the solenoid valve, refer to ["Replacing solenoid valve" on page 125](#).
7. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
8. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Using a pipe cutter, cut the 2 accumulator pipes (2) below the soldered joint.
2. Loosen the 3 screws (3) that fix the accumulator (4).
3. Remove the accumulator (4).




#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

4. Supply nitrogen to the piping circuit.
5. Heat the 2 accumulator pipes (2) using an oxygen acetylene torch.
6. When the solder is liquid, remove the 2 accumulator pipes (2).
7. Cut the nitrogen supply when the piping has cooled down.

Figure 3-24: Removing the accumulator



**Installation**

1. Proceed in reverse order.

### 3.3.2.18. Replacing plate heat exchanger H<sub>2</sub>O

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).
4. Recover the refrigerant, refer to ["Refrigerant recovery procedure" on page 94](#).
5. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
6. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Isolate the plate heat exchanger H<sub>2</sub>O (1) from the water circuit.
2. Drain the water from the plate heat exchanger H<sub>2</sub>O (1).
3. Lift and detach the plate heat exchanger sub-Cool (2) from the plate heat exchanger H<sub>2</sub>O plate (5).
4. Loosen and remove the 10 screws (3) that fix the plate heat exchanger H<sub>2</sub>O plate (5).
5. Loosen and remove the 2 bolts and washers (4) that fix the plate heat exchanger H<sub>2</sub>O (1) to the plate heat exchanger H<sub>2</sub>O plate (5).
6. Remove the plate heat exchanger H<sub>2</sub>O plate (5).



#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

7. Supply nitrogen to the piping circuit.
8. Heat the 2 plate heat exchanger H<sub>2</sub>O pipes (6) using an oxygen acetylene torch.
9. When the solder is liquid, disconnect the 2 plate heat exchanger H<sub>2</sub>O pipes (6).
10. Remove the plate heat exchanger H<sub>2</sub>O (1) with the 2 plate heat exchanger H<sub>2</sub>O pipes (6).
11. Cut the nitrogen supply when the piping has cooled down.
12. Separate the 2 plate heat exchanger H<sub>2</sub>O pipes (6) from the plate heat exchanger H<sub>2</sub>O (1).

Figure 3-25: Removing the plate heat exchanger



- 1. Plate heat exchanger H<sub>2</sub>O
- 2. Plate heat exchanger sub-cool
- 3. Screws

- 4. Nut & washer
- 5. Plate heat exchanger H<sub>2</sub>O plate
- 6. Plate heat exchanger H<sub>2</sub>O pipe

**Installation**

1. Proceed in reverse order.

### 3.3.2.19. Replacing heat exchanger inverter cooling

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove plate work when required, refer to ["Basic removal" on page 102](#).
4. Recover the refrigerant, refer to ["Refrigerant recovery procedure" on page 94](#).
5. Connect a nitrogen hose to the gas service ports (HP/LP and suction).
6. Attach a hose with core-depressor to the liquid service port to allow the release of the nitrogen.

#### PROCEDURE

##### Removal

1. Loosen and remove the 6 screws (2) that fix the heat exchanger inverter cooling (1).
2. Loosen and remove the 2 screws (3) that fix the bracket (4).
3. Using a pipe cutter cut the 2 heat exchanger inverter cooling pipes (5).
4. Remove the heat exchanger inverter cooling (1).




#### CAUTION

The maximum applied Nitrogen pressure must not exceed 0.02 MPa.

5. Supply nitrogen to the piping circuit.
6. Heat the 2 heat exchanger inverter cooling pipes (5) using an oxygen acetylene torch.
7. When the solder is liquid, remove the 2 heat exchanger inverter cooling pipes (5).
8. Cut the nitrogen supply when the piping has cooled down.

Figure 3-26: Removing the heat exchanger inverter cooling



**Installation**

1. Proceed in reverse order.

### 3.3.2.20. Replacing reactor

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102.](#)
4. Open the switch box, refer to ["Opening switch box" on page 108.](#)

#### PROCEDURE

##### Removal

1. Loosen and remove the 2 screws (1) that fix the reactor wiring.
2. Loosen the 4 screws (2) that fix the reactor (3) to the switch box (4).

**Figure 3-27: Removing the reactor**



##### Installation

1. Proceed in reverse order.

### 3.3.2.21. Replacing transformer

#### PRELIMINARY ACTIONS


1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102.](#)
4. Open the switch box, refer to ["Opening switch box" on page 108.](#)

#### PROCEDURE

##### Removal

1. Unplug the 2 connectors (1).
2. Loosen the 4 screws (2) that fix the transformer (3) to the switch box (4).

**Figure 3-28: Removing the transformer**



##### Installation

1. Proceed in reverse order.

### 3.3.2.22. Replacing inverter board A3P

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102.](#)
4. Open the switch box, refer to ["Opening switch box" on page 108.](#)

#### PROCEDURE

##### Removal



#### WARNING: RISK OF FIRE

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

1. Unplug all connectors (1) from the inverter board (2), refer to ["Component checklist" on page 163.](#)
2. Remove the 8 screws (6) that fix the wiring to the inverter board (2).
3. Remove the wiring from the cable clamps (5).
4. Remove the 5 screws (3) that fix the inverter board (2).
5. Remove the inverter board (2) from the switch box (7).




#### INFORMATION

The jumper must be plugged on the spare inverter board, refer to ["Component checklist" on page 163.](#)

6. Unplug the jumper (4) from the inverter board (2).

Figure 3-29: Removing the inverter board A3P



**Installation**

1. Proceed in reverse order.

### 3.3.2.23. Replacing main PCB A1P

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102.](#)
4. Open the switch box, refer to ["Opening switch box" on page 108.](#)

#### PROCEDURE

##### Removal

**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.


1. Unplug all connectors (1) from the main PCB (2), refer to ["Component checklist" on page 163.](#)
2. Remove the screws (3) that fix the wiring to the main PCB (2).
3. Unlatch all PCB stand-offs (4) that fix the main PCB (2).
4. Remove the main PCB (2) from the switch box (5).

**INFORMATION**

The jumper must be plugged on the spare main PCB, refer to ["Component checklist" on page 163.](#)

5. Unplug the jumper (6) from the main PCB (2).

Figure 3-30: Removing the main PCB A1P



- 1. Connector
- 2. Main PCB
- 3. Screw
- 4. PCB stand-off
- 5. Switch box
- 6. Jumper

**Installation**

1. Proceed in reverse order.
2. Set dip switch on main PCB "A1P" as follows:  
Ensure to change dip switches without power supply to Main PCB "A1P"

Table 3-6: DIP switch setting spare part PCB RWEYQ-T9Y1B (pcb ref. EB15004-14)

Model-name	Set	DS1				DS2				Spare part only
		-1	-2	-3	-4	-1	-2	-3	-4	Setting method dip switches
RWEYQ8T9Y1B	ON									DS2-2: ON (up)
	OFF									other dip switches OFF (down)
RWEYQ10T9Y1B	ON									DS2-3: ON (up)
	OFF									other dip switches OFF (down)
RWEYQ12T9Y1B	ON									DS2-2 + DS2-3: ON (up)
	OFF									other dip switches OFF (down)
RWEYQ14T9Y1B	ON									DS2-4: ON (up)
	OFF									other dip switches OFF (down)

3. If you turn the power back on, perform a re-initialization of the communication: hold the BS3 "Return" button for minimum 5 seconds. Check that the voltage at the terminals "F1F2 IN/D" changes few times between  $\pm 16$  VDC and  $\pm 0$  VDC. (Re-)initialization takes maximum 12 minutes. At the end of the initialization, the segment display goes off.
4. Perform a test run: after (re-)initialization is completed, press and hold BS2 "SET" till segment display indicates "t01". Test run will take about 20 minutes.

If you do not perform a test run, error U3-01 appears when turning on the indoor unit.

5. Test run is completed normally when segment display goes off.

### 3.3.2.24. Replacing noise filter PCB A2P

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to "[Removing main front plate](#)" on page 102.
4. Open the switch box, refer to "[Opening switch box](#)" on page 108.

#### PROCEDURE


##### Removal

**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

1. Loosen the 3 screws (1) that fix the mounting plate optional boards (2).
2. Remove the wiring from the cable clamps (3).
3. Turn the mounting plate optional boards (2) to the left.
4. Remove the 6 screws (4) that fix the wiring to the noise filter PCB (6).
5. Unlatch all PCB stand-offs (5) that fix the noise filter PCB (6).
6. Remove the noise filter PCB (6) from the switch box.

Figure 3-31: Removing the noise filter PCB A2P



**Installation**



**INFORMATION**

Replace all cable ties that were cut during removal.

1. Proceed in reverse order.

### 3.3.2.25. Replacing SUB PCB A4P

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to "Removing main front plate" on page 102.
4. Open the switch box, refer to "Opening switch box" on page 108.

#### PROCEDURE

##### Removal




**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

1. Unplug connector X36 (1) from the main PCB (2), refer to "Component checklist" on page 163.
2. Remove the 4 screws (3) that fix the mounting plate low voltage terminal block X2M (4).
3. Turn over and lower the mounting plate low voltage terminal block X2M (4).
4. Unplug the connectors (6) from the SUB PCB "A4P" (5), refer to "Component checklist" on page 163.
5. Unlatch the 6 PCB stand-offs (7) that fix the SUB PCB "A4P" (5).
6. Remove the SUB PCB "A4P" (5) from the switch box (8).

**Figure 3-32: Removing the SUB PCB A4P**



##### Installation

1. Proceed in reverse order.

### 3.3.2.26. Replacing Adapter PCB A8P

#### PRELIMINARY ACTIONS

1. Switch off the Daikin unit via the user interface.
2. Switch off the Daikin unit with the field supplied circuit breaker.
3. Remove the main front plate, refer to ["Removing main front plate" on page 102.](#)
4. Open the switch box, refer to ["Opening switch box" on page 108.](#)

#### PROCEDURE

##### Removal




**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

1. Unplug connector X1A (2) and X2A (3) from the Adapter PCB "A8P" (1), refer to ["Switch Box RWEYQ-T9Y1B" on page 167.](#)
2. Unlatch the 4PCB stand-offs (4) that fix the Adapter PCB "A8P" (1).
3. Remove the Adapter PCB "A8P" (1) from the switch box.

**Figure 3-33: Removing the Adapter PCB A8P**



- 1. Adapter PCB A8P
- 2. Connector X1A

- 3. Connector X2A
- 4. PCB stand-off

##### Installation

1. Proceed in reverse order.

### 3.3.3. Branch Selector (BS) box

#### 3.3.3.1. Replace control board BS box

##### PRELIMINARY ACTIONS

1. Switch off circuit breaker for power supply to BS unit.
2. Loosen and remove the 4 screws (1) that fix the BS box cover (2).
3. Lift the BS box cover (3) and remove it from the BS box.
4. Check power supply is disconnected: green LED be off, and check power supply terminals L-N = 0 VAC

##### PROCEDURE

##### Removal




**WARNING: RISK OF FIRE**

When reconnecting a connector to the PCB, do not apply force, as this may damage the connector or connector pins of the PCB.

1. Unplug all connectors from the control board (3).
2. Unsnap the control PCB carefully from its 7 PCB stand-offs (4).
3. Remove the control board (3) from the BS box.

**Figure 3-34: Removing the control board PCB (e.g. for BS box BS4Q14A)**



##### Installation

1. Proceed in reverse order.

### 3.3.3.2. Replacing expansion valve coil BS box

#### PRELIMINARY ACTIONS


1. Remove the 4 screws (2) that fix the top panel (1).
2. Remove the top panel (1).

#### PROCEDURE

##### Removal

1. Locate the expansion valve coil (3)
2. Unlock the expansion valve coil (3) turning clockwise or counter clockwise.
3. Remove the expansion valve coil (3) from the expansion valve (4)

**Figure 3-35: Removing expansion valve coil (e.g. for BS box BS4Q14A)**



##### Installation

1. Proceed in reverse order.



## Part 4. Maintenance

This part contains the following chapters:

Indoor unit .....	151
RWEYQ-T .....	152

### 4.1. Indoor unit

#### 4.1.1. General maintenance indoor unit

##### 1. Optimal operation conditions

	Cooling	Heating
Differential between suction temperature and discharge temperature	8~18°C	14~30°C
DB	27°C	20°C
WB	19°C	NA

##### 2. Correlation of air-conditioner's operation status, pressure and running current

COOLING	Low pressure	High pressure	Running current
Dirty air filter	Lower	Lower	Lower
Short circuit of air inlet/outlet	Lower	Lower	Lower
Air mixed in refrigerant	Higher	Higher	Higher
Water mixed in refrigerant	Lower*	Lower	Lower
Dirt mixed in refrigerant	Lower**	Lower	Lower
Refrigerant shortage (gas)	Lower	Lower	Lower
Unsatisfactory compression	Higher***	Lower	Lower

\* Water in the refrigerant freezes inside the electronic expansion valve and is basically the same phenomenon as pump down.

\*\* Dirt in the refrigerant clogs filters inside the piping and is basically the same phenomenon as pump down.

\*\*\* Pressure differential between high and low pressure becomes low.

## 4.2. RWEYQ-T

### 4.2.1. General maintenance RWEYQ-T

1. H<sub>2</sub>O plate heat-exchanger: check water inlet temperature & water flow rate is within published range.
2. Correlation of air-conditioner's operation status, pressure and running current.

COOLING	Low pressure	High pressure	Running current
Dirty air filter	Higher	Higher	Higher
Short circuit of air inlet/outlet	Higher	Higher	Higher
Air mixed in refrigerant	Higher	Higher	Higher
Water mixed in refrigerant	Lower*	Lower	Lower
Dirt mixed in refrigerant	Lower**	Lower	Lower
Refrigerant shortage (gas)	Lower***	Lower	Lower

\* Water in the refrigerant freezes inside the electronic expansion valve and is basically the same phenomenon as pump down.

\*\* Dirt in the refrigerant clogs filters inside the piping and is basically the same phenomenon as pump down.

\*\*\* Pressure differential between high and low pressure becomes low.

## Part 5. Appendix

This part contains the following chapters:

Field setting .....	155
Wiring diagram .....	159
Wiring diagram .....	159
Piping diagram .....	161
Component overview of unit .....	162
Product specific information .....	163
Switch box .....	167
Branch Selector (BS) box .....	168
Field information report .....	172



## 5.1. Field setting

### 5.1.1. RWEYQ-T default mode 2 settings

Mode 2 code no.	Default set	RWEYQ-T
		Function
0	0	※/★ zone
1	0	※/★ address
2	0	Demand address
3	0	Info not available
4	0	spare
5	0	forced indoor fan
6	0	forced thermostat-on
7	0	Info not available
8	2	target evaporation (※)
9	6	target evaporation (★)
10	0	spare
11	0	Info not available
12	0	Activate DTA104
13	0	I-net address
14	0	spare
15	0	Info not available
16	0	Info not available
17	0	Info not available
18	0	Info not available
19	0	spare
20	0	R410A additional charge
21	0	Refrigerant recovery
22	0	spare
23	0	VRT control
24	0	Output 0-10 control
25	4	lower limit 0-10 V
26	0	Info not available
27	0	spare
28	0	Power transistor check
29	0	Capacity precedence
30	3	Demand limit 1
31	1	Demand limit 2
32	0	Forced demand limit
33	0	Info not available
34	0	Indoor fan limit >130% ratio thermostat on
35	0	Height difference
36	2	Info not available
37	0	Info not available
38	0	Emergency set main module
39	0	Emergency set sub1 module
40	0	Emergency set sub2 module
41	0	Info not available
42	0	delay HJ-04 error
43	0	Info not available
44	0	Info not available
45	0	Technical cooling BS unit
46	0	Info not available
47	2	Target evaporation temperature heat recovery mode
48	0	spare
49	0	Info not available


Mode 2 code no.	Default set	RWEYQ-T
		Function
50	0	H <sub>2</sub> O brine sol
51	0	Module manual sequence set
52	0	spare
53	0	Info not available
54	0	Target evaporation temperature technical cooling
55	2	Info not available
56	0	Heating capacity less (indoor to LP)
57	0	Info not available
58	13	Info not available
59	1	Info not available
60	0	spare
61	0	Info not available
62	0	Info not available
63	0	Info not available
64	0	spare
65	0	spare
66	0	spare
67	0	spare
68	0	spare
69	0	spare
70	0	spare
71	0	Equalisation time BS unit cool<->heat
72	0	Info not available
73	0	Info not available
74	3	ZED setpoint
75	0	ZED differential
76	6	Info not available
77	1	Info not available
78	0	Info not available
79	0	Info not available
80	0	Info not available
81	1	comfort cool
82	1	comfort heat
83	1	selection cool/heat change over RA (split) indoor, or VRV
84	1	Info not available
85	0	spare
86	0	spare
87	0	Info not available
88	0	Info not available
89	0	spare
90	0	Info not available
91	0	Info not available
92	2	Info not available
93	0	spare
94	0	spare
95	0	Info not available
96	0	Info not available
97	0	spare
98	0	spare
99	0	spare

## 5.2. Detailed information setting mode

### 5.2.1. Indoor unit

See service manual VRV4 indoor units.

Figure 5-1: Check method Wiring BS-Q14A



## 5.2.2. RWEYQ-T9 field settings overview mode1 &amp; 2

RWEYQ-T - mode 1 (monitoring mode)		Display indication								
No.	Setting content	--	0	1	2	3	4	5	6	7
0	Outdoor auto configuration Q1Q2 wiring	not detected	Main	Sub 1	Sub 2	-	-	-	-	-
1	Low noise input DTA104	0: open	closed	-	-	-	-	-	-	-
2	Demand control input DTA104	0: open	closed	-	-	-	-	-	-	-
3	Back up operation	0: OFF	1: ON	-	-	-	-	-	-	-
4	spare item	0	-	-	-	-	-	-	-	-
5	Te target set *°C	-	-	3	6	7	8	9	10	11
6	Tc target set *°C	-	-	41	42	43	44	45	46	49
7	*/* zone address									0~31
8	Demand address									0~31
9	I-Net address									0~63
10	Qty indoor (VRV+RA+Hydro)									0~63
11	Qty BS units (this system)									0~63
12	Info not available									0~63
13	Qty outdoor all systems "F1F2 Out/d"									0~63
14	Qty BS units all systems "F1F2 Out/d"									0~128
15	Qty connected zones "F1F2 Out/d" (not used)									0~63
16	Qty indoor units all systems "F1F2 Out/d"									0~128
17	Error code - last forced stop									Refer to error code list
18	Error code - 2nd last forced stop									Refer to error code list
19	Error code - 3rd last forced stop									Refer to error code list
20	Software ID (main number)									8 digits, use "Set" BS2 button to view full number
21	Horsepower display	-	-	8	10	12	14	-	-	-
22	Software ID (sub number)									001~999
23	Error code - last retry									Refer to error code list
24	Error code - 2ndlast retry									Refer to error code list
25	Error code - 3red last retry									Refer to error code list
26	Info not available									0~63
27	Info not available									0~63
28	Qty modules same system (Q1Q2 wiring)	-	-	1	2	3	-	-	-	-
32	PCB board judgment	-	Check	Normal	Fault	-	-	-	-	-
40	* Comfort setting (= set 2-81)	-	Eco	Mild	Quick	Powerfull	-	-	-	-
41	* Comfort setting (= set 2-81)	-	Eco	Mild	Quick	Powerfull	-	-	-	-
42	actual Pc (Mpa)									0,00~9,99
43	actual Pe (Mpa)									0,00~9,99
44	Actual Frequency output (Hz)									0~999
45	Actual pulses Y1E (display = pulses/10)									0~300
46	Actual pulses Y2E (display = pulses/10)									0~48
47	Actual discharge pipe °C(R12T - "Tdi")									0~999
48	spare item	-	0	-	-	-	-	-	-	-
49	spare item	-	0	-	-	-	-	-	-	-
50	Actual air °C (R1T - "Ta")									-40,0~99,9
51	Actual Accumulator inlet °C (R3T -"Ts")									-40,0~99,9
52	Actual gas outlet °C Sub-cool (R5T -"Tsh")									-40,0~99,9
53	Actual gas °C PHE H <sub>2</sub> O (R4T - "Tg")									-40,0~99,9
54	Actual liquid receiver °C (R6T -"TL")									-40,0~99,9
56	Compressor hours (display =hours/100)									0~999
57	Actual Output X2M 2«3 (0~10VDC)									0~10
58	Actual H <sub>2</sub> O inlet °C (R9T)									-40,0~99,9
59	Actual H <sub>2</sub> O inlet °C (R10T)									-40,0~99,9
60	Actual compressor body °C (R13T - "Ti")									-40~999
61	Actual r410A liquid °C H <sub>2</sub> O PHE (R7T - "Tb")									-40,0~99,9
62	Actual liquid °C outlet Y2E (R11T -"Tm")									-40,0~99,9
63	Actual liquid °C stop valve liquid (R8T - "Tsc")									-40,0~99,9
64	Actual air °C (R1T - "Ta")									-40,0~99,9
65	Actual gas °C ZED circuit (R2T -"Tev")									-40,0~99,9

RWEYQ-T - mode 2 (Field setting mode)		Display indication								
No.	Setting content	0	1	2	3	4	5	6	7	8
0	※/※ Selection	<u>individual</u>	Main	Sub	-	-	-	-	-	-
1	※/※ Address	0 ~ 31								
2	Demand address	0 ~ 31								
5	Cross wiring check	<u>OFF</u>	ON	-	-	-	-	-	-	-
6	Forced thermostat-on	<u>OFF</u>	ON	-	-	-	-	-	-	-
8	Target Te °C (※)	-	3	<u>6</u>	7	8	9	10	11	-
9	Target Tc °C (※)	-	41	42	43	44	45	<u>46</u>	49	-
11	Demand set DTA104	<u>Off</u>	LNO	demand	-	-	-	-	-	-
13	I-Net address	0 ~ 63								
16	Heat output step1 KRP1 Yc-Y1	<u>OFF</u>	ON	-	-	-	-	-	-	-
20	+R410A charge	<u>OFF</u>	ON	-	-	-	-	-	-	-
21	R410A Recovery mode	<u>OFF</u>	ON	-	-	-	-	-	-	-
23	VRT control	※+※	only ※	only ※	Off	-	-	-	-	-
24	0-10VDC output	<u>OFF</u>	Individual (operation on)	Per system (operation)	Individual (thermostat)	-	-	-	-	-
25	Output X2M 2-3 minimum %	0	20	30	40	<u>50</u>	60	70	80	-
28	Power transistor check	<u>OFF</u>	ON	-	-	-	-	-	-	-
29	Capacity precedence	<u>OFF</u>	ON	-	-	-	-	-	-	-
30	Demand 1 limit current (%)	-	<u>60</u>	65	70	75	80	85	90	95
31	Demand 2 limit current (%)	-	<u>40</u>	50	55	-	-	-	-	-
32	Forced demand (without input DTA104)	<u>OFF</u>	set 2-30	set 2-31	-	-	-	-	-	-
34	Indoor fan limit >130% thermostat	<u>all modes</u>	※+※ & ※	OFF	-	-	-	-	-	-
35	Height different RWEYQ below indoor	<u>≤ 40 m</u>	≤ 90 m	do not set	-	-	-	-	-	-
36	Demand off setting	-	do not set	default	do not set	-	-	-	-	-
38	Inverter emergency set main	<u>OFF</u>	ON	-	-	-	-	-	-	-
39	Inverter emergency set sub1	<u>OFF</u>	ON	-	-	-	-	-	-	-
40	Inverter emergency set sub2	<u>OFF</u>	ON	-	-	-	-	-	-	-
42	Delay (minutes) "HJ" fault X2M 5-6 open	<u>Only th-off</u>	5	10	15	20	25	30	35	-
50	H <sub>2</sub> O brine %	0	do not set			<u>40</u>	5 ~12 do not set			
51	Module setting (Q1Q2 wiring)	<u>Automatic</u>	Main	Sub1	Sub2	-	-	-	-	-
56	Heating capacity less (indoor set to LP)	Off	Operation off	Thermo-off	<u>Operation or Th off</u>	-	-	-	-	-
71	Change over time (minutes) BS unit EVL<->EVH	5	3	7	4	-	-	-	-	-
73	ZED function	<u>OFF</u>	> capacity	> air °C	-	-	-	-	-	-
74	ZED setpoint	25	17	29	<u>31</u>	33	35	37	39	-
75	ZED □ ↓ (°C)	<u>3</u>	2	1	5	-	-	-	-	-
81	Cooling comfort setting	Eco	<u>Mild</u>	Quick	Power full	-	-	-	-	-
82	Heating comfort setting	Eco	<u>Mild</u>	Quick	Power full	-	-	-	-	-
83	※ <-> ※ selection source (heat-pump only)	VRV	<u>RA+BPMKS</u>	-	-	-	-	-	-	-

xxx : default setting

### 5.2.3. Remote controller

See service manual ESIE15-11 (VRV4 indoor units)




### 5.3.2. Field wiring

Not applicable.

5.4. Piping diagram


Figure 5-3: Piping diagram RWEYQ-T9Y1B



- |                                      |  |  |
|--------------------------------------|--|--|
| 1. Compressor motor                  | 16. Stop valve hot gas injection liquid              | 31. R11T Thermistor liquid EVT ↔ SC PHE  |
| 2. Oil separator                     | 17. Stop valve liquid inverter cooling               | 32. R12T Thermistor discharge compressor |
| 3. PHE H2O                           | 18. Expansion valve main liquid                      | 33. R13T Thermistor body compressor      |
| 4. Liquid receiver                   | 19. Expansion valve sub-cool                         | 34. M1F Fan motor n°1 inverter cooling   |
| 5. PHE Sub-cool                      | 20. Expansion valve purge                            | 35. M2F Fan motor n°2 inverter cooling   |
| 6. Heat-exchanger inverter cooling   | 21. R1T Thermistor inside ambient                    | 36. SENPL Low pressure sensor            |
| 7. Accumulator                       | 22. R2T Thermistor gas outlet inverter cooling       | 37. SENPH High pressure sensor           |
| 8. Safety valve liquid               | 23. R3T Thermistor accumulator inlet                 | 38. S1PH High pressure switch            |
| 9. Stop valve oil return accumulator | 24. R4T Thermistor gas PHE H2O                       | 39. Stop valve liquid                    |
| 10. Stop valve gas SC & Purge        | 25. R5T Thermistor gas outlet SC & Purge             | 40. Stop valve dual pressure             |
| 11. Stop valve main liquid           | 26. R6T Thermistor liquid receiver ↔ SC circuit      | 41. Stop valve suction                   |
| 12. Stop valve liquid oil return PHE | 27. R7T Thermistor liquid PHE H2O                    | 42. Refrigerant charge port              |
| 13. Stop valve Hot Gas / Oil return  | 28. R8T Thermistor liquid ↔ SC Stop valve            | 43. Non-return valve (1 way valve)       |
| 14. 4-way valve Dual Pressure        | 29. R9T Thermistor H2O in PHE (future option part)   | 44. Refrigerant filter                   |
| 15. 4-way valve PHE                  | 30. R10T Thermistor H2O out PHE (future option part) |  |

### 5.5. Component overview of unit

Figure 5-4: Component overview RWEYQ-T9Y1B / TATJU-TAYDU



- |                                      |  |  |
|--------------------------------------|--|--|
| 1. Compressor motor                  | 16. Stop valve hot gas injection liquid              | 31. R11T Thermistor liquid EVT ↔ SC PHE  |
| 2. Oil separator                     | 17. Stop valve liquid inverter cooling               | 32. R12T Thermistor discharge compressor |
| 3. PHE H2O                           | 18. Expansion valve main liquid                      | 33. R13T Thermistor body compressor      |
| 4. Liquid receiver                   | 19. Expansion valve sub-cool                         | 34. M1F Fan motor n°1 inverter cooling   |
| 5. PHE Sub-cool                      | 20. Expansion valve purge                            | 35. M2F Fan motor n°2 inverter cooling   |
| 6. Heat-exchanger inverter cooling   | 21. R1T Thermistor inside ambient                    | 36. SENPL Low pressure sensor            |
| 7. Accumulator                       | 22. R2T Thermistor gas outlet inverter cooling       | 37. SENPH High pressure sensor           |
| 8. Safety valve liquid               | 23. R3T Thermistor accumulator inlet                 | 38. S1PH High pressure switch            |
| 9. Stop valve oil return accumulator | 24. R4T Thermistor gas PHE H2O                       | 39. Stop valve liquid                    |
| 10. Stop valve gas SC & Purge        | 25. R5T Thermistor gas outlet SC & Purge             | 40. Stop valve dual pressure             |
| 11. Stop valve main liquid           | 26. R6T Thermistor liquid receiver ↔ SC circuit      | 41. Stop valve suction                   |
| 12. Stop valve liquid oil return PHE | 27. R7T Thermistor liquid PHE H2O                    | 42. Refrigerant charge port              |
| 13. Stop valve Hot Gas / Oil return  | 28. R8T Thermistor liquid ↔ SC Stop valve            | 43. Non-return valve (1 way valve)       |
| 14. 4-way valve Dual Pressure        | 29. R9T Thermistor H2O in PHE (future option part)   | 44. Refrigerant filter                   |
| 15. 4-way valve PHE                  | 30. R10T Thermistor H2O out PHE (future option part) |  |

## 5.6. Product specific information


A (°C)	B (°C)	C (°C)	D	E (min)	F (min)
135	120	100	2	100	10

### 5.6.1. Component checklist

#### 5.6.1.1. How to activate inverter test

Power transistor check mode RWEYQ-T9: disconnect U/V/W compressor!

Connect U/V/W output inverter board to inverter analyzer.



**Check 1:** LED HAP inverter board blinks. If not, activate forced thermostat-on (set 2-6). When HAP blinks, deactivate 2-6 again.

**Check 2:** AC power input (L1-L2-L3 inverter board compressor.) 380-415V unbalance max.2%.

**Check 3:** Relay "K1R" on inverter board switches: check DC voltage on P & N increase to ± 500VDC.

**Check 4:** DC = 1.42 x VAC power supply L1~L3: check at terminals P2-N3 on inverter board compressor.

**Check 5:** AC UVW 10 Hz intermediate: check 6 LED on inverter checker blink.

**Check 6:** AC UVW 240 Hz continuous output while voltage drop (discharge capacitors DC). 2 LED's light on (because high frequency) while brightness reduces.

(note\*): Actual voltage value depends on meter characteristics.

#### 5.6.1.2. Component checklist RWEYQ-T9Y1B

RWEYQ-T9Y1B	Wiring symbol			Location			Color plug	Check			
				Terminals	Pin no.			Value	Unit	Tol +/-	
Main PCB "A1P"											
S.v. oil return accumulator	Y	1	S	X	12	A	Yellow	2,1	kΩ	5%	
S.v. gas SC & Purge	Y	2	S	X	13	A	Pink	1,3	kΩ	5%	
S.v. main liquid	Y	3	S	X	15	A	White	1,3	kΩ	5%	
S.v. liquid oil return PHE	Y	4	S	X	16	A	Yellow	2,2	kΩ	5%	
S.v. Hot Gas / Oil return	Y	5	S	X	17	A	Orange	2,2	kΩ	5%	
4Way valve Dual pressure	Y	6	S	X	7	A	Green	2,2	kΩ	5%	
4Way valve PHE	Y	7	S	X	8	A	Blue	2,2	kΩ	5%	
S.v. hot gas injection liquid	Y	8	S	X	9	A	Grey	2,2	kΩ	5%	
S.v. liquid inverter cooling	Y	9	S	X	4	A	Yellow	2,2	kΩ	5%	
Expansion valve main liquid	Y	1	E	X	21	A	Black	150	Ω	15 ohm	
Expansion valve sub-cool	Y	2	E	X	22	A	White	46	Ω	3 ohm	
Expansion valve purge	Y	3	E	X	25	A	Yellow	46	Ω	3 ohm	
Crankcase heater	E	1	HC	X	11	A	Grey	1,75	kΩ	7%	
High pressure sensor	S1	NP	H	X	32	A	Red	0,5~3,5	VDC	5%	
Low pressure sensor	S1	NP	L	X	31	A	Blue	0,5~3,5	VDC	5%	
Power supply main board L1	L1	-	N	X	1	A	Blue	230	VAC	10%	
Power supply L3 (rotation check)	L3	-	N	X	77	A	White	230	VAC	10%	
Power supply main board rectifier	P	S		X	37	A	White	16	VDC	10%	
Th accumulator inlet	R	3	T	X	30	A	1-2	White	2~200	kΩ	5%
Th gas PHE H2O	R	4	T	X	30	A	3-4	White	2~200	kΩ	5%
Th gas out SCHex & purge	R	5	T	X	30	A	5-6	White	2~200	kΩ	5%
Th receiver-SCHex	R	6	T	X	30	A	7-8	White	2~200	kΩ	5%

RWEYQ-T9Y1B Main PCB "A1P"	Wiring symbol			Location				Color plug	Check		
				Terminals		Pin no.	Value		Unit	Tol +/-	
Th Liquid SCHEX	R	7	T	X	30			A			9-10
Th Liquid stopvalve-SCHex	R	8	T	X	29	A	5-6	Green	2~200	kΩ	5%
Th H2O inlet (option)	R	9	T	X	29	A	1-2	Green	2~200	kΩ	5%
Th H2O outlet (option)	R	10	T	X	29	A	3-4	Green	2~200	kΩ	5%
Th liq EVT-SCHex	R	11	T	X	18	A		White	2~200	kΩ	5%
Th discharge pipe	R	12	T	X	19	A	1-2	Red	2~200	kΩ	5%
Th body compressor	R	13	T	X	19	A	3-4	Red	2~200	kΩ	5%
Earth leakage current sensor	T	1	A	X	101	A		White	80	Ω	10%
Power A1P« A3P				X	20	A		Yellow	1,5~10	VDC	2%
Communication A1P <-> A3P				X	28	A	1-2		16,6	VDC	2%
Communication A1P<-> A3P				X	28	A	3-2		8,5	VDC	2%
Communication RWEYQ-T<-> indoor				X	1	M	IND		15~16	VDC	2%
Communication RWEYQ-T<-> Central				X	1	M	OUT		15~16	VDC	2%
Communication RWEYQ-T multi				X3M	-Q1	X37A-2	MULTI	White	2~4	VDC	2%
Communication RWEYQ-T multi				X3M	-Q2	X37A-2	MULTI	White	2~4	VDC	2%

pin 1=Δ

RWEYQ-T9Y1B SUB PCB "A4P"	Wiring symbol			Location			Color plug	Check		
				Terminals		Value		Unit	Tol +/-	
Fan motor inverter cooling (!)	M	1	F	X	3		A			Orange
Fan motor inverter cooling (!)	M	2	F	X	11	A	Orange	2,1	kΩ	5%
Th air	R	1	T	X	11	A	Orange	2 ~200	kΩ	5%
Th gas inverter cooler	R	2	T	X	12	A	Blue	2 ~200	kΩ	5%
Power supply auxiliary board L1	L1	-	N	X	1	A	Blue	230	VAC	10%

(!): At connector X11A: value / 2

RWEYQ-T9Y1B Inverter PCB "A3P"	Wiring symbol			Location			Color plug	Check		
				Terminals		Value		Unit	Tol +/-	
Compressor motor	M	1	C	U	V		W			
Power supply inverter board	L1	L2	L3	L1	L2	L3		400	VAC	10%
DC power diode module inverter	V	2	R	P21	<->	N4		550	VAC	10%
PWM power transistors inverter	V	1	R	U	V	W		200~500	VAC	10%

## 5.6.2. Safety devices

### 5.6.2.1. Drop control

Device stops according to certain conditions and restarts without showing immediate error messages (visible in monitoring mode, number 23+24+25)

Name part	Description	Wiring symbol	RWEYQ...T9Y1B				
			8	10	12	14	
Overcurrent	Model compressor	M1C	JT16KAVDKYR@S				Error
	Current protection		>22,0 A > 90 seconds or >22,5 A				
Leak current	Power supply protection	T1A	75 mA (±25%)				E2
Low pressure sensor	LP protection	S1NPL	< 0,07 Mpa (retry 3 times in 60 minutes)				E4
High pressure sensor	HP protection	S1NPH	> 3,71 Mpa (retry 3 times in 40 minutes)				E3
Discharge temperature	Overheat protection	R12T	* if >135°C, or if >120°C > 10 minutes. * Retry 2 times in 100 minutes.				F3
Inverter fin temperature	Compressor	A3P	> 100°C				P4

### 5.6.2.2. Forced Stop

Device stops according to certain conditions and displays an error code on the segment display and remote control of indoor units that are currently in operation


Name part	Description	Wiring symbol	RWEYQ...T9Y1B				
			8	10	12	14	
Overcurrent	Model compressor	M1C	JT16KAVDKYR@S				Error
	100% current A (Demand control)		10.5	13.2	15.8	18.4	
	Overcurrent		>22,0 A > 90 seconds or >22,5 A				
Low pressure sensor	LP protection	S1NPL	< 0,07 Mpa (retry 4th time in 60 minutes)				E4
High pressure sensor	HP protection	S1NPH	> 4,15 Mpa if high pressure switch fails to open				JA
High pressure switch		S1PH	> 4,0MPa (+0,0 -0,15), reset < 3,0MP±0,15				E3
Discharge temperature	Overheat protection	R12T	off >135°C 2 times in 100 minutes.				F3
Body temperature	Overheat protection	R13T	off >120°C 2 times in 100 minutes				F3
Inverter fin temperature	Compressor	A3P	> 100°C				P4

Name part	Description	Wiring symbol	RWEYQ...T9Y1B				
			8	10	12	14	
Fuse control	Main board	F1U, F2U	3,15 A (T)				U4
Fuse noise filter	Noise filer A2P	F410~412U	40,0 A (T)				LC
fuse control	Auxiliary board A4P	F1U	3,15 A (T)				LC

### 5.6.3. Control range


#### 5.6.3.1. Compression operation range

Compression operation range




Range rps compressor	SINGLE MODULE & MULTI COMBINATION			
	8	10	12	14
RWEYQ-T9Y1B	8	10	12	14
Max. individual rps	70,6	97,2	123,1	133,8
Max.nr steps	108	127	144	150

Rps = rotation per second  
Hz = rps \* 3 (6pole motor)




- rps ↑:
  - \* Te > Te target
  - \* Tc < Tc target
- rps ↓:
  - \* Te < Te target
  - \* Tc > Tc target
- Rps = in multi modules,
- Modules ≠ size, limit by Max. individual rps.
- Multi operation, unit rotation ⌀30minutes.



5.6.4. Performance Characteristics

Figure 5-5: Performance Characteristics



Notes

The values were measured during nominal cooling operation with an inlet water temperature of +30°C

EG: Ethylene glycol  
 PG: Propylene glycol  
 ACH73: plate heat exchanger (100 plates)

Influence on performance:

- EG 30%: = +0.5 K during condensation process, and -0.5 K during the evaporation process.
- EG 40%: = +0.7 K during condensation process, and -0.7 K during the evaporation process.
- PG 30%: = +1.3 K during condensation process, and -1.3 K during the evaporation process.
- PG 40%: = +1.5 K during condensation process, and -1.5 K during the evaporation process.


ACH73 // Delta pressure [kPa]					
l/min	Water	30% EG	40% EG	30% PG	40% PG
50	5,4	6,9	7,0	7,2	7,5
60	7,4	9,4	9,6	9,8	10,2
70	9,7	12,2	12,5	12,8	13,3
80	12,3	15,5	15,9	16,2	16,9
90	15,2	19,1	19,6	20,1	20,8
100	18,4	23,2	23,7	24,3	25,2
110	21,9	27,6	28,2	28,9	30,0
120	25,7	32,2	33,1	33,8	35,1
130	29,7	37,5	38,4	39,3	40,7
140	34,1	43,0	44,0	45,1	46,8
150	38,8	48,9	50,1	51,2	53,2
160	43,8	55,2	56,5	57,8	60,0
170	49,1	61,9	63,3	64,8	67,3
180	54,7	68,9	70,5	72,2	74,9
190	60,6	73,6	78,1	80,0	83,0

Water filter // Delta pressure [kPa]	
Flow (l/min)	Water
50	3,5
60	5
80	8,5
96	12,5
120	20
150	31
190	52

## 5.7. Switch box

### 5.7.1. Switch Box RWEYQ-T9Y1B

Figure 5-6: Switch box - RWEYQ-T9Y1B




Item	Description	Symbol
1	Terminal strip power supply	X1M
2	Terminal strip output signals	X2M
3	Terminal strip input signals	X3M
4	Main PCB	A1P
5	Noise filter PCB	A2P
6	Inverter PCB	A3P
7	Sub PCB	A4P
8	Adapter PCB (0~10VDC output)	A8P
9	Cool/heat selector PCB	A9P
10	Reactor nr.1	L1R
11	Reactor nr.2	L2R
12	DTA104A61 – optional PCB	-
13	Motor (fan) nr.1	M1F
14	Motor (fan) nr.2	M2F
15	Motor (fan) nr.3	M3F

## 5.8. Branch Selector (BS) box

### 5.8.1. BS1Q10A, BS1Q16A, BS1Q25A


Figure 5-7: BS box - BS1Q10A, BS1Q16A, BS1Q25A



Item	Description
1	Control board
2	Power supply terminals
3	F1F2 outdoor <-> BS unit
4	F1F2 BS <-> VRV indoor unit
5	Dual pressure pipe
6	Suction pipe
7	Liquid pipe
8	Expansion valve dual pressure
9	Expansion valve suction
10	Expansion valve liquid

### 5.8.2. BS4Q14A


Figure 5-8: BS box - BS4Q14A



Item	Description
1	Control board
2	Power supply terminals
3	F1F2 outdoor <-> BS unit
4	F1F2 BS <-> VRV indoor unit
5	Dual pressure pipe
6	Suction pipe
7	Liquid pipe
8	Expansion valve dual pressure
9	Expansion valve suction
10	Expansion valve liquid

5.8.3. BS6Q14A


Figure 5-9: BS box - BS6Q14A



Item	Description
1	Control board
2	Power supply terminals
3	F1F2 outdoor <-> BS unit
4	F1F2 BS <-> VRV indoor unit
5	Dual pressure pipe
6	Suction pipe
7	Liquid pipe
8	Expansion valve dual pressure
9	Expansion valve suction
10	Expansion valve liquid

5.8.4. BS8Q14A


Figure 5-10: BS box - BS8Q14A



Item	Description
1	Control board
2	Power supply terminals
3	F1F2 outdoor <-> BS unit
4	F1F2 BS <-> VRV indoor unit
5	Dual pressure pipe
6	Suction pipe
7	Liquid pipe
8	Expansion valve dual pressure
9	Expansion valve suction
10	Expansion valve liquid

5.8.5. BS10Q14A


Figure 5-11: BS box - BS10Q14A



Item	Description
1	Control board
2	Power supply terminals
3	F1F2 outdoor <-> BS unit
4	F1F2 BS <-> VRV indoor unit
5	Dual pressure pipe
6	Suction pipe
7	Liquid pipe
8	Expansion valve dual pressure
9	Expansion valve suction
10	Expansion valve liquid

5.8.6. BS12Q14A


Figure 5-12: BS box - BS12Q14A



Item	Description
1	Control board
2	Power supply terminals
3	F1F2 outdoor <-> BS unit
4	F1F2 BS <-> VRV indoor unit
5	Dual pressure pipe
6	Suction pipe
7	Liquid pipe
8	Expansion valve dual pressure
9	Expansion valve suction
10	Expansion valve liquid

5.8.7. BS16Q14A

Figure 5-13: BS box - BS16Q14A



Item	Description
1	Control board
2	Power supply terminals
3	F1F2 outdoor <-> BS unit
4	F1F2 BS <-> VRV indoor unit
5	Dual pressure pipe
6	Suction pipe
7	Liquid pipe
8	Expansion valve dual pressure
9	Expansion valve suction
10	Expansion valve liquid

## 5.9. Field information report

See next page.

In case a problem occurred on the unit which could not be resolved by using the content of this service manual or in case you have a problem which could be resolved but of which the manufacturer should be notified, we advise you to contact your distributor.

To facilitate the investigation, additional information is required. Please fill out the following form before contacting your distributor.



## FIELD INFORMATION REPORT

Key person info	
Name:	Company name:
Your contact details Phone number:	E-mail address:
Site address:	
Your reference:	Date of visit:

Claim info	
Title:	
Problem description:	
Error code:	Trouble date:
Problem frequency:	
Investigation steps done:	
Insert picture of the trouble.	
Current situation (solved, not solved, ...):	
Countermeasures taken:	
Comments and proposals:	
Part available for return (if applicable):	

### Application info

Application (house, apartment, office, ...):

New project or refurbishment:

Heat emitters (radiators / under floor heating / fan coils / ...):

Hydraulic layout (simple schematic):

### Unit / Installation info

Model name:

Serial number:

Installation / commissioning date:

Software version hydro PCB A1P:

Software version hydro PCB A5P:

Software version user interface:

Software version outdoor PCB:

Minimum water volume:

Maximum water volume:

Brine composition and mixture:

Brine freeze up temperature:

Space heating control (leaving water temperature, room thermostat, ext. room thermostat):

Space heating setpoint:

Domestic hot water control (reheat only, schedule only, reheat + schedule):

Domestic hot water setpoint:

Provide pictures of the field settings overview (viewable on the user interface).